

**Date:** May 26, 2009**Project No.:** 073-80026**To:** Kathy Economy**Company:** Abandoned Mine Lands Program,  
Mining and Minerals Division, New Mexico EMNRD**From:** Fiona Jordan**CC:** Robert Newcomer**Email:** fjordan@golder.com; bnewcomer@golder.com**RE:** Findings of Barbara J Sites, Abandoned Uranium Mine Lands Pilot Study Conducted March-May, 2009

---

## 1.0 INTRODUCTION AND PILOT STUDY OBJECTIVES

This memo describes the results of the Pilot Study performed by Golder Associates Inc. (Golder) at the above-referenced abandoned uranium mine sites during March-April, 2009. Golder, is under contract to the Abandoned Mine Land (AML) Program of the Mining and Minerals Division (MMD), to provide services relating to the closure of mine openings and reclamation of abandoned uranium mine lands (AUMIs) in the Poison Canyon area of the Grants Uranium District. As part of this contract, a work plan for the assessment of various sites was submitted by Golder in February 2009. The approach to completing the work plan was tailored to a narrower scoped pilot study in early April. The following outlines the objectives of the pilot study work plan at the Barbara J abandoned mine sites:

- Conduct radiological gamma ray surveys of the Barbara J mine sites and surrounding area;
- Map and describe individual mine features in these areas; and
- Collect representative soil samples from the area to assist the AML program in assessing the potential environmental hazards associated with radioactive materials at these sites.

The results of the pilot study are being presented and evaluated relative to the development of subsequent scope and direction of the project.

## 2.0 SCOPE OF WORK OF THE PILOT STUDY

The Barbara J area includes several unguarded mine/drill-hole openings as well as elevated levels of ionizing gamma radiation (ranging from 15 to greater than 2000 microR/hr). The radiation is primarily associated with uranium (U) and its daughter decay products (e.g. radium-226, thorium-230 and radon). These conditions represent an apparent hazard to human health and the environment. The more elevated radiation levels are typically associated with piles of mineralized waste rock, drill cuttings, miscellaneous debris, and apparent load-out areas. Some of these materials have been redistributed by erosion and previous earthwork at the sites.

### 3.0 PURPOSE OF PILOT STUDY

The principal purpose of the pilot study was to investigate and acquire appropriate and defensible data to aid in delineating the impacted areas so that engineering designs could be prepared to effectively address the effects of ionizing radiation associated with the wastes and other materials at the mine sites.

Other purposes included:

- Assessment of the cost effectiveness of survey methods/techniques in evaluating these types of sites and to meet project objectives;
- Assessment of the technical aspects/sensitivities of the methods used and their effectiveness in meeting objectives;
- Provide information to allow decision making regarding subsequent site assessments and project scope decisions by the MMD.

### 4.0 BACKGROUND INFORMATION

The radiological surveys associated with this pilot study were conducted at four of the more accessible sites in the Poison Canyon area (the Barbara J No. 1, No. 2, No. 3 and No. 3a mine sites), which are located just north of Haystack Road about 2 miles west from New Mexico State Highway 605.

A goal of the study was to collect sufficient radiological data to determine if a defensible relationship between gamma ray emissions and soil radionuclide concentrations could be developed, particularly at the lower soil concentrations that still pose a human health risk (an action level). If this relationship was present and a lower gamma ray activity could be defined, it would be used to delineate areas/soils requiring reclamation/mitigation.

### 5.0 GAMMA SURVEY RESULTS

The surveys consisted of obtaining gamma radiation measurements with a microR meter and a NaI detector/rate meter along pre-designated points along surveyed transects. Soil samples were collected from selected sites and were analyzed for total uranium, total thorium, Ra-226 and gross alpha/beta specific activity. The survey results were correlated to related gamma ray activity measurements obtained in the field or in Golder's warehouse laboratory at their office in Albuquerque, New Mexico.

Gamma surveys of the Barbara J mine sites were conducted between March 16<sup>th</sup> and 19<sup>th</sup>, on April 2<sup>nd</sup>, and again on April 15<sup>th</sup>, 2009. Survey points were spaced either 50 or 100 feet apart along the pre-designated transects at each mine site area (Figure 1). The transects spanned areas that had previously been identified by the AML program as surface disturbances associated with the various mine areas (Figure 1). Additional transects were surveyed at the request of the AML project manager to further evaluate gamma ray activity in previously uncharacterized areas adjacent to the mine sites (Figure 2). Gamma ray activity were measured using either a Ludlum Model 2350 or 2221 rate meter equipped with

Ludlum 44-10 shielded 2" X 2" NaI detectors and two Ludlum Model 19 microR meters. The following set of measurements was acquired for each survey point:

- A State Plane (UTM Zone 13) coordinate using a GPS (Global Positioning System) unit;
- A shielded, six-second gamma ray count taken at contact with the ground surface, and;
- An exposure rate measurement (with the microR meter) taken one meter above the ground.

Additionally, all gamma ray activity measuring instruments were calibrated at the Department of Energy's (DOE) calibration pad facility on Highway 605. Gamma ray activity measurements were obtained either by placing the NaI detector in the center of the concrete calibration pad or holding the microR meter one meter above the center of the pad. Gamma ray activity measurements (Figure 3) obtained for the calibration pads were plotted against known values of radioactivity contained within the pads (Leino, et al., 1994; George, et al., 1985). Regression analysis demonstrated a high correlation between radioactivity measurements and meter responses ( $R^2 > 0.8$ ), regardless of meter type. Current calibration certificates for the meters and detectors, results from daily function checks including acceptable count ranges (ACR), and calibration pad data for the microR meters are presented in Attachment A to this letter.

## 6.0 SOIL SAMPLING AND ANALYSIS RESULTS

Upon review of the gamma ray activity measurements, twenty-five (25) soil sampling locations were identified with the following characteristics:

- Areas 10 feet in diameter with uniform (or near uniform) gamma ray activity measurements; and
- Areas representing gamma ray activity values spanning the range of measurements observed at the four sites.

Soil samples were collected from the center of the identified sampling area to a depth of 15 cm unless refusal was encountered at a shallower depth. Refusal at a shallower depth was only noted for one sample location (Table 1, Barbara J3-3). Within each individual sampling area, a single exposure rate and three, six-second gamma ray activity measurements were made prior to sampling, using a microR meter and a shielded probe, respectively. A single (post-sampling) gamma ray activity measurement was made for the subgrade material. Each sample (approximately 1 kg of material) was collected and stored in reinforced Ziploc® plastic bags.

In Golder's warehouse laboratory, three (3) additional shielded surface-contact gamma ray activity measurements and a single, exposure-rate measurement were made and recorded for each sample. Laboratory gamma ray activity measurements were made by placing the NaI probe directly on top of the bagged sample and placing the sample on a "background" concrete platform (Table 1, "background").

The initial sampling event resulted in the collection of twenty (20) samples representing low-end

measurements. Five (5) additional samples were later collected to capture the high-end range in field measurements (400 to > 2000 microR/h). Due to Department of Transportation (DOT) constraints, only samples with readings less than 250 microR/h were submitted to the ACZ Laboratory (Steamboat Springs, Colorado) for radionuclide analyses. Sixteen (16) soil samples (12 from the initial sampling event and 4 from the latter), that spanned the range in gamma ray activity measurements made in the field and in the Golder laboratory, were submitted for radionuclide analyses. The remaining samples were archived.

As part of the sample preparation at the ACZ Laboratory, the entire sample volume was crushed, pulverized and homogenized prior to sample analysis to prevent bias resulting from any coarse fragments.

The pulverized samples were analyzed for concentrations of the following:

- Radium-226 (Ra-226),
- Total thorium,
- Total uranium, and
- Gross alpha and beta activity

The analytical results are presented in Table 1 and a copy of the ACZ Laboratory analytical reports are included in Attachment B along with the Chain of Custody documentation (COCs). Total uranium and thorium soil concentrations (mg/Kg) were converted to uranium-238 (U-238) and thorium-232 (Th-232) specific activity ( $A$ , in pCi/g) by combining the following basic radiation principles and the assumption that U-238 and Th-232 are the most abundant isotopes of uranium and thorium in the samples:

$$A = \left( \frac{0.693}{T_{1/2}} \right) N \quad (1)$$

$$m = \left( \frac{N}{A_o} \right) G_a \quad (2),$$

Where  $T_{1/2}$  is the half-life in minutes of the radionuclide being considered (e.g. U-238 =  $2.4 \times 10^{15}$  and Th-232 =  $7.4 \times 10^{15}$ ),  $m$  is the mass or concentration (mg/Kg) of the radionuclide,  $N$  is the number of disintegrating atoms,  $A_o$  is Avogadro's constant ( $6.022 \times 10^{23}$  atoms per g atomic weight) and  $G_a$  equals the atomic weight of the radionuclide (U-238 = 238 g/mol and Th-232 = 232 g/mol). One Picocurie (pCi) is equal to 2.2 disintegrating atoms per minute.

## 7.0 CORRELATION BY REGRESSION ANALYSES

Regression analyses were performed to evaluate whether there was a correlation between measured soil radionuclide (Ra-226 and U-238) concentrations and gamma ray activity counts. Linear relationships, corresponding correlation coefficients, and ninety-five percent (95%) confidence intervals were developed relating the average shielded gamma ray activity counts (measured for samples at the time of sampling in



the field or upon returning to the laboratory) to the actual soil radionuclide concentrations determined by the analytical lab. The equations were corrected for ambient cosmic or natural terrestrial gamma radiation by setting the x- and y-intercepts equal to zero.

Correlation coefficients determined for Ra-226, U-238 and field gamma count relationships were high and significant ( $r^2 > 0.7$ ,  $P < 0.05$ ), suggesting that gamma ray activity measurements made either in the field or in the laboratory could be used to reasonably predict Ra-226 (Figure 4) or U-238 soil concentrations (Figure 5). Gamma ray activity measurements made in the laboratory (red circles, Figures 4 and 5) were significantly lower than those measured in the field. This is believed to reflect the influence of “shine,” which is the radial contribution of radiation entering the NaI detector window from sources other than that contained within the sample volume. The “shine” effect was significant despite shielding the probes with lead sleeves.

Additional regression analyses were performed on the relationship between the lower Ra-226 and U-238 concentrations and corresponding gamma ray activity measurements to verify the predictive capacity of the correlation equations in a range more likely to be set as action levels or clean-up goals for the site (i.e., less than 40 pCi/g). The predictive capacity of the correlation between low-end field measurements and soil radionuclide concentrations decreased (i.e., Figure 6,  $r^2 = 0.58$  compared to Figure 4,  $r^2 = 0.97$ ), and demonstrated considerable variance as shown by the large 95% confidence interval (blue dashed lines). The X-coefficient also decreased from 0.015 to 0.004. The relationship between U-238 concentrations and low-end field gamma ray activity measurements changed significantly from that derived for the entire dataset (compare blue lines in Figure 5 and 7). The correlation between laboratory gamma ray activity measurements and Ra-226 concentrations (red line) was better ( $r^2$  increased from 0.82 for the entire dataset to 0.86 for the low-end values), but the X-coefficient decreased by a factor of 3. Regression Analysis Summaries are presented in Attachment C. Similar correlations were developed for the microR meter and are presented in Attachment D.

A comparison between the predictive capacity of the correlation developed for the entire Ra-226 field dataset and the correlation developed for the low-end values are shown in Table 2. These results infer that the low-end correlation, despite its lower correlation coefficient, is more accurate at predicting soil radionuclide concentrations from low-end gamma ray activity measurements obtained in the field (< 4000 count/0.1 min) than the correlation developed for the entire dataset. Furthermore, the upper 95% prediction interval for the low-end field measurement correlation estimates a value of 715 counts/0.1 min corresponding to an action level of 5 pCi/g soil Ra-226. In contrast, the upper 95% prediction interval for the entire dataset estimates a value of 312 counts/0.1 min to give an error rate of less than 2.5% that soil concentrations exceed the action level. The latter value sets an unrealistic clean-up goal as it is less than any recorded measurement in the field or “background” condition measured at the Golder laboratory.

Gamma survey results (Fig. 9) and four sets of calculated Ra-226 soil concentrations along with corresponding x, y coordinates were imported into ArcGIS 9.3. As described above, the datasets were populated by converting gamma survey results obtained in the field to Ra-226 concentrations using four different correlation equations:

- The linear relationship between soil Ra-226 levels and corresponding gamma measurements obtained in the field (Fig. 10).
- The linear relationship between soil Ra-226 levels and corresponding gamma measurements obtained in the field, accounting for low-end measurements (Fig. 11).
- The linear relationship between Ra-226 concentrations and gamma measurements developed at the DOE calibration facility (Fig 12).
- A contour map of Barbara J No. 2 using the upper 95% prediction correlation between soil Ra-226 levels and corresponding rate meter responses measured in the field accounting for low-end measurements (Fig. 13).

The values in each of these three datasets (Figure 10, 12-13) were classified into 15 groups along Jenks' natural breaks, which is the default classification method of ArcGIS. This classification scheme finds clusters of data and places class breaks between the clusters, by comparing the sum of squared differences of observed values to the means of their classes. In Figures 9 through 12, the cooler colors (blue) correspond to lower radiation counts/specific activity and the warmer colors (red) correspond to higher counts/activity. The classification scheme for Figure 11 was set the same as Figure 10 for comparison. The contours were drawn in by hand (Figure 13).

## 8.0 RESULTS SUMMARY

Soil Ra-226 concentrations ranged from 1.2 to 980 pCi/g and total uranium concentrations ranged from 1.3 to 3,000 mg/Kg (0.55-1,008 pCi/g). Total thorium concentrations were significantly lower, ranging from 1.2 to 3.5 mg/Kg, regardless of sample uranium or radium concentrations. Gross alpha and beta concentrations ranged from 7.3 to 1900 and 6.5 to 2,300 pCi/g, respectively.

A total of 1300 gamma ray activity survey points were made over an area spanning approximately 100 acres. Contact, shielded gamma ray activity measurements ranged from 335 to 55,000 counts/0.1 min with Ludlum model 44-10 NaI probes and Ludlum model 2350 or model 2221 rate meters. Exposure rates obtained with Ludlum model 19 microR meters ranged from 12 to over 2,000 uR/h. The "hot" spots (locations exceeding more than 10 times the lowest value reported in the field) generally fell within the surface boundaries and at features previously identified by the AML program with a few exceptions: Golder identified a "hot" spot just south of the Barbara J No. 2 mine along Haystack Rd, two "hot" spots to the north and south of Barbara J No. 3 and possibly another along the section of alluvium draining the Poison Canyon mine area to the north of Barbara J No. 3a. Highly elevated (> 50 times) levels of gamma radiation were typically associated with the presence of thin layers of gravelly limestone in small piles that were less than 4 feet across and about 2 feet high or in what appeared to be load-out areas.

## 9.0 PILOT STUDY CONCLUSIONS AND RECOMMENDATIONS

Correlation coefficients determined for the best fit lines relating soil Ra-226 and U-238 concentrations to corresponding field gamma ray counts were high and significant ( $r^2 > 0.7$ ,  $P < 0.05$ ) inferring that gamma measurements taken in the field may be used to reasonably predict Ra-226 or U-238 concentrations without the need for more extensive sampling/analyses.

In order to achieve reasonable predictions of soil radionuclide concentrations from the gamma ray activity measurements (laboratory or field), the y- and x-intercepts were set through the origin (0,0) for all correlation equations.

The linear equation relating the lower field gamma ray activity measurements to soil Ra-226 concentrations was used for field gamma ray activity measurements at values less than 4,000 count/0.1 min. This line, despite its lower correlation coefficient, has better predictive capacity to estimate soil Ra-226 concentrations when compared to results derived for the best fit line of the entire dataset. For field gamma ray activity measurements greater than 4,000 count/0.1 min, the equation developed for the entire field dataset was used.

Gamma ray activity measurements made in the laboratory were significantly lower than those measured in the field, reflecting the influence of “shine” encountered in the field. For reclamation/mitigation purposes, it is recommended that random soil samples be validated against the laboratory relationship developed in this investigation.

### Attachments or Enclosures:

|              |  |
|--------------|--|
| Table 1      | Soil Radiochemistry Results with Corresponding Field and Laboratory Gamma Measurements |
| Table 2      | Predicted Ra-226 Concentrations from Field Gamma Data                                  |
| Figure 1     | Barbara J Gamma Survey Grids   |
| Figure 2     | Barbara J Gamma Survey Additional Transect Areas                                       |
| Figure 3     | DOE Calibration Pad Facility Correlations for NaI detectors                            |
| Figure 4     | Linear Relationships between Gamma Measurements & Soil Ra-226 Concentrations           |
| Figure 5     | Linear Relationships between Soil U-238 Concentrations & Gamma Measurements            |
| Figure 6     | Linear Relationships between Gamma Measurements & Low-end Soil Ra-226 Concentrations   |
| Figure 7     | Linear Relationships between Gamma Measurements & Low-end Soil U-238 Concentrations    |
| Figure 8     | Gamma Survey   |
| Figure 9     | Ra-226 Concentrations – Field Correlation  |
| Figure 10    | Ra-226 Concentrations – Field Correlation (Low-End Measurements)                       |
| Figure 11    | Ra-226 Concentrations – Calibration Pad Correlation                                    |
| Figure 12    | Ra-226 Concentration Contours  |
| Attachment A | Calibration Pad Certificates and Calibration Pad Data                                  |
| Attachment B | ACZ Laboratory Analytical Reports  |
| Attachment C | Gamma Ray Activity Measurements Regression Analysis Summaries                          |
| Attachment D | MicroR Meter Regression Analysis Summaries   |

## TABLES

TABLE 1  
SOIL RADIOCHEMISTRY RESULTS WITH CORRESPONDING FIELD AND LABORATORY GAMMA MEASUREMENTS

| RADIONUCLIDE CHEMICAL ANALYSIS -ACZ |                    |             |            |                         |                    |                             |                             | convert<br>from total<br>Uranium<br><br>Uranium<br>238 | convert<br>from total<br>Thorium<br><br>Thorium<br>232 | total<br>radionuclides<br>(Ra, U, Th)<br><br>pCi/g | Ra-226/U<br><br>pCi/g | Th/U<br><br>pCi/g | Field Collection Counts            |         |          |          | GAI Laboratory Counts              |         |           |
|-------------------------------------|--------------------|-------------|------------|-------------------------|--------------------|-----------------------------|-----------------------------|--|--|--|-----------------------|-------------------|------------------------------------|---------|----------|----------|------------------------------------|---------|-----------|
| Sample Name                         | Collection<br>Date | Gross Alpha | Gross Beta | Radium<br>226<br>(3050) | Solids,<br>Percent | Thorium,<br>total<br>(3050) | Uranium,<br>total<br>(3050) |  |  |  |                       |                   | NaI Detector<br>(44-10)/Rate Meter |         |          | Model 19 | NaI Detector<br>(44-10)/Rate Meter |         | Model 19  |
|                                     |                    | pCi/g       | pCi/g      | pCi/g                   | %                  | mg/Kg                       | mg/Kg                       |  |  |  |                       |                   | Count/0.1 min                      |         |          | microR/h | Counts/0.1min                      |         | microR/hr |
|                                     |                    |             |            |                         |                    |                             |                             | pCi/g  | pCi/g  | pCi/g  | pCi/g                 | pCi/g             | Average                            | Std Dev | subgrade | contact  | Average<br>2350-4410               | Std Dev | contact   |
| BARBARA J#2-4                       | 3/18/09            | 7.3         | 6.5        | 1.2                     | 93.6               | 2.2                         | 1.63                        | 0.55   | 0.24   | 1.99   | 2.19                  | 0.44              | 597                                | 57.2    | 666      | 19       | 477                                | 14.2    | 12        |
| BARBARA J#1-2                       | 3/18/09            | 13          | 11         | 1.9                     | 93.1               | 2.1                         | 1.43                        | 0.48   | 0.23   | 2.61   | 3.95                  | 0.48              | 564                                | 62.6    | 673      | 19       | 526                                | 31.5    | 11        |
| BARBARA J#3-5                       | 3/18/09            | 13          | 7.9        | 1.9                     | 93                 | 3.4                         | 3.5                         | 1.18   | 0.37   | 3.45   | 1.62                  | 0.32              | 954                                | 24.6    | 1003     | 29       | 555                                | 32.6    | 15        |
| BARBARA J#3A-2                      | 3/19/09            | 30          | 18         | 5.1                     | 91.8               | 3.5                         | 3.17                        | 1.07   | 0.39   | 6.55   | 4.79                  | 0.36              | 1101                               | 139.1   | 1210     | 29       | 522                                | 22.3    | 12        |
| BARBARA J#3A-5                      | 3/19/09            | 39          | 22         | 7.5                     | 89.8               | 3.4                         | 5.61                        | 1.88   | 0.37   | 9.76   | 3.98                  | 0.20              | 890                                | 25.5    | 916      | 25       | 541                                | 42.4    | 13        |
| BARBARA J#1-1                       | 3/18/09            | 30          | 54         | 8.1                     | 89.1               | 2.7                         | 12.5                        | 4.20   | 0.30   | 12.60  | 1.93                  | 0.07              | 2253                               | 696.4   | 1718     | 65       | 620                                | 19.9    | 15        |
| BARBARA J#1-4                       | 3/18/09            | 41          | 27         | 11                      | 87.3               | 4.3                         | 7.23                        | 2.43   | 0.47   | 13.90  | 4.53                  | 0.19              | 1257                               | 110.6   | 1189     | 38       | 564                                | 26.3    | 13        |
| BARBARA J#3A-4                      | 3/19/09            | 60          | 31         | 11                      | 92.4               | 2.5                         | 22.2                        | 7.46   | 0.28   | 18.73  | 1.47                  | 0.04              | 6383                               | 241.8   | 13931    | 160      | 727                                | 15.5    | 18.5      |
| BARBARA J#2-1                       | 3/18/09            | 85          | 39         | 19                      | 92.9               | 1.9                         | 9.05                        | 3.04   | 0.21   | 22.25  | 6.25                  | 0.07              | 4393                               | 822.2   | 2827     | 120      | 1001                               | 76.7    | 9         |
| BARBARA J#3-2                       | 3/18/09            | 790         | 590        | 39                      | 91.6               | 4.2                         | 17.3                        | 5.81   | 0.46   | 45.27  | 6.71                  | 0.08              | 3167                               | 456.0   | ND       | 90       | 1598                               | 25.2    | 24        |
| BARBARA J#3-3                       | 3/18/09            | 180         | 110        | 77                      | 93.9               | 2.4                         | 146                         | 49.06  | 0.26   | 126.32   | 1.57                  | 0.01              | 7211                               | 799.5   | 8050     | 140      | 2542                               | 285.2   | 36        |
| BARBARA J#3-4                       | 3/18/09            | 220         | 130        | 86                      | 92.8               | 2.6                         | 60.9                        | 20.46  | 0.29   | 106.75   | 4.20                  | 0.01              | 5628                               | 75.6    | 3462     | 60       | 1239                               | 25.5    | 24        |
| BARBARA J2-1A                       | 4/2/09             | 470         | 610        | 220                     | 95.6               | 1.4                         | 775                         | 260.40   | 0.15   | 480.55   | 0.84                  | 6.E-04            | 15797                              | 30.9    | 15537    | ND       | 4917                               | 30.3    | ND        |
| BARBARA J3-3A                       | 4/2/09             | 470         | 640        | 230                     | 94.4               | 1.6                         | 880                         | 295.67   | 0.18   | 525.85   | 0.78                  | 6.E-04            | 20491                              | 157.9   | 23651    | 400      | 4472                               | 68.4    | nd        |
| BARBARA J3-1A                       | 4/2/09             | 1400        | 1700       | 580                     | 92.1               | 2.4                         | 2150                        | 722.39   | 0.26   | 1302.65  | 0.80                  | 4.E-04            | 27895                              | 157.1   | 21261    | 800      | 13241                              | 146.4   | nd        |
| BARBARA J3-2AS                      | 4/2/09             | 1900        | 2300       | 980                     | 95.1               | 1.4                         | 3000                        | 1007.98  | 0.15   | 1988.14  | 0.97                  | 2.E-04            | 68359                              | 22377   | 37066    | 1200     | 9086                               | 74.3    | nd        |
| BACKGROUND                          | --                 | --          | --         | --                      | --                 | --                          | --                          | --   | --   | --   | --                    | --                | --                                 | --      | --       | --       | 525                                | 32      | 13        |

**TABLE 2**  
**PREDICTED Ra-226 CONCENTRATIONS FROM FIELD GAMMA DATA**  
**USING CORRELATION EQUATIONS DEVELOPED FOR THE LOW-END VALUES AND THE**  
**ENTIRE DATASET**

| Sample ID      | Field gamma<br>ray activity<br>counts/0.1 min | Actual Ra-226<br>pCi/g | Predicted Ra-226   |                     |
|----------------|---|------------------------|--------------------|---------------------|
|                |   |                        | (low-end)<br>pCi/g | (all data)<br>pCi/g |
| BARBARA J#2-4  | 597   | 1.2                    | 2.4                | 8.8                 |
| BARBARA J#1-2  | 564   | 1.9                    | 2.3                | 8.3                 |
| BARBARA J#3-5  | 954   | 1.9                    | 3.8                | 14.1                |
| BARBARA J#3A-2 | 1101  | 5.1                    | 4.4                | 16.3                |
| BARBARA J#3A-5 | 890   | 7.5                    | 3.6                | 13.2                |
| BARBARA J#1-1  | 2253  | 8.1                    | 9.0                | 33.3                |
| BARBARA J#1-4  | 1257  | 11                     | 5.0                | 18.6                |
| BARBARA J#3A-4 | 6383  | 11                     | 25.5               | 94.5                |
| BARBARA J#2-1  | 4393  | 19                     | 17.6               | 65.0                |
| BARBARA J#3-2  | 3167  | 39                     | 12.7               | 46.9                |
| BARBARA J#3-3  | 7211  | 77                     | 28.8               | 106.7               |
| BARBARA J#3-4  | 5628  | 86                     | 22.5               | 83.3                |
| BARBARA J2-1A  | 15797   | 220                    | 63.2               | 233.8               |
| BARBARA J3-3A  | 20491   | 230                    | 82.0               | 303.3               |
| BARBARA J3-1A  | 27895   | 580                    | 111.6              | 412.8               |
| BARBARA J3-2AS | 68359   | 980                    | 273.4              | 1011.7              |

## FIGURES



Project: P:\ABQProjects\2008 Projects\073-80026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 1.mxd  
Plot: P:\ABQProjects\2008 Projects\073-80026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 1.mxd



LEGEND


Gamma Survey Estimated Area


AUM Surface Disturbance

+

REFERENCE


1) Projection: Transverse Mercator Datum, NAD 83 Coordinate System.



|   |                       |   |                |          |        |
|---|-----------------------|---|----------------|----------|--------|
| PROJECT   |                       | EMNRD<br>AML URANIUM MINES<br>McKINLEY COUNTY, NEW MEXICO |                |          |        |
| TITLE   |                       | BARBARA J GAMMA SURVEY GRIDS                              |                |          |        |
|  | PROJECT No. 073-80026 |   | SCALE AS SHOWN |          | REV. 3 |
|   | DESIGN                | ---   | ---            | FIGURE 1 |        |
|   | GIS                   | JR  | 5/19/2009      |          |        |
|   | CHECK                 | FJ  | 5/19/2009      |          |        |
|   | REVIEW                | BN  | 5/19/2009      |          |        |



Project: P:\ABQP\Projects\2008 Projects\07380026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 2



LEGEND

AUMBJ rad survey

pCi\_g

- ◆ 2.9-5.0
- ◆ 5.0-6.4
- ◆ 6.4-8.1
- ◆ 8.1-9.8
- ◆ 9.8-11.9
- ◆ 11.9-14.6
- ◆ 14.6-18.13
- ◆ 18.1-25.0
- ◆ 25.0-51.4
- ◆ 51.4-69.7
- ◆ 69.7-83.7
- ◆ 83.7-108.1
- ◆ 108.1-134.6
- ◆ 134.6-164.7
- ◆ 164.7-215.6
- ◆ 215.6-345.1
- ◆ 345.1-521.0
- ◆ 521.0-777.6

REFERENCE

- 1) Projection: Transverse Mercator Datum, NAD 83 Coordinate System.


|   |  |     |           |
|---|--|-----|-----------|
| PROJECT   | EMNRD<br>AML URANIUM MINES<br>McKINLEY COUNTY, NEW MEXICO    |     |           |
|   | TITLE<br>BARBARA J GAMMA SURVEY<br>ADDITIONAL TRANSECT AREAS |     |           |
|  | PROJECT No. 073-80026  |     |           |
|   | DESIGN   | --- | ---       |
|   | GIS  | JR  | 5/19/2009 |
|   | CHECK  | FJ  | 5/19/2009 |
|   | REVIEW   | BN  | 5/19/2009 |

FIGURE 2




**FIGURE 3**  
**DOE CALIBRATION PAD FACILITY CORRELATIONS FOR THE NAI DETECTORS USED**  
**IN THE FIELD**


| DOE CALIBRATION PADS |      |      |       |      |       |
|----------------------|------|------|-------|------|-------|
| PAD Label            | GE4  | GE2  | GPL   | GPH  | GPT   |
| Ra-226 (pCi/g)       | 83   | 88   | 376   | 67   | 397   |
| Model 2350-4410      | 5931 | 6687 | 26199 | 4308 | 28341 |
|                      | 6032 | 6631 | 25878 | 4236 | 28356 |
|                      | 6055 | 6542 | 26132 | 4355 | 28605 |
|                      |      | 6553 |       | 4381 |       |
| Average              | 6006 | 6620 | 26070 | 4300 | 28434 |

| PAD Label       | GE4  | GE2  | GPL   | GPH  | GPT   |
|-----------------|------|------|-------|------|-------|
| Ra-226 (pCi/g)  | 83   | 88   | 376   | 67   | 397   |
| Model 2221-4410 | 5357 | 5767 | 22091 | 3779 | 24433 |
| meter # 108859  | 5389 | 5886 | 22193 | 3732 | 24825 |
| det # PR 114540 | 5321 | 5624 | 22060 | 3649 | 24570 |
| Average         | 5356 | 5759 | 22115 | 3720 | 24609 |

| PAD Label        | GE4  | GPT   | GE2  | GPL   | GPH  |
|------------------|------|-------|------|-------|------|
| Ra-226 (pCi/g)   | 83   | 397   | 88   | 376   | 67   |
| Model 2221-4410a | 5309 | 24971 | 5652 | 22384 | 3650 |
| meter # 115157   | 5266 | 25019 | 5586 | 22169 | 3695 |
| det # PR 114540  | 5359 | 24874 | 5689 | 22050 | 3702 |
|                  |      | 25115 |      |       |      |
| Average          | 5311 | 24995 | 5642 | 22201 | 3682 |




**FIGURE 4**  
**LINEAR RELATIONSHIPS BETWEEN GAMMA MEASUREMENTS AND SOIL Ra-226 CONCENTRATIONS**



**Notes:**

Dashed lines represent 95% C.I.


**FIGURE 5**  
**LINEAR RELATIONSHIPS BETWEEN SOIL U-238 CONCENTRATIONS AND GAMMA MEASUREMENTS**

**Notes:**

Dashed lines represent 95% C.I.


FIGURE 6

## LINEAR RELATIONSHIPS BETWEEN GAMMA MEASUREMENTS AND LOW-END SOIL Ra-226 CONCENTRATIONS

**Notes:**

Dashed lines represent 95% C.I.


**FIGURE 7**  
**LINEAR RELATIONSHIPS BETWEEN GAMMA MEASUREMENTS AND LOW-END SOIL U-238 CONCENTRATIONS**

**Notes:**

Dashed lines represent 95% C.I.



Project: P:\ABQP\Projects\2008 Projects\073-80026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 8.pdf  
Plot: P:\ABQP\Projects\2008 Projects\073-80026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 8.pdf



LEGEND

FieldData\_AllGammaSurvey

secondcountscontact\_2350

335.0 - 566.0

566.1 - 700.0

700.1 - 852.1

852.2 - 1049.0

1049.1 - 1323.1

1323.2 - 1774.0

1774.1 - 2641.2

2641.3 - 3777.0

3777.1 - 5265.0

5265.1 - 6944.9

6945.0 - 9099.0

9099.1 - 12151.5

12151.6 - 17482.7

17482.8 - 26549.8

26549.9 - 54771.0

REFERENCE

1) Projection: Transverse Mercator Datum, NAD 83 Coordinate System.


200

0

200


Meters

SCALE 1:6,000

|  |                       |   |                |          |  |
|--|-----------------------|---|----------------|----------|--|
| PROJECT  |                       | EMNRD<br>AML URANIUM MINES<br>McKINLEY COUNTY, NEW MEXICO |                |          |  |
| TITLE  |                       | Gamma Survey  |                |          |  |
|  <div>Albuquerque, New Mexico</div> | PROJECT No. 073-80026 |   | SCALE AS SHOWN | REV. 2   |  |
|  | DESIGN                | ---   | ---            | FIGURE 8 |  |
|  | GIS                   | JR  | 5/20/2009      |          |  |
|  | CHECK                 | FJ  | 5/20/2009      |          |  |
|  | REVIEW                | BN  | 5/20/2009      |          |  |



Project: P:\ABQP\Projects\2008 Projects\073-80026 MMD - Uranium\GIS\MXDs\Uranium\MineFeatures.mxd Plot: P:\ABQP\Projects\2008 Projects\073-80026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 9.pdf



LEGEND

FieldData\_AllFieldData

SOILDATA\_\_pCi\_g\_

●

5.0 - 8.4

●

8.5 - 10.4

●

10.5 - 12.6

●

12.7 - 15.5

●

15.6 - 19.6

●

19.7 - 26.3

●

26.4 - 39.1

●

39.2 - 55.9

●

56.0 - 77.9

●

78.0 - 102.8

●

102.9 - 134.7

●

134.8 - 179.8

●

179.9 - 258.7

●


258.8 - 392.9

●

393.0 - 810.6

REFERENCE

1) Projection: Transverse Mercator Datum, NAD 83 Coordinate System.




|         |  |                             |                |
|---------|--|-----------------------------|----------------|
| PROJECT |  | EMNRD                       |                |
|         |  | AML URANIUM MINES           |                |
|         |  | McKINLEY COUNTY, NEW MEXICO |                |
| TITLE   |  | Ra-226 Concentrations       |                |
|         |  | Field Correlation           |                |
|         |  | PROJECT No. 073-80026       | SCALE AS SHOWN |
|         |  | DESIGN ---                  | REV. 2         |
|         |  | GIS JR 5/20/2009            |                |
|         |  | CHECK FJ 5/20/2009          |                |
|         |  | REVIEW BN 5/20/2009         |                |

Golder Associates  
Albuquerque, New Mexico

FIGURE 9





LEGEND


FieldData\_AllFieldData\_lowend


SOILwlow\_\_pCi\_g\_

- 1.3 - 8.4
- 8.5 - 10.4
- 10.5 - 12.6
- 12.7 - 15.5
- 15.6 - 19.6
- 19.7 - 26.3
- 26.4 - 39.1
- 39.2 - 55.9
- 56.0 - 77.9
- 78.0 - 102.8
- 102.9 - 134.7
- 134.8 - 179.8
- 179.9 - 258.7
- 258.8 - 392.9
- 393.0 - 810.6

REFERENCE

1) Projection: Transverse Mercator Datum, NAD 83 Coordinate System.




|   |   |     |           |                |
|---|---|-----|-----------|----------------|
| PROJECT   | EMNRD<br>AML URANIUM MINES<br>McKINLEY COUNTY, NEW MEXICO         |     |           |                |
| TITLE   | Ra-226 Concentrations<br>Field Correlation (Low-End Measurements) |     |           |                |
|  | PROJECT No. 073-80026   |     |           | SCALE AS SHOWN |
|   | DESIGN  | --- | ---       | REV. 2         |
|   | GIS   | JR  | 5/20/2009 | FIGURE 10      |
|   | CHECK   | FJ  | 5/20/2009 |                |
| Albuquerque, New Mexico   |   |     | REVIEW    | BN             |
|   |   |     | 5/20/2009 |                |







Plot: P:\ABQPProjects\2008 Projects\073-80026 MMD - Uranium\GIS\Export\Figures\20090519\Figure 12.pdf  
Project: P:\ABQPProjects\2008 Projects\073-80026 MMD - Uranium\GIS\MXDs\Uranium\MineFeatures.mxd



**LEGEND**

FieldData\_UpperLimitFieldData

FieldData\_UpperLimitFieldData

Rad226\_Contours


5 - 30 pCi/g

30 - 887 pCi/g

Id

**REFERENCE**

1) Projection: Transverse Mercator Datum, NAD 83 Coordinate System.



|         |  |     |           |                |
|---------|--|-----|-----------|----------------|
| PROJECT | EMNRD                                    |     |           |                |
|         | AML URANIUM MINES                        |     |           |                |
| TITLE   | McKINLEY COUNTY, NEW MEXICO              |     |           |                |
|         | Ra-226 Concentration Contours            |     |           |                |
|         | Upper Limit Field Correlation (BJ No. 2) |     |           |                |
|         | PROJECT No. 073-80026                    |     |           | SCALE AS SHOWN |
|         | DESIGN                                   | --- | ---       | FIGURE 12      |
|         | GIS                                      | JR  | 5/20/2009 |                |
|         | CHECK                                    | FJ  | 5/20/2009 |                |
|         | REVIEW                                   | BN  | 5/20/2009 |                |



## **ATTACHMENT A**

### **Calibration Pad Certificates and Calibration Pad Data**

07380026

**LOCATION:**

DATE:

**METER TYPE:**

**PERFORMED BY:**

**METER ID #:**

**DETECTOR TYPE:**

DETECTOR ID #:

H.V. /THRESHOLD

**CALIB. DATE:**

**SOURCE TYPE:**

**SOURCE #:**

**ACTIVITY (uCi):**

### Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum 44-10/44-9 and Model 2350/2221/12

**ACR**

- 1) Turn on instrument and visibly inspect meter and probe for damage especially to cables, probe's glass casing and digital display. Verify battery life.
- 2) Record date, location (site or group of sites with coordinates), model and serial #, detector model & serial #, high voltage (H.V.) threshold settings, calibration date, source type, # and activity and name of individual performing checks.
- 3) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances such as waste piles, shafts and mining-associated debris.
- 4) Record (3) six second background counts (CPS) and obtain an average.
- 5) Hold probe vertically above a known radioactive check source.
- 6) Record (10) six second source counts and obtain an average count.
- 7) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE).
- 8) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 9) An ACR **MUST** be established for each probe/meter combo and location/site.

DQC

- 1) Daily, record the date, high voltage and operator initials.
- 2) Record (3) six second background counts **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record (3) six second source counts with the probe held above the known (same distance as above) source and obtain an average source count.
- 4) Subtract the average background count from the average source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, If warranted, tag the instrument Out of Service and send to manufacturer for repair.
- 7) If second DQC falls within second ACR, proceed.

| NUMBER | BKG CPS |
|--------|---------|
| 1      | 100     |
| 2      | 100     |
| 3      | 100     |
| 4      | 100     |
| 5      | 100     |
| 6      | 100     |
| 7      | 100     |
| 8      | 100     |
| 9      | 100     |
| 10     | 100     |
| 11     | 100     |
| 12     | 100     |
| 13     | 100     |
| 14     | 100     |
| 15     | 100     |
| 16     | 100     |
| 17     | 100     |
| 18     | 100     |
| 19     | 100     |
| 20     | 100     |
| 21     | 100     |
| 22     | 100     |
| 23     | 100     |
| 24     | 100     |
| 25     | 100     |
| 26     | 100     |
| 27     | 100     |
| 28     | 100     |
| 29     | 100     |
| 30     | 100     |
| 31     | 100     |
| 32     | 100     |
| 33     | 100     |
| 34     | 100     |
| 35     | 100     |
| 36     | 100     |
| 37     | 100     |
| 38     | 100     |
| 39     | 100     |
| 40     | 100     |
| 41     | 100     |
| 42     | 100     |
| 43     | 100     |
| 44     | 100     |
| 45     | 100     |
| 46     | 100     |
| 47     | 100     |
| 48     | 100     |
| 49     | 100     |
| 50     | 100     |
| 51     | 100     |
| 52     | 100     |
| 53     | 100     |
| 54     | 100     |
| 55     | 100     |
| 56     | 100     |
| 57     | 100     |
| 58     | 100     |
| 59     | 100     |
| 60     | 100     |
| 61     | 100     |
| 62     | 100     |
| 63     | 100     |
| 64     | 100     |
| 65     | 100     |
| 66     | 100     |
| 67     | 100     |
| 68     | 100     |
| 69     | 100     |
| 70     | 100     |
| 71     | 100     |
| 72     | 100     |
| 73     | 100     |
| 74     | 100     |
| 75     | 100     |
| 76     | 100     |
| 77     | 100     |
| 78     | 100     |
| 79     | 100     |
| 80     | 100     |
| 81     | 100     |
| 82     | 100     |
| 83     | 100     |
| 84     | 100     |
| 85     | 100     |
| 86     | 100     |
| 87     | 100     |
| 88     | 100     |
| 89     | 100     |
| 90     | 100     |
| 91     | 100     |
| 92     | 100     |
| 93     | 100     |
| 94     | 100     |
| 95     | 100     |
| 96     | 100     |
| 97     | 100     |
| 98     | 100     |
| 99     | 100     |
| 100    | 100     |

1

2

3

**AVG BKG**

**SOURCE**

| NUMBER | CPS |
|--------|-----|
|--------|-----|

**1**

2

3

4

5

6

7

8

9

10

**AVG SOURCE**

ACR [(AVG SOURCE)-(AVG BKG)]:

### HIGH ACR (+ 10 %):

**LOW ACR (-10 %):**

### DAILY QUALITY CONTROL CHECK

[illegible]



07380026

LOCATION: B210212.5#  
METER TYPE: 2350-1  
METER ID #: 255840  
DETECTOR TYPE: 4410  
DETECTOR ID #: PR27.315  
H.V. /THRESHOLD 750  
CALIB. DATE: 1-7-07  
SOURCE TYPE: L3-137  
SOURCE #: 105  
ACTIVITY (uCi): 14uCi

DATE:

**PERFORMED BY:**

**ACR**

- 1) Turn on instrument and visibly inspect meter and probe for damage especially to cables, probe's glass casing and digital display. Verify battery life.
- 2) Record date, location (site or group of sites with coordinates), model and serial #, detector model & serial #, high voltage (H.V.) threshold settings, calibration date, source type, # and activity and name of individual performing checks.
- 3) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances such as waste piles, shafts and mining-associated debris.
- 4) Record (3) six second background counts (CPS) and obtain an average.
- 5) Hold probe vertically above a known radioactive check source.
- 6) Record (10) six second source counts and obtain an average count.
- 7) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE).
- 8) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 9) An ACR **MUST** be established for each probe/meter combo and location/site.

DQC

- 1) Daily, record the date, high voltage and operator initials.
- 2) Record (3) six second background counts **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record (3) six second source counts with the probe held above the known (same distance as above) source and obtain an average source count.
- 4) Subtract the average background count from the average source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, If warranted, tag the instrument Out of Service and send to manufacturer for repair.
- 7) If second DQC falls within second ACR, proceed.

## DAILY QUALITY CONTROL CHECK

[illegible]

# Abandoned Uranium Mine Land-Poison Canyon

07380026

LOCATION:

ABO WAREHOUSE

DATE:

3.19.09

METER SERIAL #

182652

PERFORMED BY:

fiore

BATT LIFE:

OK

CALIB. DATE:

4-8-08

SOURCE TYPE:

Ca-137

SOURCE #:

105

ACTIVITY (uCi):

1

REPLICATE/SCALE BACK GROUND COUNTS

1 14

2 15

3 14.5

AVG BKG 14.5

REPLICATE/SCALE

1

2

3

4

5

AVG SOURCE:

ACR [(AVG SOURCE)-(AVG BKG)]:

HIGH ACR (+ 10 %):

LOW ACR (-10 %):

## ACCEPTABLE COUNT RANGE

ACCEPTABLE COUNT RANGE SOURCE CPS

|                               | 25   | 50   | 250 | 500 | 5000 | 25   |
|-------------------------------|------|------|-----|-----|------|------|
| 1                             | 38   | 90   |     |     |      | 19   |
| 2                             | 39   | 100  |     |     |      | 19.5 |
| 3                             | 39   | 95   |     |     |      | 17   |
| 4                             | 40   | 95   |     |     |      | 19   |
| 5                             | 41   | 95   |     |     |      | 17   |
| AVG SOURCE:                   | 39.4 | 95   |     |     |      | 19.1 |
| ACR [(AVG SOURCE)-(AVG BKG)]: | 24.9 | 80.5 |     |     |      | 4.6  |
| HIGH ACR (+ 10 %):            | 27.4 | 88.6 |     |     |      | 4.1  |
| LOW ACR (-10 %):              | 22.4 | 78.5 |     |     |      | 5.1  |

## DAILY QUALITY CONTROL CHECK

| DATE   | INITIAL | BACKGROUND CPM     |    |    |         | SOURCE COUNTS |      |      |     |      |
|--------|---------|--------------------|----|----|---------|---------------|------|------|-----|------|
|        |         | 1                  | 2  | 3  | AVG BKG | 25            | 50   | 250  | 500 | 5000 |
|        |         | 15                 | 15 | 15 | 15      | 19            | 39   | 95   |     |      |
|        |         | (SOURCE)-(AVG BKG) |    |    |         | 4             | 24   | 80   |     |      |
| 4/2/09 | fiore   | 13                 | 14 | 14 | 13.6    | 18.5          | 40.5 | 100  |     |      |
|        |         | (SOURCE)-(AVG BKG) |    |    |         | 5.9           | 26.9 | 86.4 |     |      |
|        |         | (SOURCE)-(AVG BKG) |    |    |         |               |      |      |     |      |
|        |         | (SOURCE)-(AVG BKG) |    |    |         |               |      |      |     |      |
|        |         | (SOURCE)-(AVG BKG) |    |    |         |               |      |      |     |      |

## Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum MicroR Meter

### ACR

- 1) Turn on instrument and visibly inspect for damages. Verify battery life, record date, location (site or group of sites), meter model and serial #, high voltage (H.V.) setting, calibration date, source type, # and activity and name of individual performing checks.
- 2) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances. Record (3) background counts with selector in the 25 position, obtain an average.
- 3) Position meter horizontally away from known radioactive check source until needle measures 2/3rd of the 25 setting's range on the scale, record 5 source counts and obtain an average.
- 4) Move dial to next setting (50), position meter closer to the source to achieve 2/3rd the setting range, record 5 source counts and obtain an average.
- 5) Repeat step 4 for each setting (ie. 250, 500 and 5000), positioning the meter closer to the source each time.
- 6) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE) for each setting.
- 7) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count for each setting. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 8) An ACR MUST be established for each probe/meter combo and location/site.

### DQC

- 1) Daily, record the date, operator initials, and verify battery life.
- 2) Record 3 background counts at the 25 setting **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record a single source count for each setting (ie. 25, 50, 250, 500 and 5000) when the needle measures 2/3rds of setting's scale (See steps 5 and 6 for ACR above).
- 4) Subtract the average background count from each settings source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR (above) for each setting. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, tag the instrument





LOCATION: FIBQ WAKE

METER TYPE: 2350-1

METER ID #: 255840

DETECTOR TYPE: 44-10

DETECTOR ID #: PR273159

H.V. / THRESHOLD 950 T=100

CALIB. DATE: 1-10-09

SOURCE TYPE: CS-137

SOURCE #: 105

ACTIVITY (uCi): 1

DATE: 3.19.09

PERFORMED BY: Li Ma

**ACR**

- 1) Turn on instrument and visibly inspect meter and probe for damage especially to cables, probe's glass casing and digital display. Verify battery life.
- 2) Record date, location (site or group of sites with coordinates), model and serial #, detector model & serial #, high voltage (H.V.) threshold settings, calibration date, source type, # and activity and name of individual performing checks.
- 3) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances such as waste piles, shafts and mining-associated debris.
- 4) Record (3) six second background counts (CPS) and obtain an average.
- 5) Hold probe vertically above a known radioactive check source.
- 6) Record (10) six second source counts and obtain an average count.
- 7) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE).
- 8) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 9) An ACR MUST be established for each probe/meter combo and location/site.

- 1) Daily, record the date, high voltage and operator initials.
- 2) Record (3) six second background counts **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record (3) six second source counts with the probe held above the known (same distance as above) source and obtain an average source count.
- 4) Subtract the average background count from the average source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, If warranted, tag the instrument Out of Service and send to manufacturer for repair.
- 7) If second DQC falls within second ACR, proceed.

| NUMBER  | BKG CPS    |
|---------|------------|
| 1       | <u>584</u> |
| 2       | <u>533</u> |
| 3       | <u>516</u> |
| AVG BKG | <u>544</u> |
|         | SOURCE     |

| NUMBER     | CPS          |
|------------|--------------|
| 1          | <u>23101</u> |
| 2          | <u>22481</u> |
| 3          | <u>22648</u> |
| 4          | <u>21735</u> |
| 5          | <u>22640</u> |
| 6          | <u>20713</u> |
| 7          | <u>19312</u> |
| 8          | <u>23130</u> |
| 9          | <u>21856</u> |
| 10         | <u>21915</u> |
| AVG SOURCE | <u>21893</u> |

ACR [(AVG SOURCE)-(AVG BKG)]:

HIGH ACR (+ 10 %): 24082

LOW ACR (-10 %): 19304

[illegible]



## Abandoned Uranium Mine Land-Poison Canyon

07380026

LOCATION:

ABQ WAREHOUSE

DATE:

3-19-09

METER SERIAL #

253053

PERFORMED BY:

Tina

BATT LIFE:

OK

CALIB. DATE:

8-20-09

SOURCE TYPE:

Cs-137

SOURCE #:

105

ACTIVITY (uCi):

1

REPLICATE/SCALE BACK GROUND COUNTS

1

13

2

13

3

13

AVG BKG

13

REPLICATE/SCALE

1

2

3

4

5

AVG SOURCE:

ACR [(AVG SOURCE)-(AVG BKG)]:

HIGH ACR (+ 10 %):

LOW ACR (-10 %):

## ACCEPTABLE COUNT RANGE

ACCEPTABLE COUNT RANGE SOURCE CPS

| 8" 25 | 3" 50 | 250  | 500 | 5000 |
|-------|-------|------|-----|------|
| 22    | 42    | 85   |     |      |
| 21    | 42    | 90   |     |      |
| 22    | 42    | 80   |     |      |
| 22    | 42    | 85   |     |      |
| 21    | 42    | 80   |     |      |
| 21.6  | 42    | 84   |     |      |
| 8.6   | 29    | 71   |     |      |
| 9.5   | 26.1  | 78.1 |     |      |
| 7.7   | 31.9  | 64.0 |     |      |

## DAILY QUALITY CONTROL CHECK

| DATE    | INITIAL | BACKGROUND CPM |    |    |         | SOURCE COUNTS      |     |      |      |      |
|---------|---------|----------------|----|----|---------|--------------------|-----|------|------|------|
|         |         | 1              | 2  | 3  | AVG BKG | 25                 | 50  | 250  | 500  | 5000 |
| 3-19-09 | A       | 12.5           | 13 | 13 | 12.8    | 22                 | 42  | 85   |      |      |
|         |         |                |    |    |         | (SOURCE)-(AVG BKG) | 9.2 | 29.2 | 72.2 |      |
|         |         |                |    |    |         | (SOURCE)-(AVG BKG) |     |      |      |      |
|         |         |                |    |    |         | (SOURCE)-(AVG BKG) |     |      |      |      |
|         |         |                |    |    |         | (SOURCE)-(AVG BKG) |     |      |      |      |
|         |         |                |    |    |         | (SOURCE)-(AVG BKG) |     |      |      |      |

## Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum MicroR Meter

## ACR

- 1) Turn on instrument and visibly inspect for damages. Verify battery life, record date, location (site or group of sites), meter model and serial #, high voltage (H.V.) setting, calibration date, source type, # and activity and name of individual performing checks.
- 2) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances. Record (3) background counts with selector in the 25 position, obtain an average.
- 5) Position meter horizontally away from known radioactive check source until needle measures 2/3rd of the 25 setting's range on the scale, record 5 source counts and obtain an average.
- 6) Move dial to next setting (50), position meter closer to the source to achieve 2/3rd the setting range, record 5 source counts and obtain an average.
- 7) Repeat step 6 for each setting (ie. 250, 500 and 5000), positioning the meter closer to the source each time.
- 8) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE) for each setting.
- 9) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count for each setting. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 10) An ACR MUST be established for each probe/meter combo and location/site.

## DQC

- 1) Daily, record the date, operator initials, and verify battery life.
- 2) Record 3 background counts at the 25 setting **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record a single source count for each setting (ie. 25, 50, 250, 500 and 5000) when the needle measures 2/3rds of setting's scale (See steps 5 and 6 for ACR above).
- 4) Subtract the average background count from each settings source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR (above) for each setting. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, tag the instrument out of service with a note indicating reason.

07380026

- 1) Record the date, operator initials, and verify battery life at each use.
- 2) Record 3 background counts for the 25 setting at location where ACR was performed, obtain an average background count.
- 3) Record a single source count for each setting (ie. 25, 50, 250, 500 and 5000) when needle measures 2/3rds of setting's scale (See steps 5 and 6 for ACR above).
- 4) Subtract the average background count from each setting's source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR (above) for each setting. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, tag the instrument out of service. otherwise proceed as normal.



# Abandoned Uranium Mine Land-Poison Canyon

07380026

LOCATION:

39133416 / 242660 NAD 27

DATE:

3.16 12:45

METER SERIAL #

253033

PERFORMED BY:

fiore

BATT LIFE:

OK

## ACCEPTABLE COUNT RANGE

CALIB. DATE:

8-20-08

SOURCE TYPE:

CS

SOURCE #:

105

ACTIVITY (uCi):

1uCi

REPLICATE/SCALE BACK GROUND COUNTS

1 10

2 10

3 10

AVG BKG 10

REPLICATE/SCALE

1

2

3

4

5

AVG SOURCE:

ACR [(AVG SOURCE)-(AVG BKG)]:

HIGH ACR (+ 10 %):

LOW ACR (-10 %):

ACCEPTABLE COUNT RANGE SOURCE CPS

|                               | 25  | 50 | 250 | 500 | 5000 |
|-------------------------------|-----|----|-----|-----|------|
| 1                             | 18  | 40 | 90  |     |      |
| 2                             | 18  | 40 | 90  |     |      |
| 3                             | 18  | 40 | 90  |     |      |
| 4                             | 18  | 40 | 90  |     |      |
| 5                             | 18  | 40 | 90  |     |      |
| AVG SOURCE:                   | 18  | 40 | 90  |     |      |
| ACR [(AVG SOURCE)-(AVG BKG)]: | 8   | 30 | 80  |     |      |
| HIGH ACR (+ 10 %):            | 8.8 | 33 | 88  |     |      |
| LOW ACR (-10 %):              | 7.2 | 27 | 72  |     |      |

## DAILY QUALITY CONTROL CHECK

| DATE               | INITIAL | BACKGROUND CPM     |      |    |         | SOURCE COUNTS |      |      |     |      |
|--------------------|---------|--------------------|------|----|---------|---------------|------|------|-----|------|
|                    |         | 1                  | 2    | 3  | AVG BKG | 25            | 50   | 250  | 500 | 5000 |
| 3/16               | fiore   | 11                 | 10.5 | 10 | 10.5    | 17            | 38   | 80   |     |      |
| (SOURCE)-(AVG BKG) |         |                    |      |    |         | 6.5           | 27.5 | 69.5 |     |      |
| 3/17               | fiore   | 13                 | 13   | 13 | 13      | 20            | 43   | 85   |     |      |
| (SOURCE)-(AVG BKG) |         |                    |      |    |         | 7             | 30   | 72   |     |      |
| 3/18               | fiore   | 11                 | 12   | 13 | 12      | 21            | 38   | 90   |     |      |
| 39133416 / 242660  |         | (SOURCE)-(AVG BKG) |      |    |         | 9             | 26   | 78   |     |      |
| 3/19               | fiore   | 12                 | 13   | 13 | 12.7    | 23            | 42   | 90   |     |      |

too low

## Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum MicroR Meter

### ACR

- 1) Turn on instrument and visibly inspect for damages. Verify battery life, record date, location (site or group of sites), meter model and serial #, high voltage (H.V.) setting, calibration date, source type, # and activity and name of individual performing checks.
- 2) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances. Record (3) background counts with selector in the 25 position, obtain an average.
- 5) Position meter horizontally away from known radioactive check source until needle measures 2/3rd of the 25 setting's range on the scale, record 5 source counts and obtain an average.
- 6) Move dial to next setting (50), position meter closer to the source to achieve 2/3rd the setting range, record 5 source counts and obtain an average.
- 7) Repeat step 6 for each setting (ie. 250, 500 and 5000), positioning the meter closer to the source each time.
- 8) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE) for each setting.
- 9) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count for each setting. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 10) An ACR MUST be established for each probe/meter combo and location/site.

### DQC

- 1) Daily, record the date, operator initials, and verify battery life.
- 2) Record 3 background counts at the 25 setting **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record a single source count for each setting (ie. 25, 50, 250, 500 and 5000) when the needle measures 2/3rds of setting's scale (See steps 5 and 6 for ACR above).
- 4) Subtract the average background count from each settings source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR (above) for each setting. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, tag the instrument





## Abandoned Uranium Mine Land-Poison Canyon

07380026

LOCATION:

METER MODEL &amp; SERIAL #

19 (182652)

DATE:

4/15/09

PERFORMED BY:

BATT LIFE:

OK

CALIB. DATE:

4/28/08

SOURCE TYPE:

CS-137

SOURCE #:

ACTIVITY (uCi):

5µCi

REPLICATE/SCALE BACK GROUND COUNTS

|         |    |
|---------|----|
| 1       | 11 |
| 2       | 10 |
| 3       | 12 |
| AVG BKG | 11 |

REPLICATE/SCALE

1

2

3

4

5

AVG SOURCE:

ACR [(AVG SOURCE)-(AVG BKG)]:

HIGH ACR (+ 10 %):

LOW ACR (-10 %):

## ACCEPTABLE COUNT RANGE

ACCEPTABLE COUNT RANGE SOURCE CPS

| 25   | 50   | 250   | 500 | 5000 |
|------|------|-------|-----|------|
| 18   | 38   | 200   |     |      |
| 20   | 38   | 200   |     |      |
| 19   | 40   | 210   |     |      |
| 20   | 37   | 200   |     |      |
| 19   | 39   | 200   |     |      |
| 19.2 | 38.4 | 202   |     |      |
| 8.2  | 27.4 | 191   |     |      |
| 9.0  | 30.1 | 210.5 |     |      |
| 7.4  | 24.7 | 172   |     |      |

source was contained within

## DAILY QUALITY CONTROL CHECK

| DATE | INITIAL | BACKGROUND CPM |    |    |         | SOURCE COUNTS |      |     |     |      |
|------|---------|----------------|----|----|---------|---------------|------|-----|-----|------|
|      |         | 1              | 2  | 3  | AVG BKG | 25            | 50   | 250 | 500 | 5000 |
|      |         | 10             | 11 | 11 | 10.7    | 17            | 38   | 200 |     |      |
|      |         |                |    |    |         | 6.3           | 27.3 | 179 |     |      |
|      |         |                |    |    |         |               |      |     |     |      |
|      |         |                |    |    |         |               |      |     |     |      |
|      |         |                |    |    |         |               |      |     |     |      |
|      |         |                |    |    |         |               |      |     |     |      |
|      |         |                |    |    |         |               |      |     |     |      |
|      |         |                |    |    |         |               |      |     |     |      |

## Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum MicroR Meter

## ACR

- 1) Turn on instrument and visibly inspect for damages. Verify battery life, record date, location (GPS coordinates), meter model and serial #, high voltage (H.V.) setting, calibration date, source type, # and activity and name of individual performing checks.
- 2) Select a location for establishing ACR and background(BKG). The location should reflect the lowest counts in an area and have few physical disturbances. Record (3) background counts with selector in the 25 position, obtain an average.
- 5) Position meter horizontally away from radioactive check source until needle measures 2/3rd of the 25 setting's range on the scale, record 5 source counts and obtain an average.
- 6) Move dial to next setting, position meter closer to the source to achieve 2/3rd the setting range, record 5 source counts and obtain an average.
- 7) Repeat step 6 for each setting, positioning the meter closer to the source each time.
- 8) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE) for each setting.
- 9) Determine ACR by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count for each setting. These values represent an ACR one can expect when conducting daily quality control checks for a given location.
- 10) Establish an ACR for each probe/meter combo and location/site.

## DQC

- 1) Record the date, operator initials, and verify battery life at each use.
- 2) Record 3 background counts for the 25 setting at location where ACR was performed, obtain an average background count.
- 3) Record a single source count for each setting (ie. 25, 50, 250, 500 and 5000) when needle measures 2/3rds of setting's scale (See steps 5 and 6 for ACR above).
- 4) Subtract the average background count from each setting's source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR (above) for each setting. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, tag the instrument out of service, otherwise proceed as normal.

Abandoned Uranium Mine Land-Poison Canyon  
07380026

LOCATION: CAL PLOTS  
METER SERIAL #: 152652  
BATT LIFE: OK  
CALIB. DATE: 3/14/09  
SOURCE TYPE: CS  
SOURCE #: 105  
ACTIVITY (uCi): 1

DATE: 3/16/09  
PERFORMED BY: RB

ACCEPTABLE COUNT RANGE

REPLICATE/SCALE

ACCEPTABLE COUNT RANGE SOURCE CPS

1 14 13  
2 14 12  
3 16 14  
AVG BKG 14.6 13

1  
2  
3  
4  
5

| 25    | 50    | 250   | 2500 | 5000  | 250 |
|-------|-------|-------|------|-------|-----|
| 20    | 38    | 100   | 19   | 44    | 170 |
| 20    | 40    | 110   | 20   | 44    | 180 |
| 18    | 40    | 110   | 19   | 45    | 180 |
| 20    | 40    | 110   | 20   | 45    | 175 |
| 19    | 40    | 110   | 21   | 46    | 185 |
| 19.4  | 39.5  | 108   | 20   | 44.45 | 178 |
| 4.8   | 24.9  | 93.4  | 7    | 25.32 | 165 |
| 21.34 | 43.45 | 118.8 | 8    | 35    | 182 |
| 17.46 | 35.55 | 97.2  | 6    | 29    | 149 |

AVG SOURCE:

HIGH ACR (+10 %):

LOW ACR (-10 %):

DAILY QUALITY CONTROL CHECK

| DATE               | INITIAL | BACKGROUND CPM |    |    |         | SOURCE COUNTS |    |     |     |      |
|--------------------|---------|----------------|----|----|---------|---------------|----|-----|-----|------|
|                    |         | 1              | 2  | 3  | AVG BKG | 25            | 50 | 250 | 500 | 5000 |
| 3/16/09            | JAC/FJ  | 14             | 15 | 16 | 15      | 22            | 44 | 110 | 35  |      |
| (SOURCE)-(AVG BKG) |         |                |    |    |         | 7             | 29 | 75  |     |      |
| 3/16/09            | JAC/RB  | 26             | 26 | 26 | 26      | 28            | 48 | 110 |     |      |
| (SOURCE)-(AVG BKG) |         |                |    |    |         | 2             | 22 | 84  |     |      |
| 3/17/09            | JAC/RB  | 12             | 13 | 14 | 13      | 20            | 43 | 180 |     |      |
| (SOURCE)-(AVG BKG) |         |                |    |    |         | 7             | 30 | 167 |     |      |
| 3/18/09            | JAC     | 12             | 14 | 14 | 13      | 18            | 42 | 165 |     |      |
| 3/19/09            | JAC     | 13             | 13 | 14 | 13      | 15            | 29 | 152 |     |      |

Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum MicroR Meter

- 1) Turn on instrument and visibly inspect for damages. Verify battery life, record date, location (site or group of sites), meter model and serial #, high voltage (H.V.) setting, calibration date, source type, # and activity and name of individual performing checks.
- 2) Select a location for establishing ACR and background (BKG). The location should reflect the lowest count in an area and have few physical disturbances. Record (3) background counts with selector in the 25 position, obtain an average.
- 3) Position meter horizontally away from known radioactive check source until needle measures 2/3rd of the 25 setting's range on the scale, record 5 source counts and obtain an average.
- 4) Move dial to next setting (50), position meter closer to the source to achieve 2/3rd the setting range, record 5 source counts and obtain an average.
- 5) Repeat step 4 for each setting (ie. 250, 500 and 5000), positioning the meter closer to the source each time.
- 6) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE) for each setting.
- 7) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count for each setting. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 8) An ACR MUST be established for each probe/meter combo and location/site.

DQC

- 1) Daily, record the date, operator initials, and verify battery life.
- 2) Record 3 background counts at the 25 setting AT THE SAME LOCATION that the ACR was performed and obtain an average background count.
- 3) Record a single source count for each setting (ie. 25, 50, 250, 500 and 5000) when the needle measures 2/3rds of setting's scale (See steps 5 and 6 for ACR above).
- 4) Subtract the average background count from each settings source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR (above) for each setting. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, tag the instrument out of service.

Background Location C BS#2  
S side of Row @ drainage

35° 19' 34.673 S N UTM 83  
107° 49' 57.249 S W







### ACCEPTABLE COUNT RANGE

[illegible]

# Abandoned Uranium Mine Land-Poison Canyon

07380026

## ACCEPTABLE COUNT RANGE

LOCATION: DOE Pond  
 METER TYPE: Ludlum 2221  
 METER ID #: 108859  
 DETECTOR TYPE: NaI  
 DETECTOR ID #: Pr 114540  
 H.V. /THRESHOLD: 858/105  
 CALIB. DATE: 3/2/09  
 SOURCE TYPE: Cs  
 SOURCE #: 105  
 ACTIVITY (uCi): 1

DATE: 3/16/09

PERFORMED BY: JAC

### Acceptable Count Range (ACR) and Daily Quality Control Check (DQC) Procedures for Ludlum 44-10/44-9 and Model 2350/2221/12

#### ACR

- 1) Turn on instrument and visibly inspect meter and probe for damage especially to cables, probe's glass casing and digital display. Verify battery life.
- 2) Record date, location (site or group of sites with coordinates), model and serial #, detector model & serial #, high voltage (H.V.) threshold settings, calibration date, source type, # and activity and name of individual performing checks.
- 3) Select a location for establishing ACR and background(BKG). The location should reflect the lowest count in an area and have few physical disturbances such as waste piles, shafts and mining-associated debris.
- 4) Record (3) six second background counts (CPS) and obtain an average.
- 5) Hold probe vertically above a known radioactive check source.
- 6) Record (10) six second source counts and obtain an average count.
- 7) Subtract the average background count (AVG BKG) from the average source count (AVG SOURCE).
- 8) Determine the acceptable count range (ACR) by subtracting 10 % (low) from and adding 10 % (high) to the average source minus background count. These values represent the acceptable count range one can expect when conducting daily quality control checks for a given location.
- 9) An ACR MUST be established for each probe/meter combo and location/site.

#### DQC

- 1) Daily, record the date, high voltage and operator initials.
- 2) Record (3) six second background counts **AT THE SAME LOCATION** that the ACR was performed and obtain an average background count.
- 3) Record (3) six second source counts with the probe held above the known (same distance as above) source and obtain an average source count.
- 4) Subtract the average background count from the average source count.
- 5) Compare the (AVG SOURCE)-(AVG BKG) count to the high and low ACR. The DQC should fall within this range.
- 6) If the instrument fails to fall within the ACR established for a given location evaluate conditions to insure no changes in background, source, etc. occurred and perform a second ACR and DQC. If the instrument fails again, If warranted, tag the instrument Out of Service and send to manufacturer for repair.
- 7) If second DQC falls within second ACR, proceed.

672  
 1540  
 1556  
 1504  
 1516  
 1560  
 1465  
 1537  
 1528  
 1610  
 1549

1212  
 746 760  
 798  
 740  
 831  
 781  
 697  
 755  
 772  
 776  
 763

1812

NUMBER  
 1 1548 627  
 2 1549 596  
 3 1588 572

AVG BKG 1561.7 = 1562

SOURCE  
 NUMBER CPS  
 1 14027 12583  
 2 14268 12536  
 3 14075 12676  
 4 14348 12368  
 5 14204 12638  
 6 14089 12411  
 7 14072 12747  
 8 14272 12525  
 9 14239 12778  
 10 14314 12632

AVG SOURCE 14190 12579

ACR [(AVG SOURCE)-(AVG BKG)]:

HIGH ACR (+ 10 %): 15609 13837

LOW ACR (-10 %): 12772 11321

## DAILY QUALITY CONTROL CHECK

| DATE    | INITIAL | H.V. | BACKGROUND CPM |     |     | AVG BKG | SOURCE CPM |       |       | AVG SOURCE | (AVG SOURCE)-(AVG BKG) |
|---------|---------|------|----------------|-----|-----|---------|------------|-------|-------|------------|------------------------|
| 3/16/09 | JAC     | 858  | 556            | 599 | 583 | 579     | 14120      | 13873 | 14334 | 14109      | 13526                  |
| 3/16/09 | JAC     | -    | 678            | 620 | 677 | 658     | 12959      | 12896 | 12807 | 12887      | 12229                  |
| "       | "       | -    | 627            | 596 | 572 | 598     | 12699      | 12557 | 12700 |            | 12054                  |
| 3/17/09 | JAC/RB  | 868  | 408            | 414 | 406 | 409     | 12987      | 13075 | 12941 | 12991      | 12582                  |
| 3/18/09 | JAC/RB  | 861  | 393            | 400 | 383 | 392     | 13184      | 12813 | 12741 | 12981      | 12489                  |
| 3/19/09 | JAC/RB  | 870  | 367            | 341 | 379 | 362     | 14280      | 14267 | 14241 | 14263      | 13901                  |

BATT

OK

5.8





# Certificate of Calibration

## Ratemeter / Scaler Certificate of Calibration



Environmental Restoration Group, Inc.  
8809 Washington St. NE, Suite 150  
Albuquerque, NM 87113  
(505) 298-4224

Manufacturer: Ludlum Model: 2221 Serial No.: 115157

All Ranges Calibrated Electronically; Ludlum Pulsar Generator Serial No.: ☐ 97743 ☒ 201932

This calibration conforms to the requirements and acceptable calibration conditions of ANSI N323A - 1997  
NMRCB Registration No. 481-3 • Calibration of Radiation Detection Instruments & Devices

☒ Mechanical ck. ☒ Meter Zeroed ☒ Geotropism ck. ☒ F/S Response ck. ☒ Audio ck.

☒ THR/WIN ck. High Voltage ck.: ☒ 500v ☒ 1000v ☒ 1500v ☒ Battery ck. (min 4.4 vdc)

Threshold Setting: 10 mV

Instrument found within tolerance (+/- 10%) ☒ Yes ☐ No

| Reference<br>Calibration Point | Instrument<br>"As Found Reading" | Instrument<br>Meter Reading |
|--------------------------------|----------------------------------|-----------------------------|
| 400 Kcpm                       | <u>400 Kcpm</u>                  | <u>400 Kcpm</u>             |
| 100 Kcpm                       | <u>100 Kcpm</u>                  | <u>100 Kcpm</u>             |
| 40 Kcpm                        | <u>40 Kcpm</u>                   | <u>40 Kcpm</u>              |
| 10 Kcpm                        | <u>10 Kcpm</u>                   | <u>10 Kcpm</u>              |
| 4 Kcpm                         | <u>4 Kcpm</u>                    | <u>4 Kcpm</u>               |
| 1 Kcpm                         | <u>1 Kcpm</u>                    | <u>1 Kcpm</u>               |
| 400 cpm                        | <u>400 cpm</u>                   | <u>400 cpm</u>              |
| 100 cpm                        | <u>100 cpm</u>                   | <u>100 cpm</u>              |

| Reference<br>Calibration Point | Instrument<br>"As Found Reading" | Log Scale<br>Count Rate | Integrated Counts<br>(1-minute count) |
|--------------------------------|----------------------------------|-------------------------|---------------------------------------|
| 400 Kcpm                       | <u>400 Kcpm</u>                  | <u>400 Kcpm</u>         | <u>398735</u>                         |
| 40 Kcpm                        | <u>40 Kcpm</u>                   | <u>40 Kcpm</u>          | <u>39872</u>                          |
| 4 Kcpm                         | <u>4 Kcpm</u>                    | <u>4 Kcpm</u>           | <u>3987</u>                           |
| 400 cpm                        | <u>400 cpm</u>                   | <u>400 cpm</u>          | <u>399</u>                            |

Calibrated By: [Signature]

Calibration Date: 9.2.08

Calibration Due: 9.2.09

Reviewed By: Chad P. L.

Date: 9/2/08



# Certificate of Calibration

## Ratemeter / Scaler Certificate of Calibration



Environmental Restoration Group, Inc.  
8809 Washington St. NE, Suite 150  
Albuquerque, NM 87113  
(505) 298-4224

Manufacturer: Ludlum Model: 2221r Serial No.: 86306

All Ranges Calibrated Electronically; Ludlum Pulser Generator Serial No.: ☐ 97743 ☒ 201932

This calibration conforms to the requirements and acceptable calibration conditions of ANSI N323A - 1997  
NMRCB Registration No. 481-3 • Calibration of Radiation Detection Instruments & Devices

☒ Mechanical ck. ☒ Meter Zeroed ☒ Geotropism ck. ☒ F/S Response ck. ☒ Audio ck.


☒ THR/WIN ck. High Voltage ck.: ☒ 500v ☒ 1000v ☒ 1500v ☒ Battery ck. (min 4.4 vdc)

Threshold Setting: 10 mV

Instrument found within tolerance (+/- 10%) ☒ Yes ☐ No

| Reference<br>Calibration Point | Instrument<br>"As Found Reading" | Instrument<br>Meter Reading |
|--------------------------------|----------------------------------|-----------------------------|
| 400 Kcpm                       | <u>400 Kcpm</u>                  | <u>400 Kcpm</u>             |
| 100 Kcpm                       | <u>100 Kcpm</u>                  | <u>100 Kcpm</u>             |
| 40 Kcpm                        | <u>40 Kcpm</u>                   | <u>40 Kcpm</u>              |
| 10 Kcpm                        | <u>10 Kcpm</u>                   | <u>10 Kcpm</u>              |
| 4 Kcpm                         | <u>4 Kcpm</u>                    | <u>4 Kcpm</u>               |
| 1 Kcpm                         | <u>1 Kcpm</u>                    | <u>1 Kcpm</u>               |
| 400 cpm                        | <u>400 cpm</u>                   | <u>400 cpm</u>              |
| 100 cpm                        | <u>100 cpm</u>                   | <u>100 cpm</u>              |

| Reference<br>Calibration Point | Instrument<br>"As Found Reading" | Log Scale<br>Count Rate | Integrated Counts<br>(1-minute count) |
|--------------------------------|----------------------------------|-------------------------|---------------------------------------|
| 400 Kcpm                       | <u>400 Kcpm</u>                  | <u>400 Kcpm</u>         | <u>398320</u>                         |
| 40 Kcpm                        | <u>40 Kcpm</u>                   | <u>40 Kcpm</u>          | <u>39824</u>                          |
| 4 Kcpm                         | <u>4 Kcpm</u>                    | <u>4 Kcpm</u>           | <u>3983</u>                           |
| 400 cpm                        | <u>400 cpm</u>                   | <u>400 cpm</u>          | <u>398</u>                            |

Calibrated By: 

Calibration Date: 12-15-08

Calibration Due: 12-15-09

Reviewed By: 

Date: 12/15/08

# Certificate of Calibration

## Voltage Plateau Form



Environmental Restoration Group, Inc.  
8809 Washington St. NE, Suite 150  
Albuquerque, NM 87113  
(505) 298-4224

Detector Mfg.: Ludlum Model: 44-10 Serial No.: PR122628  
Counter Mfg.: Ludlum Model: 2221 Serial No.: 108846

This calibration conforms to the requirements and acceptable calibration conditions of ANSI N323A - 1997.  
NMRCB Registration No. 481-3 • Calibration of Radiation Detection Instruments & Devices

Counter Threshold Setting: 10 mV Cable Length: ☐ 39 inch, ☐ 5 foot, ☒ Other: Curly

Detector geometry to source: ☐ Face, ☒ Side, ☐ Below, ☐ Other: \_\_\_\_\_

Distance to source: ☐ Contact, ☒ 6-Inches, ☐ Other: 1/2"

Alpha Source: ☐ Th230 @ 13,000 dpm (2/14/08) sn: 4098-03 ☐ Other: \_\_\_\_\_

Beta Source: ☐ Tc99 @ 16,800 dpm (2/14/08) sn: 4099-03 ☐ Other: \_\_\_\_\_

Gamma Source: ☒ Cs-137 @ 5.81  $\mu$ Ci (3/07/07) sn: 4097-03 ☐ Other: Am-241 1  $\mu$ Ci

Count Time: 1 Minute

| High Voltage | Gross Source Counts | Background Counts |
|--------------|---------------------|-------------------|
| 700          | 66530               |                   |
| 800          | 77472               |                   |
| 900          | 81357               |                   |
| 1000         | 83078               |                   |
| 1050         | 83246               |                   |
| 1100         | 83455               | 11759             |
| 1150         | 83640               |                   |
| 1200         | 85308               |                   |
|              |                     |                   |

Comments: Recommended Operating High Voltage: 1100 volts

Calibrated By: 

Calibration Date: 12-15-08

Calibration Due: 12-15-09

Reviewed By: 

Date: 12/15/08

# Certificate of Calibration

## Voltage Plateau Form



Environmental Restoration Group, Inc.  
8809 Washington St. NE, Suite 150  
Albuquerque, NM 87113  
(505) 298-4224

Detector Mfg.: Ludlum Model: 44-10 Serial No.: PR114540  
Counter Mfg.: Ludlum Model: 2221 Serial No.: 115157

This calibration conforms to the requirements and acceptable calibration conditions of ANSI N323A - 1997.  
NMRCB Registration No. 481-3 • Calibration of Radiation Detection Instruments & Devices

Counter Threshold Setting: 10 mV Cable Length: ☒ 39 inch, ☐ 5 foot, ☐ Other: \_\_\_\_\_

Detector geometry to source: ☐ Face, ☒ Side, ☐ Below, ☐ Other: \_\_\_\_\_

Distance to source: ☐ Contact, ☒ 6-Inches, ☐ Other: \_\_\_\_\_

Alpha Source : ☐ Th230 @ 13,000 dpm (2/14/08) sn: 4098-03 ☐ Other: \_\_\_\_\_

Beta Source: ☐ Tc99 @ 16,800 dpm (2/14/08) sn: 4099-03 ☐ Other: \_\_\_\_\_

Gamma Source : ☒ Cs-137 @ 5.32 $\mu$ Ci (2/18/09) sn: 4097-03 ☐ Other: Am-241 1  $\mu$ Ci

Count Time: 1 Minute

| High Voltage | Gross Source Counts | Background Counts |
|--------------|---------------------|-------------------|
| 700          | 73004               |                   |
| 800          | 78988               |                   |
| 850          | 81304               | 10744             |
| 900          | 81959               |                   |
| 950          | 82902               |                   |
| 1000         | 84292               |                   |
| 1050         | 88960               |                   |
|              |                     |                   |
|              |                     |                   |

Comments: Recommended Operating High Voltage: 850 volts

Calibrated By: \_\_\_\_\_

Calibration Date: 4/13/09

Calibration Due: 4/13/10

Reviewed By: \_\_\_\_\_

Date: 4/13/09





Designer and Manufacturer  
of  
Scientific and Industrial  
Instruments

# CERTIFICATE OF CALIBRATION

**LUDLUM MEASUREMENTS, INC.**  
POST OFFICE BOX 810 PH. 325-235-5494  
501 OAK STREET FAX NO. 325-235-4672  
SWEETWATER, TEXAS 79556, U.S.A.

CUSTOMER ERG (ENVIRO RES GRP) ORDER NO. 20107226/324704

Mfg. Ludlum Measurements, Inc. Model 19 Serial No. 182652

Mfg. \_\_\_\_\_ Model \_\_\_\_\_ Serial No. \_\_\_\_\_

Cal. Date 28-Apr-08 Cal Due Date 28-Apr-09 Cal. Interval 1 Year Meterface 202-016

Check mark ☒ applies to applicable instr. and/or detector IAW mfg. spec. T. 73 °F RH 30 % Alt 705.8 mm Hg

☐ New Instrument ☐ Instrument Received ☒ Within Toler.  $\pm 10\%$  ☐ 10-20% ☐ Out of Tol. ☐ Requiring Repair ☐ Other-See comments

☒ Mechanical ck. ☒ Meter Zeroed ☐ Background Subtract ☐ Input Sens. Linearity

☒ F/S Resp. ck. ☒ Reset ck. ☐ Window Operation ☐ Geotropism

☒ Audio ck. ☐ Alarm Setting ck. ☒ Batt. ck. (Min. Volt) 2.2 VDC

☐ Calibrated in accordance with LMI SOP 14.8 rev 12/05/89. ☒ Calibrated in accordance with LMI SOP 14.9 rev 02/07/97.

Instrument Volt Set 550 V Input Sens. 34 mV Det. Oper. \_\_\_\_\_ V at \_\_\_\_\_ mV Threshold Dial Ratio \_\_\_\_\_ = \_\_\_\_\_ mV

☐ HV Readout (2 points) Ref./Inst. \_\_\_\_\_ / \_\_\_\_\_ V Ref./Inst. \_\_\_\_\_ / \_\_\_\_\_ V

## COMMENTS:

Gamma Calibration: GM detectors positioned perpendicular to source except for M 44-9 in which the front of probe faces source.

| RANGE/MULTIPLIER | REFERENCE CAL. POINT  | INSTRUMENT REC'D "AS FOUND READING" | INSTRUMENT METER READING* |
|------------------|-----------------------|-------------------------------------|---------------------------|
| 5000             | 4000 uR/hr            | 4000                                | 4000                      |
| 5000             | 1000 uR/hr            | 1000                                | 1000                      |
| 500              | 400 uR/hr = 72400 cpm | 400                                 | 400                       |
| 500              | 100 uR/hr             | 100                                 | 100                       |
| 250              | 200 uR/hr = 34000 cpm | 200                                 | 200                       |
| 250              | 100 uR/hr             | 100                                 | 100                       |
| 50               | 7240 cpm              | 40                                  | 40                        |
| 50               | 1810 cpm              | 10                                  | 10                        |
| 25               | 3400 cpm              | 20                                  | 20                        |
| 25               | 850 cpm               | 5                                   | 5                         |

\*Uncertainty within  $\pm 10\%$  C.F. within  $\pm 20\%$

50, 25 Range(s) Calibrated Electronically

| REFERENCE CAL. POINT | INSTRUMENT RECEIVED | INSTRUMENT METER READING* | REFERENCE CAL. POINT | INSTRUMENT RECEIVED | INSTRUMENT METER READING* |
|----------------------|---------------------|---------------------------|----------------------|---------------------|---------------------------|
| Digital readout      |                     |                           | Log Scale            |                     |                           |
|                      |                     |                           |                      |                     |                           |
|                      |                     |                           |                      |                     |                           |
|                      |                     |                           |                      |                     |                           |
|                      |                     |                           |                      |                     |                           |

Ludlum Measurements, Inc. certifies that the above instrument has been calibrated by standards traceable to the National Institute of Standards and Technology, or to the calibration facilities of other International Standards Organization members, or have been derived from accepted values of natural physical constants or have been derived by the ratio type of calibration techniques. The calibration system conforms to the requirements of ANSI/NCSL Z540-1-1994 and ANSI N323-1978 State of Texas Calibration License No. LO-1963

**Reference Instruments and/or Sources:** ☐ S-394/1122 ☐ 1131 ☐ 781 ☐ 059 ☐ 280  
Cs-137 Gamma S/N ☐ 1162 ☐ G112 ☒ M565 ☐ 5105 ☐ T1008 ☐ T879 ☐ E552 ☐ E551 ☐ 720 ☐ 734 ☐ 1616 ☐ Neutron Am-241 Be S/N T-304  
☐ Alpha S/N \_\_\_\_\_ ☐ Beta S/N \_\_\_\_\_ ☐ Other \_\_\_\_\_  
☒ m 500 S/N 238275 ☐ Oscilloscope S/N \_\_\_\_\_ ☒ Multimeter S/N 83750210

Calibrated By: [Signature] Date 28-APR-08  
Reviewed By: [Signature] Date 28 Apr 08

## **ATTACHMENT B**

### **ACZ Laboratory Analytical Reports**

April 28, 2009

## Report to:

Bob Newcomer  
Golder Associates, Inc.  
5200 Pasadena, N.E. Suite C  
Albuquerque, NM 87113

## Bill to:

Toni Sanchez  
Golder Associates, Inc.  
5200 Pasadena NE Suite C  
Albuquerque, NM 87113

cc: Fiona Jordan

Project ID: 07380026.0002

ACZ Project ID: L75211

Bob Newcomer:

Enclosed are the analytical results for sample(s) submitted to ACZ Laboratories, Inc. (ACZ) on April 09, 2009. This project has been assigned to ACZ's project number, L75211. Please reference this number in all future inquiries.


All analyses were performed according to ACZ's Quality Assurance Plan, version 12.0. The enclosed results relate only to the samples received under L75211. Each section of this report has been reviewed and approved by the appropriate Laboratory Supervisor, or a qualified substitute.

Except as noted, the test results for the methods and parameters listed on ACZ's current NELAC certificate letter (#ACZ) meet all requirements of NELAC.

This report shall be used or copied only in its entirety. ACZ is not responsible for the consequences arising from the use of a partial report.

All samples and sub-samples associated with this project will be disposed of after May 28, 2009. If the samples are determined to be hazardous, additional charges apply for disposal (typically less than \$10/sample). If you would like the samples to be held longer than ACZ's stated policy or to be returned, please contact your Project Manager or Customer Service Representative for further details and associated costs. ACZ retains analytical reports for five years.

If you have any questions or other needs, please contact your Project Manager.



Scott Habermehl has reviewed  
and approved this report.





**Golder Associates, Inc.**

Project ID: 07380026.0002

Sample ID: BARBARA J3-1A

ACZ Sample ID: **L75211-01**

Date Sampled: 04/02/09 12:45

Date Received: 04/09/09

Sample Matrix: Soil

## Metals Analysis

| Parameter             | EPA Method   | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------------|--------------|--------|------|----|-------|-----|-----|----------------|---------|
| Thorium, total (3050) | M6020 ICP-MS | 2.4    | B    | *  | mg/Kg | 0.5 | 3   | 04/21/09 3:11  | erf     |
| Uranium, total (3050) | M6020 ICP-MS | 2150   |      | *  | mg/Kg | 3   | 10  | 04/21/09 18:07 | erf     |

## Soil Analysis

| Parameter       | EPA Method              | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------|-------------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Solids, Percent | CLPSOW390, PART F, D-98 | 92.1   |      | *  | %     | 0.1 | 0.5 | 04/10/09 13:00 | lwt     |

## Soil Preparation

| Parameter               | EPA Method       | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-------------------------|------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Air Dry at 34 Degrees C | USDA No. 1, 1972 |        |      |    |       |     |     | 04/10/09 12:30 | lwt     |
| Crush and Pulverize     | USDA No. 1, 1972 |        |      |    |       |     |     | 04/13/09 10:00 | lwt     |
| Digestion - Hot Plate   | M3050B ICP-MS    |        |      |    |       |     |     | 04/14/09 9:35  | lwt     |

## Report Header Explanations

|         |   |
|---------|---|
| Batch   | A distinct set of samples analyzed at a specific time   |
| Found   | Value of the QC Type of interest  |
| Limit   | Upper limit for RPD, in %.  |
| Lower   | Lower Recovery Limit, in % (except for LCSS, mg/Kg)   |
| MDL     | Method Detection Limit. Same as Minimum Reporting Limit. Allows for instrument and annual fluctuations. |
| PCN/SCN | A number assigned to reagents/standards to trace to the manufacturer's certificate of analysis          |
| PQL     | Practical Quantitation Limit, typically 5 times the MDL.  |
| QC      | True Value of the Control Sample or the amount added to the Spike                                       |
| Rec     | Amount of the true value or spike added recovered, in % (except for LCSS, mg/Kg)                        |
| RPD     | Relative Percent Difference, calculation used for Duplicate QC Types                                    |
| Upper   | Upper Recovery Limit, in % (except for LCSS, mg/Kg)   |
| Sample  | Value of the Sample of interest   |

## QC Sample Types

|       |  |       |  |
|-------|--|-------|--|
| AS    | Analytical Spike (Post Digestion)                      | LCSWD | Laboratory Control Sample - Water Duplicate  |
| ASD   | Analytical Spike (Post Digestion) Duplicate            | LFB   | Laboratory Fortified Blank                   |
| CCB   | Continuing Calibration Blank                           | LFM   | Laboratory Fortified Matrix                  |
| CCV   | Continuing Calibration Verification standard           | LFMD  | Laboratory Fortified Matrix Duplicate        |
| DUP   | Sample Duplicate                                       | LRB   | Laboratory Reagent Blank                     |
| ICB   | Initial Calibration Blank                              | MS    | Matrix Spike                                 |
| ICV   | Initial Calibration Verification standard              | MSD   | Matrix Spike Duplicate                       |
| ICSAB | Inter-element Correction Standard - A plus B solutions | PBS   | Prep Blank - Soil                            |
| LCSS  | Laboratory Control Sample - Soil                       | PBW   | Prep Blank - Water                           |
| LCSSD | Laboratory Control Sample - Soil Duplicate             | PQV   | Practical Quantitation Verification standard |
| LCSW  | Laboratory Control Sample - Water                      | SDL   | Serial Dilution                              |

## QC Sample Type Explanations

|                         |   |
|-------------------------|---|
| Blanks                  | Verifies that there is no or minimal contamination in the prep method or calibration procedure. |
| Control Samples         | Verifies the accuracy of the method, including the prep procedure.                              |
| Duplicates              | Verifies the precision of the instrument and/or method.   |
| Spikes/Fortified Matrix | Determines sample matrix interferences, if any.   |
| Standard                | Verifies the validity of the calibration.   |

## ACZ Qualifiers (Qual)

|   |   |
|---|---|
| B | Analyte concentration detected at a value between MDL and PQL. The associated value is an estimated quantity.   |
| H | Analysis exceeded method hold time. pH is a field test with an immediate hold time.   |
| U | The material was analyzed for, but was not detected above the level of the associated value.<br>The associated value is either the sample quantitation limit or the sample detection limit. |

## Method References

- (1) EPA 600/4-83-020. Methods for Chemical Analysis of Water and Wastes, March 1983.
- (2) EPA 600/R-93-100. Methods for the Determination of Inorganic Substances in Environmental Samples, August 1993.
- (3) EPA 600/R-94-111. Methods for the Determination of Metals in Environmental Samples - Supplement I, May 1994.
- (5) EPA SW-846. Test Methods for Evaluating Solid Waste, Third Edition with Update III, December 1996.
- (6) Standard Methods for the Examination of Water and Wastewater, 19th edition, 1995.

## Comments

- (1) QC results calculated from raw data. Results may vary slightly if the rounded values are used in the calculations.
- (2) Soil, Sludge, and Plant matrices for Inorganic analyses are reported on a dry weight basis.
- (3) Animal matrices for Inorganic analyses are reported on an "as received" basis.

For a complete list of ACZ's Extended Qualifiers, please click:

<http://www.acz.com/public/extquallist.pdf>

**Golder Associates, Inc.**

ACZ Project ID: **L75211**

Project ID: 07380026.0002

**Solids, Percent**

CLPSOW390, PART F, D-98

| ACZ ID          | Type | Analyzed       | PCN/SCN | QC | Sample | Found | Units | Rec | Lower | Upper | RPD | Limit | Qual |
|-----------------|------|----------------|---------|----|--------|-------|-------|-----|-------|-------|-----|-------|------|
| <b>WG262077</b> |      |                |         |    |        |       |       |     |       |       |     |       |      |
| WG262077PBS     | PBS  | 04/10/09 13:00 |         |    |        | U     | %     |     | 99.9  | 100.1 |     |       |      |
| L75214-01DUP    | DUP  | 04/10/09 13:00 |         |    | 95.1   | 93.96 | %     |     |       |       | 1.2 | 20    |      |

**Thorium, total (3050)**

M6020 ICP-MS

| ACZ ID          | Type | Analyzed      | PCN/SCN    | QC   | Sample | Found | Units | Rec  | Lower  | Upper | RPD  | Limit | Qual |
|-----------------|------|---------------|------------|------|--------|-------|-------|------|--------|-------|------|-------|------|
| <b>WG262507</b> |      |               |            |      |        |       |       |      |        |       |      |       |      |
| WG262507ICV     | ICV  | 04/21/09 2:42 | MS090326-1 | .05  |        | .0477 | mg/L  | 95.4 | 90     | 110   |      |       |      |
| WG262507ICB     | ICB  | 04/21/09 2:47 |            |      |        | U     | mg/L  |      | -0.003 | 0.003 |      |       |      |
| WG262158PBS     | PBS  | 04/21/09 3:06 |            |      |        | U     | mg/Kg |      | -1.5   | 1.5   |      |       |      |
| L75214-01MS     | MS   | 04/21/09 3:34 | MS090311-4 | 12.5 | 1.4    | 13.5  | mg/Kg | 96.8 | 75     | 125   |      |       |      |
| L75214-01MSD    | MSD  | 04/21/09 3:48 | MS090311-4 | 12.5 | 1.4    | 13.16 | mg/Kg | 94.1 | 75     | 125   | 2.55 | 20    |      |

**Uranium, total (3050)**

M6020 ICP-MS

| ACZ ID          | Type | Analyzed       | PCN/SCN    | QC  | Sample | Found  | Units | Rec  | Lower   | Upper  | RPD | Limit | Qual |
|-----------------|------|----------------|------------|-----|--------|--------|-------|------|---------|--------|-----|-------|------|
| <b>WG262537</b> |      |                |            |     |        |        |       |      |         |        |     |       |      |
| WG262537ICV     | ICV  | 04/21/09 17:39 | MS090326-1 | .05 |        | .04907 | mg/L  | 98.1 | 90      | 110    |     |       |      |
| WG262537ICB     | ICB  | 04/21/09 17:44 |            |     |        | U      | mg/L  |      | -0.0003 | 0.0003 |     |       |      |
| WG262158PBS     | PBS  | 04/21/09 18:03 |            |     |        | U      | mg/Kg |      | -0.15   | 0.15   |     |       |      |
| L75214-01MS     | MS   | 04/21/09 18:31 | MS090311-4 | 625 | 3000   | 3210   | mg/Kg | 33.6 | 75      | 125    |     |       | M3   |
| L75214-01MSD    | MSD  | 04/21/09 18:45 | MS090311-4 | 625 | 3000   | 3187.5 | mg/Kg | 30   | 75      | 125    | 0.7 | 20    | M3   |



**Golder Associates, Inc.**

ACZ Project ID: **L75211**

| ACZ ID    | WORKNUM  | PARAMETER             | METHOD       | QUAL | DESCRIPTION   |
|-----------|----------|-----------------------|--------------|------|---|
| L75211-01 | WG262537 | Uranium, total (3050) | M6020 ICP-MS | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |

**Golder Associates, Inc.**

Project ID: 07380026.0002  
Sample ID: BARBARA J3-1A  
Locator:

ACZ Sample ID: **L75211-01**  
Date Sampled: 04/02/09 12:45  
Date Received: 04/09/09  
Sample Matrix: Soil

Gross Alpha &amp; Beta (3050)

Prep Method:

M9310

| Parameter   | Measure Date   | Prep Date | Result | Error(+/-) | LLD | Units | XQ | Analyst |
|-------------|----------------|-----------|--------|------------|-----|-------|----|---------|
| Gross Alpha | 04/24/09 13:05 |           | 1400   | 39         | 2.2 | pCi/g | *  | bjl     |
| Gross Beta  | 04/24/09 13:05 |           | 1700   | 27         | 4.5 | pCi/g | *  | bjl     |

Radium 226 (3050)

Prep Method:

M903.1

| Parameter         | Measure Date   | Prep Date | Result | Error(+/-) | LLD  | Units | XQ | Analyst |
|-------------------|----------------|-----------|--------|------------|------|-------|----|---------|
| Radium 226 (3050) | 04/22/09 16:52 |           | 580    | 4          | 0.38 | pCi/g | *  | mwm     |

## Report Header Explanations

|            |  |
|------------|--|
| Batch      | A distinct set of samples analyzed at a specific time  |
| Error(+/-) | Calculated sample specific uncertainty   |
| Found      | Value of the QC Type of interest   |
| Limit      | Upper limit for RPD, in %.   |
| LCL        | Lower Control Limit, in % (except for LCSS, mg/Kg)   |
| LLD        | Calculated sample specific Lower Limit of Detection  |
| PCN/SCN    | A number assigned to reagents/standards to trace to the manufacturer's certificate of analysis |
| PQL        | Practical Quantitation Limit   |
| QC         | True Value of the Control Sample or the amount added to the Spike                              |
| Rec        | Amount of the true value or spike added recovered, in % (except for LCSS, mg/Kg)               |
| RER        | Relative Error Ratio, calculation used for Dup. QC taking into account the error factor.       |
| UCL        | Upper Control Limit, in % (except for LCSS, mg/Kg)   |
| Sample     | Value of the Sample of interest  |

## QC Sample Types

|      |                                   |        |                                     |
|------|-----------------------------------|--------|-------------------------------------|
| DUP  | Sample Duplicate                  | MS/MSD | Matrix Spike/Matrix Spike Duplicate |
| LCSS | Laboratory Control Sample - Soil  | PBS    | Prep Blank - Soil                   |
| LCSW | Laboratory Control Sample - Water | PBW    | Prep Blank - Water                  |

## QC Sample Type Explanations

|                 |  |
|-----------------|--|
| Blanks          | Verifies that there is no or minimal contamination in the prep method procedure. |
| Control Samples | Verifies the accuracy of the method, including the prep procedure.               |
| Duplicates      | Verifies the precision of the instrument and/or method.                          |
| Matrix Spikes   | Determines sample matrix interferences, if any.                                  |

## ACZ Qualifiers (Qual)

|   |  |
|---|--|
| H | Analysis exceeded method hold time.  |
| R | Poor spike recovery accepted because the other spike in the set fell within the given limits.                |
| T | High Replicate Error Ratio (RER) accepted because sample concentrations are less than 10x the MDL.           |
| U | No nuclides detected above the Lower Limit of Detection (LLD)  |
| V | High blank data accepted because sample concentration is 10 times higher than blank concentration            |
| X | QC is out of control. See Case Narrative.  |
| Z | Poor spike recovery is accepted because sample concentration is four times greater than spike concentration. |

## Method Prefix Reference

|     |   |
|-----|---|
| M   | EPA methodology, including those under SDWA, CWA, and RCRA                        |
| SM  | Standard Methods for the Examination of Water and Wastewater, 19th edition, 1995. |
| D   | ASTM  |
| RP  | DOE   |
| ESM | DOE/ESM   |

## Comments

- (1) Solid matrices are reported on a dry weight basis.
- (2) Preparation method: "Method" indicates preparation defined in analytical method.
- (3) QC results calculated from raw data. Results may vary slightly if the rounded values are used in the calculations.

For a complete list of ACZ's Extended Qualifiers, please click:

<http://www.acz.com/public/extquallist.pdf>



**Golder Associates, Inc.**

ACZ Project ID: **L75211**

Project ID: 07380026.0002

**Alpha** M9310 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN    | QC     | Sample | Error | LLD | Found | Error | LLD  | Rec   | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|------------|--------|--------|-------|-----|-------|-------|------|-------|-------|-------|---------|-------|------|
| <b>WG262764</b> |         |          |            |        |        |       |     |       |       |      |       |       |       |         |       |      |
| WG262565PBS     | PBS     | 04/24/09 |            |        |        |       |     | .39   | 0.29  | 0.27 |       |       | 0.54  |         |       |      |
| WG262565LCSS    | LCSS    | 04/24/09 | RC081215-1 | 32.42  |        |       |     | 28    | 2.8   | 0.54 | 86.4  | 52    | 129   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/24/09 |            |        | 1400   | 39    | 2.2 | 1200  | 37    | 2.3  |       |       |       | 3.72    | 2     | RN   |
| L75211-01DUP    | DUP-RPD | 04/24/09 |            |        | 1400   | 39    | 2.2 | 1200  | 37    | 2.3  |       |       |       | 15.4    | 20    | RN   |
| L75212-02MS     | MS      | 04/24/09 | RC081215-1 | 101.32 | 470    | 23    | 2.2 | 430   | 24    | 2.6  | -39.5 | 52    | 129   |         |       | M3   |

**Beta** M9310 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN  | QC     | Sample | Error | LLD | Found | Error | LLD  | Rec  | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|----------|--------|--------|-------|-----|-------|-------|------|------|-------|-------|---------|-------|------|
| <b>WG262764</b> |         |          |          |        |        |       |     |       |       |      |      |       |       |         |       |      |
| WG262565PBS     | PBS     | 04/24/09 |          |        |        |       |     | 1.2   | 0.6   | 0.77 |      |       | 1.54  |         |       |      |
| WG262565LCSS    | LCSS    | 04/24/09 | PCN30789 | 40     |        |       |     | 39    | 2.6   | 1.6  | 97.5 | 65    | 104   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/24/09 |          |        | 1700   | 27    | 4.5 | 1300  | 23    | 4.4  |      |       |       | 11.28   | 2     | RC   |
| L75214-01MS     | MS      | 04/24/09 | PCN30789 | 111.11 | 2300   | 31    | 4.5 | 2600  | 33    | 4.5  | 270  | 65    | 104   |         |       | M3   |

**Radium 226 (3050)** M903.1 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN    | QC    | Sample | Error | LLD  | Found | Error | LLD  | Rec   | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|------------|-------|--------|-------|------|-------|-------|------|-------|-------|-------|---------|-------|------|
| <b>WG262679</b> |         |          |            |       |        |       |      |       |       |      |       |       |       |         |       |      |
| WG262382PBS     | PBS     | 04/22/09 |            |       |        |       |      | -.01  | 0.19  | 0.48 |       |       | 0.96  |         |       |      |
| WG262382LCSS    | LCSS    | 04/22/09 | RC090209-1 | 47.83 |        |       |      | 53    | 1.5   | 0.6  | 110.8 | 44    | 128   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/22/09 |            |       | 580    | 4     | 0.38 | 670   | 4.5   | 0.41 |       |       |       | 14.95   | 2     | RN   |
| L75211-01DUP    | DUP-RPD | 04/22/09 |            |       | 580    | 4     | 0.38 | 670   | 4.5   | 0.41 |       |       |       | 14.4    | 20    | RN   |
| L75214-01MS     | MS      | 04/22/09 | RC090209-1 | 47.83 | 980    | 5.9   | 0.48 | 1300  | 8.2   | 0.73 | 669   | 44    | 128   |         |       | M3   |

**Golder Associates, Inc.**

ACZ Project ID: **L75211**

| ACZ ID    | WORKNUM  | PARAMETER         | METHOD | QUAL | DESCRIPTION   |
|-----------|----------|-------------------|--------|------|---|
| L75211-01 | WG262764 | Gross Alpha       | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|           |          |                   | M9310  | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |
|           |          | Gross Beta        | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|           |          |                   | M9310  | RC   | For a solid matrix, the matrix duplicate precision assessment (RPD or RER) exceeded the control limit, which is attributable to the non-homogeneity of the sample.                                    |
|           | WG262679 | Radium 226 (3050) | M903.1 | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|           |          |                   | M903.1 | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |

**Golder Associates, Inc.**

ACZ Project ID: **L75211**

**Metals Analysis**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                       |              |
|-----------------------|--------------|
| Thorium, total (3050) | M6020 ICP-MS |
| Uranium, total (3050) | M6020 ICP-MS |

**Radiochemistry**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                   |        |
|-------------------|--------|
| Radium 226 (3050) | M903.1 |
|-------------------|--------|

**Soil Analysis**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                 |                         |
|-----------------|-------------------------|
| Solids, Percent | CLPSOW390, PART F, D-98 |
|-----------------|-------------------------|



**Golder Associates, Inc.**  
 07380026.0002

ACZ Project ID: L75211  
 Date Received: 4/9/2009  
 Received By:  
 Date Printed: 4/9/2009

**Receipt Verification**

|  | YES | NO | NA |
|--|-----|----|----|
| 1) Does this project require special handling procedures such as CLP protocol? |     |    | X  |
| 2) Are the custody seals on the cooler intact?                                 |     |    | X  |
| 3) Are the custody seals on the sample containers intact?                      |     |    | X  |
| 4) Is there a Chain of Custody or other directive shipping papers present?     | X   |    |    |
| 5) Is the Chain of Custody complete?   | X   |    |    |
| 6) Is the Chain of Custody in agreement with the samples received?             | X   |    |    |
| 7) Is there enough sample for all requested analyses?                          | X   |    |    |
| 8) Are all samples within holding times for requested analyses?                | X   |    |    |
| 9) Were all sample containers received intact?                                 | X   |    |    |
| 10) Are the temperature blanks present?  |     |    | X  |
| 11) Is the trip blank for Cyanide present?                                     |     |    | X  |
| 12) Is the trip blank for VOA present?   |     |    | X  |
| 13) Are samples requiring no headspace, headspace free?                        |     |    | X  |
| 14) Do the samples that require a Foreign Soils Permit have one?               |     |    | X  |

**Exceptions: If you answered no to any of the above questions, please describe**

N/A

**Contact (For any discrepancies, the client must be contacted)**

N/A

**Shipping Containers**

| Cooler Id | Temp (°C) | Rad (μR/hr) |
|-----------|-----------|-------------|
| NA8194    | 14.8      | 170         |
|           |           |             |
|           |           |             |
|           |           |             |

Client must contact ACZ Project Manager if analysis should not proceed for samples received outside of thermal preservation acceptance criteria.

**Notes**

**Golder Associates, Inc.**  
 07380026.0002

ACZ Project ID: L75211  
 Date Received: 4/9/2009  
 Received By:

**Sample Container Preservation**

| SAMPLE    | CLIENT ID     | R < 2 | G < 2 | BK < 2 | Y < 2 | YG < 2 | B < 2 | O < 2 | T > 12 | N/A | RAD | ID                       |
|-----------|---------------|-------|-------|--------|-------|--------|-------|-------|--------|-----|-----|--------------------------|
| L75211-01 | BARBARA J3-1A |       |       |        |       |        |       |       |        | X   |     | <input type="checkbox"/> |

**Sample Container Preservation Legend**

| Abbreviation | Description            | Container Type | Preservative/Limits |
|--------------|------------------------|----------------|---------------------|
| R            | Raw/Nitric             | RED            | pH must be < 2      |
| B            | Filtered/Sulfuric      | BLUE           | pH must be < 2      |
| BK           | Filtered/Nitric        | BLACK          | pH must be < 2      |
| G            | Filtered/Nitric        | GREEN          | pH must be < 2      |
| O            | Raw/Sulfuric           | ORANGE         | pH must be < 2      |
| P            | Raw/NaOH               | PURPLE         | pH must be > 12 *   |
| T            | Raw/NaOH Zinc Acetate  | TAN            | pH must be > 12     |
| Y            | Raw/Sulfuric           | YELLOW         | pH must be < 2      |
| YG           | Raw/Sulfuric           | YELLOW GLASS   | pH must be < 2      |
| N/A          | No preservative needed | Not applicable |                     |
| RAD          | Gamma/Beta dose rate   | Not applicable | must be < 250 µR/hr |

\* pH check performed by analyst prior to sample preparation

Sample IDs Reviewed By: \_\_\_\_\_

Page 13 of 13



April 28, 2009

## Report to:

Bob Newcomer  
Golder Associates, Inc.  
5200 Pasadena, N.E. Suite C  
Albuquerque, NM 87113

## Bill to:

Toni Sanchez  
Golder Associates, Inc.  
5200 Pasadena NE Suite C  
Albuquerque, NM 87113

cc: Fiona Jordan

Project ID: 07380026.0002

ACZ Project ID: L75212

Bob Newcomer:

Enclosed are the analytical results for sample(s) submitted to ACZ Laboratories, Inc. (ACZ) on April 09, 2009. This project has been assigned to ACZ's project number, L75212. Please reference this number in all future inquiries.


All analyses were performed according to ACZ's Quality Assurance Plan, version 12.0. The enclosed results relate only to the samples received under L75212. Each section of this report has been reviewed and approved by the appropriate Laboratory Supervisor, or a qualified substitute.

Except as noted, the test results for the methods and parameters listed on ACZ's current NELAC certificate letter (#ACZ) meet all requirements of NELAC.

This report shall be used or copied only in its entirety. ACZ is not responsible for the consequences arising from the use of a partial report.

All samples and sub-samples associated with this project will be disposed of after May 28, 2009. If the samples are determined to be hazardous, additional charges apply for disposal (typically less than \$10/sample). If you would like the samples to be held longer than ACZ's stated policy or to be returned, please contact your Project Manager or Customer Service Representative for further details and associated costs. ACZ retains analytical reports for five years.

If you have any questions or other needs, please contact your Project Manager.



Scott Habermehl has reviewed  
and approved this report.



**Golder Associates, Inc.**

Project ID: 07380026.0002

Sample ID: BARBARA J3-3A

ACZ Sample ID: **L75212-01**

Date Sampled: 04/02/09 00:00

Date Received: 04/09/09

Sample Matrix: Soil

## Metals Analysis

| Parameter             | EPA Method   | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------------|--------------|--------|------|----|-------|-----|-----|----------------|---------|
| Thorium, total (3050) | M6020 ICP-MS | 1.6    | B    | *  | mg/Kg | 0.5 | 3   | 04/21/09 3:15  | erf     |
| Uranium, total (3050) | M6020 ICP-MS | 880    |      | *  | mg/Kg | 1   | 5   | 04/21/09 18:12 | erf     |

## Soil Analysis

| Parameter       | EPA Method              | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------|-------------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Solids, Percent | CLPSOW390, PART F, D-98 | 94.4   |      | *  | %     | 0.1 | 0.5 | 04/10/09 13:00 | lwt     |

## Soil Preparation

| Parameter               | EPA Method       | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-------------------------|------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Air Dry at 34 Degrees C | USDA No. 1, 1972 |        |      |    |       |     |     | 04/10/09 12:40 | lwt     |
| Crush and Pulverize     | USDA No. 1, 1972 |        |      |    |       |     |     | 04/13/09 10:10 | lwt     |
| Digestion - Hot Plate   | M3050B ICP-MS    |        |      |    |       |     |     | 04/14/09 10:40 | lwt     |

**Golder Associates, Inc.**

Project ID: 07380026.0002

Sample ID: BARBARA J2-1A

ACZ Sample ID: **L75212-02**

Date Sampled: 04/02/09 00:00

Date Received: 04/09/09

Sample Matrix: Soil

## Metals Analysis

| Parameter             | EPA Method   | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------------|--------------|--------|------|----|-------|-----|-----|----------------|---------|
| Thorium, total (3050) | M6020 ICP-MS | 1.4    | B    | *  | mg/Kg | 0.5 | 3   | 04/21/09 3:25  | erf     |
| Uranium, total (3050) | M6020 ICP-MS | 775    |      | *  | mg/Kg | 0.5 | 3   | 04/21/09 18:21 | erf     |

## Soil Analysis

| Parameter       | EPA Method              | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------|-------------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Solids, Percent | CLPSOW390, PART F, D-98 | 95.6   |      | *  | %     | 0.1 | 0.5 | 04/10/09 13:00 | lwt     |

## Soil Preparation

| Parameter               | EPA Method       | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-------------------------|------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Air Dry at 34 Degrees C | USDA No. 1, 1972 |        |      |    |       |     |     | 04/10/09 12:50 | lwt     |
| Crush and Pulverize     | USDA No. 1, 1972 |        |      |    |       |     |     | 04/13/09 10:20 | lwt     |
| Digestion - Hot Plate   | M3050B ICP-MS    |        |      |    |       |     |     | 04/14/09 11:45 | lwt     |



## Report Header Explanations

|         |   |
|---------|---|
| Batch   | A distinct set of samples analyzed at a specific time   |
| Found   | Value of the QC Type of interest  |
| Limit   | Upper limit for RPD, in %.  |
| Lower   | Lower Recovery Limit, in % (except for LCSS, mg/Kg)   |
| MDL     | Method Detection Limit. Same as Minimum Reporting Limit. Allows for instrument and annual fluctuations. |
| PCN/SCN | A number assigned to reagents/standards to trace to the manufacturer's certificate of analysis          |
| PQL     | Practical Quantitation Limit, typically 5 times the MDL.  |
| QC      | True Value of the Control Sample or the amount added to the Spike                                       |
| Rec     | Amount of the true value or spike added recovered, in % (except for LCSS, mg/Kg)                        |
| RPD     | Relative Percent Difference, calculation used for Duplicate QC Types                                    |
| Upper   | Upper Recovery Limit, in % (except for LCSS, mg/Kg)   |
| Sample  | Value of the Sample of interest   |

## QC Sample Types

|       |  |       |  |
|-------|--|-------|--|
| AS    | Analytical Spike (Post Digestion)                      | LCSWD | Laboratory Control Sample - Water Duplicate  |
| ASD   | Analytical Spike (Post Digestion) Duplicate            | LFB   | Laboratory Fortified Blank                   |
| CCB   | Continuing Calibration Blank                           | LFM   | Laboratory Fortified Matrix                  |
| CCV   | Continuing Calibration Verification standard           | LFMD  | Laboratory Fortified Matrix Duplicate        |
| DUP   | Sample Duplicate                                       | LRB   | Laboratory Reagent Blank                     |
| ICB   | Initial Calibration Blank                              | MS    | Matrix Spike                                 |
| ICV   | Initial Calibration Verification standard              | MSD   | Matrix Spike Duplicate                       |
| ICSAB | Inter-element Correction Standard - A plus B solutions | PBS   | Prep Blank - Soil                            |
| LCSS  | Laboratory Control Sample - Soil                       | PBW   | Prep Blank - Water                           |
| LCSSD | Laboratory Control Sample - Soil Duplicate             | PQV   | Practical Quantitation Verification standard |
| LCSW  | Laboratory Control Sample - Water                      | SDL   | Serial Dilution                              |

## QC Sample Type Explanations

|                         |   |
|-------------------------|---|
| Blanks                  | Verifies that there is no or minimal contamination in the prep method or calibration procedure. |
| Control Samples         | Verifies the accuracy of the method, including the prep procedure.                              |
| Duplicates              | Verifies the precision of the instrument and/or method.   |
| Spikes/Fortified Matrix | Determines sample matrix interferences, if any.   |
| Standard                | Verifies the validity of the calibration.   |

## ACZ Qualifiers (Qual)

|   |   |
|---|---|
| B | Analyte concentration detected at a value between MDL and PQL. The associated value is an estimated quantity.   |
| H | Analysis exceeded method hold time. pH is a field test with an immediate hold time.   |
| U | The material was analyzed for, but was not detected above the level of the associated value.<br>The associated value is either the sample quantitation limit or the sample detection limit. |

## Method References

- (1) EPA 600/4-83-020. Methods for Chemical Analysis of Water and Wastes, March 1983.
- (2) EPA 600/R-93-100. Methods for the Determination of Inorganic Substances in Environmental Samples, August 1993.
- (3) EPA 600/R-94-111. Methods for the Determination of Metals in Environmental Samples - Supplement I, May 1994.
- (5) EPA SW-846. Test Methods for Evaluating Solid Waste, Third Edition with Update III, December 1996.
- (6) Standard Methods for the Examination of Water and Wastewater, 19th edition, 1995.

## Comments

- (1) QC results calculated from raw data. Results may vary slightly if the rounded values are used in the calculations.
- (2) Soil, Sludge, and Plant matrices for Inorganic analyses are reported on a dry weight basis.
- (3) Animal matrices for Inorganic analyses are reported on an "as received" basis.

For a complete list of ACZ's Extended Qualifiers, please click:

<http://www.acz.com/public/extquallist.pdf>

**Golder Associates, Inc.**

ACZ Project ID: **L75212**

Project ID: 07380026.0002

**Solids, Percent**

CLPSOW390, PART F, D-98

| ACZ ID          | Type | Analyzed       | PCN/SCN | QC | Sample | Found | Units | Rec | Lower | Upper | RPD | Limit | Qual |
|-----------------|------|----------------|---------|----|--------|-------|-------|-----|-------|-------|-----|-------|------|
| <b>WG262077</b> |      |                |         |    |        |       |       |     |       |       |     |       |      |
| WG262077PBS     | PBS  | 04/10/09 13:00 |         |    |        | U     | %     |     | 99.9  | 100.1 |     |       |      |
| L75214-01DUP    | DUP  | 04/10/09 13:00 |         |    | 95.1   | 93.96 | %     |     |       |       | 1.2 | 20    |      |

**Thorium, total (3050)**

M6020 ICP-MS

| ACZ ID          | Type | Analyzed      | PCN/SCN    | QC   | Sample | Found | Units | Rec  | Lower  | Upper | RPD  | Limit | Qual |
|-----------------|------|---------------|------------|------|--------|-------|-------|------|--------|-------|------|-------|------|
| <b>WG262507</b> |      |               |            |      |        |       |       |      |        |       |      |       |      |
| WG262507ICV     | ICV  | 04/21/09 2:42 | MS090326-1 | .05  |        | .0477 | mg/L  | 95.4 | 90     | 110   |      |       |      |
| WG262507ICB     | ICB  | 04/21/09 2:47 |            |      |        | U     | mg/L  |      | -0.003 | 0.003 |      |       |      |
| WG262158PBS     | PBS  | 04/21/09 3:06 |            |      |        | U     | mg/Kg |      | -1.5   | 1.5   |      |       |      |
| L75214-01MS     | MS   | 04/21/09 3:34 | MS090311-4 | 12.5 | 1.4    | 13.5  | mg/Kg | 96.8 | 75     | 125   |      |       |      |
| L75214-01MSD    | MSD  | 04/21/09 3:48 | MS090311-4 | 12.5 | 1.4    | 13.16 | mg/Kg | 94.1 | 75     | 125   | 2.55 | 20    |      |

**Uranium, total (3050)**

M6020 ICP-MS

| ACZ ID          | Type | Analyzed       | PCN/SCN    | QC  | Sample | Found  | Units | Rec  | Lower   | Upper  | RPD | Limit | Qual |
|-----------------|------|----------------|------------|-----|--------|--------|-------|------|---------|--------|-----|-------|------|
| <b>WG262537</b> |      |                |            |     |        |        |       |      |         |        |     |       |      |
| WG262537ICV     | ICV  | 04/21/09 17:39 | MS090326-1 | .05 |        | .04907 | mg/L  | 98.1 | 90      | 110    |     |       |      |
| WG262537ICB     | ICB  | 04/21/09 17:44 |            |     |        | U      | mg/L  |      | -0.0003 | 0.0003 |     |       |      |
| WG262158PBS     | PBS  | 04/21/09 18:03 |            |     |        | U      | mg/Kg |      | -0.15   | 0.15   |     |       |      |
| L75214-01MS     | MS   | 04/21/09 18:31 | MS090311-4 | 625 | 3000   | 3210   | mg/Kg | 33.6 | 75      | 125    |     |       | M3   |
| L75214-01MSD    | MSD  | 04/21/09 18:45 | MS090311-4 | 625 | 3000   | 3187.5 | mg/Kg | 30   | 75      | 125    | 0.7 | 20    | M3   |

**Golder Associates, Inc.**

ACZ Project ID: **L75212**

| ACZ ID    | WORKNUM  | PARAMETER             | METHOD       | QUAL | DESCRIPTION   |
|-----------|----------|-----------------------|--------------|------|---|
| L75212-01 | WG262537 | Uranium, total (3050) | M6020 ICP-MS | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
| L75212-02 | WG262537 | Uranium, total (3050) | M6020 ICP-MS | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |

**Golder Associates, Inc.**

Project ID: 07380026.0002  
Sample ID: BARBARA J3-3A  
Locator:

ACZ Sample ID: **L75212-01**  
Date Sampled: 04/02/09 0:00  
Date Received: 04/09/09  
Sample Matrix: Soil

Gross Alpha &amp; Beta (3050)

Prep Method:

M9310

| Parameter   | Measure Date   | Prep Date | Result | Error(+/-) | LLD | Units | XQ | Analyst |
|-------------|----------------|-----------|--------|------------|-----|-------|----|---------|
| Gross Alpha | 04/24/09 13:06 |           | 470    | 23         | 2.2 | pCi/g | *  | bjl     |
| Gross Beta  | 04/24/09 13:06 |           | 640    | 17         | 4.5 | pCi/g | *  | bjl     |

Radium 226 (3050)

Prep Method:

M903.1

| Parameter         | Measure Date   | Prep Date | Result | Error(+/-) | LLD  | Units | XQ | Analyst |
|-------------------|----------------|-----------|--------|------------|------|-------|----|---------|
| Radium 226 (3050) | 04/22/09 16:54 |           | 230    | 2.8        | 0.45 | pCi/g | *  | mwm     |



**Golder Associates, Inc.**

Project ID: 07380026.0002  
Sample ID: BARBARA J2-1A  
Locator:

ACZ Sample ID: **L75212-02**  
Date Sampled: 04/02/09 0:00  
Date Received: 04/09/09  
Sample Matrix: Soil

Gross Alpha &amp; Beta (3050)

Prep Method:

M9310

| Parameter   | Measure Date   | Prep Date | Result | Error(+/-) | LLD | Units | XQ | Analyst |
|-------------|----------------|-----------|--------|------------|-----|-------|----|---------|
| Gross Alpha | 04/24/09 13:08 |           | 470    | 23         | 2.2 | pCi/g | *  | bjl     |
| Gross Beta  | 04/24/09 13:08 |           | 610    | 16         | 4.5 | pCi/g | *  | bjl     |

Radium 226 (3050)

Prep Method:

M903.1

| Parameter         | Measure Date   | Prep Date | Result | Error(+/-) | LLD  | Units | XQ | Analyst |
|-------------------|----------------|-----------|--------|------------|------|-------|----|---------|
| Radium 226 (3050) | 04/22/09 16:55 |           | 220    | 3.2        | 0.65 | pCi/g | *  | mwm     |

## Report Header Explanations

|            |  |
|------------|--|
| Batch      | A distinct set of samples analyzed at a specific time  |
| Error(+/-) | Calculated sample specific uncertainty   |
| Found      | Value of the QC Type of interest   |
| Limit      | Upper limit for RPD, in %.   |
| LCL        | Lower Control Limit, in % (except for LCSS, mg/Kg)   |
| LLD        | Calculated sample specific Lower Limit of Detection  |
| PCN/SCN    | A number assigned to reagents/standards to trace to the manufacturer's certificate of analysis |
| PQL        | Practical Quantitation Limit   |
| QC         | True Value of the Control Sample or the amount added to the Spike                              |
| Rec        | Amount of the true value or spike added recovered, in % (except for LCSS, mg/Kg)               |
| RER        | Relative Error Ratio, calculation used for Dup. QC taking into account the error factor.       |
| UCL        | Upper Control Limit, in % (except for LCSS, mg/Kg)   |
| Sample     | Value of the Sample of interest  |

## QC Sample Types

|      |                                   |        |                                     |
|------|-----------------------------------|--------|-------------------------------------|
| DUP  | Sample Duplicate                  | MS/MSD | Matrix Spike/Matrix Spike Duplicate |
| LCSS | Laboratory Control Sample - Soil  | PBS    | Prep Blank - Soil                   |
| LCSW | Laboratory Control Sample - Water | PBW    | Prep Blank - Water                  |

## QC Sample Type Explanations

|                 |  |
|-----------------|--|
| Blanks          | Verifies that there is no or minimal contamination in the prep method procedure. |
| Control Samples | Verifies the accuracy of the method, including the prep procedure.               |
| Duplicates      | Verifies the precision of the instrument and/or method.                          |
| Matrix Spikes   | Determines sample matrix interferences, if any.                                  |

## ACZ Qualifiers (Qual)

|   |  |
|---|--|
| H | Analysis exceeded method hold time.  |
| R | Poor spike recovery accepted because the other spike in the set fell within the given limits.                |
| T | High Replicate Error Ratio (RER) accepted because sample concentrations are less than 10x the MDL.           |
| U | No nuclides detected above the Lower Limit of Detection (LLD)  |
| V | High blank data accepted because sample concentration is 10 times higher than blank concentration            |
| X | QC is out of control. See Case Narrative.  |
| Z | Poor spike recovery is accepted because sample concentration is four times greater than spike concentration. |

## Method Prefix Reference

|     |   |
|-----|---|
| M   | EPA methodology, including those under SDWA, CWA, and RCRA                        |
| SM  | Standard Methods for the Examination of Water and Wastewater, 19th edition, 1995. |
| D   | ASTM  |
| RP  | DOE   |
| ESM | DOE/ESM   |

## Comments

- (1) Solid matrices are reported on a dry weight basis.
- (2) Preparation method: "Method" indicates preparation defined in analytical method.
- (3) QC results calculated from raw data. Results may vary slightly if the rounded values are used in the calculations.

For a complete list of ACZ's Extended Qualifiers, please click:

<http://www.acz.com/public/extquallist.pdf>

**Golder Associates, Inc.**

ACZ Project ID: **L75212**

Project ID: 07380026.0002

**Alpha** M9310 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN    | QC     | Sample | Error | LLD | Found | Error | LLD  | Rec   | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|------------|--------|--------|-------|-----|-------|-------|------|-------|-------|-------|---------|-------|------|
| <b>WG262764</b> |         |          |            |        |        |       |     |       |       |      |       |       |       |         |       |      |
| WG262565PBS     | PBS     | 04/24/09 |            |        |        |       |     | .39   | 0.29  | 0.27 |       |       | 0.54  |         |       |      |
| WG262565LCSS    | LCSS    | 04/24/09 | RC081215-1 | 32.42  |        |       |     | 28    | 2.8   | 0.54 | 86.4  | 52    | 129   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/24/09 |            |        | 1400   | 39    | 2.2 | 1200  | 37    | 2.3  |       |       |       | 3.72    | 2     | RN   |
| L75211-01DUP    | DUP-RPD | 04/24/09 |            |        | 1400   | 39    | 2.2 | 1200  | 37    | 2.3  |       |       |       | 15.4    | 20    | RN   |
| L75212-02MS     | MS      | 04/24/09 | RC081215-1 | 101.32 | 470    | 23    | 2.2 | 430   | 24    | 2.6  | -39.5 | 52    | 129   |         |       | M3   |

**Beta** M9310 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN  | QC     | Sample | Error | LLD | Found | Error | LLD  | Rec  | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|----------|--------|--------|-------|-----|-------|-------|------|------|-------|-------|---------|-------|------|
| <b>WG262764</b> |         |          |          |        |        |       |     |       |       |      |      |       |       |         |       |      |
| WG262565PBS     | PBS     | 04/24/09 |          |        |        |       |     | 1.2   | 0.6   | 0.77 |      |       | 1.54  |         |       |      |
| WG262565LCSS    | LCSS    | 04/24/09 | PCN30789 | 40     |        |       |     | 39    | 2.6   | 1.6  | 97.5 | 65    | 104   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/24/09 |          |        | 1700   | 27    | 4.5 | 1300  | 23    | 4.4  |      |       |       | 11.28   | 2     | RC   |
| L75214-01MS     | MS      | 04/24/09 | PCN30789 | 111.11 | 2300   | 31    | 4.5 | 2600  | 33    | 4.5  | 270  | 65    | 104   |         |       | M3   |

**Radium 226 (3050)** M903.1 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN    | QC    | Sample | Error | LLD  | Found | Error | LLD  | Rec   | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|------------|-------|--------|-------|------|-------|-------|------|-------|-------|-------|---------|-------|------|
| <b>WG262679</b> |         |          |            |       |        |       |      |       |       |      |       |       |       |         |       |      |
| WG262382PBS     | PBS     | 04/22/09 |            |       |        |       |      | -.01  | 0.19  | 0.48 |       |       | 0.96  |         |       |      |
| WG262382LCSS    | LCSS    | 04/22/09 | RC090209-1 | 47.83 |        |       |      | 53    | 1.5   | 0.6  | 110.8 | 44    | 128   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/22/09 |            |       | 580    | 4     | 0.38 | 670   | 4.5   | 0.41 |       |       |       | 14.95   | 2     | RN   |
| L75211-01DUP    | DUP-RPD | 04/22/09 |            |       | 580    | 4     | 0.38 | 670   | 4.5   | 0.41 |       |       |       | 14.4    | 20    | RN   |
| L75214-01MS     | MS      | 04/22/09 | RC090209-1 | 47.83 | 980    | 5.9   | 0.48 | 1300  | 8.2   | 0.73 | 669   | 44    | 128   |         |       | M3   |

**Golder Associates, Inc.**

ACZ Project ID: **L75212**

| ACZ ID           | WORKNUM  | PARAMETER         | METHOD | QUAL | DESCRIPTION   |
|------------------|----------|-------------------|--------|------|---|
| <b>L75212-01</b> | WG262764 | Gross Alpha       | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|                  |          |                   | M9310  | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |
|                  |          | Gross Beta        | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|                  |          |                   | M9310  | RC   | For a solid matrix, the matrix duplicate precision assessment (RPD or RER) exceeded the control limit, which is attributable to the non-homogeneity of the sample.                                    |
|                  | WG262679 | Radium 226 (3050) | M903.1 | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|                  |          |                   | M903.1 | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |
|                  |          |                   |        |      |   |
|                  |          |                   |        |      |   |
| <b>L75212-02</b> | WG262764 | Gross Alpha       | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|                  |          |                   | M9310  | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |
|                  |          | Gross Beta        | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|                  |          |                   | M9310  | RC   | For a solid matrix, the matrix duplicate precision assessment (RPD or RER) exceeded the control limit, which is attributable to the non-homogeneity of the sample.                                    |
|                  | WG262679 | Radium 226 (3050) | M903.1 | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|                  |          |                   | M903.1 | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |
|                  |          |                   |        |      |   |
|                  |          |                   |        |      |   |



**Golder Associates, Inc.**

ACZ Project ID: **L75212**

**Metals Analysis**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                       |              |
|-----------------------|--------------|
| Thorium, total (3050) | M6020 ICP-MS |
| Uranium, total (3050) | M6020 ICP-MS |

**Radiochemistry**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                   |        |
|-------------------|--------|
| Radium 226 (3050) | M903.1 |
|-------------------|--------|

**Soil Analysis**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                 |                         |
|-----------------|-------------------------|
| Solids, Percent | CLPSOW390, PART F, D-98 |
|-----------------|-------------------------|

**Golder Associates, Inc.**  
07380026.0002

ACZ Project ID: L75212  
Date Received: 4/9/2009  
Received By:  
Date Printed: 4/9/2009

**Receipt Verification**

|  | YES | NO | NA |
|--|-----|----|----|
| 1) Does this project require special handling procedures such as CLP protocol? |     |    | X  |
| 2) Are the custody seals on the cooler intact?                                 |     |    | X  |
| 3) Are the custody seals on the sample containers intact?                      |     |    | X  |
| 4) Is there a Chain of Custody or other directive shipping papers present?     | X   |    |    |
| 5) Is the Chain of Custody complete?   | X   |    |    |
| 6) Is the Chain of Custody in agreement with the samples received?             | X   |    |    |
| 7) Is there enough sample for all requested analyses?                          | X   |    |    |
| 8) Are all samples within holding times for requested analyses?                | X   |    |    |
| 9) Were all sample containers received intact?                                 | X   |    |    |
| 10) Are the temperature blanks present?  |     |    | X  |
| 11) Is the trip blank for Cyanide present?                                     |     |    | X  |
| 12) Is the trip blank for VOA present?   |     |    | X  |
| 13) Are samples requiring no headspace, headspace free?                        |     |    | X  |
| 14) Do the samples that require a Foreign Soils Permit have one?               |     |    | X  |

**Exceptions: If you answered no to any of the above questions, please describe**

N/A

**Contact (For any discrepancies, the client must be contacted)**

N/A

**Shipping Containers**

| Cooler Id | Temp (°C) | Rad (μR/hr) |
|-----------|-----------|-------------|
| NA8195    | 16.3      | 100         |
|           |           |             |
|           |           |             |
|           |           |             |

Client must contact ACZ Project Manager if analysis should not proceed for samples received outside of thermal preservation acceptance criteria.

**Notes**

**Golder Associates, Inc.**  
 07380026.0002

ACZ Project ID: L75212  
 Date Received: 4/9/2009  
 Received By:

**Sample Container Preservation**

| SAMPLE    | CLIENT ID     | R < 2 | G < 2 | BK < 2 | Y < 2 | YG < 2 | B < 2 | O < 2 | T > 12 | N/A | RAD | ID                       |
|-----------|---------------|-------|-------|--------|-------|--------|-------|-------|--------|-----|-----|--------------------------|
| L75212-01 | BARBARA J3-3A |       |       |        |       |        |       |       |        | X   |     | <input type="checkbox"/> |
| L75212-02 | BARBARA J2-1A |       |       |        |       |        |       |       |        | X   |     | <input type="checkbox"/> |

**Sample Container Preservation Legend**

| Abbreviation | Description            | Container Type | Preservative/Limits |
|--------------|------------------------|----------------|---------------------|
| R            | Raw/Nitric             | RED            | pH must be < 2      |
| B            | Filtered/Sulfuric      | BLUE           | pH must be < 2      |
| BK           | Filtered/Nitric        | BLACK          | pH must be < 2      |
| G            | Filtered/Nitric        | GREEN          | pH must be < 2      |
| O            | Raw/Sulfuric           | ORANGE         | pH must be < 2      |
| P            | Raw/NaOH               | PURPLE         | pH must be > 12 *   |
| T            | Raw/NaOH Zinc Acetate  | TAN            | pH must be > 12     |
| Y            | Raw/Sulfuric           | YELLOW         | pH must be < 2      |
| YG           | Raw/Sulfuric           | YELLOW GLASS   | pH must be < 2      |
| N/A          | No preservative needed | Not applicable |                     |
| RAD          | Gamma/Beta dose rate   | Not applicable | must be < 250 µR/hr |

\* pH check performed by analyst prior to sample preparation

Sample IDs Reviewed By: \_\_\_\_\_

**ACZ** Laboratories, Inc.

2773 Downhill Drive Steamboat Springs, CO 80487 (800) 334-5493

## CHAIN of CUSTODY

Report to:

Name: Bob Newcarver  
Company: Boulder Associates Inc  
E-mail: bob.newcarver@boulder.com

Address: 5200 Pasadena Blvd  
Albuquerque NM 87113  
Telephone: 505-821-3043

Copy of Report to:

Name: Fiona Jordan  
Company: Spider Associates

E-mail: jordan@golder.com  
Telephone: 505-821-3043

Invoice to:

Name: Toni Sanchez  
Company: Boulder Associates  
E-mail: toni\_sanchez@boulder.com

Address: 5200 Pasadena Ave. C  
Alhambra, NM 87113  
Telephone: 505-821-3043

If sample(s) received past holding time (HT), or if insufficient HT remains to complete analysis before expiration, shall ACZ proceed with requested short HT analyses?

|     |                          |
|-----|--------------------------|
| YES | <input type="checkbox"/> |
| NO  | <input type="checkbox"/> |

**If "NO" then ACZ will contact client for further instruction. If neither "YES" nor "NO"**

**As indicated, ACZ will proceed with the requested analyses, even if HT is expired, and data will be qualified.**

## PROJECT INFORMATION

## ANALYSES REQUESTED (attach list or use quote number)

|  |                 |
|--|-----------------|
| Quote #:                                 | AUML            |
| Project/PO #:                            | 07380026.0002   |
| Shipping Co.:                            | Fed Ex          |
| Tracking #:                              | 471158010000191 |
| Reporting state for compliance testing:  |                 |
| Are any samples NRC licensable material? |                 |

[illegible]

| SAMPLE IDENTIFICATION | DATE TIME | Matrix |
|-----------------------|-----------|--------|
|-----------------------|-----------|--------|

| SAMPLE IDENTIFICATION | DATE/TIME | Matrix |
|-----------------------|-----------|--------|
| Barbara J3-3A         | 4/2/09    | SD     |
| Barbara J2-1A         | 4/2/09    | SD     |

Matrix SW (Surface Water) · GW (Ground Water) · WW (Waste Water) · DW (Drinking Water) · SL (Sludge) · SO (Soil) · OL (Oil) · Other (Specify)

## REMARKS

please crush & pulverize entire sample

| RELINQUISHED BY:   | DATE/TIME    | RECEIVED BY:       | DATE/TIME    | Page |
|--------------------|--------------|--------------------|--------------|------|
| <i>[Signature]</i> | 4/16/09 11am | <i>[Signature]</i> | 4-9-09 14:00 | Of   |
|                    |              |                    |              |      |
|                    |              |                    |              |      |



April 28, 2009

## Report to:

Bob Newcomer  
Golder Associates, Inc.  
5200 Pasadena, N.E. Suite C  
Albuquerque, NM 87113

## Bill to:

Toni Sanchez  
Golder Associates, Inc.  
5200 Pasadena NE Suite C  
Albuquerque, NM 87113

cc: Fiona Jordan

Project ID: 07380026.0002

ACZ Project ID: L75214

Bob Newcomer:

Enclosed are the analytical results for sample(s) submitted to ACZ Laboratories, Inc. (ACZ) on April 09, 2009. This project has been assigned to ACZ's project number, L75214. Please reference this number in all future inquiries.


All analyses were performed according to ACZ's Quality Assurance Plan, version 12.0. The enclosed results relate only to the samples received under L75214. Each section of this report has been reviewed and approved by the appropriate Laboratory Supervisor, or a qualified substitute.

Except as noted, the test results for the methods and parameters listed on ACZ's current NELAC certificate letter (#ACZ) meet all requirements of NELAC.

This report shall be used or copied only in its entirety. ACZ is not responsible for the consequences arising from the use of a partial report.

All samples and sub-samples associated with this project will be disposed of after May 28, 2009. If the samples are determined to be hazardous, additional charges apply for disposal (typically less than \$10/sample). If you would like the samples to be held longer than ACZ's stated policy or to be returned, please contact your Project Manager or Customer Service Representative for further details and associated costs. ACZ retains analytical reports for five years.

If you have any questions or other needs, please contact your Project Manager.



Scott Habermehl has reviewed  
and approved this report.



**Golder Associates, Inc.**

Project ID: 07380026.0002  
Sample ID: BARBARA J3-2AS

ACZ Sample ID: **L75214-01**  
Date Sampled: 04/02/09 00:00  
Date Received: 04/09/09  
Sample Matrix: Soil

## Metals Analysis

| Parameter             | EPA Method   | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------------|--------------|--------|------|----|-------|-----|-----|----------------|---------|
| Thorium, total (3050) | M6020 ICP-MS | 1.4    | B    | *  | mg/Kg | 0.5 | 3   | 04/21/09 3:29  | erf     |
| Uranium, total (3050) | M6020 ICP-MS | 3000   |      | *  | mg/Kg | 3   | 10  | 04/21/09 18:26 | erf     |

## Soil Analysis

| Parameter       | EPA Method              | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-----------------|-------------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Solids, Percent | CLPSOW390, PART F, D-98 | 95.1   |      | *  | %     | 0.1 | 0.5 | 04/10/09 13:00 | lwt     |

## Soil Preparation

| Parameter               | EPA Method       | Result | Qual | XQ | Units | MDL | PQL | Date           | Analyst |
|-------------------------|------------------|--------|------|----|-------|-----|-----|----------------|---------|
| Air Dry at 34 Degrees C | USDA No. 1, 1972 |        |      |    |       |     |     | 04/10/09 13:00 | lwt     |
| Crush and Pulverize     | USDA No. 1, 1972 |        |      |    |       |     |     | 04/13/09 10:30 | lwt     |
| Digestion - Hot Plate   | M3050B ICP-MS    |        |      |    |       |     |     | 04/14/09 12:50 | lwt     |

## Report Header Explanations

|         |   |
|---------|---|
| Batch   | A distinct set of samples analyzed at a specific time   |
| Found   | Value of the QC Type of interest  |
| Limit   | Upper limit for RPD, in %.  |
| Lower   | Lower Recovery Limit, in % (except for LCSS, mg/Kg)   |
| MDL     | Method Detection Limit. Same as Minimum Reporting Limit. Allows for instrument and annual fluctuations. |
| PCN/SCN | A number assigned to reagents/standards to trace to the manufacturer's certificate of analysis          |
| PQL     | Practical Quantitation Limit, typically 5 times the MDL.  |
| QC      | True Value of the Control Sample or the amount added to the Spike                                       |
| Rec     | Amount of the true value or spike added recovered, in % (except for LCSS, mg/Kg)                        |
| RPD     | Relative Percent Difference, calculation used for Duplicate QC Types                                    |
| Upper   | Upper Recovery Limit, in % (except for LCSS, mg/Kg)   |
| Sample  | Value of the Sample of interest   |

## QC Sample Types

|       |  |       |  |
|-------|--|-------|--|
| AS    | Analytical Spike (Post Digestion)                      | LCSWD | Laboratory Control Sample - Water Duplicate  |
| ASD   | Analytical Spike (Post Digestion) Duplicate            | LFB   | Laboratory Fortified Blank                   |
| CCB   | Continuing Calibration Blank                           | LFM   | Laboratory Fortified Matrix                  |
| CCV   | Continuing Calibration Verification standard           | LFMD  | Laboratory Fortified Matrix Duplicate        |
| DUP   | Sample Duplicate                                       | LRB   | Laboratory Reagent Blank                     |
| ICB   | Initial Calibration Blank                              | MS    | Matrix Spike                                 |
| ICV   | Initial Calibration Verification standard              | MSD   | Matrix Spike Duplicate                       |
| ICSAB | Inter-element Correction Standard - A plus B solutions | PBS   | Prep Blank - Soil                            |
| LCSS  | Laboratory Control Sample - Soil                       | PBW   | Prep Blank - Water                           |
| LCSSD | Laboratory Control Sample - Soil Duplicate             | PQV   | Practical Quantitation Verification standard |
| LCSW  | Laboratory Control Sample - Water                      | SDL   | Serial Dilution                              |

## QC Sample Type Explanations

|                         |   |
|-------------------------|---|
| Blanks                  | Verifies that there is no or minimal contamination in the prep method or calibration procedure. |
| Control Samples         | Verifies the accuracy of the method, including the prep procedure.                              |
| Duplicates              | Verifies the precision of the instrument and/or method.   |
| Spikes/Fortified Matrix | Determines sample matrix interferences, if any.   |
| Standard                | Verifies the validity of the calibration.   |

## ACZ Qualifiers (Qual)

|   |   |
|---|---|
| B | Analyte concentration detected at a value between MDL and PQL. The associated value is an estimated quantity.   |
| H | Analysis exceeded method hold time. pH is a field test with an immediate hold time.   |
| U | The material was analyzed for, but was not detected above the level of the associated value.<br>The associated value is either the sample quantitation limit or the sample detection limit. |

## Method References

- (1) EPA 600/4-83-020. Methods for Chemical Analysis of Water and Wastes, March 1983.
- (2) EPA 600/R-93-100. Methods for the Determination of Inorganic Substances in Environmental Samples, August 1993.
- (3) EPA 600/R-94-111. Methods for the Determination of Metals in Environmental Samples - Supplement I, May 1994.
- (5) EPA SW-846. Test Methods for Evaluating Solid Waste, Third Edition with Update III, December 1996.
- (6) Standard Methods for the Examination of Water and Wastewater, 19th edition, 1995.

## Comments

- (1) QC results calculated from raw data. Results may vary slightly if the rounded values are used in the calculations.
- (2) Soil, Sludge, and Plant matrices for Inorganic analyses are reported on a dry weight basis.
- (3) Animal matrices for Inorganic analyses are reported on an "as received" basis.

For a complete list of ACZ's Extended Qualifiers, please click:

<http://www.acz.com/public/extquallist.pdf>



**Golder Associates, Inc.**

ACZ Project ID: **L75214**

Project ID: 07380026.0002

**Solids, Percent**

CLPSOW390, PART F, D-98

| ACZ ID          | Type | Analyzed       | PCN/SCN | QC | Sample | Found | Units | Rec | Lower | Upper | RPD | Limit | Qual |
|-----------------|------|----------------|---------|----|--------|-------|-------|-----|-------|-------|-----|-------|------|
| <b>WG262077</b> |      |                |         |    |        |       |       |     |       |       |     |       |      |
| WG262077PBS     | PBS  | 04/10/09 13:00 |         |    |        | U     | %     |     | 99.9  | 100.1 |     |       |      |
| L75214-01DUP    | DUP  | 04/10/09 13:00 |         |    | 95.1   | 93.96 | %     |     |       |       | 1.2 | 20    |      |

**Thorium, total (3050)**

M6020 ICP-MS

| ACZ ID          | Type | Analyzed      | PCN/SCN    | QC   | Sample | Found | Units | Rec  | Lower  | Upper | RPD  | Limit | Qual |
|-----------------|------|---------------|------------|------|--------|-------|-------|------|--------|-------|------|-------|------|
| <b>WG262507</b> |      |               |            |      |        |       |       |      |        |       |      |       |      |
| WG262507ICV     | ICV  | 04/21/09 2:42 | MS090326-1 | .05  |        | .0477 | mg/L  | 95.4 | 90     | 110   |      |       |      |
| WG262507ICB     | ICB  | 04/21/09 2:47 |            |      |        | U     | mg/L  |      | -0.003 | 0.003 |      |       |      |
| WG262158PBS     | PBS  | 04/21/09 3:06 |            |      |        | U     | mg/Kg |      | -1.5   | 1.5   |      |       |      |
| L75214-01MS     | MS   | 04/21/09 3:34 | MS090311-4 | 12.5 | 1.4    | 13.5  | mg/Kg | 96.8 | 75     | 125   |      |       |      |
| L75214-01MSD    | MSD  | 04/21/09 3:48 | MS090311-4 | 12.5 | 1.4    | 13.16 | mg/Kg | 94.1 | 75     | 125   | 2.55 | 20    |      |

**Uranium, total (3050)**

M6020 ICP-MS

| ACZ ID          | Type | Analyzed       | PCN/SCN    | QC  | Sample | Found  | Units | Rec  | Lower   | Upper  | RPD | Limit | Qual |
|-----------------|------|----------------|------------|-----|--------|--------|-------|------|---------|--------|-----|-------|------|
| <b>WG262537</b> |      |                |            |     |        |        |       |      |         |        |     |       |      |
| WG262537ICV     | ICV  | 04/21/09 17:39 | MS090326-1 | .05 |        | .04907 | mg/L  | 98.1 | 90      | 110    |     |       |      |
| WG262537ICB     | ICB  | 04/21/09 17:44 |            |     |        | U      | mg/L  |      | -0.0003 | 0.0003 |     |       |      |
| WG262158PBS     | PBS  | 04/21/09 18:03 |            |     |        | U      | mg/Kg |      | -0.15   | 0.15   |     |       |      |
| L75214-01MS     | MS   | 04/21/09 18:31 | MS090311-4 | 625 | 3000   | 3210   | mg/Kg | 33.6 | 75      | 125    |     |       | M3   |
| L75214-01MSD    | MSD  | 04/21/09 18:45 | MS090311-4 | 625 | 3000   | 3187.5 | mg/Kg | 30   | 75      | 125    | 0.7 | 20    | M3   |

**Golder Associates, Inc.**

ACZ Project ID: **L75214**

| ACZ ID    | WORKNUM  | PARAMETER             | METHOD       | QUAL | DESCRIPTION   |
|-----------|----------|-----------------------|--------------|------|---|
| L75214-01 | WG262537 | Uranium, total (3050) | M6020 ICP-MS | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |

**Golder Associates, Inc.**

Project ID: 07380026.0002  
Sample ID: BARBARA J3-2AS  
Locator:

ACZ Sample ID: **L75214-01**  
Date Sampled: 04/02/09 0:00  
Date Received: 04/09/09  
Sample Matrix: Soil

Gross Alpha &amp; Beta (3050)

Prep Method:

M9310

| Parameter   | Measure Date   | Prep Date | Result | Error(+/-) | LLD | Units | XQ | Analyst |
|-------------|----------------|-----------|--------|------------|-----|-------|----|---------|
| Gross Alpha | 04/24/09 13:09 |           | 1900   | 46         | 2.3 | pCi/g | *  | bjl     |
| Gross Beta  | 04/24/09 13:09 |           | 2300   | 31         | 4.5 | pCi/g | *  | bjl     |

Radium 226 (3050)

Prep Method:

M903.1

| Parameter         | Measure Date   | Prep Date | Result | Error(+/-) | LLD  | Units | XQ | Analyst |
|-------------------|----------------|-----------|--------|------------|------|-------|----|---------|
| Radium 226 (3050) | 04/22/09 16:57 |           | 980    | 5.9        | 0.48 | pCi/g | *  | mwm     |



## Report Header Explanations

|            |  |
|------------|--|
| Batch      | A distinct set of samples analyzed at a specific time  |
| Error(+/-) | Calculated sample specific uncertainty   |
| Found      | Value of the QC Type of interest   |
| Limit      | Upper limit for RPD, in %.   |
| LCL        | Lower Control Limit, in % (except for LCSS, mg/Kg)   |
| LLD        | Calculated sample specific Lower Limit of Detection  |
| PCN/SCN    | A number assigned to reagents/standards to trace to the manufacturer's certificate of analysis |
| PQL        | Practical Quantitation Limit   |
| QC         | True Value of the Control Sample or the amount added to the Spike                              |
| Rec        | Amount of the true value or spike added recovered, in % (except for LCSS, mg/Kg)               |
| RER        | Relative Error Ratio, calculation used for Dup. QC taking into account the error factor.       |
| UCL        | Upper Control Limit, in % (except for LCSS, mg/Kg)   |
| Sample     | Value of the Sample of interest  |

## QC Sample Types

|      |                                   |        |                                     |
|------|-----------------------------------|--------|-------------------------------------|
| DUP  | Sample Duplicate                  | MS/MSD | Matrix Spike/Matrix Spike Duplicate |
| LCSS | Laboratory Control Sample - Soil  | PBS    | Prep Blank - Soil                   |
| LCSW | Laboratory Control Sample - Water | PBW    | Prep Blank - Water                  |

## QC Sample Type Explanations

|                 |  |
|-----------------|--|
| Blanks          | Verifies that there is no or minimal contamination in the prep method procedure. |
| Control Samples | Verifies the accuracy of the method, including the prep procedure.               |
| Duplicates      | Verifies the precision of the instrument and/or method.                          |
| Matrix Spikes   | Determines sample matrix interferences, if any.                                  |

## ACZ Qualifiers (Qual)

|   |  |
|---|--|
| H | Analysis exceeded method hold time.  |
| R | Poor spike recovery accepted because the other spike in the set fell within the given limits.                |
| T | High Replicate Error Ratio (RER) accepted because sample concentrations are less than 10x the MDL.           |
| U | No nuclides detected above the Lower Limit of Detection (LLD)  |
| V | High blank data accepted because sample concentration is 10 times higher than blank concentration            |
| X | QC is out of control. See Case Narrative.  |
| Z | Poor spike recovery is accepted because sample concentration is four times greater than spike concentration. |

## Method Prefix Reference

|     |   |
|-----|---|
| M   | EPA methodology, including those under SDWA, CWA, and RCRA                        |
| SM  | Standard Methods for the Examination of Water and Wastewater, 19th edition, 1995. |
| D   | ASTM  |
| RP  | DOE   |
| ESM | DOE/ESM   |

## Comments

- (1) Solid matrices are reported on a dry weight basis.
- (2) Preparation method: "Method" indicates preparation defined in analytical method.
- (3) QC results calculated from raw data. Results may vary slightly if the rounded values are used in the calculations.

For a complete list of ACZ's Extended Qualifiers, please click:

<http://www.acz.com/public/extquallist.pdf>

**Golder Associates, Inc.**

ACZ Project ID: **L75214**

Project ID: 07380026.0002

**Alpha** M9310 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN    | QC     | Sample | Error | LLD | Found | Error | LLD  | Rec   | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|------------|--------|--------|-------|-----|-------|-------|------|-------|-------|-------|---------|-------|------|
| <b>WG262764</b> |         |          |            |        |        |       |     |       |       |      |       |       |       |         |       |      |
| WG262565PBS     | PBS     | 04/24/09 |            |        |        |       |     | .39   | 0.29  | 0.27 |       |       | 0.54  |         |       |      |
| WG262565LCSS    | LCSS    | 04/24/09 | RC081215-1 | 32.42  |        |       |     | 28    | 2.8   | 0.54 | 86.4  | 52    | 129   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/24/09 |            |        | 1400   | 39    | 2.2 | 1200  | 37    | 2.3  |       |       |       | 3.72    | 2     | RN   |
| L75211-01DUP    | DUP-RPD | 04/24/09 |            |        | 1400   | 39    | 2.2 | 1200  | 37    | 2.3  |       |       |       | 15.4    | 20    | RN   |
| L75212-02MS     | MS      | 04/24/09 | RC081215-1 | 101.32 | 470    | 23    | 2.2 | 430   | 24    | 2.6  | -39.5 | 52    | 129   |         |       | M3   |

**Beta** M9310 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN  | QC     | Sample | Error | LLD | Found | Error | LLD  | Rec  | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|----------|--------|--------|-------|-----|-------|-------|------|------|-------|-------|---------|-------|------|
| <b>WG262764</b> |         |          |          |        |        |       |     |       |       |      |      |       |       |         |       |      |
| WG262565PBS     | PBS     | 04/24/09 |          |        |        |       |     | 1.2   | 0.6   | 0.77 |      |       | 1.54  |         |       |      |
| WG262565LCSS    | LCSS    | 04/24/09 | PCN30789 | 40     |        |       |     | 39    | 2.6   | 1.6  | 97.5 | 65    | 104   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/24/09 |          |        | 1700   | 27    | 4.5 | 1300  | 23    | 4.4  |      |       |       | 11.28   | 2     | RC   |
| L75214-01MS     | MS      | 04/24/09 | PCN30789 | 111.11 | 2300   | 31    | 4.5 | 2600  | 33    | 4.5  | 270  | 65    | 104   |         |       | M3   |

**Radium 226 (3050)** M903.1 pCi/g

| ACZ ID          | Type    | Analyzed | PCN/SCN    | QC    | Sample | Error | LLD  | Found | Error | LLD  | Rec   | Lower | Upper | RPD/RER | Limit | Qual |
|-----------------|---------|----------|------------|-------|--------|-------|------|-------|-------|------|-------|-------|-------|---------|-------|------|
| <b>WG262679</b> |         |          |            |       |        |       |      |       |       |      |       |       |       |         |       |      |
| WG262382PBS     | PBS     | 04/22/09 |            |       |        |       |      | -.01  | 0.19  | 0.48 |       |       | 0.96  |         |       |      |
| WG262382LCSS    | LCSS    | 04/22/09 | RC090209-1 | 47.83 |        |       |      | 53    | 1.5   | 0.6  | 110.8 | 44    | 128   |         |       |      |
| L75211-01DUP    | DUP-RER | 04/22/09 |            |       | 580    | 4     | 0.38 | 670   | 4.5   | 0.41 |       |       |       | 14.95   | 2     | RN   |
| L75211-01DUP    | DUP-RPD | 04/22/09 |            |       | 580    | 4     | 0.38 | 670   | 4.5   | 0.41 |       |       |       | 14.4    | 20    | RN   |
| L75214-01MS     | MS      | 04/22/09 | RC090209-1 | 47.83 | 980    | 5.9   | 0.48 | 1300  | 8.2   | 0.73 | 669   | 44    | 128   |         |       | M3   |

**Golder Associates, Inc.**

ACZ Project ID: **L75214**

| ACZ ID    | WORKNUM  | PARAMETER         | METHOD | QUAL | DESCRIPTION   |
|-----------|----------|-------------------|--------|------|---|
| L75214-01 | WG262764 | Gross Alpha       | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|           |          |                   | M9310  | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |
|           |          | Gross Beta        | M9310  | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|           |          |                   | M9310  | RC   | For a solid matrix, the matrix duplicate precision assessment (RPD or RER) exceeded the control limit, which is attributable to the non-homogeneity of the sample.                                    |
|           | WG262679 | Radium 226 (3050) | M903.1 | M3   | The spike recovery value is unusable since the analyte concentration in the sample is disproportionate to the spike level. The recovery of the associated control sample (LCS or LFB) was acceptable. |
|           |          |                   | M903.1 | RN   | Sample concentration is greater than 5x LLD; RPD was used for data validation. Replicate Error Ratio (RER) is greater than 2. Precision judged to be in control.                                      |



**Golder Associates, Inc.**

ACZ Project ID: **L75214**

**Metals Analysis**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                       |              |
|-----------------------|--------------|
| Thorium, total (3050) | M6020 ICP-MS |
| Uranium, total (3050) | M6020 ICP-MS |

**Radiochemistry**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                   |        |
|-------------------|--------|
| Radium 226 (3050) | M903.1 |
|-------------------|--------|

**Soil Analysis**

The following parameters are not offered for certification or are not covered by NELAC certificate #ACZ.

|                 |                         |
|-----------------|-------------------------|
| Solids, Percent | CLPSOW390, PART F, D-98 |
|-----------------|-------------------------|

**Golder Associates, Inc.**  
 07380026.0002

ACZ Project ID: L75214  
 Date Received: 4/9/2009  
 Received By:  
 Date Printed: 4/9/2009

**Receipt Verification**

|  | YES | NO | NA |
|--|-----|----|----|
| 1) Does this project require special handling procedures such as CLP protocol? |     |    | X  |
| 2) Are the custody seals on the cooler intact?                                 |     |    | X  |
| 3) Are the custody seals on the sample containers intact?                      |     |    | X  |
| 4) Is there a Chain of Custody or other directive shipping papers present?     | X   |    |    |
| 5) Is the Chain of Custody complete?   | X   |    |    |
| 6) Is the Chain of Custody in agreement with the samples received?             | X   |    |    |
| 7) Is there enough sample for all requested analyses?                          | X   |    |    |
| 8) Are all samples within holding times for requested analyses?                | X   |    |    |
| 9) Were all sample containers received intact?                                 | X   |    |    |
| 10) Are the temperature blanks present?  |     |    | X  |
| 11) Is the trip blank for Cyanide present?                                     |     |    | X  |
| 12) Is the trip blank for VOA present?   |     |    | X  |
| 13) Are samples requiring no headspace, headspace free?                        |     |    | X  |
| 14) Do the samples that require a Foreign Soils Permit have one?               |     |    | X  |

**Exceptions: If you answered no to any of the above questions, please describe**

N/A

**Contact (For any discrepancies, the client must be contacted)**

N/A

**Shipping Containers**

| Cooler Id | Temp (°C) | Rad (μR/hr) |
|-----------|-----------|-------------|
| NA8193    | 15.7      | 200         |
|           |           |             |
|           |           |             |
|           |           |             |

Client must contact ACZ Project Manager if analysis should not proceed for samples received outside of thermal preservation acceptance criteria.

**Notes**

**Golder Associates, Inc.**  
 07380026.0002

ACZ Project ID: L75214  
 Date Received: 4/9/2009  
 Received By:

**Sample Container Preservation**

| SAMPLE    | CLIENT ID      | R < 2 | G < 2 | BK < 2 | Y < 2 | YG < 2 | B < 2 | O < 2 | T > 12 | N/A | RAD | ID                       |
|-----------|----------------|-------|-------|--------|-------|--------|-------|-------|--------|-----|-----|--------------------------|
| L75214-01 | BARBARA J3-2AS |       |       |        |       |        |       |       |        | X   |     | <input type="checkbox"/> |

**Sample Container Preservation Legend**

| Abbreviation | Description            | Container Type | Preservative/Limits |
|--------------|------------------------|----------------|---------------------|
| R            | Raw/Nitric             | RED            | pH must be < 2      |
| B            | Filtered/Sulfuric      | BLUE           | pH must be < 2      |
| BK           | Filtered/Nitric        | BLACK          | pH must be < 2      |
| G            | Filtered/Nitric        | GREEN          | pH must be < 2      |
| O            | Raw/Sulfuric           | ORANGE         | pH must be < 2      |
| P            | Raw/NaOH               | PURPLE         | pH must be > 12 *   |
| T            | Raw/NaOH Zinc Acetate  | TAN            | pH must be > 12     |
| Y            | Raw/Sulfuric           | YELLOW         | pH must be < 2      |
| YG           | Raw/Sulfuric           | YELLOW GLASS   | pH must be < 2      |
| N/A          | No preservative needed | Not applicable |                     |
| RAD          | Gamma/Beta dose rate   | Not applicable | must be < 250 µR/hr |

\* pH check performed by analyst prior to sample preparation

Sample IDs Reviewed By: \_\_\_\_\_



Page 13 of 13

## **ATTACHMENT C**

### **Gamma Ray Activity Measurements Regression Analysis Summaries**

## REGRESSION ANALYSIS -LOW-END Ra-226 FIELD DATA

| <i>Regression Statistics</i> |       |  |  |  |  | 95 % C. I. |       |       |
|------------------------------|-------|--|--|--|--|------------|-------|-------|
|                              |       |  |  |  |  | counts     | upper | lower |
| Multiple R                   | 0.76  |  |  |  |  | 0          | 0.00  | 0.00  |
| R Square                     | 0.58  |  |  |  |  | 300        | 2.00  | 0.43  |
| Adj. R Square                | 0.47  |  |  |  |  | 750        | 5.00  | 1.08  |
| Standard Error               | 10.35 |  |  |  |  | 1500       | 9.99  | 2.15  |
| Observations                 | 10    |  |  |  |  | 3000       | 19.98 | 4.31  |
|                              |       |  |  |  |  | 6000       | 39.97 | 8.61  |
|                              |       |  |  |  |  | 8000       |       | 11.49 |

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 1316.33   | 1316.33   | 12.29    | 0.01                  |
| Residual   | 9         | 964.20    | 107.13    |          |                       |
| Total      | 10        | 2280.53   |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.004               | 0.001            | 3.505         | 0.007          | 0.001            | 0.007            |

## REGRESSION ANALYSIS -LOW-END Ra-226 LAB

| <i>Regression Statistics</i> |      |  |  |  |  | 95 % C. I. |       |       |
|------------------------------|------|--|--|--|--|------------|-------|-------|
|                              |      |  |  |  |  | counts     | upper | lower |
| Multiple R                   | 0.93 |  |  |  |  | 0          | 0.00  | 0.00  |
| R Square                     | 0.86 |  |  |  |  | 500        | 11.64 | 6.20  |
| Adjusted R Square            | 0.75 |  |  |  |  | 700        | 16.29 | 8.67  |
| Standard Error               | 5.97 |  |  |  |  | 900        | 20.94 | 11.15 |
| Observations                 | 10   |  |  |  |  | 1200       | 27.92 | 14.87 |
|                              |      |  |  |  |  | 1500       | 34.91 | 18.59 |
|                              |      |  |  |  |  | 2500       |       | 30.98 |

| <i>ANOVA</i> |           |           |           |          |                       |
|--------------|-----------|-----------|-----------|----------|-----------------------|
|              | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
| Regression   | 1         | 1959.81   | 1959.8077 | 54.9954  | 0.0001                |
| Residual     | 9         | 320.72    | 35.6358   |          |                       |
| Total        | 10        | 2280.53   |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.018               | 0.002            | 7.416         | 0.000          | 0.012            | 0.023            |



## REGRESSION ANALYSIS -LOW-END Ra-226 FIELD (y-intercept)

| Regression Statistics |       |  |  |  |  | 95 % C. I. |       |        |
|-----------------------|-------|--|--|--|--|------------|-------|--------|
|                       |       |  |  |  |  | counts     | upper | lower  |
| Multiple R            | 0.49  |  |  |  |  | 0          | 16.18 | -7.43  |
| R Square              | 0.24  |  |  |  |  | 400        | 19.00 | -7.95  |
| Adj. R Square         | 0.15  |  |  |  |  | 1000       | 23.22 | -8.73  |
| Standard Error        | 10.51 |  |  |  |  | 2000       | 30.26 | -10.02 |
| Observations          | 10.00 |  |  |  |  | 3000       | 37.30 | -11.31 |
|                       |       |  |  |  |  | 4000       | 44.34 | -12.60 |
|                       |       |  |  |  |  | 5000       | 51.38 | -13.89 |
|                       |       |  |  |  |  | 6000       | 58.43 | -15.18 |

| ANOVA      |      |         |        |      |                |
|------------|------|---------|--------|------|----------------|
|            | df   | SS      | MS     | F    | Significance F |
| Regression | 1.00 | 279.63  | 279.63 | 2.53 | 0.15           |
| Residual   | 8.00 | 883.65  | 110.46 |      |                |
| Total      | 9.00 | 1163.28 |        |      |                |

|              | Coefficients | Std. Err. | t Stat | P-value | Lower 95% | Upper 95% |
|--------------|--------------|-----------|--------|---------|-----------|-----------|
| Intercept    | 4.37         | 5.12      | 0.85   | 0.42    | -7.43     | 16.18     |
| X Variable 1 | 0.00         | 0.00      | 1.59   | 0.15    | 0.00      | 0.01      |

## REGRESSION ANALYSIS -LOW-END Ra-226 (y-intercept)

| Regression Statistics |       |  |  |  |  | 95 % C. I. |       |        |
|-----------------------|-------|--|--|--|--|------------|-------|--------|
|                       |       |  |  |  |  | counts     | upper | lower  |
| Multiple R            | 0.97  |  |  |  |  | 0          | -7.57 | -16.94 |
| R Square              | 0.95  |  |  |  |  | 500        | 11.41 | -3.92  |
| Adj. R Square         | 0.94  |  |  |  |  | 700        | 19.01 | 1.29   |
| Standard Error        | 2.69  |  |  |  |  | 900        | 26.61 | 6.50   |
| Observations          | 10.00 |  |  |  |  | 1200       | 38.00 | 14.31  |
|                       |       |  |  |  |  | 1500       | 49.39 | 22.13  |
|                       |       |  |  |  |  | 2500       |       | 48.17  |

| ANOVA      |      |         |         |        |                |
|------------|------|---------|---------|--------|----------------|
|            | df   | SS      | MS      | F      | Significance F |
| Regression | 1.00 | 1105.53 | 1105.53 | 153.13 | 0.00           |
| Residual   | 8.00 | 57.76   | 7.22    |        |                |
| Total      | 9.00 | 1163.28 |         |        |                |

|              | Coefficients | Std. Err. | t Stat | P-value | Lower 95% | Upper 95% |
|--------------|--------------|-----------|--------|---------|-----------|-----------|
| Intercept    | -12.26       | 2.03      | -6.04  | 0.00    | -16.94    | -7.57     |
| X Variable 1 | 0.03         | 0.00      | 12.37  | 0.00    | 0.03      | 0.04      |

## REGRESSION ANALYSIS --LOW-END U-238 FIELD DATA

| <i>Regression Statistics</i> |       |  |  |  | 95 % C. I. |       |       |
|------------------------------|-------|--|--|--|------------|-------|-------|
|                              |       |  |  |  | counts     | upper | lower |
| Multiple R                   | 0.95  |  |  |  | 0          | 0.00  | 0.00  |
| R Square                     | 0.90  |  |  |  | 400        | 0.60  | 0.36  |
| Adj. R Square                | 0.79  |  |  |  | 1000       | 1.50  | 0.90  |
| Standard Error               | 1.20  |  |  |  | 2000       | 3.01  | 1.80  |
| Observations                 | 10.00 |  |  |  | 3000       | 4.51  | 2.69  |
|                              |       |  |  |  | 4000       | 6.02  | 3.59  |
|                              |       |  |  |  | 5000       | 7.52  | 4.49  |
|                              |       |  |  |  | 6000       | 9.02  | 5.39  |

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 115.85    | 115.85    | 80.4593  | 0.0000                |
| Residual   | 9         | 12.96     | 1.44      |          |                       |
| Total      | 10        | 128.81    |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.0012              | 0.0001           | 8.9699        | 0.0000         | 0.0009           | 0.0015           |

## REGRESSION ANALYSIS --LOW-END U-238 LAB DATA

| <i>Regression Statistics</i> |      |  |  |  | 95 % C. I. |       |       |
|------------------------------|------|--|--|--|------------|-------|-------|
|                              |      |  |  |  | counts     | upper | lower |
| Multiple R                   | 0.87 |  |  |  | 0          | 0.00  | 0.00  |
| R Square                     | 0.75 |  |  |  | 500        | 2.84  | 1.13  |
| Adj. R Square                | 0.64 |  |  |  | 700        | 3.98  | 1.58  |
| Standard Error               | 1.88 |  |  |  | 900        | 5.11  | 2.03  |
| Observations                 | 10   |  |  |  | 1200       | 6.81  | 2.71  |
|                              |      |  |  |  | 1500       | 8.52  | 3.39  |
|                              |      |  |  |  | 2500       |       | 5.65  |

| <i>ANOVA</i> |           |           |           |          |                       |
|--------------|-----------|-----------|-----------|----------|-----------------------|
|              | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
| Regression   | 1         | 97.15     | 97.15     | 27.611   | 0.001                 |
| Residual     | 9         | 31.67     | 3.52      |          |                       |
| Total        | 10        | 128.81    |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.0040              | 0.0008           | 5.2547        | 0.0005         | 0.0023           | 0.0057           |

## REGRESSION ANALYSIS -LOW-END U-238 FIELD DATA (y-intercept)

| <i>Regression Statistics</i> |       |  |  |  |  | 95 % C. I. |       |       |
|------------------------------|-------|--|--|--|--|------------|-------|-------|
|                              |       |  |  |  |  | counts     | upper | lower |
| Multiple R                   | 0.87  |  |  |  |  | 0          | 1.89  | -0.84 |
| R Square                     | 0.76  |  |  |  |  | 400        | 2.50  | -0.61 |
| Adj. R Square                | 0.73  |  |  |  |  | 1000       | 3.43  | -0.26 |
| Standard Error               | 1.21  |  |  |  |  | 2000       | 4.97  | 0.32  |
| Observations                 | 10.00 |  |  |  |  | 3000       | 6.51  | 0.90  |
|                              |       |  |  |  |  | 4000       | 8.06  | 1.47  |
|                              |       |  |  |  |  | 5000       | 9.60  | 2.05  |
|                              |       |  |  |  |  | 6000       | 11.14 | 2.63  |

| ANOVA      |           |           |           |          |                       |
|------------|-----------|-----------|-----------|----------|-----------------------|
|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
| Regression | 1.00      | 38.07     | 38.07     | 25.79    | 0.00                  |
| Residual   | 8.00      | 11.81     | 1.48      |          |                       |
| Total      | 9.00      | 49.88     |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0.52                | 0.59             | 0.88          | 0.40           | -0.84            | 1.89             |
| X Variable 1 | 0.00                | 0.00             | 5.08          | 0.00           | 0.00             | 0.00             |

## REGRESSION ANALYSIS -LOW-END U-238\_LAB DATA (y-intercept)

| <i>Regression Statistics</i> |       |  |  |  |  | 95 % C. I. |       |       |
|------------------------------|-------|--|--|--|--|------------|-------|-------|
|                              |       |  |  |  |  | counts     | upper | lower |
| Multiple R                   | 0.60  |  |  |  |  | 0          | 3.34  | -3.59 |
| R Square                     | 0.37  |  |  |  |  | 500        | 7.61  | -3.74 |
| Adj. R Square                | 0.29  |  |  |  |  | 700        | 9.31  | -3.80 |
| Standard Error               | 1.99  |  |  |  |  | 900        | 11.02 | -3.86 |
| Observations                 | 10.00 |  |  |  |  | 1200       | 13.58 | -3.95 |
|                              |       |  |  |  |  | 1500       | 16.13 | -4.04 |
|                              |       |  |  |  |  | 2500       | 24.66 | -4.35 |

| ANOVA      |           |           |           |          |                       |
|------------|-----------|-----------|-----------|----------|-----------------------|
|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
| Regression | 1.00      | 18.24     | 18.24     | 4.61     | 0.06                  |
| Residual   | 8.00      | 31.64     | 3.95      |          |                       |
| Total      | 9.00      | 49.88     |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | -0.12               | 1.50             | -0.08         | 0.94           | -3.59            | 3.34             |
| X Variable 1 | 0.00                | 0.00             | 2.15          | 0.06           | 0.00             | 0.01             |



## REGRESSION ANALYSIS -Ra-226 FIELD DATA

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.98  |
| R Square                     | 0.97  |
| Adj. R Square                | 0.90  |
| Standard Error               | 55.15 |
| Observations                 | 16.00 |

## ANOVA

|          | <i>df</i> | <i>SS</i>  | <i>MS</i>  | <i>F</i> | <i>Significance F</i> |
|----------|-----------|------------|------------|----------|-----------------------|
|          | 1.00      | 1368075.12 | 1368075.12 | 449.72   | 0.00                  |
| Residual | 15.00     | 45630.41   | 3042.03    |          |                       |
| Total    | 16.00     | 1413705.53 |            |          |                       |

|            | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept  | 0.00                | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable | 0.015               | 0.00             | 21.21         | 0.00           | 0.013            | 0.016            |

| 95 % C. I. |         |         |
|------------|---------|---------|
| counts     | upper   | lower   |
| 400        | 6.49    | 5.31    |
| 1000       | 16.24   | 13.27   |
| 5000       | 81.19   | 66.36   |
| 10000      | 162.37  | 132.72  |
| 20000      | 324.75  | 265.43  |
| 40000      | 649.50  | 530.86  |
| 60000      | 974.24  | 796.29  |
| 80000      | 1298.99 | 1061.72 |

## REGRESSION ANALYSIS -Ra-226 LAB DATA

| <i>Regression Statistics</i> |        |
|------------------------------|--------|
| Multiple R                   | 0.90   |
| R Square                     | 0.82   |
| Adj. R Square                | 0.75   |
| Standard Error               | 131.46 |
| Observations                 | 16.00  |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 1154490.5 | 1154490.5 | 66.8     | 0.00                  |
| Residual   | 15        | 259215.07 | 17281.00  |          |                       |
| Total      | 16        | 1413705.5 |           |          |                       |

|            | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept  | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable | 0.060               | 0.01             | 8.17          | 0.00           | 0.04             | 0.08             |

| 95 % C. I. |         |        |
|------------|---------|--------|
| counts     | upper   | lower  |
| 400        | 30.47   | 17.87  |
| 800        | 60.94   | 35.73  |
| 1600       | 121.89  | 71.47  |
| 3200       | 243.78  | 142.93 |
| 6400       | 487.55  | 285.86 |
| 12000      | 914.16  | 536.00 |
| 20000      | 1523.60 | 893.33 |

## REGRESSION ANALYSIS -Ra-226 LAB DATA (including intercept)

| <i>Regression Statistics</i> |        |
|------------------------------|--------|
| Multiple R                   | 0.88   |
| R Square                     | 0.77   |
| Adj. R Square                | 0.75   |
| Standard Error               | 133.79 |
| Observations                 | 16.00  |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 838565.91 | 838565.91 | 46.85    | 0.00                  |
| Residual   | 14        | 250610.02 | 17900.72  |          |                       |
| Total      | 15        | 1089175.9 |           |          |                       |

|            | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept  | -28.97              | 41.78            | -0.69         | 0.50           | -118.59          | 60.65            |
| X Variable | 0.06                | 0.01             | 6.84          | 0.00           | 0.04             | 0.08             |

| <i>95 % C. I.</i> |              |              |
|-------------------|--------------|--------------|
| <i>counts</i>     | <i>upper</i> | <i>lower</i> |
| 0                 | 60.65        | -118.59      |
| 400               | 94.44        | -100.92      |
| 750               | 124.01       | -85.46       |
| 1500              | 187.38       | -52.33       |
| 3000              | 314.11       | 13.92        |
| 6000              | 567.57       | 146.44       |
| 12000             | 1074.49      | 411.46       |
| 22000             |              | 853.16       |

## REGRESSION ANALYSIS -Ra-226 FIELD DATA (including intercept)

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.98  |
| R Square                     | 0.96  |
| Adj. R Square                | 0.96  |
| Standard Error               | 55.22 |
| Observations                 | 16.00 |

## ANOVA

|            | <i>df</i> | <i>SS</i>  | <i>MS</i>  | <i>F</i> | <i>Significance F</i> |
|------------|-----------|------------|------------|----------|-----------------------|
| Regression | 1.00      | 1046485.04 | 1046485.04 | 343.18   | 0.00                  |
| Residual   | 14.00     | 42690.89   | 3049.35    |          |                       |
| Total      | 15.00     | 1089175.92 |            |          |                       |

|            | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept  | -15.94              | 16.24            | -0.98         | 0.34           | -50.77           | 18.88            |
| X Variable | 0.015               | 0.00             | 18.53         | 0.00           | 0.013            | 0.017            |

| <i>95 % C. I.</i> |              |              |
|-------------------|--------------|--------------|
| <i>counts</i>     | <i>upper</i> | <i>lower</i> |
| 400               | 25.66        | -45.40       |
| 1000              | 35.82        | -37.35       |
| 5000              | 103.56       | 16.33        |
| 10000             | 188.24       | 83.44        |
| 20000             | 357.59       | 217.65       |
| 40000             | 696.29       | 486.06       |
| 60000             | 1035.00      | 754.47       |
| 80000             | 1373.70      | 1022.89      |

## REGRESSION ANALYSIS -U-238 FIELD DATA

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.97  |
| R Square                     | 0.93  |
| Adj. R Square                | 0.87  |
| Standard Error               | 86.18 |
| Observations                 | 16.00 |

| 95 % C. I. |         |         |
|------------|---------|---------|
| counts     | upper   | lower   |
| 400        | 7.28    | 5.42    |
| 1000       | 18.20   | 13.56   |
| 5000       | 90.98   | 67.81   |
| 10000      | 181.97  | 135.62  |
| 20000      | 363.93  | 271.24  |
| 40000      | 727.87  | 542.49  |
| 60000      | 1091.80 | 813.73  |
| 80000      | 1455.73 | 1084.97 |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 1584642   | 1584642   | 213.343  | 0.000                 |
| Residual   | 15        | 111415    | 7428      |          |                       |
| Total      | 16        | 1696057   |           |          |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.016               | 0.001            | 14.606        | 0.000          | 0.014            | 0.018            |

## REGRESSION ANALYSIS -U-238 LABORTORY DATA

| <i>Regression Statistics</i> |        |
|------------------------------|--------|
| Multiple R                   | 0.93   |
| R Square                     | 0.86   |
| Adj. R Square                | 0.80   |
| Standard Error               | 124.93 |
| Observations                 | 16     |

| 95 % C. I. |        |         |
|------------|--------|---------|
| counts     | upper  | lower   |
| 0          | 0.00   | 0.00    |
| 400        | 33.19  | 21.21   |
| 800        | 66.38  | 42.42   |
| 1600       | 132.75 | 84.83   |
| 3200       | 265.50 | 169.67  |
| 6400       | 531.00 | 339.33  |
| 12000      | 995.63 | 636.25  |
| 20000      |        | 1060.41 |

## ANOVA


|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i>  | <i>Significance F</i> |
|------------|-----------|-----------|-----------|-----------|-----------------------|
| Regression | 1         | 1461953.5 | 1461953.5 | 93.673461 | 1.398E-07             |
| Residual   | 15        | 234103.69 | 15606.913 |           |                       |
| Total      | 16        | 1696057.2 |           |           |                       |

|              | <i>Coefficients</i> | <i>Std. Err.</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|------------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A             | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.068               | 0.007            | 9.679         | 0.000          | 0.053            | 0.083            |



## **ATTACHMENT D**

### **MicroR Meter Regression Analysis Summaries**



## REGRESSION ANALYSIS SUMMARY OUTPUT-Laboratory Ra-226

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.86  |
| R Square                     | 0.74  |
| Adj. R Squa                  | 0.63  |
| Standard Err                 | 8.05  |
| Observation                  | 10.00 |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 1697.83   | 1697.83   | 26.22    | 0.00                  |
| Residual   | 9         | 582.70    | 64.74     |          |                       |
| Total      | 10        | 2280.53   |           |          |                       |

|              | <i>Coefficients</i> | <i>Std Err</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|----------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A           | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.754               | 0.147          | 5.121         | 0.001          | 0.421            | 1.087            |

## SUMMARY OUTPUT-Field Ra-226

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.79  |
| R Square                     | 0.62  |
| Adj. R Squa                  | 0.51  |
| Standard Err                 | 9.84  |
| Observation                  | 10.00 |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 1408.4    | 1408.4    | 14.5     | 0.01                  |
| Residual   | 9         | 872.1     | 96.9      |          |                       |
| Total      | 10        | 2280.5    |           |          |                       |

|              | <i>Coefficients</i> | <i>Std Err</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|----------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A           | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.157               | 0.041          | 3.812         | 0.004          | 0.064            | 0.251            |



## REGRESSION ANALYSIS SUMMARY OUTPUT-Laboratory U-238

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.75  |
| R Square                     | 0.56  |
| Adj. R Square                | 0.47  |
| Standard Error               | 10.86 |
| Observations                 | 12.00 |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i>  | <i>Significance F</i> |
|------------|-----------|-----------|-----------|-----------|-----------------------|
| Regression | 1         | 1657.3    | 1657.3013 | 14.059904 | 0.004                 |
| Residual   | 11        | 1296.6    | 117.87429 |           |                       |
| Total      | 12        | 2953.9    |           |           |                       |

|              | <i>Coefficients</i> | <i>Std Err</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|----------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A           | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.58                | 0.15           | 3.75          | 0.00           | 0.24             | 0.92             |

## SUMMARY OUTPUT-Field U-238

| <i>Regression Statistics</i> |       |
|------------------------------|-------|
| Multiple R                   | 0.69  |
| R Square                     | 0.48  |
| Adj. R Square                | 0.39  |
| Standard Error               | 11.79 |
| Observations                 | 12.00 |

## ANOVA

|            | <i>df</i> | <i>SS</i> | <i>MS</i> | <i>F</i> | <i>Significance F</i> |
|------------|-----------|-----------|-----------|----------|-----------------------|
| Regression | 1         | 1424.2    | 1424.2    | 10.24    | 0.01                  |
| Residual   | 11        | 1529.7    | 139.1     |          |                       |
| Total      | 12        | 2953.9    |           |          |                       |

|              | <i>Coefficients</i> | <i>Std Err</i> | <i>t Stat</i> | <i>P-value</i> | <i>Lower 95%</i> | <i>Upper 95%</i> |
|--------------|---------------------|----------------|---------------|----------------|------------------|------------------|
| Intercept    | 0                   | #N/A           | #N/A          | #N/A           | #N/A             | #N/A             |
| X Variable 1 | 0.13                | 0.04           | 3.20          | 0.01           | 0.04             | 0.23             |

