

## Naphtha Tank Fire

## Deer Park, TX

# Preliminary Air Sampling and Analysis Plan (SAP)

Version 1.0<sup>1</sup>

Prepared on Behalf of:

**Intercontinental Terminals Company** 

Prepared By:

CTEH, LLC

5120 Northshore Drive

Little Rock, AR 72118

501-801-8500

March 18, 2019

|              | Name/Organization | Signature  | Date Signed |
|--------------|-------------------|------------|-------------|
| Prepared by: | Scott Malm        | Scott Malm | 3/17/19     |
| Reviewed by: |                   |            |             |
| Approved by: |                   |            |             |
| Approved by: |                   |            |             |

<sup>&</sup>lt;sup>1</sup> Please note that this Preliminary Air Sampling and Analysis Plan must still undergo CTEH internal review and approval.

#### **Air Monitoring and Sampling Strategy**

CTEH®, LLC is focusing on the mixtures, chemicals, and indicators of flammability chosen below because they are among the most important and readily monitored hazards of burning naphtha products. The possible hazards of a naphtha fire vary by the mixture and composition of naphtha as well as with the environmental conditions associated with the surrounding area. Monitoring and sampling for some chemicals or indicators of the presence of naphtha may be conducted less frequently or even discontinued as product-specific information becomes available or as initial monitoring and sampling results indicate that these chemicals and indicators do not pose a health concern.

The strategy is to utilize two broadly defined monitoring plans: 1) Community Monitoring; 2) Site Assessment. Community Monitoring may take place in those residential and commercial locations immediately surrounding the incident site, not necessarily currently occupied by members of the community. Unlike monitoring, Site Assessment does not necessarily represent ambient air monitoring near breathing zone level. Site Assessment may involve a variety of different monitoring tasks intended to provide information that may help to delineate the nature and extent of the release (e.g. fence line monitoring, worst case determination, container head space, ground level, etc.).

Free-roaming handheld real-time air monitoring may be conducted in a variety of areas based on levels of activity, proximity to the release, and site conditions. Fixed-location handheld real-time locations may be established in the Community in order to provide concentration averages that may be observed and analyzed over time in distinct geographic locations in the community.

Radio-telemetering RAE Systems® AreaRAE/AreaRAE Plus units may be deployed in all monitoring plans to allow for continuous air monitoring in multiple areas. AreaRAE/AreaRAE Plus readings may be received and monitored in a centralized location by CTEH® personnel to allow for recognition, communication, and response to changing conditions.

Discrete air samples may be collected in all monitoring areas and sent to an off-site laboratory for chemical analysis. These analytical air sampling techniques may be used to provide air quality data beyond the scope of real-time instruments. When necessary, discrete air samples may be collected to provide air quality data over a period of time for more direct comparison to community exposure standards or guidelines.



#### **CTEH Site-Specific Action Levels**

CTEH site-specific action levels may be employed in all air monitoring plans to provide information for corrective action to limit potential exposures. These values do not replace community exposure standards or guidelines, but are intended to represent a concentration limit that triggers a course of action to better address public safety and community health. Action level exceedances will be communicated to Site Management and the CTEH Project Technical Director by the CTEH Project Manager (PM). Site-Specific Action Levels are not utilized for Site Characterization monitoring.



### **Plan 1: Community Monitoring**

Objective: Report air levels of analytes documented during monitoring efforts

| Analyte             | Action<br>Level      | Action to be Taken  | Basis   | Instrument                  | Detection<br>Limit                    | Notes                                       | Correction<br>Factor |
|---------------------|----------------------|---|---|-----------------------------|---------------------------------------|---|----------------------|
| Total VOCs          | 0.5 ppm<br>5 minutes | Report reading to PM. Assess for the presence of benzene/toluene/hexane, if requested | Approximate background level -<br>Reading sustained for 5 minutes | MultiRAE PID<br>AreaRAE PID | 0.1 ppm                               | Measuring range: 1 – 5,000 ppm              | NA                   |
| Naphtha             | Detection            | Sample only as requested,<br>Report reading to PM                                     | Inform PM/PTD of potential off-<br>site issues                    | Gastec tube #106            | 0.1 ppm                               | Measuring range: 0.5 – 28 ppm               | Var.                 |
| Naphthalene         | Detection            | Sample only as requested,<br>Report reading to PM                                     | Inform PM/PTD of potential off-<br>site issues                    | Gastec tube<br>#60          | 0.5 ppm                               | Range: 0.5 to 14<br>Volume: 200 mL          | Var.                 |
|                     |                      | Sample only as requested,   | s requested, Inform PM/PTD of potential off-                      | 0.05 ppm                    | UltraRAE - Change SEP tube frequently | NA  |                      |
| Benzene             | Detection            | Report reading to PM  |   | Gastec tube #121L           | 0.05 ppm                              | Range: 0.1 – 65 ppm<br>Volume: Variable     | Var.                 |
| Toluene             | Detection            | Sample only as requested,<br>Report reading to PM                                     | Inform PM/PTD of potential off-<br>site issues                    | Gastec tube #122L           | 0.5 ppm                               | Range: 1 – 100 ppm<br>Volume: Variable      | Var.                 |
| Hexane              | Detection            | Sample only as requested,<br>Report reading to PM                                     | Inform PM/PTD of potential off-<br>site issues                    | Gastec tube #102L           | 1 ppm                                 | Range: 4 – 1,200 ppm<br>Volume: Variable    | Var.                 |
|                     |                      |   |   | MultiRAE Sensor             | 1 ppm                                 | MultiRAE - Measuring<br>range: 0 – 100 ppm  | NA                   |
| Hydrogen<br>sulfide | Detection            | Exit Area, report reading to PM   | Inform PM/PTD of potential offsite issues                         | MultiRAE Pro<br>Sensor      | 0.1 ppm                               | MultiRAE Pro - Measuring range: 0 – 100 ppm | NA                   |
|                     |                      |   |   | Gastec tube #4LL            | 0.1 ppm                               | Range: 0.25 to 120<br>Volume: Variable      | Var.                 |
| V. dana             | Datastia             | etection Report Reading to PM   | Inform PM/PTD of potential offsite issues                         | Gastec tube #123            | 1 ppm                                 | Measuring range: 5 – 625 ppm                | Var.                 |
| Xylene              | Detection            |   |   | Gastec tube #123L           | 1 ppm                                 | Measuring range: 2 – 200 ppm                | Var.                 |



| Combustion Products  |                                    |   |  |                  |                         |  |                      |
|--|------------------------------------|---|--|------------------|-------------------------|--|----------------------|
| Analyte  | Action<br>Level                    | Action to be Taken                                | Basis  | Instrument       | Detection<br>Limit      | Notes  | Correction<br>Factor |
| Particulate<br>Matter (PM <sub>2.5</sub><br>or PM <sub>10</sub> )* | 138<br>μg/m³<br>Sustained<br>5 min | Report reading to PM                              | Wildfire Smoke Guidelines for 1 hr.<br>avg. upper-bound breakpoint for<br>unhealthy for sensitive groups AQI | SidePak AM510    | 0.001 mg/m <sup>3</sup> | PM <sub>2.5</sub> impactor –<br>50% cut-off at 2.5<br>micron PM <sub>10</sub><br>impactor – 50% cut-<br>off at 10 micron | NA                   |
| PM <sub>2.5</sub> or PM <sub>10</sub>                              | 79 μg/m³<br>8 hr.                  | Report reading to PM                              | See above - 8 hr. guideline  | SidePak AM510    | 0.001 mg/m <sup>3</sup> | See above  | NA                   |
|  | 25 ppm<br>5 min                    |   | MultiRAE Sensor 1 ppm  | 1 ppm            | Range: 0 – 500 ppm      | NA   |                      |
|  |                                    | Report reading to PM                              | ½ TEEL-O. Inform PM/PTD of potential off-site issues   | Gastec tube #1LC | 0.5 ppm                 | Range: 1 – 30 ppm<br>Volume: 100 mL  | 1                    |
|  | 0.2 ppm<br>Re<br>5 min             | Report reading to PM                              | AEGL-1 Value. Inform PM/PTD of potential off-site issues   | MultiRAE Sensor  | 0.1 ppm                 | Range: 0 – 20 ppm  | NA                   |
| Sulfur dioxide   |                                    |   |  | Gastec tube #5Lb | 0.05 ppm                | Range: 0.05 – 10<br>ppm Volume:<br>Var.  | Var.                 |
|  |                                    |   |  | MultiRAE PID     | 1 ppm                   | Measuring range: 1<br>– 5,000 ppm  | 16                   |
| Nitrogen   | 0.5 ppm                            | Report reading to PM                              | PAC-1 Value (based on 60m AEGL). Inform PM/PTD of potential off-site   | MultiRAE Sensor  | 0.1 ppm                 | Range: 0 – 20 ppm  | NA                   |
| dioxide  | 5 min                              | 5 min '   | issues   | Gastec tube #9L  | 0.1 ppm                 | Range: 0.5 – 125<br>ppm<br>Volume: Var.  | Var.                 |
| Formaldehyde   | Detection                          | Sample only as requested,<br>Report reading to PM | Inform PM/PTD of potential off-site issues   | Gastec tube #91L | 0.05 ppm                | Range: 0.1 – 40<br>ppm<br>Volume: Var.   | Var.                 |

<sup>\*</sup>PM<sub>2.5</sub> is especially prone to interference from high humidity, in cases of high humidity, PM<sub>10</sub> impactors may be used which are not as sensitive to humidity. In general, correction factors may be used to adjust PM readings for humidity. Monitoring for combustion products may be discontinued when the fire is extinguished.



| Flamma  | Flammability    |                                  |                    |                              |                              |                              |                           |                           |      |
|---------|-----------------|----------------------------------|--------------------|------------------------------|------------------------------|------------------------------|---------------------------|---------------------------|------|
| Analyte | Action<br>Level | Corrected<br>Value               | Action to be Taken | Basis                        | Instrument                   | Detection<br>Limit           | Notes                     | Correction<br>Factor      |      |
| LEL     | 1 %             | 2 5 %                            | 2.5 %              | Notify PM                    | Elevated LEL sustained 1 min | MultiRAE Sensor              | 1 %                       | Measuring range: 1 – 100% | 2.5* |
|         | 1 min           | 2.5 /0                           | Notify 1 Wi        | Elevated EEE sustained 1 min | AreaRAE Sensor               | 1 70                         | Wicasaring range. 1 100/0 | 2.5                       |      |
| LEL     | 1 4% 10         | 4 % 10 % Exit area and Notify PM |                    | MultiRAE Sensor              | 1 %                          | Measuring range: 1 – 100%    | 2.5*                      |                           |      |
| LLL     | 4 /0            |                                  |                    | AreaRAE Sensor               | 1 /0                         | ivicasuring range. 1 – 100/0 | 2.5                       |                           |      |

<sup>\*</sup>Rough estimate based on common crude oil volatiles.

### Plan 2: Site Assessment

Objective: Characterize nature and extent of release

| Analyte     | Action<br>Level   | Action to be Taken         | Basis | Instrument                  | Detection Limit | Notes                                   | Correction Factor |
|-------------|-------------------|----------------------------|-------|-----------------------------|-----------------|---|-------------------|
| Total VOCs  | NA                | Report reading to PM       | NA    | MultiRAE PID<br>AreaRAE PID | 0.1 ppm         | Measuring range: 1 – 5,000 ppm          | NA                |
| Naphtha     | NA                | Report reading to PM       | NA    | Gastec tube #106            | 0.1 ppm         | Measuring range: 0.5 – 28 ppm           | Var.              |
| Naphthalene | NA                | Report reading to PM       | NA    | Gastec tube #60             | 0.5 ppm         | Range: 0.5 to 14 ppm                    | Var.              |
| Ponzono     | NA                | NA Report reading to PM    | NA    | UltraRAE PID                | 0.05 ppm        | UltraRAE - Change SEP tube frequently   | NA                |
| Benzene     |                   |                            | IVA   | Gastec tube #121L           | 0.05 ppm        | Range: 0.1 – 65 ppm Volume: Variable    | Var.              |
| Toluene     | NA                | Report reading to PM       | NA    | Gastec tube #122L           | 0.5 ppm         | Range: 1 – 100 ppm Volume: Variable     | Var.              |
| Hexane      | NA                | Report reading to PM       | NA    | Gastec tube #102L           | 1 ppm           | Range: 4 – 1,200 ppm Volume: Variable   | Var.              |
|             |                   |                            |       | MultiRAE Sensor             | 1 ppm           | Measuring range: 0 – 100 ppm            | NA                |
| Hydrogen    | NA Report reading | Papart roading to DNA      | NA    | MultiRAE Pro Sensor         | 0.1 ppm         | Measuring range: 0 – 100 ppm            | NA                |
| Sulfide     |                   | Report reading to Pivi     |       | MultiRAE PID                | 0.1 ppm         | Measuring range: 0 – 5,000 ppm          | 3.3               |
|             |                   |                            |       | Gastec tube #4LL            | 0.1 ppm         | Range: 0.25 to 2.5 ppm Volume: 1,000 mL | Var.              |
| Xylene      | NA                | NA Report reading to PM NA | NIA   | Gastec tube #123            | 1 ppm           | Measuring range: 5 – 625 ppm            | Var.              |
|             |                   |                            | INA   | Gastec tube #123L           | 1 ppm           | Measuring range: 2 – 200 ppm            | Var.              |



| Analytical Methods              |                                    |                          |       |  |  |  |
|---------------------------------|------------------------------------|--------------------------|-------|--|--|--|
| Analyte                         | Media/Can                          | Method                   | Notes |  |  |  |
| VOCs                            | MiniCans (1L)                      | EPA TO-15 with TICs      |       |  |  |  |
| Benzene                         | Charcoal tube                      | NIOSH 1501               |       |  |  |  |
| BTEX (+Hexane)                  | 3M 3520 Badge or Assay 566         | Modified NIOSH 1500/1501 |       |  |  |  |
| PAHs (18 PNAH Profile - Galson) | 37PTFE 2.0/Treated Amberlite XAD-2 | Method 5506              |       |  |  |  |



### **General Information on Procedures (Assessment Techniques) Used**

| Procedure                               | Description   |
|---|---|
| Guardian Network                        | A Guardian network may be established with AreaRAEs equipped with electrochemical sensors at locations around the work zone perimeter. The AreaRAEs will be telemetering instantaneous data at 15-second intervals to a computer console. MultiRAE Pros may also be used in the network. The data will be visible in real-time at the computer console and will be monitored 24 hours per day by CTEH personnel.  |
| Real-Time Handheld<br>Survey            | CTEH staff members may utilize handheld instruments (e.g. MultiRAE Plus; ppbRAE, Gastec colorimetric detector tubes, etc.) to measure airborne chemical concentrations. CTEH will use these handheld instruments primarily to monitor the ambient air quality at breathing zone level.  Additionally, measurements may be made at grade level, as well as in elevated workspaces, as indicated by chemical properties or site conditions.  CTEH may also use these techniques to verify detections observed by the AreaRAE network. |
| Fixed Real-Time<br>Monitoring locations | Multiple Community locations may be identified and monitored at the same location approximately once per hour using handheld instruments.  This allows the use of statistical analysis more effectively than with a random approach.  |
| Analytical sampling                     | Analytical sampling may be used to validate the fixed and handheld real-time monitoring data, or to provide data beyond the scope of the real-time instruments. Analytical samples may be collected as whole air samples in evacuated canisters or on specific collection media, and sent to an off-site laboratory for further chemical analysis.  |
| Particulate Monitoring<br>Network       | A network of data-logging particulate monitors may be set up and positioned around the Community.   |



### **Quality Assurance/Quality Control Procedures**

| Method     | Procedure   |
|------------|---|
| Real-Time  | Real-time instruments may be calibrated in excess of the manufacturer's recommendations.  At a minimum whenever indicated by site conditions or instrument readings.  Co-located sampling for analytical analysis may be conducted, if necessary, to assess accuracy and precision in the field.  Lot numbers and expiration dates may be recorded with use of Gastec colorimetric tubes. |
| Analytical | Chain of custody documents may be completed for each sample.  Level IV data validation may be performed on the first sample group analyzed.  Level II data validation may be performed on 20% of all samples.  Level IV data validation may be performed on 10% of all samples.   |
| Reporting  | Daily data summaries may be provided for informational purposes using data that have not undergone complete QA/QC.  Comprehensive reports of real-time and/or analytical data may be generated following QA/QC and may be delivered 60 days following receipt of validated results, if applicable.  |

### Glossary

| Term            | Definition   |
|-----------------|--|
| Sustained       | Instrument reading above the action level continuously for the listed time period.   |
| Excursion Limit | Whenever a reading exceeds an ACGIH® TLV by 5 times (if the chemical does not have a STEL- or Ceiling-based action level), exit the area and notify the PM |
| Breathing zone  | The area within an approximate 10-inch radius of an individual's nose and mouth.   |
| Ambient Air     | That portion of the atmosphere (indoor or outdoor) to which workers and the general public have access.  |



| In the section titled:         |                   |           |             |  |  |  |
|--------------------------------|-------------------|-----------|-------------|--|--|--|
|                                |                   |           |             |  |  |  |
|                                | Name/Organization | Signature | Date Signed |  |  |  |
| Prepared by:                   |                   |           |             |  |  |  |
| Review by:                     |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Change from version 1.1 to 1.2 |                   |           |             |  |  |  |
| In the section titled:         |                   |           |             |  |  |  |
|                                |                   |           |             |  |  |  |
|                                | Name/Organization | Signature | Date Signed |  |  |  |
| Prepared by:                   |                   |           |             |  |  |  |
| Review by:                     |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |
| Approved by:                   |                   |           |             |  |  |  |



Change from version 1.0 to 1.1