



**Fw: West Lake Landfill: analytical methods for isotopic Ra, Th, U in groundwater**

Barry Evans to: Dan Gravatt

06/07/2012 10:50 AM

Dan,

How do you want to proceed since it sounds like the methods are different?

Barry

----- Forwarded by Barry Evans/R7/USEPA/US on 06/07/2012 10:47 AM -----

From: Cindy White/MTG/USEPA/US  
To: Barry Evans/R7/USEPA/US@EPA  
Cc: Dan Gravatt/R7/USEPA/US@EPA  
Date: 06/07/2012 10:45 AM  
Subject: Re: Fw: West Lake Landfill: analytical methods for isotopic Ra, Th, U in groundwater

---

Barry,

Our methods are as follows:

Uranium/Thorium: **NAREL-U-Eichrom** and **NAREL-Th-Eichrom** --- extraction chromatography methods with counting by alpha spectroscopy. I'm not sure how these compare to NAS NS3004 and NAS NS3050. I'm not familiar with those method names, but if I google them, it looks like they are fluorometric methods. Confirm with the other lab.

Radium-226: **NAREL-Ra226-Eichrom** --- extraction chromatography with counting by alpha spectroscopy. This is different from the EPA 903.1 which is radon emanation method.

Radium-228: **NAREL-Ra-05** --- which is similar to the EPA 904.0 method.

If you think our methods are comparable and you want us to do the work, please complete the attached *Project Request Form* and return to me for approvals.



NAREL ANALYTICAL REQUEST FORM 11-18-11.doc

Thanks,

Cindy White  
Analytical Services Coordinator  
USEPA/NAREL  
540 S. Morris Avenue  
Montgomery, AL 36115  
334-270-7052 Work  
334-270-3454 FAX

Barry Evans

Good Morning Cindy, Below is an email from the...

06/07/2012 09:26:53 AM

From: Barry Evans/R7/USEPA/US

0714

40458419

3.0



Superfund

0401

To: Cindy White/MTG/USEPA/US@EPA  
Cc: Dan Gravatt/R7/USEPA/US@EPA  
Date: 06/07/2012 09:26 AM  
Subject: Fw: West Lake Landfill: analytical methods for isotopic Ra, Th, U in groundwater

---

Good Morning Cindy,

Below is an email from the Project Leader for the radchem project we have been discussing. They would like to use methods comparable to the PRP lab since EPA is taking splits and having them analyzed (by NAREL). Do the radchem method references below mean anything to you? If you are familiar with them, are they comparable to the methods that your lab will utilize? Please advise.

Regards,  
Barry

----- Forwarded by Barry Evans/R7/USEPA/US on 06/07/2012 09:22 AM -----

From: Dan Gravatt/R7/USEPA/US  
To: Barry Evans/R7/USEPA/US@EPA  
Date: 06/06/2012 10:15 AM  
Subject: Fw: West Lake Landfill: analytical methods for isotopic Ra, Th, U in groundwater

---

Barry, this is what I got back from the PRP's contractor on the analytical methods they intend to use at my Westlake site where I'll be splitting samples. Are these method designations for Ra, Th, U something NAREL would be familiar with? I've never heard of the NAS methods...

Thanks,  
Daniel R. Gravatt, PG  
US EPA Region 7 SUPR / MOKS  
901 North 5th Street, Kansas City, KS 66101  
Phone (913) 551-7324 Fax (913) 551-7063

Principles and integrity are expensive, but they are among the very few things worth having.

----- Forwarded by Dan Gravatt/R7/USEPA/US on 06/06/2012 10:13 AM -----

From: "Paul Rosasco" <paulrosasco@emsidenver.com>  
To: Dan Gravatt/R7/USEPA/US@EPA  
Date: 06/06/2012 10:11 AM  
Subject: RE: West Lake Landfill: analytical methods for isotopic Ra, Th, U in groundwater

---

The analytical methods that we currently anticipate using are listed below. I may not have the most current alphanumeric designation ("B" or "C") for the semivolatile method.

Analytes	Analytical Method
Thorium isotopes	NAS NS-3004
Uranium isotopes	NAS NS-3050
Radium-226	EPA 903.1

Radium-228	EPA 904.0

**From:** Dan Gravatt [mailto:Gravatt.Dan@epamail.epa.gov]

**Sent:** Monday, June 04, 2012 3:12 PM

**To:** Paul Rosasco

**Subject:** West Lake Landfill: analytical methods for isotopic Ra, Th, U in groundwater

Paul,

I am trying to put together analytical services to do splits of some groundwater samples for the upcoming groundwater sampling event. My lab folks think they have identified an internal EPA lab that can do the work, but I want to make sure they are using similar or identical methodology to your lab so the results are truly comparable. Could you give me the analytical method numbers and the analytical method descriptions themselves, if possible, so I can compare to our lab's methods?

Thanks,

Daniel R. Gravatt, PG

US EPA Region 7 SUPR / MOKS

901 North 5th Street, Kansas City, KS 66101

Phone (913) 551-7324 Fax (913) 551-7063

Principles and integrity are expensive, but they are among the very few things worth having.



# NAREL ANALYTICAL REQUEST FORM

This form must be completed at least 14 days before sending any samples to NAREL for analysis. The requester is to complete all fields highlighted in **BLUE** and e-mail the form to Cindy White ([white.cindy@epa.gov](mailto:white.cindy@epa.gov)) along with an electronic copy of the project's QA plan and detailed site and project description.

Requester:		Request Date:	
Title:		Office/Region:	
Address			
Phone:		FAX:	
E-mail:			

## PROJECT INFORMATION

Please provide or attach a detailed site and project description including known or suspected hazards.

Site Name and location:

Site Program Type: ☐ Regional ☐ Superfund ☐ Other

Expected Arrival Date at NAREL:

Number of Samples and Matrices:	Soil	Sediment	Water	Air Filter	Tissue	Other

## PROJECT SPECIFIC REQUIREMENTS

For requirements other than NAREL standards, an Analytical Protocol Specification (APS) form must be completed. (Please see attachments for NAREL standards and the APS form.)

Specialized Handling: ☐ Radiochemicals ☐ Hazardous Chemicals ☐ Biohazards ☐ Other

Sample Preparation: ☐ NAREL Standard ☐ Other

Quality Control: ☐ NAREL Standard ☐ Other

Turnaround Time: ☐ NAREL Standard ☐ Other

Data Reporting: ☐ NAREL Standard ☐ Other

MDCs & RLs: ☐ NAREL Standard ☐ Other

## NAREL ANALYTICAL SERVICES

Analysis	Check to Request	Analysis	Check to Request
Gamma Spectrometry (21 day ingrowth)	<input type="checkbox"/>	Americium	<input type="checkbox"/>
Gamma Spectrometry	<input type="checkbox"/>	Technetium-99	<input type="checkbox"/>
Gross Alpha/Beta	<input type="checkbox"/>	Radium-226 (water only)	<input type="checkbox"/>
Tritium (water only)	<input type="checkbox"/>	Radium-228	<input type="checkbox"/>
Iodine-131 (water only)	<input type="checkbox"/>	Plutonium	<input type="checkbox"/>
Strontium	<input type="checkbox"/>	Neptunium (soil only)	<input type="checkbox"/>
Uranium	<input type="checkbox"/>	Metals	<input type="checkbox"/>
Thorium	<input type="checkbox"/>	Mercury	<input type="checkbox"/>



## ATTACHMENT 1

### NAREL STANDARD SAMPLE PREPARATION

Liquid samples are checked for pH and adjusted if necessary. Otherwise liquid samples are analyzed as received.

Solid samples are dried and ashed for all analyses except gamma which uses the dried portion. If only gamma and gross alpha and beta analyses are requested, then samples are only dried for analysis. Foreign materials such as rocks, sticks, leaves, etc. are removed before ashing.

Filter preparation is based on filter type, size, and requested analysis. Filters may be analyzed as received or may be dissolved prior to analysis.

### NAREL STANDARD QUALITY CONTROL INFORMATION

Standard QC analyses at NAREL are performed on batches of up to 20 samples of similar matrices. The QC analyses include:

Method	Method blank	LCS	Replicates	Matrix spike
Gross $\alpha/\beta$ for air filters			X	
Gross $\alpha/\beta$ for water	X	X	X	X
Gross $\alpha/\beta$ for other matrices	X	X	X	
Gamma-ray spectrometry	X	X	X	
Tritium in water	X	X	X	X
Tritium in other matrices	X	X	X	If there is a chemical separation
Actinides	X	X	X	
Radium-228	X	X	X	X
Strontium	X	X	X	
Iodine-131	X	X	X	
Technetium-99	X	X	X	X
Metals	X	X	X	X
Mercury	X	X	X	X

**Note:** For analyses requiring duplicate (replicate) and matrix spike analyses, a sufficient amount of sample must be received. The sample-duplicate combination and the sample-matrix spike combination can be performed on two different samples, e.g., one will be split and duplicated, the second will be split and spiked, or on one sample if at least three volumes of sample are received.

### NAREL STANDARD TURNAROUND TIMES

Turnaround times are based on the date of receipt of the last sample for the project and are given in weeks.

Method	Solid	Water	Air Filter
Gamma-ray spectrometry	2	2	3
Gross $\alpha/\beta$	3	2	3
Tritium	*	4	*
Iodine-131	*	3	*
Strontium	6	5	6
Actinides	6	6	6
Radium-228	6	6	6
Metals	4	4	*
Mercury	4	4	*

\* Analysis not available

# ATTACHMENT 1

## NAREL STANDARD DATA REPORTING

The NAREL standard data deliverable includes sample and QC results. Results will be reported as pCi/gdry for solids, pCi/L for liquids, and pCi/m<sup>3</sup> for air filters. Results for hazardous waste analyses will be reported as µg/L for liquids and mass/kg for soils. A hard copy of the report will be sent to the requester. (Electronic data deliverables are available upon request.)

## NAREL STANDARD SAMPLE DISPOSAL

Samples will be returned to the requester if NAREL cannot arrange for disposal at a minimal cost.

## NAREL STANDARD MDCs & RLs

Standard MDCs and reporting limits are listed in the tables below. MDCs and Reporting Limits depend on a number of variables including sample size, counting times, instrument backgrounds, matrix interferences, dilutions, etc. The actual MDC and Reporting Limit for each sample will be different from those listed below based on each of these variables.

## RADIOCHEMICAL MDCs

Analysis Type	Drinking Water Aliquot Size	Drinking Water MDC	Water (other) Aliquot Size	Water (other) MDC	Solids Aliquot Size	Solids MDC	Air Aliquot Size	Air MDC
Gross Alpha	500 mL	1.8 pCi/L	200 mL	4.4 pCi/L	0.1 g	8.7 pCi/g		
Gross Beta	500 mL	1.4 pCi/L	200 mL	3.5 pCi/L	0.1 g	7 pCi/g	2500 m <sup>3</sup>	0.0015 pCi/m <sup>3</sup>
Radium-226			1 L	0.02 pCi/L	0.5 g	0.04 pCi/g		
Radium-228			1 L	1 pCi/L	0.5 g	2 pCi/g		
Iodine-131			2 L	0.7 pCi/L				
Strontium-89			2 L	1 pCi/L	0.5 g	4 pCi/g		
Strontium-90			2 L	1 pCi/L	0.5 g	4 pCi/g		
Uranium- 234, 235, 238 Thorium-230, 232 Plutonium-238, 239 Americium-241			1 L	0.1 pCi/L	0.5 g	0.2 pCi/g	60000 m <sup>3</sup>	2 pCi/m <sup>3</sup>
Thorium-227			1 L	0.2 pCi/L	0.5 g	0.35 pCi/g		
Thorium-228			1 L	0.15 pCi/L	0.5 g	0.3 pCi/g		
Tritium			10 mL	0.1 nCi/L				

## Inorganic Metals Reporting Limits

Analyte	Water Reporting Limit	Soil / Sediment Reporting Limit	Analyte	Water Reporting Limit	Soil / Sediment Reporting Limit
Aluminum	200 :g/L	20 mg/kg	Magnesium	5000 :g/L	500 mg/kg
Antimony	60 :g/L	6 mg/kg	Manganese	15 :g/L	1.5 mg/kg
Arsenic	10 :g/L	1 mg/kg	Mercury	0.2 :g/L	0.1 mg/kg
Barium	200 :g/L	20 mg/kg	Nickel	40 :g/L	4 mg/kg
Beryllium	5 :g/L	0.5 mg/kg	Potassium	5000 :g/L	500 mg/kg
Cadmium	5 :g/L	0.5 mg/kg	Selenium	5 :g/L	0.5 mg/kg
Calcium	5000 :g/L	500 mg/kg	Silver	10 :g/L	1 mg/kg
Chromium	10 :g/L	1 mg/kg	Sodium	5000 :g/L	500 mg/kg
Cobalt	50 :g/L	5 mg/kg	Thallium	10 :g/L	1 mg/kg
Copper	25 :g/L	2.5 mg/kg	Vanadium	50 :g/L	5 mg/kg
Iron	100 :g/L	10 mg/kg	Zinc	20 :g/L	2 mg/kg
Lead	3 :g/L	0.3 mg/kg			

**ATTACHMENT 2**  
**Analytical Protocol Specification**  
**(APS)**

Please complete the APS for any project specific requirements where the NAREL standards listed above do not meet those required by the project's QA plan. More than one APS may be necessary to cover all requirements. NAREL will respond if requirements cannot be met by offering alternatives to the requirements which will be described on an Analytical Protocol Specification Alternate Proposal (APSAP) form and attached to the Project Acceptance Form (PAF.). The PAF and any APSAP forms will be sent to the requester for signatures indicating acceptance of the data delivery dates and any proposed alternatives.

Site/Project Name: \_\_\_\_\_

Analyte List: \_\_\_\_\_ Analysis Restrictions: \_\_\_\_\_

Matrix: \_\_\_\_\_ Possible interferences: \_\_\_\_\_

Concentration range: \_\_\_\_\_ Action level: \_\_\_\_\_

**MQOs**

**Analytical QC**

<b>Batch size:</b> <input type="checkbox"/> 20 samples <input type="checkbox"/> Other _____		
<b>QC Sample Type</b>	<b>Frequency</b>	<b>Evaluation Criteria</b>
<input type="checkbox"/> Method blank		
<input type="checkbox"/> Duplicate		
<input type="checkbox"/> Laboratory control sample		
<input type="checkbox"/> Matrix spike		
<input type="checkbox"/> Matrix spike duplicate		

**Analytical Process Requirements**

<b>Activity</b>	<b>Special Requirements</b>
Sample receipt and inspection	
Laboratory sample preparation	
Sample dissolution	
Chemical separations	
Preparing sources for counting	
Nuclear counting	
Data reduction and reporting	
Sample disposal	
Other	

**Turnaround Time Requirements**

<b>Analysis</b>	<b>Special Requirements</b>

Other requirement not listed above: \_\_\_\_\_

Requester's signature: \_\_\_\_\_ Date: \_\_\_\_\_

## **ATTACHMENT 3**

### **NAREL SAMPLE SHIPMENT GUIDELINES**

This document provides guidance in the shipment of environmental samples to NAREL for radiochemical and/or hazardous chemical analyses.

All shipments must comply with the requirements of current DOT regulations. Refer to the DOT Hazardous Materials Regulations contained in Title 49 CFR Subtitle B, Chapter 1, Subchapter C, Parts 171 through 180.

Before collecting samples please refer to the attached table for requested sample sizes, containers and preservatives. For matrices not listed contact the NAREL Analytical Services Coordinator at (334)270-7052.

Before shipping samples, notify the NAREL Analytical Services Coordinator at (334)270-7052 and arrange for sample receipt and subsequent sample return 6 months after results have been reported.

When packing samples for shipment:

- Seal individual samples in plastic bags, preferably ziplock bags.
- Use the correct amount of absorbent material for the volume present. Approved absorbent materials include vermiculite and cat litter.
- The temperature of samples requiring refrigeration during transport **MUST** be maintained at or below 6°C.
- Ice in a sealed plastic bag or reusable ice substitute freeze packs are acceptable cooling media.
- Chain of Custody forms **MUST** be sealed in a large ziplock bag and taped to the inside of the cooler lid.

After samples are packed for shipment, secure the cooler with tape and attach a custody seal across the seam of the cooler lid.

All samples **MUST** be shipped overnight to arrive Monday through Friday. No deliveries are accepted on weekends or Federal holidays.

**Send all samples to:**

**Cindy White  
Analytical Services Coordinator  
National Air and Radiation Environmental Laboratory  
540 South Morris Avenue  
Montgomery, Alabama 36115  
(334) 270-7052**

**ATTACHMENT 4**  
**SAMPLE COLLECTION AND ANALYSIS INFORMATION**

	Water Samples				Soil / Sediment Samples			
Analysis	Collection Volume	Acceptable Containers	Preservative	Holding Times	Collection Volume (g)	Acceptable Containers	Preservative	Holding Times
Metals (except mercury)	600 mL	Polyethylene	HNO <sub>3</sub> to pH <2	6 months	200 g	Polyethylene	Cool to ≤ 6 ° C	6 months
Mercury	400 mL	Polyethylene	HNO <sub>3</sub> to pH <2	28 days	200 g	Polyethylene	Cool to ≤ 6 ° C	28 days
Volatile Organics	2 X 40 mL no headspace	40 mL glass vials w/ Teflon lined caps	pH <2 with H <sub>2</sub> SO <sub>4</sub> , HCl, or solid NaHSO <sub>4</sub> Cool to ≤ 6 ° C	14 days	2 X 5 g	40 mL glass vials with Teflon lined cap	Solid NaHSO <sub>4</sub> Cool to ≤ 6 ° C	14 days
Pesticides & PCBs Semivolatile Organics	2 L	2 X 1 L amber glass container with Teflon lined cap	Cool to ≤ 6 ° C	Samples extracted within 7 days of collection and extracts analyzed within 40 days following extraction	1 full 8 oz glass jar	8 oz glass jar with Teflon lined cap	Cool to ≤ 6 ° C	Samples extracted within 14 days of collection and extracts analyzed within 40 days following extraction
Tritium	200 mL	Glass with Teflon lined caps	None, <b>NO ACID</b>	NA				
Other Radiochemical Analyses	4 L*	Plastic or glass	HNO <sub>3</sub> to pH <2	NA	~ 500 g	Plastic or glass	None	NA

\*Sufficient volume must be provided to allow a dedicated aliquant for gamma analysis.