

Department of Environmental Quality

Northwest Region Portland Office 2020 SW 4th Avenue, Suite 400 Portland, OR 97201-4987 (503) 229-5263 FAX (503) 229-6945 TTY (503) 229-5471

January 29, 2015

Stuart Dearden

Sanofi-Aventis U.S. 55 Corporate Drive Mail Code 55A-300A Bridgewater, NJ 08807

Re: Final Outfall 22B IRAM Performance Monitoring Sampling and Analysis Plan RP-Portland Site ECSI #155

Dear Mr. Dearden:

On November 14, 2014 the Department of Environmental Quality (DEQ) received a letter titled *Re: Response to Comments and Revised Draft Outfall 22B Sampling and Analysis Plan*, prepared by Golder Associates for StarLink Logistics Inc. (StarLink). The letter provided direct responses to DEQ's and EPA's comments on the *Draft Outfall 22B IRAM Performance Monitoring Sampling and Analysis Plan* (SAP) as well as an updated SAP.

In our December 4, 2014 letter to StarLink, DEQ determined that the revised SAP did not fully address DEQ's requested modifications. Therefore, consistent with Section 7.K(4) of the Consent Order, DEQ modified the document as outlined in our letter. DEQ has incorporated these modifications into a final document under DEQ letterhead. A redline version of the *Final Outfall 22B IRAM Performance Monitoring Sampling and Analysis Plan*, which highlights DEQ changes is attached for your records.


DEQ appreciates the effort made by StarLink to submit the *Revised Draft Outfall 22B Sampling and Analysis Plan*. Please feel free to contact me at 503 229-6748 if you have any questions.

Sincerely,

Scott Manzano, Project Manager DEQ NWR Cleanup Program

Attachments: 1. Final Outfall 22B IRAM Performance Monitoring, Sampling and Analysis Plan, Former Rhone-Poulenc – Portland Site

C: Joan Underwood, Quantum Management Group Jim Benedict, Cable, Huston, Benedict, Haagensen & Lloyd Keith Johnson, DEQ Rich Muza, EPA Gary Vrooman, DOJ Natural Resources ECSI #155



Final Outfall 22B E-IRAM IRAM Performance Monitoring, Sampling and Analysis Plan, Former RhonePoulenc – Portland Site

February 2015



Northwest Region Cleanup Section

811 SW 6th Avenue Portland, OR 97204

Phone: (503) 229-5696 (800) 452-4011 Fax: (503) 229-6762

Contact: David Lacey www.oregon.gov/DEQ

DEQ is a leader in restoring, maintaining and enhancing the quality of Oregon's air, land and water.



Last Updated: xx/xx/xx

This report prepared by:

Oregon Department of Environmental Quality 811 SW 6th Avenue Portland, OR 97204 1-800-452-4011 www.oregon.gov/deq

> Contact: David Lacey 503-229-5354

Table of Contents

| 1. | Objective | . 1 |
|----|---|-----|
| | Scope and Methodology | |
| | | |
| | 2.1 Groundwater Level Monitoring | 2 |
| | 2.2 Flow Estimation | 2 |
| | 2.3 Sample Collection | 2 |
| | 2.4 Quality Assurance/Quality Control | 3 |
| 3. | Scheduling, Evaluation and Reporting | .3 |
| | 3.1 Monitoring Schedule | 3 |
| | 3.2 Data Evaluation and Additional Sampling | 3 |
| | 3.3 Reporting | 5 |
| | 4.0 References | |
| | 5. Attachments | 5 |
| | | |

Attachment A: Figure 1 – Outfall 22B Stormwater Sewer System, Lining and Repairs Completed, (showing monitoring locations)

Attachment B:Standard Operating Procedures (SOPs)

Attachment C: Table 1 – List of Analyses, Table 2-Method Detection and Reporting Limits, Table J-1 Revised (4/29/14) Screening Levels for Constituents Detected in Groundwater and Surface Water Samples

Attachment D: Outfall Sampling Worksheet

1. Objective

StarLink Logistics, Inc. (StarLink) completed the work for the Outfall 22B Expanded Interim Remedial Action Measure (E-IRAM). The E-IRAM Work Plan required the submittal of a Sampling and Analysis Plan (SAP) to provide data to evaluate whether the objective of the E-IRAM is achieved. This SAP describes the additional objective for the monitoring program requested by DEQ and describes the monitoring that will collect the data to evaluate the performance of the 22B E-IRAM that repaired the City of Portland (City) Outfall 22B storm sewer system.

The objective of the original work plan for the E-IRAM was to minimize or eliminate discharge of RP related constituents at Outfall 22B. An additional objective is to monitor and assess if the multi-source dry weather discharge from Outfall 22B poses a risk to the river. This SAP provides for observation and sampling of dry weather flow at Outfall 22B, observation and measurement of dry weather flow in manholes along the NW Front Avenue and collection of groundwater level measurements in selected monitoring wells within the Outfall 22B basin.

The Outfall 22B IRAM and Outfall 22B Expanded IRAM were implemented to address exceedances of JSCS SLVs for numerous Rhone Poulenc contaminants of interest in dry weather flow discharging from within the outfall piping and from water discharging outside the outfall piping. The objective of the performance monitoring is to demonstrate that the Outfall 22B stormwater system pathway is adequately addressed and does not pose an unacceptable risk to the river. Protectiveness will be assessed as follows:

- 1. Determine if dry weather flow is present
- 2. Determine if contaminants exceed JSCS SLVs
- 3. Evaluate if exceedances pose an unacceptable risk to the river
- 4. Determine if additional actions are needed.

2. Scope and Methodology

The Outfall 22B stormwater system consists of a City storm sewer along NW Front Avenue that discharges to the river upstream of the BNSF railroad bridge. Private laterals connect to the Outfall 22B stormwater system from Metro, MMGL (formerly Schnitzer)/Air-Liquide, Gould, and previously Arkema. The total length of the City and private Outfall 22B storm sewer is approximately 8,000 linear feet (see Figures 1 through 3 in AMEC 2009a).

Dry weather observations and if possible, flow measurements, will occur between City manhole MH-10 and Outfall 22B (Attachment A: Figure 1). Sampling will occur at the outfall. Monitoring will include measuring dry weather flow and sampling the Outfall 22B discharge. Groundwater levels will be measured at select wells adjacent to NW Front Avenue and on Metro property. Water level measurements will be compared to 22B pipe invert elevations and dry weather flow observations and measurements to evaluate whether groundwater levels influence the quantity and quality of dry weather flow.

Dry weather monitoring will be conducted at least 72 hours after a precipitation event. A precipitation event is measureable precipitation. The nearest rain gauge data (NW Yeon Avenue) will be evaluated to predict a 72-hour dry period to target for sampling. Seepage, if any, observed around the outfall discharge downstream from MH-3 will be photographed, documented in the field notes and in the quarterly or annual reports (per Section 3.0). If seepage is observed, sampling will be attempted.

Video logging will be completed every five years after the expiration of the installation contractor's guarantee period for the E IRAM the first monitoring event until the Record of Decision (ROD) is issued for the site.

2.1 Groundwater Level Monitoring

Manual water level measurements will be recorded at shallow monitoring wells W-03-S, W-04-S, W-11-S, W-16-S, MW-15(S)-14 and ASW-05 shown in Figure 1 (Attachment A). Access to monitoring wells will be confirmed at least 30 days prior to a scheduled monitoring event. StarLink will request a waiver from the DEQ project manager from the requirement to monitor the well(s) for which no access has been granted. Field procedures for manual water level measurements are provided in Attachment B.

2.2 Flow Estimation

General observations of dry weather flow and flow measurements will be recorded in the field notes at City manholes MH-10, MH-9, MH-8, MH-7, MH-6, MH-4, and MH-3 and at Outfall 22B. Manhole MH-5 will not be monitored as the orientation of the structure is such that the manhole is not directly over the flow channel, making observations and measurements unfeasible. Approximate flow velocity will be measured with a Marsh McBirney flow meter or suitable area-velocity measuring device. Flow depth and width will be measured manually in the main flow channel of each manhole. Flow rate at each manhole will be estimated by manual measurement of flow depth, pipe diameter and flow velocity using the flow meter following by calculation of flow rate using standard conduit flow rate calculations. Discharge rate at the outfall will be measured with the flow meter. A bucket and stopwatch will be used if there is insufficient flow to use the flow meter.

2.3 Sample Collection

One water quality sample and one field replicate will be collected of Outfall 22B discharge during each monitoring event, if discharge is present. The sample will be collected following methodology described in Surface Water Sampling SOP-10 (Attachment B) and submitted for laboratory analysis of the constituent groups and analyses listed in Table 1 (Attachment C). Sampling will only be conducted when the outfall is clear of debris, sufficient free-flowing discharge can be sampled during the sample event and turbidity at the time of sampling is less than 10 ntu (to prevent collection of dislodged sediment within the conveyance system). Sampling will be conducted when the outfall is clear of debris and sufficient free-flowing discharge can be sampled during each event. If equipment is necessary to clear the debris, StarLink will work with the City and DEQ to determine how to clear the debris and timing. Outfall clearance will be confirmed by StarLink one month prior to planned sampling.

The small distance (approximately 1") between the lip of the outfall and the receiving concrete swale and the low flow rate expected to be encountered at the time of sampling does not allow for typical sized sample containers to be lowered directly into the flow for sampling. Samples will be collected by lowering a disposable, clean, widemouth glass jar (dipper) into the outfall discharge and filling the dipper as practicable. The sample will then be transferred to the respective unpreserved or preserved sample containers with care and minimal sample disturbance. Dissolved metals samples will be collected using a peristaltic pump and clean tubing to transfer the sample from the dipper through a clean, disposable 0.45 micron filter to the appropriate sample container.

Sample containers will be labeled with sample identification, time, and date. An outfall sampling worksheet will be completed at the time of sampling (Attachment D). Samples will be packaged for shipment in a cooler with ice and be accompanied by a chain-of-custody tracking form. A trip blank will also be stored and transported in the cooler containing samples collected for VOC analysis per Table 1 (Attachment C). Samples will be delivered directly under chain-of-custody to a qualified laboratory or their representative within applicable holding times.

Water quality parameters including pH, specific conductance, dissolved oxygen, oxidation-reduction potential, temperature, and turbidity will be measured in the field upon completion of sample collection. If flow is not deep enough to lower the multi-parameter probe directly into the flow, outfall discharge will be collected and measured in a dipper.

Decontamination of monitoring and sampling equipment will be conducted per SOP-3 (Attachment B). Waste generated during sampling and monitoring activities will be handled and documented as described in SOP-13 (Attachment B).

Samples at individual manholes may be taken depending on sampling results and data evaluation as described in Section 3.2. SOP-10 (Attachment B) provides a description of sampling procedures in manholes.

2.4 Quality Assurance/Quality Control

Sample integrity and quality control will be maintained and met by following the Quality Assurance Project Plan 2009 Update (QAPP) produced by AMEC Earth & Environmental, Inc. for the RP – Portland Site and submitted to DEQ on September 16, 2009 (AMEC 2009b).

Field quality control sample collection and analysis will include the following:

- Trip blanks one trip blank per cooler containing VOC samples
- Rinsate blanks one per day per matrix when non-dedicated equipment is used and one per bath of in-line water filters (inorganics only)
- Field replicate one field replicate for all parameters per sample event
- MS/MSD sufficient sample will be collected for the laboratory to run MS/MSD analyses within the sample batch

Requirements for sample containers, volumes, preservation, and hold times are included in Table 4 of the QAPP (AMEC 2009b). Method detection and reporting limits are provided in Attachment C – Table 2.

Field water quality meters will be calibrated at the beginning of the day and results will be documented in the field logbook. Observation of field conditions will be collected during the monitoring event.

3. Scheduling, Evaluation and Reporting

3.1 Monitoring Schedule

Dry weather monitoring will be conducted quarterly during the first two years and annually thereafter until the ROD is issued for the site. The search for a dry weather flow sampling period will begin once 1) the SAP is approved, 2) a City permit has been obtained and 3) access agreements (dependent on an approved work plan) are in-place or a waiver for monitoring is obtained from DEQ if access agreements have not been obtained. The first month of each quarter will be targeted for sampling but will be dependent on observation of a 72-hour dry period prior to initiating sampling. Annual monitoring will be conducted in the spring of each year (March through May) to reflect high groundwater conditions, so that the targeted quarterly monitoring months will be January, April, July and October and the targeted annual monitoring month will be April.

DEQ will be notified one week before observation for a 72-hour dry period begins. Since sampling requires a minimum 72-hour dry period prior to each monitoring event, scheduled sampling will also be confirmed with DEQ the day prior to the anticipated sampling. However, if no 72-hour dry period occurs during the quarter, the monitoring will be conducted after the first available 72-hour dry period after the quarter.

3.2 Data Evaluation and Additional Sampling

Data evaluations described below will be conducted after receipt and validation of laboratory analytical results.

- Groundwater elevation data will be tabulated and compared to historical elevation data and to the nearest pipe invert elevations to assess sewer line sections that are below the water table
- Dry weather analytical results will be compared to the following:

Final Outfall 22B IRAM Performance Monitoring, Sampling and Analysis Plan

- SLVs (see Attachment C Table J-1)
- Historical (i.e., pre-IRAM) dry-weather (non-stormwater) analytical results for samples collected from Outfall 22B
- Other data sets as appropriate, including but not limited to historical stormwater and nonstormwater analytical results for nearby properties and sites
- Groundwater analytical data

Detection of one or more constituents at concentrations above SLVs in dry-weather flow samples does not mean that the discharge of dry-weather flow to the river causes or contributes to unacceptable risk to human health or the environment. Consistent with DEQ guidance (DEQ, 2010), other lines of evidence may be used to evaluate whether detected constituent concentrations above SLVs, if any, pose an unacceptable risk to human health and the environment. Other lines of evidence may include, but not be limited to, discharge volume, constituent concentration and initial dilution and mixing in the receiving stream and the potential for recontamination based on the presence of sediment in the discharge.

If one or more <u>organic</u> constituents are detected at a concentration above their respective SLV and it is identified as posing an unacceptable risk to human health and the environment, and the source of the constituent(s) cannot be identified through the evaluations described above, additional sampling, including, but not limited to sampling at individual manholes MH-10, MH-9, MH-8, MH-7, MH-6, MH-5, MH-4, MH-3, and Manhole 9 on Metro property, may be will be required. Additional sampling may be proposed by StarLink. Sampling will be conducted at individual manholes if the following conditions are met:

- Dry-weather sampling conditions are met (72-hour period of no detectable precipitation) and
- Sufficient flow is present at manholes MH-10, MH-9, MH-8, MH-7, MH-6, MH-5, MH-4 and MH-3 as well as Manhole 9 on Metro property, in order to obtain representative samples for the target analytical suites (where SLVs are exceeded).

Performance of the IRAM will be based on the full suite of analytes as presented in Attachment A Table 1 of the SAP. StarLink may request a reduction in the suite of analytes based on the results of the first two years of monitoring.

There are multiple potential third-party sources of constituents to Outfall 22B that can impact dry-weather flow sampling results including non-stormwater, stormwater and sediment carried with stormwater or groundwater flow from:

- Arkema
- NL/Gould
- MMGL (formerly Schnitzer)/Air Liquide
- ESCO
- Metro
- BNSF
- Dredge spoils placed near and adjacent to Outfall 22B prior to and during the construction of Outfall 22B
- Urban run-off from Highway 30, North Front Avenue, and other areas
- Precipitation

Past monitoring has not identified the source of flow, sediments or observed constituent impacts within the Outfall 22B storm sewer. Determining the source of any constituents detected in dry weather (non-stormwater) samples collected from the Outfall 22B storm sewer may not be possible, even with additional sampling at individual manholes.

3.3 Reporting

A performance monitoring report will be prepared within 30 days of the monitoring event (if no samples were collected) or within 30 days from receipt of laboratory data if samples were collected and analyzed. The report will be stamped by a licensed professional and will include the following information:

- Introduction/Background
- Summary of monitoring event actions including precipitation information to document conditions prior to a monitoring event
- Summary of field observations
- Deviations from the SAP
- Summary tables of validated analytical results with comparison to site-specific SLVs other data sets as described in Section 3.2
- Field notes (provided in an attachment)
- Laboratory data sheets (provided in an attachment)
- Analytical data validation report (provided in an attachment)
- Comparison of observed groundwater levels to invert elevations (Table 16, AMEC, 2008) with the inclusion of Metro stormwater system invert elevations near monitoring wells W-15-S(15) and ASW-05.
- An evaluation and conclusion on whether the dry weather discharge poses a risk to the river and
 a recommendation on whether manhole sampling is proposed if a constituent is above a sitespecific SLV. Conclusions/Recommendations regarding the adequacy of the IRAM in eliminating
 the Basin 22B groundwater infiltration pathway, and if additional work/repair is needed at the
 time of the report.

At the completion of the two-year period of quarterly monitoring events a report will be prepared including an evaluation of data trends, conclusions, and recommendations regarding the performance of the E-IRAM IRAM.

4.0 References

- AMEC 2008. Outfall 22B Interim Remedial Action Measure Technical Memorandum RP-Portland Site. Submitted to the Oregon Department of Environmental Quality. Prepared for SLLI. May 1, 2008.
- AMEC 2009a. Draft Outfall 22B Expanded Interim Remedial Action Measure Work Plan RP Portland Site. Submitted to the Oregon Department of Environmental Quality. Prepared for SLLI. April 6, 2009.
- AMEC 2009b. Quality Assurance Project Plan 2009 Update Remedial Investigation Activities RP Portland Site. Submitted to the Oregon Department of Environmental Quality. Prepared for SLLI. September 16, 2009.
- DEQ 2010, Guidance for Evaluating the Stormwater Pathway at Upland Sites. Oregon Department of Environmental Quality, Environmental Cleanup Program, Portland, Oregon. Updated October 2010.

5. Attachments

The following are included as attachments to this SAP.

Attachment A: Figure 1 - Outfall 22B Storm Sewer System, Lining and Repairs Completed,

(showing monitoring locations)

Attachment B: Standard Operating Procedures (SOPs)

Attachment C: Table 1 – List of Analyses


Final Outfall 22B IRAM Performance Monitoring, Sampling and Analysis Plan

Table 2 – Method Detection and Reporting Limits

Table J-1 – TABLE J-1 REVISED (4/29/14) Screening Level Values for Constituents Detected in Groundwater and Surface Water Samples

Attachment D: Outfall Sampling Worksheet

ATTACHMENT A FIGURE



ATTACHMENT B
STANDARD OPERATING PROCEDURES (SOPs)

METHODOLOGY FOR WATER LEVEL DETERMINATION

1.0 PURPOSE

Depth to water measurements are used to compute groundwater elevations. Water levels may be collected manually with an electronic water level probe or automatically with a pressure transducer and associated datalogger. This standard operating procedure (SOP) is specific to manual water level determination. Manual water level readings are the most common type of water level determination. Generally, this method is used if continuous water level data are not required, and at wells where non-aqueous phase liquid (NAPL) is suspected or present.

2.0 EQUIPMENT LIST

- 1) Photo-ionization detector (PID) for environmental sites
- 2) Well lock keys
- 3) Blank Water Level and NAPL Thickness Measurement Form, other site-specific form, and/or field logbook with indelible pens
- 4) Electronic water level probe
- 5) If NAPL is expected, interface probe and check-valve Teflon bailer with new cord
- 6) Knife or scissors
- 7) Decontamination equipment (see SOP 3 Decontamination Procedure and sampling plan for additional site-specific requirements)
- 8) Site map and site health and safety plan (HASP)
- 9) PPE appropriate for site (see HASP if applicable)

3.0 PROCEDURE

Depth to groundwater and total well depth measurements will be made with an electronic well sounding (water level) probe. This probe is capable of measuring the depth from the top of the well casing to the nearest 0.01 foot.

- 1) Measurements are taken from cleanest to most heavily impacted wells, based on historic data where available.
- Check well for security damage or evidence of tampering and record pertinent observations. Note any maintenance tasks that should be completed, such as well cap or padlock replacement.

- 3) Unlock and remove the cap from the well casing, allowing the pressure to equalize in well.
- 4) At sites with suspected environmental contamination, after removing the well cap immediately measure the air space in the well bore for the presence of volatile organic compound (VOC) vapors using a PID. The PID reading will aid in the determination of the appropriate level of personal protective equipment (PPE) at each well.
- 5) For wells where NAPL is not suspected, the water level probe sensor head is lowered into the well opening until an auditory or visual signal is obtained. The sensor is slightly raised and lowered to determine the strongest signal, indicating the top of the water level surface in the well casing. For wells where NAPL is suspected, use an interface probe and follow probe instructions to determine the type of signal for water versus product.
- 6) The measurement is read off the tape at the point that corresponds to the survey mark on top of the well casing and recorded on the Water Level and NAPL Thickness Measurement Form, other site-specific form, or the field logbook to nearest the 0.01 foot. The depth to fluid is measured from an established point on the well casing and is later subtracted from the elevation of that mark to calculate groundwater (or product) elevation at the well location. Record both depth to NAPL and depth to water, where applicable.
- 7) Measure a total depth of the well to the nearest 0.1-foot. If the well is deeper than 100 feet (the typical length of water level probes), a weighted tape may be used to determine total well depth. If free-phase product is suspected, use the interface probe to check for the possible presence of dense NAPL (DNAPL) near the well bottom.
- 8) Decontaminate the exposed tape and water level or interface probe sensor head prior to rolling it onto the equipment reel.
- 9) For wells with known NAPL or where evidence of NAPL is observed on the water level probe, a disposable, weighted bailer will be used to determine whether NAPL is present. If present, visually examine the NAPL for color, background odor, evidence of NAPL product sheen or droplets, etc. Record these observations and a NAPL thickness corresponding to the thickness observed in the bailer on the Water Level and NAPL Thickness Measurement Form, other site-specific form, or field logbook.
- 10) Contain and dispose of PPE, bailer and cord (if used), and decontamination water according to site-specific requirements.

RP - PORTLAND SITE SOP - 3 DECONTAMINATION PROCEDURE

1.0 PURPOSE

Decontamination of non-disposable equipment is performed at sites where environmental contamination is known or suspected. This is done to minimize the potential for cross-contamination between sampling locations (potentially resulting in unrepresentative samples and/or causing the spread of contamination) and also to protect human health and safety.

2.0 EQUIPMENT LIST

- 1) Deionized water
- 2) Plastic buckets
- 3) Spray bottles
- 4) Disposable rags or paper towels
- 5) Alconox, methanol, hexane
- 6) Potable water (can be replaced by deionized water)
- 7) Site map and site health and safety plan (HASP)
- 8) PPE appropriate for site (see HASP if applicable)

3.0 PROCEDURE

Sampling equipment (e.g., water samplers, flow cells, pumps, water level meter, etc.) will be decontaminated as follows:

- 1) Soap wash (dilute solution of Alconox or equivalent in potable water solution);
- 2) Potable water rinse;
- 3) Solvent rinse (methanol, hexane, or similar); and
- 4) Distilled/deionized water rinse.

If non-aqueous-phase liquid (NAPL) is encountered, probes and sounding tape will be wiped with a solvent-soaked towel during retrieval, and the equipment will be decontaminated with a solvent rinse as described above. For locations with NAPL or suspected NAPL, the sampling equipment used will be washed with hexane prior to the soap wash.

Decontamination fluids will be stored in an appropriately labeled tank and transported from the generation point to the RP wastewater treatment system for discharge in accordance with the NPDES permit modification granted to RP on September 20, 1999. This will occur on the day of generation. All decontamination fluids will be discharged to the RP wastewater treatment system because both hazardous and non-hazardous waste can be disposed of in the RP wastewater treatment system. The quantity of water discharged to the RP wastewater treatment system will be recorded on the 90-Day Investigation Derived Waste Log.

RP - PORTLAND SITE SOP - 10 SURFACE WATER SAMPLING METHODOLOGY

1.0 PURPOSE

Surface water samples are often collected for observation and analysis to determine the chemical and physical characteristics of the surface water at a given location. Surface water samples can be collected from streams, rivers, channels, sewers, ponds, lakes, lagoons, or any other accessible surface water body. Several sampling methods can be employed depending on access, level of anticipated contamination, depth of water, and other considerations.

2.0 EQUIPMENT LIST

- 1) Sampling equipment (see descriptions below)
- 2) Photoionization detector (PID) for environmental sites
- 3) Access keys or tools
- 4) Appropriate field sampling form and/or field logbook with indelible pens
- 5) Knife or scissors
- 6) Safety equipment (e.g., harness), as appropriate
- 7) Decontamination equipment (see SOP 3 Decontamination Procedure and sampling plan for additional site-specific requirements)
- 8) Site map and site health and safety plan (HASP), if applicable
- 9) PPE appropriate for site (see HASP if applicable)

3.0 PROCEDURE

The collection of samples from surface water bodies presents unique challenges. The sampling can be easy and routine such as collecting a surface water sample from a two-foot deep stream or may dictate special equipment to access the sample (wide streams with a high flow rate or tidal channels). Health and safety should be a major consideration in selecting an appropriate sampling method. Each person on a barge or in a boat in water above the sampler's wrist must be equipped with a life preserver and/or lifeline. When collecting samples from a fast moving stream, the person collecting the sample should be fitted with a safety harness and lifeline.

Prior to sample collection, the water body characteristics (size, depth, flow) should be recorded in the field logbook. Sampling should proceed from downstream to upstream locations to minimize the disturbance that would affect sample quality. If sediment

samples are collected at the same location as the surface water sample, the surface water sample must be collected first. When wading in a stream or pond, care must be taken not to collect the water sample where bottom sediments have been disturbed.

The factors that should be considered when selecting a sampling method include width, depth and flow of the location being sampled, and whether the sample will be collected from the shore or a vessel. Surface water samples can be accomplished by using the following samplers:

- Laboratory cleaned sample bottle;
- Disposable dippers;
- Subsurface bottle samplers;
- Stainless steel, discrete interval bomb samplers;
- Kemmerer depth sampler;
- Horizontal water bottle samplers; or
- Peristaltic pump.

Samples collected near the surface can be collected directly into the laboratory cleaned sample bottle or with a dipper. In situations where the water cannot be reached, the sample container can be attached to an extension. A subsurface bottle sampler or disposable dippers also can be used for this application.

For stratified water columns in ponds and lakes, it may be necessary to collect a water sample at depth, beneath the surface of the water. A depth sampler such as a Kemmerer depth sampler, sub surface bottle sampler, bomb sampler or horizontal water bottle samplers would allow collection of discrete water samples at various depths.

Dippers

Dippers allow remote sampling of ponds, streams, and manholes from hard to reach areas. A dipper is simply a bottle attached to an extension that is immersed into a liquid to collect a sample (Figure 1). Disposable dippers can be used to eliminate problems associated with decontamination and cross contamination of samples. Some dipper samplers are equipped with a pivoting head to sample in hard to reach areas such as sewers or outflow pipes.



Subsurface Bottle Samplers

These samplers (also called Wheaton Dip Sampler) consist of a glass bottle mounted on a metal pole of fixed length (Figure 2). An extension allows the bottle to be opened and closed under water for discrete sampling.



Figure 2. Sub Surface Grab Sampler

The procedure for sampling is as follows:

- 1) Prior to use test the sampler several times in a bucket of clean water to ensure proper adjustment.
- 2) Submerge sampler into liquid to be sampled.
- 3) When desired depth is reached open the sample bottle by pulling extension. Some samplers use a remote valve that can be opened and closed by pulling and releasing a ring on the handle.
- 4) The bottle is full when air bottles no longer escape to the surface.
- 5) Close the sample bottle by pushing the extension (or releasing the ring).

6) Transfer sample to the appropriate laboratory cleaned sample container.

Bomb Samplers

The bomb sampler is useful for collecting samples at various vertical locations in a water column (Figure 3). The sampler can be filled when contact is made with a hard surface or by pulling up on a separate line to a trigger at a desired depth. Retrieving the sampler or releasing the pull line reseals the sampler. This sampler would generally be operated from a boat or dock.



Figure 3. Stainless Steel Bomb Sampler

The procedure for use is as follows:

- 1) Lower the bomb sampler carefully to the desired depth, allowing the line for trigger to remain slack at all times.
- 2) When the desired depth is reached, pull the trigger line until taut.
- 3) Release the trigger line and retrieve the sampler.
- 4) Transfer the sample to the appropriate sample container by pulling the trigger.

Kemmerer Sampler

As with the bomb sampler, the Kemmerer sampler is useful to collect water samples from various depths in a water column. The Kemmerer sampler would generally be operated from a boat or dock. The sampling device consists of an open tube with two sealing end pieces. These end pieces can be withdrawn from the tube and set in the open position. These remain in the open position until the sampler is at the desired depth and then a weighted messenger is sent down the line or cable, releasing the end pieces and trapping the sample in the tube. The sampling tube is exposed to material

while travelling down to the sampling the depth, which in some conditions in a stratified water column may cross contaminate the sample.



Figure 4. Kemmerer plastic bottle sampler.

Procedure for use:

- 1) Set the sampling device so that the sealing end pieces are pulled away from the sampling tube, allowing the water to pass through the tube.
- 2) Lower the pre-set sampling device to the desire depth.
- 3) Send down the messenger, closing the sampling device.
- 4) Retrieve the sampler.
- 5) Transfer the sample to the appropriate sample container.

Peristaltic Pump

A peristaltic pump can be used to collect a surface water sample from below the water surface of a lake or pond. The intake tubing can be place at place at a discrete depth below the water body surface. The sample should be collected at flow rate less than 400 milliliters per minute.

Procedures of use:

- 1) Place the appropriate flexible tubing in the peristaltic pump head.
- 2) Use dedicated disposable tubing for the intake and discharge tubing.

| Place intake tubing a sampling depth. Use a buoy or anchor rope to hold the tubing in place while sampling. |
|---|
| 4) Collect the sample a low flow rate (50 to 400 milliliters per minute). |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

RP - PORTLAND SITE

SOP - 11

FIELD PARAMETER MEASUREMENT FOR SURFACE WATER AND OUTFALL DISCHARGE SAMPLING

1.0 PURPOSE

Measurements of pH, oxidation-reduction potential (ORP), air and water temperature, conductivity, tubidity, and dissolved oxygen (DO) concentrations will be obtained with calibrated instruments at all sample sites prior to sample collection. At some locations ferrous iron also may be included.

2.0 EQUIPMENT LIST

- 1) Portable, battery-powered multiprobe equipment (e.g., YSI 650 MDS or YSI 610) with calibration solutions and instructions
- 2) Turbidity meter
- 3) Ferrous iron field test kit, stocked with reagents
- 4) Appropriate field forms for recording readings and/or field logbook with indelible pens
- 5) Knife or scissors
- 6) Decontamination equipment (see SOP 3 Decontamination Procedure and sampling plan for additional site-specific requirements)
- 7) Site map and site health and safety plan (HASP), if applicable
- 8) PPE appropriate for site (see HASP if applicable)

3.0 PROCEDURE

Procedures for collection of specific field parameters are provided in the sections below.

Temperature, pH, Specific Conductance, DO, and ORP

Field measurements for temperature, pH, specific conductance, DO, and ORP will be measured with portable, battery-powered instruments (e.g., YSI 650 MDS or YSI 610 D multiprobes). Procedures for calibration and measurements are outlined in the user manuals included with these instruments. At a minimum, these instruments will be calibrated each day before sampling activities begin. If possible, these field parameters will be measured directly by lowering the probe into the water body at the

sampling location prior to collecting the water and sediment sample. The probe will be decontaminated between measurements as outlined in SOP - 3.

Measurements for Turbidity

Turbidity will be measured once per sample immediately prior to filling sample bottles. Turbidity will be measured using appropriate portable, battery-powered field equipment and results will be recorded in nephelometric turbidity units (NTU). Dilution of the sample may be required for water with high turbidity.

Ferrous Iron (Fe2+)

Field measurement of ferrous iron (Fe2+) will be conducted using a colormetric technique. Summary of procedures for Fe2+ measurement:

- 1) Wash all lab ware between tests with a non-abrasive detergent or solvent. Do not use paper towels on the plastic tubes, as this may scratch them.
- 2) Rinse all tubes thoroughly with the sample water prior to testing.
- 3) Fill a viewing tube to the first 5-millitier (mL) line to be used as a blank.
- 4) Place the blank tube in the top left opening of the color comparator.
- 5) Fill the measuring vial to the 25-mL mark with the sample water.
- 6) Use the supplied clippers to open the powder pillow.
- 7) Add the contents of the powder pillow to the measuring vial.
- 8) Swirl to mix and allow three (3) minutes for full color development. An orange color will develop if Fe2+ is present.
- 9) Fill a second viewing tube with the prepared sample from the measuring vial to the first 5-mL mark.
- 10) Place the second tube in the top right opening of the color comparator.
- 11) Hold the comparator up to a light source and rotate the color disk until the color matches in the two openings.
- 12) Read the mg/L Fe2+ result in the scale window.
- 13) Place the tested water into the container of Investigation Derived Waste (IDW) and rinse the viewing tubes and the measuring vial.

RP - PORTLAND SITE SOP - 13 WASTE MANAGEMENT PROCEDURES

1.0 PURPOSE

To promote proper and consistent handling, storage, and disposal of waste generated during field investigations to prevent or minimize the potential for the spread of contamination, creation of sanitary hazards, or visual degradation of the RP site through the spread of litter.

2.0 EQUIPMENT LIST

- 1) Site health and safety plan (HASP), including site map
- 2) Personal Protective Equipment (PPE) appropriate for site (see HASP)
- 3) 90-Day Investigation Derived Waste Log form (attached)
- 4) Daily Water Disposal Log form (attached)
- 5) Field logbook
- 6) Waste labels
- 7) Indelible pens
- 8) Heavy duty plastic sacks
- 9) Portable water storage tank
- 10) Department of Transportation (DOT) approved removable head 55-gallon steel drums
- 11) As appropriate for work involving non-aqueous phase liquid (NAPL), on-site chemical-resistant container with secondary containment (e.g., 30-gallon, Teflonbonded, hard-top steel drum with volumetric gauge contained with secondary containment and cover, and large dedicated funnel)
- 12) As appropriate for work involving NAPL, portable chemical-resistant container with secondary containment (e.g., 3-gallon Teflon-bonded steel container within 5-gallon bucket)
- 13) As appropriate for oversight of waste transport, manifest forms (hazardous and/or non-hazardous)

3.0 PROCEDURES

Wastes generated during field investigations may include decontamination water, PPE, disposable sampling equipment, NAPL, and/or other hazardous and non-hazardous

wastes. Waste water will be discharged to the on-site wastewater treatment system, as described below. Solid waste and NAPL will be stored in the RP property waste storage facility pending disposal, as described below.

Containers of waste in the RP waste storage facility should not be opened without knowledge of contents and use of appropriate personal protective equipment (PPE). Reference the project HASP for specific procedures and protections to be implemented during waste handling and inventory.

Collection, Documentation, and Storage of Solid Waste

Personal Protective Equipment (PPE)

All disposable health and safety PPE (Tyvek® suits, gloves, etc.) will be collected and stored in heavy duty plastic sacks and transported to the RP waste storage facility on the same day it was generated. The sacks with discarded PPE will be placed in DOT-approved removable head steel drums.

Disposable Sampling Equipment

All disposable sampling equipment (disposable bailers, plastic tubing, etc.) will be collected and stored in heavy duty plastic sacks and transported to the RP waste storage facility on the same day it was generated. The sacks will be placed in DOT-approved removable head steel drums.

Non-Hazardous Wastes

Non-hazardous wastes that may be generated during field activities include paper, food containers and wrapping, aluminum cans, bottles, plastic bags, and other miscellaneous types of debris. This material will be contained in plastic refuse sacks for disposal in approved waste receptacles (dumpsters). Disposal will occur daily.

Collection, Documentation, and Disposal of Waste Water

All decontamination fluids and purge water from well sampling and/or development, will be contained in an appropriately labeled portable tank located on the back of a field truck for transport to the RP property.

Decontamination and well purge water will be evacuated from the portable water tank using the sump pump assembly available at the RP wastewater treatment system. Transport to the RP property and discharge to the treatment system will occur on the day of generation. The quantity of water discharged to the RP wastewater treatment system will be recorded on the Daily Water Disposal Log, attached.

Collection, Documentation, and Storage of NAPL or NAPL/Fluid Mixtures

NAPL and NAPL/fluid mixtures generated during field events where NAPL is intentionally removed from wells will be placed in a portable, chemical-resistant container with secondary containment for transportation from the well to the RP waste storage facility. The contents of the portable container will be transferred to a stationary chemical-resistant container with secondary containment by discharging the fluid through a dedicated, industrial-sized funnel with a flip-top reclosable lid to eliminate splashing and spills. Appropriate PPE, consistent with or more protective than that used for NAPL collection, will be worn during transfer of NAPL from the portable container to the stationary container. Transport of NAPL from the collection site and transfer into the stationary container will occur on the day of generation.

The total quantity of NAPL and NAPL/fluid mixture removed, expected to be quarts per well, during each day will be recorded on the 90-Day Investigation Derived Waste Log (attached).

Temporary Container Labelling

All containers of waste generated during field investigations will be labeled with information appropriate for accurate tracking and identification of the containers and their contents. The labels will be waterproof markings or adhesive labels applied on both sides and the lids of each 55-gallon drum or container.

Drums will be labeled with the following information:

RP ACTIVITY (i.e., RI/FS) WASTE TYPE (i.e., Investigation-Derived Waste (IDW))

HOLD FOR ANALYSIS

DATE FIRST ACCUMULATED (example: March 18, 2002)

STATION IDENTIFIER (example: NDL-102-S)

TYPE OF WASTE/MEDIA (example: disposable poly-sleeve/soil)

Each container will be assigned a unique identification number and will be logged onto the 90-Day Investigation Derived Waste Log, attached. Wastes will be categorized and containerized based on media type and waste stream. Following waste determination, these temporary markings will be removed and each container will be labeled with an appropriate hazardous or non-hazardous waste label.

Current Revision – 2/14/03 Page 4 of 5

SOIL AND PPE/DEBRIS 90-DAY INVESTIGATION DERIVED WASTE LOG RI/FS RP - Portland Site

| Remaining Capacity of Drum (in %) | %09 | | | | | |
|--|-----------------|--|--|--|--|--|
| Amount/Volume Transferred | 1/2 drum | | | | | |
| Samples collected for lab analysis (for soil)? | Ν | | | | | |
| Activity Description | Spr 2000 GW | | | | | |
| Type of Waste | drill cuttings | | | | | |
| Area/location(s) | RP-07-S | | | | | |
| | NRA | | | | | |
| Date | 4/22/2002 | | | | | |
| Container Number | Example: 048 | | | | | |

Notes:

LA = Lake Area

IA = Insecticide Area HA = Herbicide Area

NRA = Non-RP Area

DAILY WATER DISPOSAL LOG RI/FS RP - Portland Site

| Date | | Area/Location(s) | Type of Waste | Activity Description | Volume Generated/Transferred* (Give Units of Measure) |
|-----------------------|-----|------------------|---------------|----------------------|---|
| Example: 4/22/2002 | ΓA | RP-04-16 | Purge Water | Fall 2001 GW | 15 gallons |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| Notes: | .50 | | | | |

Notes:

LA = Lake Area IA = Insecticide Area

HA = Herbicide Area NRA = Non-RP Area

ATTACHMENT C TABLES

DRAFT

Attachment A Table 1 - List of Analyses

| Dry Weather Monitoring Water Sample Analysis | | | | | |
|--|------------------------|--|--|--|--|
| Constituent Group ¹ | Method ² | | | | |
| Total/Dissolved Metals | EPA 200.7 or EPA 200.8 | | | | |
| PCDDs/PCDFs | EPA 1613B | | | | |
| Total/Dissolved Mercury | EPA 1631E | | | | |
| Polychlorinated Biphenyls (PCBs) | EPA 1668 | | | | |
| Hexavalent Chromium | EPA 7195 or EPA 7196A | | | | |
| Volatile Organic Compounds (VOCs) | EPA 8260C | | | | |
| Semivolatile Organic Compounds (SVOCs) | EPA 8270D | | | | |
| Polycyclic Aromatic Hydrocarbons (PAHs) | EPA 8270 SIM | | | | |
| Organochlorine Pesticides | EPA 1699 | | | | |
| Chlorinated Herbicides | EPA 8151A | | | | |
| Petroleum Hydrocarbon Identification | NWTPH-HCID | | | | |
| Diesel Quantitation | NWTPH-Dx | | | | |
| Gasoline Quantitation | NWTPH-Gx | | | | |

Notes:

NWTPH-Dx method run without silica gel.



¹Refer to Table 2 of the QAPP (AMEC 2009b) for a list of analytes within each constituent group.

²Methods from Table 1 of the QAPP (AMEC 2009b)

| EPA Method 8260C - VOCs | | | |
|-----------------------------|-------|-------|-------|
| Constituent | MDL | MRL | Units |
| Acetone | 10.0 | 20.0 | μg/L |
| Acrolein | 5.00 | 10.0 | μg/L |
| Acrylonitrile | 1.00 | 2.00 | μg/L |
| Benzene | 0.125 | 0.250 | μg/L |
| Bromobenzene | 0.250 | 0.500 | μg/L |
| Bromochloromethane | 0.500 | 1.00 | μg/L |
| Bromodichloromethane | 0.500 | 1.00 | μg/L |
| Bromoform | 0.500 | 1.00 | μg/L |
| Bromomethane | 5.00 | 5.00 | μg/L |
| 2-Butanone (MEK) | 5.00 | 10.0 | μg/L |
| n-Butylbenzene | 0.500 | 1.00 | μg/L |
| sec-Butylbenzene | 0.500 | 1.00 | μg/L |
| tert-Butylbenzene | 0.500 | 1.00 | μg/L |
| Carbon disulfide | 5.00 | 10.0 | μg/L |
| Carbon tetrachloride | 0.250 | 0.500 | μg/L |
| Chlorobenzene | 0.250 | 0.500 | μg/L |
| Chloroethane | 5.00 | 5.00 | μg/L |
| 2-Chloroethyl vinyl ether | 5.00 | 10.0 | μg/L |
| Chloroform | 0.500 | 1.00 | μg/L |
| Chloromethane | 2.50 | 5.00 | μg/L |
| 2-Chlorotoluene | 0.500 | 1.00 | μg/L |
| 4-Chlorotoluene | 0.500 | 1.00 | μg/L |
| Dibromochloromethane | 0.500 | 1.00 | μg/L |
| 1,2-Dibromo-3-chloropropane | 2.50 | 5.00 | μg/L |
| 1,2-Dibromoethane (EDB) | 0.250 | 0.500 | μg/L |
| Dibromomethane | 0.500 | 1.00 | μg/L |
| 1,2-Dichlorobenzene | 0.250 | 0.500 | μg/L |
| 1,3-Dichlorobenzene | 0.250 | 0.500 | μg/L |
| 1,4-Dichlorobenzene | 0.250 | 0.500 | μg/L |
| Dichlorodifluoromethane | 0.500 | 1.00 | μg/L |
| 1,1-Dichloroethane | 0.250 | 0.500 | μg/L |
| 1,2-Dichloroethane (EDC) | 0.250 | 0.500 | μg/L |
| 1,1-Dichloroethene | 0.250 | 0.500 | μg/L |
| cis-1,2-Dichloroethene | 0.250 | 0.500 | μg/L |
| trans-1,2-Dichloroethene | 0.250 | 0.500 | μg/L |
| 1,2-Dichloropropane | 0.250 | 0.500 | μg/L |
| 1,3-Dichloropropane | 0.500 | 1.00 | μg/L |
| 2,2-Dichloropropane | 0.500 | 1.00 | μg/L |
| 1,1-Dichloropropene | 0.500 | 1.00 | μg/L |
| cis-1,3-Dichloropropene | 0.500 | 1.00 | μg/L |
| trans-1,3-Dichloropropene | 0.500 | 1.00 | μg/L |
| Ethylbenzene | 0.250 | 0.500 | μg/L |
| Hexachlorobutadiene | 2.50 | 5.00 | μg/L |
| n-Hexane | 0.500 | 1.00 | μg/L |
| 2-Hexanone | 5.00 | 10.0 | μg/L |

| la damathana | Ir oo | 110.0 | /I |
|---|------------------|--------|--------|
| lodomethane | 5.00 | 10.0 | μg/L |
| Isopropylbenzene | 0.500 | 1.00 | μg/L |
| 4-Isopropyltoluene | 0.500 | 1.00 | μg/L |
| Methylene chloride | 2.50 | 5.00 | μg/L |
| 4-Methyl-2-pentanone (MiBK) | 5.00 | 10.0 | μg/L |
| Methyl tert-butyl ether (MTBE) | 0.500 | 1.00 | μg/L |
| Naphthalene | 1.00 | 2.00 | μg/L |
| n-Propylbenzene | 0.250 | 0.500 | μg/L |
| Styrene | 0.500 | 1.00 | μg/L |
| 1,1,1,2-Tetrachloroethane | 0.250 | 0.500 | μg/L |
| 1,1,2,2-Tetrachloroethane | 0.250 | 0.500 | μg/L |
| Tetrachloroethene (PCE) | 0.250 | 0.500 | μg/L |
| Tetrahydrofuran | 5.00 | 10.0 | μg/L |
| 1,2,3-Trichlorobenzene | 1.00 | 2.00 | μg/L |
| 1,2,4-Trichlorobenzene | 1.00 | 2.00 | μg/L |
| 1,1,1-Trichloroethane | 0.250 | 0.500 | μg/L |
| 1,1,2-Trichloroethane | 0.250 | 0.500 | μg/L |
| Trichloroethene (TCE) | 0.250 | 0.500 | μg/L |
| Trichlorofluoromethane | 1.00 | 2.00 | μg/L |
| 1,2,3-Trichloropropane | 0.500 | 1.00 | μg/L |
| 1,1,2-Trichloro-1,2,2-trifluoroethane (Freon-113) | 1.00 | 2.00 | μg/L |
| 1,2,4-Trimethylbenzene | 0.500 | 1.00 | μg/L |
| 1,3,5-Trimethylbenzene | 0.500 | 1.00 | μg/L |
| Toluene | 0.500 | 1.00 | μg/L |
| Vinyl acetate | 5.00 | 10.0 | μg/L |
| Vinyl chloride | 0.250 | 0.500 | μg/L |
| m,p-Xylene | 0.500 | 1.00 | μg/L |
| o-Xylene | 0.250 | 0.500 | μg/L |
| EPA Method 8270D - SVOCs and 8270 SIM (PAHs) | 0.230 | 0.300 | Iμ9/ L |
| Constituent | MDL | MRL | Units |
| Acenaphthene | 0.0100 | 0.0200 | |
| · | | | µg/L |
| Acenaphthylene | 0.0100 0.0100 | 0.0200 | µg/L |
| Anthracene | | 0.0200 | µg/L |
| Benz(a)anthracene | 0.0100 | 0.0200 | μg/L |
| Benzo(a)pyrene | 0.0150 | 0.0300 | μg/L |
| Benzo(b)fluoranthene | 0.0100 | 0.0200 | µg/L |
| Benzo(k)fluoranthene | 0.0100 | 0.0200 | μg/L |
| Benzo(b+k)fluoranthene(s) | 0.0200 | 0.0400 | μg/L |
| Benzo(g,h,i)perylene | 0.0100 | 0.0200 | μg/L |
| Chrysene | 0.0100 | 0.0200 | μg/L |
| Dibenz(a,h)anthracene | 0.0100 | 0.0200 | μg/L |
| Fluoranthene | 0.0100 | 0.0200 | μg/L |
| Fluorene | 0.0100 | 0.0200 | μg/L |
| Indeno(1,2,3-cd)pyrene | 0.0100 | 0.0200 | μg/L |
| 1-Methylnaphthalene | 0.0200 | 0.0400 | μg/L |
| 2-Methylnaphthalene | 0.0200 | 0.0400 | μg/L |
| Naphthalene | 0.0200 | 0.0400 | μg/L |

Table 2 - Method Detection and Reporting Limits

| Phenanthrene | 0.0100 | 0.0200 | μg/L |
|------------------------------|--------|--------|------|
| Pyrene | 0.0100 | 0.0200 | μg/L |
| Carbazole | 0.0150 | 0.0300 | μg/L |
| Dibenzofuran | 0.0100 | 0.0200 | μg/L |
| 4-Chloro-3-methylphenol | 0.100 | 0.200 | μg/L |
| 2-Chlorophenol | 0.0500 | 0.100 | μg/L |
| 2,4-Dichlorophenol | 0.0500 | 0.100 | μg/L |
| 2,4-Dimethylphenol | 0.0500 | 0.100 | μg/L |
| 2,4-Dinitrophenol | 0.250 | 0.500 | μg/L |
| 4,6-Dinitro-2-methylphenol | 0.250 | 0.500 | μg/L |
| 2-Methylphenol | 0.0250 | 0.0500 | μg/L |
| 3+4-Methylphenol(s) | 0.0250 | 0.0500 | μg/L |
| 2-Nitrophenol | 0.100 | 0.200 | μg/L |
| 4-Nitrophenol | 0.100 | 0.200 | μg/L |
| Pentachlorophenol (PCP) | 0.200 | 0.400 | μg/L |
| Phenol | 0.200 | 0.400 | μg/L |
| 2,3,4,6-Tetrachlorophenol | 0.0500 | 0.100 | μg/L |
| 2,4,5-Trichlorophenol | 0.0500 | 0.100 | μg/L |
| 2,4,6-Trichlorophenol | 0.0500 | 0.100 | μg/L |
| Bis(2-ethylhexyl)phthalate | 1.10 | 2.20 | μg/L |
| Butyl benzyl phthalate | 1.50 | 3.00 | μg/L |
| Diethylphthalate | 1.50 | 3.00 | μg/L |
| Dimethylphthalate | 1.50 | 3.00 | μg/L |
| Di-n-butylphthalate | 1.50 | 3.00 | μg/L |
| Di-n-octyl phthalate | 1.50 | 3.00 | μg/L |
| N-Nitrosodimethylamine | 0.0250 | 0.0500 | μg/L |
| N-Nitroso-di-n-propylamine | 0.0250 | 0.0500 | μg/L |
| N-Nitrosodiphenylamine | 0.0250 | 0.0500 | μg/L |
| Bis(2-Chloroethoxy) methane | 0.0250 | 0.0500 | μg/L |
| Bis(2-Chloroethyl) ether | 0.0250 | 0.0500 | μg/L |
| Bis(2-Chloroisopropyl) ether | 0.0250 | 0.0500 | μg/L |
| Hexachlorobenzene | 0.0100 | 0.0200 | μg/L |
| Hexachlorobutadiene | 0.0250 | 0.0500 | μg/L |
| Hexachlorocyclopentadiene | 0.0500 | 0.100 | μg/L |
| Hexachloroethane | 0.0250 | 0.0500 | μg/L |
| 2-Chloronaphthalene | 0.0100 | 0.0200 | μg/L |
| 1,2-Dichlorobenzene | 0.0250 | 0.0500 | μg/L |
| 1,3-Dichlorobenzene | 0.0250 | 0.0500 | μg/L |
| 1,4-Dichlorobenzene | 0.0250 | 0.0500 | μg/L |
| 1,2,4-Trichlorobenzene | 0.0250 | 0.0500 | μg/L |
| 4-Bromophenyl phenyl ether | 0.0250 | 0.0500 | μg/L |
| 4-Chlorophenyl phenyl ether | 0.0250 | 0.0500 | μg/L |
| Aniline | 0.0500 | 0.100 | μg/L |
| 4-Chloroaniline | 0.0250 | 0.0500 | μg/L |
| 2-Nitroaniline | 0.200 | 0.400 | μg/L |
| 3-Nitroaniline | 0.200 | 0.400 | μg/L |
| 4-Nitroaniline | 0.200 | 0.400 | μg/L |

| Nitrobenzene | 0.100 | 0.200 | μg/L |
|--------------------------------------|--------|--------|-------|
| 2,4-Dinitrotoluene | 0.100 | 0.200 | μg/L |
| 2,6-Dinitrotoluene | 0.100 | 0.200 | μg/L |
| Benzoic acid | 1.25 | 2.50 | μg/L |
| Benzyl alcohol | 0.100 | 0.200 | μg/L |
| Isophorone | 0.0250 | 0.0500 | μg/L |
| Azobenzene (1,2-DPH) | 0.0250 | 0.0500 | μg/L |
| Benzidine | 0.100 | 0.200 | μg/L |
| Bis(2-Ethylhexyl) adipate | 0.0500 | 0.100 | μg/L |
| 3,3'-Dichlorobenzidine | 0.100 | 0.200 | μg/L |
| 1,2-Dinitrobenzene | 0.250 | 0.500 | μg/L |
| 1,3-Dinitrobenzene | 0.250 | 0.500 | μg/L |
| 1,4-Dinitrobenzene | 0.250 | 0.500 | μg/L |
| Pyridine | 0.100 | 0.200 | μg/L |
| 2,3,5,6-Tetrachlorophenol | 0.0500 | 0.100 | μg/L |
| EPA Method 200.7 or EPA Method 200.8 | • | • | |
| Constituent | MDL | MRL | Units |
| Arsenic | 0.500 | 2.00 | μg/L |
| Barium | 0.500 | 1.00 | μg/L |
| Cadmium | 0.500 | 1.00 | μg/L |
| Calcium | 50.0 | 100.0 | μg/L |
| Chromium | 0.500 | 2.00 | μg/L |
| Copper | 1.00 | 2.00 | μg/L |
| Iron | 25.0 | 50.0 | μg/L |
| Lead | 0.500 | 1.00 | μg/L |
| Magnesium | 250.0 | 500.0 | μg/L |
| Manganese | 0.500 | 1.00 | μg/L |
| Nickel | 0.500 | 2.00 | μg/L |
| Selenium | 1.00 | 2.00 | μg/L |
| Silver | 0.500 | 1.00 | μg/L |
| Zinc | 2.00 | 4.00 | μg/L |
| EPA Method 1631E | | | |
| Constituent | MDL | MRL | Units |
| Mercury | 0.0002 | 0.0005 | μg/L |
| EPA Method 7195 or EPA Method 7196A | | | |
| Constituent | MDL | MRL | Units |
| Hexavalent Chromium | 5 | 10 | μg/L |
| EPA Method 1699 | | | |
| Constituent | MDL | MRL | Units |
| Hexachlorobenzene | 3.7 | 40 | pg/L |
| alpha-BHC | 1.8 | 40 | pg/L |
| Lindane (gamma-BHC) | 2.7 | 40 | pg/L |
| beta-BHC | 3.6 | 40 | pg/L |
| delta-BHC | 2.1 | 40 | pg/L |
| Heptachlor | 0.8 | 200 | pg/L |
| Aldrin | 0.9 | 40 | pg/L |
| Oxychlordane | 2.8 | 40 | pg/L |

| cis-Heptachlor Expoxide | 2 | 40 | pg/L |
|--------------------------|-----|-----|-------|
| trans-Heptachlor Epoxide | 8.5 | 80 | pg/L |
| trans-Chlordane (gamma) | 2.7 | 40 | pg/L |
| trans-Nonachlor | 2.3 | 40 | pg/L |
| cis-Chlordane (alpha) | 2.2 | 40 | pg/L |
| Endosulfan I | 8.5 | 400 | pg/L |
| 2,4'-DDE | 1.1 | 80 | pg/L |
| 4,4'-DDE | 1.4 | 80 | pg/L |
| Dieldrin | 2.1 | 40 | pg/L |
| Endrin | 2.2 | 80 | pg/L |
| cis-Nonachlor | 2.3 | 40 | pg/L |
| Endosulfan II | 17 | 400 | pg/L |
| 2,4'-DDD | 2.7 | 40 | pg/L |
| 2,4'-DDT | 4.4 | 80 | pg/L |
| 4,4'-DDD | 3.2 | 40 | pg/L |
| 4,4'-DDT | 4.5 | 80 | pg/L |
| Endosulfan Sulfate | 5.6 | 400 | pg/L |
| 4,4'-Methoxychlor | 2.8 | 400 | pg/L |
| Mirex | 0.9 | 40 | pg/L |
| Endrin Aldehyde | 3.5 | 400 | pg/L |
| Endrin Ketone | 3.4 | 400 | pg/L |
| EPA Method 1668A | | | |
| Constituent | MDL | MRL | Units |
| PCB 1 | 82 | 200 | pg/L |
| PCB 2 | 4 | 10 | pg/L |
| PCB 3 | 88 | 200 | pg/L |
| PCB 4 | 172 | 500 | pg/L |
| PCB 10 | 22 | 50 | pg/L |
| PCB 9 | 20 | 50 | pg/L |
| PCB 7 | 15 | 50 | pg/L |
| PCB 6 | 13 | 50 | pg/L |
| PCB 5 | 11 | 50 | pg/L |
| PCB 8 | 121 | 500 | pg/L |
| PCB 14 | 31 | 100 | pg/L |
| PCB 11 | 105 | 200 | pg/L |
| PCB 13 | 28 | 100 | pg/L |
| PCB 12 | 28 | 100 | pg/L |
| PCB 15 | 183 | 500 | pg/L |
| PCB 19 | 42 | 100 | pg/L |
| PCB 30 | 175 | 500 | pg/L |
| PCB 18 | 175 | 500 | pg/L |
| PCB 17 | 86 | 200 | pg/L |
| PCB 27 | 59 | 200 | pg/L |
| PCB 24 | 53 | 200 | pg/L |
| PCB 16 | 35 | 100 | pg/L |
| PCB 32 | 84 | 200 | pg/L |
| PCB 34 | 74 | 200 | pg/L |

| PCB 23 | 50 | 200 | pg/L |
|--------|-----|-----|------|
| PCB 29 | 83 | 200 | pg/L |
| PCB 26 | 83 | 200 | pg/L |
| PCB 25 | 55 | 200 | pg/L |
| PCB 31 | 152 | 500 | pg/L |
| PCB 28 | 192 | 500 | pg/L |
| PCB 20 | 192 | 500 | pg/L |
| PCB 21 | 51 | 200 | pg/L |
| PCB 33 | 51 | 200 | pg/L |
| PCB 22 | 90 | 200 | pg/L |
| PCB 36 | 79 | 200 | pg/L |
| PCB 39 | 85 | 200 | pg/L |
| PCB 38 | 83 | 200 | pg/L |
| PCB 35 | 77 | 200 | pg/L |
| PCB 37 | 132 | 200 | pg/L |
| PCB 54 | 118 | 200 | pg/L |
| PCB 50 | 58 | 200 | pg/L |
| PCB 53 | 58 | 200 | pg/L |
| PCB 45 | 51 | 200 | pg/L |
| PCB 51 | 51 | 200 | pg/L |
| PCB 46 | 101 | 200 | pg/L |
| PCB 52 | 191 | 500 | pg/L |
| PCB 73 | 160 | 500 | pg/L |
| PCB 43 | 94 | 200 | pg/L |
| PCB 69 | 115 | 500 | pg/L |
| PCB 49 | 115 | 500 | pg/L |
| PCB 48 | 76 | 200 | pg/L |
| PCB 65 | 195 | 500 | pg/L |
| PCB 47 | 195 | 500 | pg/L |
| PCB 44 | 195 | 500 | pg/L |
| PCB 62 | 57 | 200 | pg/L |
| PCB 75 | 57 | 200 | pg/L |
| PCB 59 | 57 | 200 | pg/L |
| PCB 42 | 61 | 200 | pg/L |
| PCB 41 | 119 | 500 | pg/L |
| PCB 71 | 119 | 500 | pg/L |
| PCB 40 | 119 | 500 | pg/L |
| PCB 64 | 70 | 200 | pg/L |
| PCB 72 | 158 | 500 | pg/L |
| PCB 68 | 149 | 500 | pg/L |
| PCB 57 | 125 | 500 | pg/L |
| PCB 58 | 127 | 500 | pg/L |
| PCB 67 | 147 | 500 | pg/L |
| PCB 63 | 138 | 500 | pg/L |
| PCB 61 | 171 | 500 | pg/L |
| PCB 70 | 171 | 500 | pg/L |
| PCB 76 | 171 | 500 | pg/L |

| PCB 74 | 171 | 500 | ng/l |
|---------|------------|------|------|
| PCB 66 | 162 | 500 | pg/L |
| | | | pg/L |
| PCB 55 | 120 | 500 | pg/L |
| PCB 56 | 98 | 200 | pg/L |
| PCB 60 | 131 | 500 | pg/L |
| PCB 80 | 175 | 500 | pg/L |
| PCB 79 | 173 | 500 | pg/L |
| PCB 78 | 171 | 500 | pg/L |
| PCB 81 | 177 | 500 | pg/L |
| PCB 77 | 169 | 500 | pg/L |
| PCB 104 | 228 | 500 | pg/L |
| PCB 96 | 210 | 500 | pg/L |
| PCB 103 | 225 | 500 | pg/L |
| PCB 94 | 121 | 500 | pg/L |
| PCB 95 | 221 | 500 | pg/L |
| PCB 100 | 221 | 500 | pg/L |
| PCB 93 | 221 | 500 | pg/L |
| PCB 102 | 221 | 500 | pg/L |
| PCB 98 | 221 | 500 | pg/L |
| PCB 88 | 118 | 500 | pg/L |
| PCB 91 | 118 | 500 | pg/L |
| PCB 84 | 124 | 500 | pg/L |
| PCB 89 | 195 | 500 | pg/L |
| PCB 121 | 209 | 500 | pg/L |
| PCB 92 | 115 | 500 | pg/L |
| PCB 113 | 241 | 1000 | pg/L |
| PCB 90 | 241 | 1000 | pg/L |
| PCB 101 | 241 | 1000 | pg/L |
| PCB 83 | 217 | 500 | pg/L |
| PCB 99 | 217 | 500 | pg/L |
| PCB 112 | 245 | 1000 | pg/L |
| PCB 119 | 149 | 500 | |
| PCB 108 | 149 | 500 | pg/L |
| PCB 86 | 149 | 500 | pg/L |
| PCB 97 | 149 | 500 | pg/L |
| PCB 125 | | 500 | pg/L |
| PCB 125 | 149 149 | 500 | pg/L |
| | | | pg/L |
| PCB 117 | 104 | 200 | pg/L |
| PCB 116 | 104 | 200 | pg/L |
| PCB 85 | 104 | 200 | pg/L |
| PCB 110 | 243 | 1000 | pg/L |
| PCB 115 | 243 | 1000 | pg/L |
| PCB 82 | 133 | 500 | pg/L |
| PCB 111 | 243 | 1000 | pg/L |
| PCB 120 | 147 | 500 | pg/L |
| PCB 107 | 200 | 1000 | pg/L |
| PCB 124 | 200 | 1000 | pg/L |

| PCB 109 | 102 | 500 | na/l |
|---------|------------|------|------|
| | 103 | | pg/L |
| PCB 123 | 150 | 500 | pg/L |
| PCB 106 | 143 | 500 | pg/L |
| PCB 118 | 193 | 500 | pg/L |
| PCB 122 | 117 | 500 | pg/L |
| PCB 114 | 120 | 500 | pg/L |
| PCB 105 | 109 | 200 | pg/L |
| PCB 127 | 278 | 1000 | pg/L |
| PCB 126 | 136 | 500 | pg/L |
| PCB 155 | 339 | 1000 | pg/L |
| PCB 152 | 238 | 1000 | pg/L |
| PCB 150 | 328 | 1000 | pg/L |
| PCB 136 | 91 | 200 | pg/L |
| PCB 145 | 317 | 1000 | pg/L |
| PCB 148 | 324 | 1000 | pg/L |
| PCB 151 | 112 | 500 | pg/L |
| PCB 135 | 112 | 500 | pg/L |
| PCB 154 | 112 | 500 | pg/L |
| PCB 144 | 167 | 500 | pg/L |
| PCB 147 | 179 | 500 | pg/L |
| PCB 149 | 179 | 500 | pg/L |
| PCB 134 | 134 | 500 | pg/L |
| PCB 143 | 134 | 500 | pg/L |
| PCB 139 | 196 | 500 | pg/L |
| PCB 140 | 196 | 500 | pg/L |
| PCB 131 | 121 | 500 | pg/L |
| PCB 142 | 311 | 500 | pg/L |
| PCB 132 | 125 | 500 | pg/L |
| PCB 133 | 169 | 500 | pg/L |
| PCB 165 | 361 | 1000 | pg/L |
| PCB 146 | 182 | 500 | pg/L |
| PCB 161 | 352 | 1000 | |
| PCB 153 | 130 | 500 | pg/L |
| PCB 168 | 130 | 500 | pg/L |
| PCB 141 | 93 | 200 | pg/L |
| PCB 130 | | 500 | pg/L |
| PCB 137 | 136 300 | 1000 | pg/L |
| | | | pg/L |
| PCB 164 | 136 | 500 | pg/L |
| PCB 138 | 211 | 500 | pg/L |
| PCB 163 | 211 | 500 | pg/L |
| PCB 129 | 211 | 500 | pg/L |
| PCB 160 | 211 | 500 | pg/L |
| PCB 158 | 96 | 200 | pg/L |
| PCB 166 | 124 | 500 | pg/L |
| PCB 128 | 124 | 500 | pg/L |
| PCB 159 | 348 | 1000 | pg/L |
| PCB 162 | 355 | 1000 | pg/L |

| PCB 156 PCB 157 PCB 157 PCB 169 PCB 169 PCB 169 PCB 169 PCB 168 PCB 179 PCB 188 PCB 179 PCB 184 PCB 176 PCB 186 PCB 176 PCB 186 PCB 187 PCB 187 PCB 183 PCB 183 PCB 183 PCB 187 PCB 183 PCB 187 PCB 188 PCB 187 PCB 188 PCB 187 PCB 187 PCB 188 PCB 187 PCB 187 PCB 187 PCB 181 PCB 187 PCB 183 PCB 183 PCB 185 PCB 187 PCB 189 PCB 177 PCB 181 PCB 177 PCB 181 PCB 177 PCB 181 PCB 173 PCB 174 PCB 175 PCB 179 PCB 179 PCB 179 PCB 179 PCB 180 PCB 190 PCB 200 PGP 1 PCB 200 PGP 200 PGP 1 PCB 200 PGP 1 PCB 200 PGP 1 PCB 200 PGP 1 PCB 200 PGP 200 PGP 1 PCB 200 PGP 1 PCB 200 PGP 1 PCB 200 PGP 1 PCB 200 PGP | PCB 167 | 115 | 500 | pg/L |
|--|------------------|------|------|-------|
| PCB 157 PCB 169 PCB 169 PCB 188 PCB 179 PCB 179 PCB 184 PCB 186 PCB 186 PCB 187 PCB 186 PCB 187 PCB 186 PCB 187 PCB 187 PCB 187 PCB 187 PCB 188 PCB 189 PCB 181 PCB 180 PGB 181 PCB 180 PGB 181 PCB 180 PGB 181 PCB 180 PGB 18 | | | | |
| PCB 169 PCB 188 PCB 188 PCB 179 PCB 184 PCB 176 PCB 184 PCB 176 PCB 186 PCB 177 PCB 186 PCB 178 PCB 178 PCB 178 PCB 178 PCB 178 PCB 175 PCB 182 PCB 183 PCB 183 PCB 184 PCB 186 PCB 187 PCB 187 PCB 187 PCB 188 PCB 187 PCB 188 PCB 188 PCB 188 PCB 188 PCB 188 PCB 187 PCB 188 PCB 189 PCB 190 PCB 189 PCB 190 PCB 191 PCB 190 PCB 190 PCB 190 PCB 191 PCB 190 PCB 190 PCB 191 PCB 190 PCB 19 | | | | |
| PCB 188 PCB 179 PCB 179 PCB 184 A03 1000 pg/L PCB 176 PCB 186 PCB 176 BEB 186 BEB 1000 pg/L PCB 187 PCB 187 PCB 187 PCB 183 BEB 1000 pg/L PCB 183 BEB 1000 pg/L PCB 185 BEB 1000 pg/L PCB 186 BEB 1000 pg/L PCB 187 PCB 187 PCB 188 A01 1000 pg/L PCB 188 BEB 1000 pg/L PCB 187 PCB 188 BEB 1000 pg/L PCB 188 BEB 1000 pg/L PCB 181 BEB 1000 pg/L PCB 180 BEB 136 BEB 137 BEB 136 BEB 136 BEB 136 BEB 136 BEB 136 BEB 136 BEB 137 BEB 136 BEB 136 BEB 136 BEB 137 BEB 136 BEB 136 BEB 136 BEB 137 BEB 136 BEB 1400 BEB 14 BEB 146 BEB 146 BEB 146 BEB 146 BEB 146 BEB 146 BE | | | | |
| PCB 179 PCB 184 PCB 184 PCB 186 PCB 176 PCB 186 PCB 177 PCB 186 PCB 178 PCB 178 PCB 178 PCB 177 PCB 187 PCB 187 PCB 188 PCB 188 PCB 188 PCB 188 PCB 187 PCB 188 PCB 187 PCB 188 PCB 187 PCB 188 PCB 187 PCB 188 PCB 187 PCB 187 PCB 187 PCB 188 PCB 187 PCB 188 PCB 189 PCB 190 PCB 190 PCB 190 PCB 189 PCB 190 PCB 234 PCB 190 PCB 201 PCB 190 PCB 202 PCB 204 PCB 197 PCB 198 PCB 199 PCB 203 PCB 198 PCB 199 PCB 203 PCB 199 PCB 203 PCB 196 PCB 196 PCB 196 PCB 197 PCB 208 PCB 198 PCB 209 PCB 209 PCB 209 PCB 200 PGC 207 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 208 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 208 PCB 209 PCB 208 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 208 PCB 209 PCB 209 PCB 200 PGC 207 PCB 208 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 207 PCB 208 PCB 209 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 207 PCB 208 PCB 209 PCB 209 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 206 PCB 207 PCB 206 PCB 207 PCB 207 PCB 206 PCB 207 PCB 207 PCB 208 PCB 209 PCB 209 PCB 209 PCB 200 PGC 207 PCB 206 PCB 207 PCB 207 PCB 207 PCB 207 PCB 207 PCB 207 PCB 208 PCB 209 PCB 209 PCB 209 PCB 200 PGC 207 PCB 207 PCB 207 PCB 207 PCB 208 PCB 209 PCB 209 PCB 200 PGC 207 PCB 20 | | | | |
| PCB 184 PCB 176 PCB 1776 BBS BBS BBS BBS BBS BBS BBS | | | | |
| PCB 176 PCB 186 PCB 178 PCB 178 PCB 177 PCB 178 PCB 177 PCB 187 PCB 182 PCB 183 PCB 184 PCB 185 PCB 185 PCB 185 PCB 174 PCB 186 PCB 177 PCB 181 PCB 171 PCB 171 PCB 173 PCB 172 PCB 172 PCB 172 PCB 192 PCB 193 PCB 193 PCB 193 PCB 193 PCB 193 PCB 196 PCB 197 PCB 199 PCB 199 PCB 190 PCB 197 PCB 197 PCB 197 PCB 197 PCB 197 PCB 197 PCB 199 PCB 190 PCB 201 PCB 20 | | | | |
| PCB 186 407 1000 pg/L PCB 178 221 500 pg/L PCB 175 383 1000 pg/L PCB 187 191 500 pg/L PCB 182 398 1000 pg/L PCB 183 401 1000 pg/L PCB 183 401 1000 pg/L PCB 185 401 1000 pg/L PCB 185 401 1000 pg/L PCB 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 177 141 500 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 173 374 1000 pg/L PCB 173 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 190 pCB 190 pCB 190 pCB 190 pCB 190 pCB 234 500 pg/L PCB 201 440 1000 pg/L PCB 202 441 1000 pg/L PCB 204 447 1000 pg/L PCB 205 pCB 199 PCB 205 pCB 245 1000 pg/L PCB 207 pCB 199 pCB 207 pCB 199 pCB 245 pCB 207 pCB 199 pCB 203 pCB 199 pCB 204 pCB 199 pCB 205 pCB 199 pCB 207 pCB 199 pCB 208 pG/L PCB 209 pCB 209 pG/L PCB 209 pCB 209 pG/L PCB 209 pCB 209 pG/L PCB 209 pG/L PCB 209 pG/L PCB 209 pG/L PCB 200 pg/L PCB 209 pG/L PCB 206 pG/L PCB 209 pG/L PCB 200 pG/L PCB | | | | |
| PCB 178 221 500 pg/L PCB 175 383 1000 pg/L PCB 187 191 500 pg/L PCB 182 398 1000 pg/L PCB 183 401 1000 pg/L PCB 185 401 1000 pg/L PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 196 234 500 pg/L PCB 198 177 500 p | | | | |
| PCB 175 383 1000 pg/L PCB 187 191 500 pg/L PCB 182 398 1000 pg/L PCB 183 401 1000 pg/L PCB 185 401 1000 pg/L PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 173 374 1000 pg/L PCB 173 374 1000 pg/L PCB 192 420 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 193 136 500 pg/L PCB 190 136 500 pg/L PCB 191 418 1000 pg/L PCB 192 420 100 pg/L PCB 193 177 500 pg/L PCB 196 179 418 10 | | | | |
| PCB 187 PCB 182 398 1000 pg/L PCB 182 398 1000 pg/L PCB 185 401 1000 pg/L PCB 185 401 1000 pg/L PCB 185 401 1000 pg/L PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 177 141 500 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 173 377 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 193 136 500 pg/L PCB 190 PCB 191 418 1000 pg/L PCB 191 418 1000 pg/L PCB 191 418 1000 pg/L PCB 190 PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 189 177 500 pg/L PCB 201 440 1000 pg/L PCB 201 441 1000 pg/L PCB 201 442 1000 pg/L PCB 201 440 1000 pg/L PCB 201 PCB 201 PCB 201 PCB 201 PCB 201 PCB 203 PCB 204 PCB 203 PCB 204 PCB 206 PCB 207 PCB 208 PCB 209 PCB 200 PC | | | | |
| PCB 182 398 1000 pg/L PCB 183 401 1000 pg/L PCB 185 401 1000 pg/L PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 171 374 1000 pg/L PCB 173 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 193 136 500 pg/L PCB 190 418 1000 pg/L PCB 191 418 1000 pg/L PCB 190 234 500 pg/L PCB 190 234 500 pg/L PCB 201 442 1000 pg/L PCB 202 442 1000 pg/L PCB 203 447 1000 pg/L PCB 204 447 1000 <td< td=""><td></td><td></td><td></td><td></td></td<> | | | | |
| PCB 183 401 1000 pg/L PCB 185 401 1000 pg/L PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 190 234 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 203 440 1000 pg/L PCB 204 447 1000 p | | | | |
| PCB 185 401 1000 pg/L PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 173 374 1000 pg/L PCB 173 377 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 197 162 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 203 442 1000 pg/L PCB 204 447 1000 pg/L PCB 205 442 1000 pg/L PCB 206 245 1000 pg/L PCB 207 245 1000 <th< td=""><td></td><td></td><td></td><td></td></th<> | | | | |
| PCB 174 186 500 pg/L PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 192 418 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 180 175 500 pg/L PCB 190 234 500 pg/L PCB 201 440 1000 pg/L PCB 202 442 1000 pg/L PCB 197 245 1000 pg | | | | |
| PCB 177 141 500 pg/L PCB 181 396 1000 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 201 40 1000 pg/L PCB 202 442 1000 pg/L PCB 203 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB | | | | |
| PCB 181 396 1000 pg/L PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 190 234 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 203 442 1000 pg/L PCB 204 447 1000 pg/L PCB 205 442 1000 pg/L PCB 197 245 1000 pg/L PCB 208 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PC | | | | |
| PCB 171 374 1000 pg/L PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 203 440 1000 pg/L PCB 204 447 1000 pg/L PCB 205 447 1000 pg/L PCB 206 447 1000 pg/L PCB 207 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 196 429 1000 pg/L PC | | | | |
| PCB 173 374 1000 pg/L PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 201 424 1000 pg/L PCB 202 442 1000 pg/L PCB 203 440 1000 pg/L PCB 204 447 1000 pg/L PCB 205 245 1000 pg/L PCB 206 245 1000 pg/L PCB 207 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 208 444 1000 pg/L PCB 209 447 1000 pg/L PCB 208 444 1000 pg/L P | | | | |
| PCB 172 377 1000 pg/L PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 203 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 199 203 500 pg/L PCB 203 444 1000 pg/L PCB 204 429 1000 pg/L PCB 205 427 1000 pg/L PCB 194 170 500 pg/L PCB | | | | |
| PCB 192 420 1000 pg/L PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 1990 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 203 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 204 444 1000 pg/L PCB 205 427 1000 pg/L PCB 196 429 1000 pg/L PCB 208 449 1000 pg/L PC | | | | |
| PCB 193 136 500 pg/L PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 208 245 1000 pg/L PCB 198 203 500 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB | | | | |
| PCB 180 136 500 pg/L PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 203 429 1000 pg/L PCB 204 429 1000 pg/L PCB 196 429 1000 pg/L PCB 197 427 1000 pg/L PCB 198 427 1000 pg/L PCB 208 449 1000 pg/L PCB 208 449 1000 pg/L PCB 206 451 1000 pg/L P | | | | |
| PCB 191 418 1000 pg/L PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 208 455 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EP | | | | |
| PCB 170 162 500 pg/L PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units < | | | | |
| PCB 190 234 500 pg/L PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 203 429 1000 pg/L PCB 203 444 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 208 449 1000 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 206 451 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | | | | |
| PCB 189 177 500 pg/L PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | | | | |
| PCB 202 442 1000 pg/L PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | | | | |
| PCB 201 440 1000 pg/L PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 449 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 202 | | | |
| PCB 204 447 1000 pg/L PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 209 153 500 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 201 | 440 | | |
| PCB 197 245 1000 pg/L PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 204 | | | |
| PCB 200 245 1000 pg/L PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 197 | | 1000 | |
| PCB 198 203 500 pg/L PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 200 | 245 | 1000 | |
| PCB 199 203 500 pg/L PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 198 | 203 | 500 | |
| PCB 196 429 1000 pg/L PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 199 | 203 | 500 | |
| PCB 203 444 1000 pg/L PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 196 | 429 | 1000 | |
| PCB 195 427 1000 pg/L PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 203 | 444 | | |
| PCB 194 170 500 pg/L PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 195 | 427 | 1000 | |
| PCB 208 449 1000 pg/L PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 194 | 170 | 500 | |
| PCB 208 455 1000 pg/L PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 208 | 449 | 1000 | |
| PCB 207 453 1000 pg/L PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 208 | 455 | 1000 | |
| PCB 206 451 1000 pg/L PCB 209 153 500 pg/L EPA Method 1613B Constituent MDL MRL Units | PCB 207 | 453 | 1000 | |
| PCB 209 153 500 pg/L EPA Method 1613B MDL MRL Units | PCB 206 | 451 | 1000 | |
| EPA Method 1613B Constituent MDL MRL Units | PCB 209 | 153 | 500 | |
| | EPA Method 1613B | • | - | |
| 2,3,7,8-TCDD 1.83 5 pg/L | Constituent | MDL | MRL | Units |
| | 2,3,7,8-TCDD | 1.83 | 5 | pg/L |

| 1,2,3,4,7,8-HxCDD | 1,2,3,7,8-PeCDD | 7.33 | 25 | pg/L |
|---|--------------------------|------|------|-------|
| 1.2.3,6.7,8-HxCDD | | | | |
| 1,2,3,7,8,9-HxCDD | | 4.43 | 25 | |
| 1,2,3,4,6,7,8-HpCDD | 1,2,3,7,8,9-HxCDD | 4.16 | 25 | |
| OCDD 6.21 50 pg/L 2,3,7,8-TCDF 1,50 5 pg/L 1,23,7,8-PeCDF 3,41 25 pg/L 2,3,4,7,8-PeCDF 6,24 25 pg/L 1,2,3,4,7,8-HxCDF 4,02 25 pg/L 1,2,3,4,7,8-HxCDF 3,36 25 pg/L 1,2,3,7,8,9-HxCDF 6,86 25 pg/L 1,2,3,7,8,9-HxCDF 6,86 25 pg/L 1,2,3,4,7,8,9-HpCDF 6,96 25 pg/L 1,2,3,4,7,8,9-HpCDF 6,96 25 pg/L 0CDF 9,96 50 pg/L EPA Method 8151A WRL Units Constituent MDL MRL Units 2,4-D 0,04 0,08 µg/L 2,4-DB 0,04 0,08 µg/L 2,4-DB 0,04 0,08 µg/L 2,4-DF 0,04 0,08 µg/L 2,4-DF 0,04 0,08 µg/L 2,4 | | 5.49 | 25 | • • |
| 2,3,7,8-TCDF 1.50 5 pg/L 1,2,3,7,8-PeCDF 3.41 25 pg/L 2,3,4,7,8-PeCDF 4.02 25 pg/L 1,2,3,4,7,8-HxCDF 4.02 25 pg/L 1,2,3,6,7,8-HxCDF 3.36 25 pg/L 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,7,8,9-HpCDF 6.96 25 pg/L 1,2,3,4,7,8,9-HpCDF 6.96 25 pg/L 0CDF 9.96 50 pg/L EPA Method 8151A WRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4-DT 0.04 0.08 µg/L Glopyralid 0.04 <td< td=""><td>·</td><td>6.21</td><td>50</td><td></td></td<> | · | 6.21 | 50 | |
| 1,2,3,7,8-PeCDF 3.41 25 pg/L 2,3,4,7,8-PeCDF 6.24 25 pg/L 1,2,3,47,8-HxCDF 4.02 25 pg/L 1,2,3,4,6,7,8-HxCDF 3.36 25 pg/L 2,3,4,6,7,8-HxCDF 5.26 25 pg/L 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,6,7,8-HpCDF 6.96 25 pg/L 0CDF 9.96 50 pg/L EPA Method 8151A Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 <tp>µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L</tp> | 2,3,7,8-TCDF | 1.50 | 5 | |
| 2,3,4,7,8-PeCDF 6.24 25 pg/L 1,2,3,4,7,8-HxCDF 4.02 25 pg/L 1,2,3,4,6,7,8-HxCDF 5.26 25 pg/L 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,6,7,8-HyCDF 5.93 25 pg/L 1,2,3,4,7,8,9-HpCDF 6.96 25 pg/L OCDF 9.96 50 pg/L EPA Method 8151A *********************************** | 1,2,3,7,8-PeCDF | 3.41 | 25 | |
| 1,2,3,4,7,8-HxCDF 4.02 25 pg/L 1,2,3,6,7,8-HxCDF 3.36 25 pg/L 2,3,4,6,7,8-HxCDF 5.26 25 pg/L 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,7,8,9-HpCDF 5.93 25 pg/L 0CDF 9.96 50 pg/L EPA Method 8151A ***Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L | 2,3,4,7,8-PeCDF | 6.24 | 25 | |
| 1,2,3,6,7,8-HxCDF 3.36 25 pg/L 2,3,4,6,7,8-HxCDF 5.26 25 pg/L 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,6,7,8-HpCDF 5.93 25 pg/L 0CDF 9.96 50 pg/L EPA Method 8151A Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L | 1,2,3,4,7,8-HxCDF | 4.02 | 25 | |
| 2,3,4,6,7,8-HxCDF 5.26 25 pg/L 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,6,7,8-HpCDF 5.93 25 pg/L 1,2,3,4,7,8,9-HpCDF 6.96 25 pg/L COCDF 9.96 50 pg/L EPA Method 8151A USA Description of the pg/L Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dinoseb 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPP 0.04 | 1,2,3,6,7,8-HxCDF | 3.36 | 25 | |
| 1,2,3,7,8,9-HxCDF 6.86 25 pg/L 1,2,3,4,6,7,8-HpCDF 5.93 25 pg/L 1,2,3,4,7,8,9-HpCDF 6.96 25 pg/L OCDF 9.96 50 pg/L EPA Method 8151A Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPP 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L <td></td> <td>5.26</td> <td>25</td> <td></td> | | 5.26 | 25 | |
| 1,2,3,4,6,7,8-HpCDF 5,93 25 pg/L 1,2,3,4,7,8,9-HpCDF 6,96 25 pg/L OCDF 9,96 50 pg/L EPA Method 8151A Units Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPP 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Pictoram 0.04 0.08 | 1,2,3,7,8,9-HxCDF | 6.86 | 25 | |
| 1,2,3,4,7,8,9-HpCDF 6.96 25 pg/L OCDF 9.96 50 pg/L EPA Method 8151A Units Constituent MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dinoseb 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Picloram 0.04 0.08 µg/L Quinclorac 0.04 0.08 | 1,2,3,4,6,7,8-HpCDF | 5.93 | 25 | |
| EPA Method 8151A Constituent | 1,2,3,4,7,8,9-HpCDF | 6.96 | 25 | |
| EPA Method 8151A MDL MRL Units 2,4-D 0.04 0.08 µg/L 2,4-DB 0.04 0.08 µg/L 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dinoseb 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Picloram 0.04 0.08 µg/L Quinclorac 0.04 0.08 µg/L Triclopyr 0.04 0.08 µg/L Method NWTPH-HCIDD/Gx/DX MDL MRL Units <td< td=""><td>OCDF</td><td>9.96</td><td>50</td><td></td></td<> | OCDF | 9.96 | 50 | |
| 2,4-D 0.04 0.08 μg/L 2,4-DB 0.04 0.08 μg/L 2,4,5-T 0.04 0.08 μg/L 2,4,5-TP 0.04 0.08 μg/L Acifluorfen 0.04 0.08 μg/L Bentazon 0.04 0.08 μg/L Clopyralid 0.04 0.08 μg/L Dicamba 0.04 0.08 μg/L Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX 0.04 0.08 μg/L Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 | EPA Method 8151A | | • | 1. 9 |
| 2,4-DB 0.04 0.08 μg/L 2,4,5-T 0.04 0.08 μg/L 2,4,5-TP 0.04 0.08 μg/L Acifluorfen 0.04 0.08 μg/L Bentazon 0.04 0.08 μg/L Clopyralid 0.04 0.08 μg/L Dicamba 0.04 0.08 μg/L Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX 0.04 0.08 μg/L Constituent MDL MRL Units NWTPH-GX 0.15 0.25 mg/L | Constituent | MDL | MRL | Units |
| 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dinoseb 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPP 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Picloram 0.04 0.08 µg/L Quinclorac 0.04 0.08 µg/L Triclopyr 0.04 0.08 µg/L Method NWTPH-HCIDD/Gx/DX 0.04 0.08 µg/L Constituent MDL MRL Units NWTPH-GX 0.15 0.25 0.5 mg/L | 2,4-D | 0.04 | 0.08 | μg/L |
| 2,4,5-T 0.04 0.08 µg/L 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dinoseb 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPP 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Picloram 0.04 0.08 µg/L Quinclorac 0.04 0.08 µg/L Triclopyr 0.04 0.08 µg/L Method NWTPH-HCIDD/Gx/DX MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 0.25 0.5 mg/L | 2,4-DB | 0.04 | 0.08 | μg/L |
| 2,4,5-TP 0.04 0.08 µg/L Acifluorfen 0.04 0.08 µg/L Bentazon 0.04 0.08 µg/L Clopyralid 0.04 0.08 µg/L Dicamba 0.04 0.08 µg/L Dichlorprop 0.04 0.08 µg/L Dinoseb 0.04 0.08 µg/L MCPA 0.04 0.08 µg/L MCPP 0.04 0.08 µg/L Pentachlorophenol 0.04 0.08 µg/L Picloram 0.04 0.08 µg/L Quinclorac 0.04 0.08 µg/L Triclopyr 0.04 0.08 µg/L Method NWTPH-HCIDD/Gx/DX MRL Units Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | 2,4,5-T | 0.04 | 0.08 | |
| Acifluorfen 0.04 0.08 μg/L Bentazon 0.04 0.08 μg/L Clopyralid 0.04 0.08 μg/L Dicamba 0.04 0.08 μg/L Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX 0.04 0.08 μg/L Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 0.25 mg/L | 2,4,5-TP | 0.04 | 0.08 | |
| Bentazon 0.04 0.08 μg/L Clopyralid 0.04 0.08 μg/L Dicamba 0.04 0.08 μg/L Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 0.25 mg/L | Acifluorfen | 0.04 | 0.08 | μg/L |
| Dicamba 0.04 0.08 μg/L Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX WTPH-HCID MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 0.25 mg/L | Bentazon | 0.04 | 0.08 | |
| Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX WRL Units Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 0.25 mg/L | Clopyralid | 0.04 | 0.08 | |
| Dichlorprop 0.04 0.08 μg/L Dinoseb 0.04 0.08 μg/L MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX WRL Units Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-GX 0.15 0.25 mg/L | Dicamba | 0.04 | 0.08 | μg/L |
| MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX WRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | Dichlorprop | 0.04 | 0.08 | |
| MCPA 0.04 0.08 μg/L MCPP 0.04 0.08 μg/L Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX WRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | Dinoseb | 0.04 | 0.08 | μg/L |
| Pentachlorophenol 0.04 0.08 μg/L Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | MCPA | 0.04 | 0.08 | |
| Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | MCPP | 0.04 | 0.08 | μg/L |
| Picloram 0.04 0.08 μg/L Quinclorac 0.04 0.08 μg/L Triclopyr 0.04 0.08 μg/L Method NWTPH-HCIDD/Gx/DX Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | | | | μg/L |
| Triclopyr 0.04 0.08 µg/L Method NWTPH-HCIDD/Gx/DX Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | Picloram | 0.04 | 0.08 | |
| Method NWTPH-HCIDD/Gx/DX Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | Quinclorac | 0.04 | 0.08 | μg/L |
| Method NWTPH-HCIDD/Gx/DX Constituent MDL MRL Units NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | Triclopyr | 0.04 | 0.08 | μg/L |
| NWTPH-HCID 0.25 0.5 mg/L NWTPH-Gx 0.15 0.25 mg/L | Method NWTPH-HCIDD/Gx/DX | | | |
| NWTPH-Gx 0.15 0.25 mg/L | Constituent | MDL | MRL | Units |
| 5 | NWTPH-HCID | 0.25 | 0.5 | mg/L |
| NWTPH-Dx 0.3 0.6 mg/L | NWTPH-Gx | 0.15 | 0.25 | mg/L |
| | NWTPH-Dx | 0.3 | 0.6 | mg/L |

Screening Level Values for Constituents Detected in Groundwater and Surface Water Samples RI/SCE Report

| RP - Portland Site | , |
|--------------------|---|
|--------------------|---|

| Constituent of Interest ¹ | CAS Number | Surrogate | SCE Screening Value ² | Source |
|--|--------------------------|--|--|---|
| Metals (mg/L) | | 1 | | In |
| Aluminum Antimony | 7429-90-5 7440-36-0 | | 0.05 0.006 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Anumony Arsenic | 7440-38-2 | | 1.4E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Barium | 7440-39-3 | | 0 004 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Beryllium | 7440-41-7 | | 1.17E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Boron | 7440-42-8 | | 1 6E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Cadmium | 7440-43-9 | | 9 0E-05 | Portland Harbor BERA TRVs, April 11, 2008. |
| Calcium | 7440-70-2 | | 116 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Chromium Cobalt | 7440-47-3 7440-48-4 | | 0 074 0 011 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Copper | 7440-46-4 | | 2.7E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Cyanide | 57-12-5 | | 5 2E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Hexavalent Chromium | 18540-29-9 | | 4 3E-05 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Iron | 7439-89-6 | | 1 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Lead | 7439-92-1 | | 5.4E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Magnesium | 7439-95-4 | | 82 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Manganese | 7439-96-5 | | 0.01 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Mercury | 7439-97-6 7439-98-7 | | 1 2E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Molybdenum Nickel | 7439-98-7 7440-02-0 | + | 0.18 0.016 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Potassium | 7440-02-0 | 1 | 53 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Selenium | 7782-49-2 | | 0 005 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Silver | 7440-22-4 | | 1 2E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Sodium | 7440-23-5 | | 680 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Sulfate | | | | |
| Thallium Tin | 7440-28-0 7440-31-5 | | 4.7E-05 0 073 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Uranium | 7440-61-1 | | 2 6E-03 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Vanadium | 7440-62-2 | | 2 6E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Zinc | 7440-66-6 | | 0 033 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| PCDD/PCDFs (mg/L) | | | | |
| 1,2,3,4,6,7,8,9-OCDD | 3268-87-9 | 2 3 7 8-TCDD TEF ^{3,4} | 1.7E-09 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,4,6,7,8,9-OCDF | 39001-02-0 | 2 3 7 8-TCDD TEF ^{3,4} | 1.7E-09 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,4,6,7,8-HpCDD | 35822-46-9 | 2,3,7,8-TCDD TEF ³ | 5.1E-11 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,4,6,7,8-HpCDF | 67562-39-4 | 2,3,7,8-TCDD TEF ³ | 5.1E-11 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,4,7,8,9-HpCDF 1,2,3,4,7,8-HxCDD | 55673-89-7 39227-28-6 | 2.3.7.8-TCDD TEF ³ | 5.1E-11 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,4,7,8-HxCDF | 70648-26-9 | 2 3 7 8-TCDD TEF ³ 2 3 7 8-TCDD TEF ³ | 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,6,7,8-HxCDD | 57653-85-7 | 2 3 7 8-TCDD TEF ³ | 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,6,7,8-HxCDF | 57117-44-9 | 2 3 7 8-TCDD TEF ³ | 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,7,8,9-HxCDD | 19408-74-3 | 2 3 7 8-TCDD TEF ³ | 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,7,8,9-HxCDF | 72918-21-9 | 2 3 7 8-TCDD TEF ³ | 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,7,8-PeCDD | 40321-76-4 | 2 3 7 8-TCDD TEF ³ | 5.1E-13 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2,3,7,8-PeCDF | 57117-41-6 | 2 3 7 8-TCDD TEF ^{3,4} | 1.7E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 2,3,4,6,7,8-HxCDF | 60851-34-5 | 2 3 7 8-TCDD TEF3 | 3 0E-12 | 2,3,7,8-TCDD/TEF; EPA AWQC, 1993 |
| 2,3,4,7,8-PeCDF | 57117-31-4 | 2 3 7 8-TCDD TEF ^{3,4} | 1.7E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 2,3,7,8-TCDD | 1746-01-6 | 2.4 | 5.1E-13 | Portland Harbor BERA TRVs, April 11, 2008. |
| 2,3,7,8-TCDF | 51207-31-9 | 2 3 7 8-TCDD TEF ^{3,4} | 5.1E-12 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Herbicides (mg/L) 2,4,5-T | 93-76-5 | | 0 004 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| 2 4 5-TP (Silvex) | 93-70-3 | | 0 004 | Portland Harbor BERA TRVs, April 11, 2008. |
| 2,4-D | 94-75-7 | | 0 004 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| 2,4-DB | 94-82-6 | | 0 004 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| Bromoxynil | 1689-84-5 | | 0 005 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| Dalapon | 75-99-0 | | 0.2 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Dicamba | 1918-00-9 | | 0.01 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark8 |
| Dichlorprop | 120-36-5 | | 0 004 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| Dinoseb | 88-85-7 | | 5 0E-05 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| MCPA | 94-74-6 | 1 | 2 6E-03 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| MCPP | 93-65-2 | MCPA ⁴ | 2 6E-03 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ |
| Insecticides (mg/L) 2,4'-DDD | 53-19-0 | 4,4'-DDT | 3.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 2,4 -DDD 2.4'-DDE | 3424-82-6 | 4,4-DDT 4.4'-DDT | 2.20E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 2,4'-DDT | 789-02-6 | 4,4'-DDT | 2.20E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 4,4'-DDD | 72-54-8 | 4 4'-DDT ⁴ | 3.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 4,4'-DDE | 72-55-9 | 4 4'-DDT ⁴ | 2.20E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 4,4'-DDT | 50-29-3 | | 2.20E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Total DDx | 000000 | 4,4'-DDT | 1 0E-06 | EPA NRWQC SLV, 2004 |
| Aldrin alpha-BHC | 309-00-2 319-84-6 | | 5 0E-09 4.90E-07 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| alpha-BHC alpha-Chlordane | 5103-71-9 | Chlordane | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| beta-BHC | 319-85-7 | | 1.70E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Chlordane | 57-74-9 | | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| cis-Nonachlor | 5103-73-1 | Chlordane | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |

Screening Level Values for Constituents Detected in Groundwater and Surface Water Samples RI/SCE Report

RP - Portland Site

| Constituent of CAS Interest ¹ Number | | Surrogate | SCE Screening Value ² | Source | | | | |
|---|------------------------|---|--|---|--|--|--|--|
| Diazinon | 333-41-5 | | 0 026 | EPA RSLs, May 2010. | | | | |
| delta-BHC | 319-86-8 | beta-BHC | 3.70E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Dieldrin | 60-57-1 | | 5.40E-09 5.10E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Endosulfan I Endosulfan II | 959-98-8 33213-65-9 | Endosulfan I | 5.10E-05 5.10E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Endosulfan Sulfate | 1031-07-8 | Endosulfan I ⁴ | 5.10E-05 | Oak Ridge National Laboratory Tier II SCV | | | | |
| Endrin | 72-20-8 | Lildosullali i | 2.30E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Endrin Aldehyde | 7421-93-4 | Endrin⁴ | 2.30E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Endrin Ketone | 53494-70-5 | Endrin | 2.30E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| gamma-BHC (Lindane) | 58-89-9 | | 8 0E-05 | DEQ AWQC SLV, 2004. | | | | |
| gamma-Chlordane | 5103-74-2 | Chlordane | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Heptachlor Heptachlor Epoxide | 76-44-8 1024-57-3 | | 7.90E-09 3.90E-09 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Hexachlorobenzene | 118-74-1 | | 2.90E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Malathion | 121-75-5 | | 0.73 | EPA RSLs, May 2010. | | | | |
| Methoxychlor | 72-43-5 | | 1.90E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Mirex | 2385-85-5 | | 1 0E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Oxychlordane | 27304-13-8 | Chlordane | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Total Chlordane | 1 | Chlordane | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Total Endosulfans 6 | 1 | | 5.10E-05 | Oak Ridge National Laboratory Tier II SCV | | | | |
| Total Hexachlorocyclohexanes Toxaphene | 8001-35-2 | 1 | 2.20E-03 2.80E-08 | Oak Ridge National Laboratory Tier II SCV Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| trans-Nonachlor | 39765-80-5 | Chlordane | 8.10E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| PCBs (mg/L) | 22.00.00 | | J. 10E 00 | | | | | |
| PCB 77 | 32598-13-3 | 2 3 7 8-TCDD TEF ^{3,4} | 5.20E-10 | 2,3,7,8-TCDD/TEF; EPA AWQC, 1993 | | | | |
| PCB 105 | 32598-14-4 | 2 3 7 8-TCDD TEI | 1.70E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| PCB 114 | 74472-37-0 | 2 3 7 8-TCDD TEF ^{3,4} | 1.70E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| PCB 118 | 31508-00-6 | 2 3 7 8-TCDD TEF ^{3,4} | 1.70E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| PCB 156 & 157 | 38380-08-4 | 2 3 7 8-TCDD TEF ^{3,4} | 1.70E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| PCB 167 | 52663-72-6 | 2 3 7 8-TCDD TEF ^{3,4} | 1.70E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| PCB 189 | 39635-31-9 | 2 3 7 8-TCDD TEF ^{3,4} | 1.70E-08 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Total PCBs 7 | 1336-36-3 | | 6.40E-09 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| SVOCs (mg/L) | | | | | | | | |
| 1-Methylnaphthalene | 90-12-0 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2,3,4,6-Tetrachlorophenol | 58-90-2 | | 0 001 | Canadian Water Quality Guidance Surface Water Quality Screening Level Benchmark ⁸ | | | | |
| 2 3 5-Trimethylnaphthalene | 2245-38-7 | Naphthalene | 1.40E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2,4,5-Trichlorophenol | 95-95-4 | 2,4,6-Trichlorophenol 4 | 3.20E-03 | Oak Ridge National Laboratory Tier II SCV Toxicological Benchmarks for Screening in Potential Contaminants of Concern for Effects on Aquatic Biota, 1996 Revision | | | | |
| 2,4,6-Trichlorophenol | 88-06-2 | | 2.40E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2,4-Dibromophenol | 615-58-7 | 2,4-Dichlorophenol | 0 029 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2,4-Dichlorophenol | 120-83-2 | , | 0 029 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2,4-Dimethylphenol | 105-67-9 | | 0 042 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. | | | | |
| 2,4-Dinitrophenol | 51-28-5 | | 0 073 | EPA Region 4 Water Screening Level Value ⁸ | | | | |
| 2,6-Dichloro-4-methylphenol | 2432-12-4 | 4-Chloro-3-Methylphenol | 3.20E-04 | Portland Harbor BERA TRVs, April 11, 2008 | | | | |
| 2,6-Dichlorobenzothiazole 2,6-Dichlorophenol | 3622-23-9 87-65-0 | 2,4-Dichlorophenol | 0 029 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2 6-Dimethylnaphthalene | 581-42-0 | Naphthalene | 1.40E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2-Chlorophenol | 95-57-8 | rapraratorio | 0 015 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2-Methyl-4,6-Dinitrophenol | 534-52-1 | | 2.90E-03 | EPA RSLs, May 2010. | | | | |
| 2-Methylnaphthalene | 91-57-6 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2-Methylphenol | 95-48-7 | | 0 013 0.15 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 2-Nitrophenol 3 & 4-Methylphenol | 88-75-5 1319-77-3 | 2-Methylphenol | 0.15 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 3,3'-Dichlorobenzidine | 91-94-1 | 2 Wethylphener | 2.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 3/4-Cresol | 65794-96-9 | | 3 0E-04 | EPA Region 4 Water Screening Level Value ⁸ | | | | |
| 3-Chlorophenol | 108-43-0 | 2-Chlorophenol | 0 015 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 4,6-Dichloro-o-cresol | 1570-65-6 | 2-Chlorophenol/ | 3.20E-04 | | | | | |
| | | 4-Chloro-3-Methylphenol 5 | | Portland Harbor BERA TRVs, April 11, 2008 | | | | |
| 4-Chloro-3-Methylphenol | 59-50-7 | 0.061 | 3.20E-04 | Portland Harbor BERA TRVs, April 11, 2008 | | | | |
| 4-Chloro-o-cresol | 1570-64-5 | 2-Chlorophenol/ | 3.20E-04 | Portland Harbor BERA TRVs, April 11, 2008 | | | | |
| 4-Chlorophenol | 106-48-9 | 4-Chloro-3-Methylphenol 5 2-Chlorophenol | 0 015 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| 4-Methylphenol (p-Cresol) | 106-44-5 | 2-Methylphenol ⁴ | 0 013 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. | | | | |
| 4-Nitrophenol | 100-02-7 | 2-ivietriyiprierioi | 0.15 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Acenaphthene | 83-32-9 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Acenaphthylene | 208-96-8 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Anthracene | 120-12-7 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzo(a)anthracene | 56-55-3 | + | 1.80E-06 1.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzo(a)pyrene Benzo(b)fluoranthene | 50-32-8 205-99-2 | + | 1.80E-06 1.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzo(g h i)Perylene | 191-24-2 | 1 | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzo(k)Fluoranthene | 207-08-9 | | 1.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzofluoranthenes | 56832-73-6 | Benzo(k)Fluoranthene | 1.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzoic Acid | 65-85-0 | | 0 042 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Benzyl Alcohol | 100-51-6 | | 8.60E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| bis(2-Chloroethyl)ether | 111-44-4 | + | 1.20E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| bis(2-Chloroisopropyl)ether bis(2-Ethylhexyl)phthalate | 108-60-1 117-81-7 | + | 3.20E-04 2.20E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Butylbenzylphthalate | 85-68-7 | 1 | 0 003 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Carbazole | 86-74-8 | | 3.40E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| Chrysene | 218-01-9 | | 1.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |
| o.i.jooilo | | | 1.80E-06 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. | | | | |

Screening Level Values for Constituents Detected in Groundwater and Surface Water Samples RI/SCE Report

| RP | - P | ort | lan | Ы | Site |
|-----|-----|-----|------|---|------|
| RE. | - 6 | UΙL | ıaıı | u | JILE |

| | 1 | | | |
|---|------------------------|---------------------------------|--|---|
| Constituent of Interest ¹ | CAS Number | Surrogate | SCE Screening Value ² | Source |
| Dibenzofuran | 132-64-9 | | 3.70E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Diethylphthalate | 84-66-2 | | 0 003 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Dimethylphthalate | 131-11-3 84-74-2 | | 0 003 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Di-n-butylphthalate di-n-Octyl Phthalate | 117-84-0 | | 0 003 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Fluoranthene | 206-44-0 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Fluorene | 86-73-7 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Indeno(1,2,3-cd)pyrene Isophorone | 193-39-5 78-59-1 | | 1.80E-06 0 071 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Naphthalene | 91-20-3 | | 1.40E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| n-Nitrosodimethylamine | 62-75-9 | | 4.20E-07 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| n-Nitrosodiphenylamine | 86-30-6 | | 6 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Pentachlorophenol Phenanthrene | 87-86-5 85-01-8 | | 3 0E-04 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Phenol | 108-95-2 | | 0.11 | DEQ Guidance for Level II Ecological Risk Assessment SLVs, 2001. |
| Pyrene | 129-00-0 | | 2 0E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Tetrachlorophenols | 25167-83-3 | 2,3,4,6-Tetrachlorophenol | 0 001 | EPA Regional Screening Levels, 2009. |
| Petroleum Hydrocarbons (mg/L) Diesel-Range Organics (DRO) | 68334-30-5 | | | |
| Gasoline Range Hydrocarbons | 86290-81-5 | | | |
| Residual-Range Organics (RRO) | WEY-130-500 | | | |
| VOCs (mg/L) | | | | ID 4 111 1 1000 D |
| 1,1,1-Trichloroethane | 71-55-6 | | 0 011 6.70E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,1,2,2-Tetrachloroethane 1,1,2-Trichloroethane | 79-34-5 79-00-5 | | 6.70E-05 2.40E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,1-Dichloroethane | 75-34-3 | 1 1-Dichloroethene ⁴ | 2.40E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,1-Dichloroethene | 75-35-4 | | 0 007 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,1-Dichloropropene | | cis-1,3-Dichloropropene | 5.50E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1 2 3-Trichlorobenzene 1 2 3-Trichloropropane | 87-61-6 96-18-4 | | 0 029 7.20E-07 | EPA RSLs May 2010. EPA RSLs May 2010. |
| 1,2,4-Trichlorobenzene | 120-82-1 | | 2.30E-03 | EPA RSLs, May 2010. |
| 1,2,4-Trimethylbenzene | 95-63-6 | | 7.30E-03 | Portland Harbor BERA TRVs, April 11, 2008. |
| 1,2-Dibromo-3-Chloropropane | 96-12-8 | | 3.20E-07 | EPA RSLs, May 2010. |
| 1,2-Dichlorobenzene 1,2-Dichloroethane | 95-50-1 107-06-2 | | 0 014 1.50E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,2-Dichloroethene | 540-59-0 | | 0.33 | EPA RSLs, May 2010. |
| 1,2-Dichloropropane | 78-87-5 | | 3.90E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 1,3,5-Trimethylbenzene | 108-67-8 | | 7.30E-03 | Portland Harbor BERA TRVs, April 11, 2008. |
| 1,3-Dichlorobenzene 1,3-Dichloropropane | 541-73-1 142-28-9 | | 0 014 0.73 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. EPA RSLs, May 2010. |
| 1,4-Dichlorobenzene | 106-46-7 | | 4.30E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 2 2-Dichloropropane | 594-20-7 | | | - |
| 2-Butanone (MEK) | 78-93-3 | | 7.1 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 2-Chlorotoluene 2-Ethyl-1-hexanol | 95-49-8 104-76-7 | | 0.73 0.2 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Ecotox Value for Bluegill (LC50/50). |
| 2-Ethyl-1-nexarior 2-Hexanone | 591-78-6 | | 0.2 | EPA RSLs, May 2010. |
| 4-Chlorotoluene | 106-43-4 | | 0.73 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 4-Isopropyltoluene | 99-87-6 | Isopropylbenzene | 7.30E-03 | Portland Harbor BERA TRVs, April 11, 2008. |
| 4-Methyl-2-pentanone (MIBK) 5-Methyl-2-heptanol | 108-10-1 54630-50-1 | | 0.17 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| 6-Methyl-1-heptanol | 1653-40-3 | | | |
| Acetone | 67-64-1 | | 1.5 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Benzene | 71-43-2 | | 4.10E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Bromobenzene Bromochloromethane | 108-86-1 74-97-5 | Bromodichloromethane | 0 088 1.20E-04 | EPA RSLs May 2010. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Bromodichloromethane | 75-27-4 | Biomodiciloromethane | 1.20E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Bromoform | 75-25-2 | | 8.50E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Bromomethane | 74-83-9 | | 8.70E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Carbon Disulfide Carbon Tetrachloride | 75-15-0 56-23-5 | | 9.20E-04 1.60E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Chlorobenzene | 108-90-7 | | 0.05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Chloroethane | 75-00-3 | | 0 047 | Portland Harbor BERA TRVs, April 11, 2008. |
| Chloromothono | 67-66-3 74-87-3 | | 1.90E-04 0.19 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Chloromethane cis-1,2-Dichloroethene | 156-59-2 | | 0.19 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| cis-1,3-Dichloropropene | 10061-01-5 | | 5.50E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Dibromochloromethane | 124-48-1 | | 1.50E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Dibromomethane Dichlorodifluoromethane | 74-95-3 75-71-8 | | 8.20E-03 0.39 | EPA RSLs May 2010. Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Diethyl ether | 60-29-7 | | 7.3 | EPA RSLs, May 2010. |
| Ethylbenzene | 100-41-4 | | 1.50E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Hexachlorobutadiene | 87-68-3 | | 8.60E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| lodomethane | 74-88-4 | Bromomethane | 8.70E-03 7.50E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Isobutyl Alcohol Isopropylbenzene | 78-83-1 98-82-8 | Isopropanol 4 | 7.50E-03 7.30E-03 | EPA Region 6 Surface Water Screening Benchmark Portland Harbor BERA TRVs, April 11, 2008. |
| m,p-Xylenes | 1330-20-7 | | 1.80E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Methyl tert-Butyl Ether (MTBE) | 1634-04-4 | | 0 012 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Methylene Chloride | 75-09-2 | | 4.80E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| n-Butylbenzene | 104-51-8 | | 0 036 | Update to Guidance for Conducting Ecological Risk Assessments at Remediation Sites in Texas RG-263 (Revised), January 2006. Update to Guidance for Conducting Ecological Risk Assessments at Remediation Sites in |
| n-Propylbenzene | 103-65-1 | | 0 064 | Texas RG-263 (Revised), January 2006. |
| o-Cymene | 527-84-4 | | 7.30E-03 | Portland Harbor BERA TRVs, April 11, 2008. |
| o-Xylene | 95-47-6 | | 0 013 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |

Screening Level Values for Constituents Detected in Groundwater and Surface Water Samples RI/SCE Report

RP - Portland Site

| Constituent of Interest ¹ | CAS Number | Surrogate | SCE Screening Value ² | Source |
|--------------------------------------|---------------|-----------|--|---|
| sec-Butylbenzene | 135-98-8 | | 0 041 | Update to Guidance for Conducting Ecological Risk Assessments at Remediation Sites in |
| | 100 10 5 | | 2.4 | Texas RG-263 (Revised), January 2006. |
| Styrene | 100-42-5 | | 0.1 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| tert-Butylbenzene | 98-06-6 | | 0 048 | Update to Guidance for Conducting Ecological Risk Assessments at Remediation Sites in Texas RG-263 (Revised), January 2006. |
| Tetrachloroethene | 127-18-4 | | 1.10E-04 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Toluene | 108-88-3 | | 9.80E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Total Xylenes | 1330-20-7 | | 1.80E-03 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| trans-1,2-Dichloroethene | 156-60-5 | | 0.1 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| trans-1,3-Dichloropropene | 10061-02-6 | | 5.50E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Trichloroethene | 79-01-6 | | 0 002 | EPA RSLs, May 2010. |
| Trichlorofluoromethane | 75-69-4 | | 1.3 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |
| Vinyl Chloride | 75-01-4 | | 1.60E-05 | Portland Harbor JSCS Document, Table 3-1 updated July 2007. |

Notes

¹Constituents detected in groundwater and surface water datasets included in the SCE screening.

² SCE screening value is that stipulated at the May 4, 2010 DEQ/StarLink Meeting.

Otherwise it is the most conservative of the following sources:

"Other" values from multiple sources as stipulated in DEQ Comment Letter dated July 1, 2009.

Portland Harbor BERA TRVs, April 11, 2008.

Most conservative JSCS value. Note: EPA Tap Water PRGs listed on JSCS Table 3-1 were

updated with the April 2009 RSLs prior to determination of the most conservative JSCS value

DEQ Level II ERA SLV (most conservative surface water value).

EPA Region 3,6,9 Consolidated RSLs, Note: If no tap water value provided, but MCL provided, then MCL used.

Values from multiple sources as stipulated in DEQ Comment Letter dated February 5, 2010 ³ Value calculated by dividing 2,3,7,8-TCDD screening value by the 2005 WHO TEF value for

humans and mammals (JSCS values) or the most conservative 1998 WHO TEF for birds, mammals, and fish (DEQ 7/1/09 value).

⁴Listed analyte is used as a surrogate only when analyte-specific SLVs are unavailable.

⁵ 4-Chloro-3-methylphenol is used as a surrogate only for the Portland Harbor TRV, because no TRV is available for 2-chlorophenol.

⁶ Value stipulated in February 5, 2010 DEQ Comment Letter corrected for decimal place discrepancy.

⁷ Value applies to Total PCBs (as congeners) and Total PCBs (as Aroclors).

⁸ The primary source is reported as referenced by DEQ in letters dated July 1, 2009 and February 5, 2010.

Acronyms and Abbreviations

-- = not available mg/L = milligrams per liter

AWQC = Ambient Water Quality Criteria

BERA = baseline ecological risk assessment

CAS = Chemical Abstract Service

DEQ = Oregon Department of Environmental Quality

EPA = United States Environmental Protection Agency

ERA = ecological risk assessment

JSCS = Portland Harbor Joint Source Control Strategy

MCL = Maximum Contaminant Level NRWQC = National Recommended Water Quality Criteria

PCB = polychlorinated biphenyl

PRG = preliminary remediation goal RSL = regional screening level

SCE = Source Control Evaluation

SLV = screening level value

SVOC = semivolatile organic compound

TEF = toxic equivalency factor TRV = toxicity reference value

VOC = volatile organic compound WHO = World Health Organization

ATTACHMENT D
OUTFALL SAMPLING WORKSHEET

OUTFALL 22B PERFORMANCE MONITORING SURFACE WATER AND OUTFALL SAMPLING WORKSHEFT

| SAMPLE LOCATION: | | | | | DATE: | | | START TIME: | | |
|---|--------------------|--------------------------|---|----------------------------------|----------|-----------------|---------|-------------|----------|------|
| PERSONNEL: | | | | | WEATHER: | | | | | |
| | | | | | | | | | | |
| | ME | ASUREMENT TYPE | VALUE/UNITS | INSTRUM | 1FNT | | COI | MMENTS | | |
| | AIR TEMP (| | VALUE/ UNITS | INSTRUIV | JIVIENI | | | VIIVILIVIS | | |
| | | MPERATURE (°C) | | | | | | | | |
| | SAMPLE DEPTH (TWC) | | | | | | | | | |
| | pH | | | | | | | | | |
| | ORP | | | | | | | | | |
| | CONDUCTI | VITY | | | | | | | | |
| | TURBIDITY | | | | | | | | | |
| | FERROUS II | RON | | | | | | | | |
| | DISSOLVED | OXYGEN | | | | | | | | |
| | OBSERVATI | | | | | | | | | |
| | | | | | | | | | | |
| ADDITIONAL C | OMMENTS/0 | DBSERVATION | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | SAMPLE C | OLLECTION | | | | | | |
| SAMPLE NUME | BFR | | QA/QC SAMPLE NO. | | | SAMPLE | TIMF: | | | |
| SAMPLE COMP | | | Crit Co or iivii EE ivo. | | | 0/11/11/22 | 111112. | | | |
| LABORATORY | | | | COC# | | | | | | |
| LABORATORY | | | | COC # | | | | | | |
| LABORATORY | | | | COC# | | | | | | |
| LABORATORY | | | | COC # | | | | | | |
| <u> </u> | | METERS | PRESERVATION/SIZE | NUMBER/VOLUME | IA | l Boratory # | ICED | (Y/N) | COMM | FNTS |
| Total/Dissolve | | 200.7 or EPA 200.8 | 1 500ml HDPE HNO3 pH<2, cool | TOWNSER VOESTIVE | | | 1028 | (17.14) | COLVIIVA | |
| Total/Dissolve | | | 4°C 1 250ml HDPE HNO3 pH<2, cool | | | | | | | |
| | | 7195 or EPA 7196A | 1 250ml HDPE cool 4°C | | | | | | | |
| | | ls (VOCs) EPA 8260C | 3 40 mL Glass Vials, HCL pH<2, | | | | | | | |
| | | ounds (SVOCs) EPA 8270D | cool 4°C 2 1L Amber Glass, cool 4°C | | | | | | | |
| | | | 2 1L Amber Glass, cool 4°C | | | | | | | |
| Polycyclic Aromatic Hydrocarbons (PAHs) EPA 8270 SIM Organochlorine Pesticides EPA 1699 | | | | | | | | | | |
| Chlorinated He | | | 2 1L Amber Glass, cool 4°C 2 1L Amber Glass, cool 4°C | | | | | | | |
| PCDDs/PCDFs | | OIJIA | · | | | | | | | |
| | | entification NWTPH-HCID | 2 1L Amber Glass, cool 4°C 1 500ml Glass, HCL pH<2, cool | | | | | | | |
| Diesel Quantit | | | 4°C 1 500ml Glass, HCL pH<2, cool | | | | | | | |
| Gasoline Quan | | | 4°C 3 40ml Glass Vials, HCL pH<2, | | | | | | | |
| Gasoline Quan | ititation NW I | rп-uX | cool 4°C | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| SOP-3: DECON | TAMINATION | I PROCEDURES FOLLOWED? Y | ES/NO: | SAMPLE METHOD U | SED: | | | | | |
| QA/QC SAMPLE COLL/DESCRIBE: | | | | SAMPLE TYPE (GRAB, SPLIT, ETC.): | | | | | | |
| CHAIN OF CUSTODY COMPLETED? YES/NO: | | | INSTRUMENT CALIBRATION (DATE/TIME): | | | | | | | |
| WASTE DISPOSAL METHOD: | | | CALIBRATION STANDARD: | | | | | | | |
| | | | | | | | | | | |
| ADDITIONAL C | OMMENTS: | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |