UNITED STATES ENVIRONMENTAL PROTECTION AGENCY WASHINGTON, D.C. 20460



Office of Pesticide Programs

Antimicrobials Division (AD) September 13, 2013

SUBJECT:

Zinc Oxide

Guideline:

OCSPP 830.1620

Description of Production Process

Particle size, fiber length, and diameter distribution

Applicant:	Arch/Lonza				
EPA Reg. No.:	62190-29				
Product Name	Chemonite Part C				
DP Barcode:	413186				
MRID :	49085501				
Active Ingredient on OPPIN	Zinc oxide				
% Active	97%				
PC Code	088502				
CAS#	1314-13-2				

FROM:

Chris Jiang

Product Science Branch

Antimicrobials Division (7510P)

THRU:

Karen Hicks, Lead

Acute Toxicity/Product Chemistry Team

Product Science Branch

Antimicrobials Division (7510P)

TO:

Tom Luminello, Jr.

Regulatory Management Branch II Antimicrobials Division (7510P) Philo Grand 9113113 The Chris Johns for KP 9113/13

Background

The data package consists of:

- 1. Transmittal Document signed by John French of Arch/Lonza
- Particle size analysis using Chemonite Part C, OCSPP 830.1620 –
 Description of Production Process: Particle size, fiber length, and diameter completed on March 20, 2013
- 3. Particle size analysis of 5 batches of Zinc Oxide powder sample by American Chemet Corporation, East Helena MT

MRID	Citation	Receipt Date
49085501 Zinc Oxide: Chemonite Part C Manufacturing Process Report and Particle Size Report		3/21/2013

Good Laboratory Practices Statement:

This study was done according to GLP requirements.

Particle Size Distribution Table

Item	Description					Comment			
	lo	lentity of	Test Mat	erial					
Composition	Zinc Oxide								
Source	American Chemet Corporation								
Lot/Batch ID	87096,	87097							
		Sample I	Preparati	on					
Sample Amount	Enough								
Dispersion Medium	Reagent alcohol 200 proof (Pharmco-AAPR) / Aerosol OT solution								
Dispersion Equipment	Cole-Parmer 8891 sonication machine								
Duration of Dispersion Treatment	1 second								
Dispersion Verification	Repeat at 1 second duration as necessary till a 70-90% measuring range is achieved.								
		Analyti	c Method	1					
Measurement Principle	Light sca								
Instrument/Model		LA-910 Pa							
Software Version	Windows	TM WET	(LA-910)	ver. 3.72					
Graphical Representation		Frequency Distribution diameter vs. frequency							
Limits of Measurement (min/max)	Not prov	ided							
Calibration or Standardization Procedure (reference materials)	Calibrate	ed using b	lank settir	ng					
Precision: Repeatability or Reproducibility	Not prov								
		Re	sults						
Distribution Basis (mass, number, or volume)	diameter								
Mean Diameter (µm)	1.6559	1.8348	1.1614	1.1686					
10% size (μm)	0.6243	0.6781	0.3207	0.3207					
50% size (μm)	1.3571	1.4576	0.8779	0.8750					
90% size (μm)	3.1112	3.5185	2.3380	2.3624	3.9650				
Min/max of Size Range (µm)	0.1-10 μm								
% less than 0.1 µm	N/A								
	Additio	nal Infor	mation/C	omment	S				
The product has particles of no con	ncern.								