# TABLE A-1.

# TECHNICAL REVIEW ACTION SUMMARY SDG 10316058

Arsenic		
Cadmium		J1, J+1
Potassium		J2, J+2
Selenium		J-1
If the field is	left b	plank no actions or qualifications were necessary.
J1 -		Positive result is flagged as estimated (J) due to uncertainty at the low level.
J2 -		Result is flagged as estimated (J) due to non-compliant serial dilution reproducibility.
J+1 -		Positive result <2 PQL is flagged as estimated with the potential for high bias (J+) due to non-compliant CRI recovery.
J+2 -	•	Positive result is flagged as estimated with the potential for high bias (J+) due to non-compliant MS/MSD recoveries.
J-1 -	•	Result <2 PQL is flagged as estimated with the potential for low bias

(J-) due to non-compliant CRI recovery.

# TECHNICAL REVIEW REPORT

**SDG 10316268** 

**ELEMENTAL PARAMETERS** 

### TECHINCAL REVIEW REPORT

### SDG 10316268

### **ELEMENTAL PARAMETERS**

The data evaluation was based on USEPA SW-846 Method 6010B for cadmium, potassium, and phosphorus and 6020 for arsenic and selenium (Methods) and included the following parameters:

- calibration
- blanks
- \* ICP interference check sample
  - matrix spike analysis
  - duplicate sample analysis
- \* laboratory control sample analysis
- \* ICP serial dilution analysis
- \* ICPMS internal standard analysis
  - detection limits
  - overall assessment

Table A-2 summarizes the technical review actions that are detailed below.

Data validation, described in SW-846 and the Guidelines, which includes an evaluation of the usability of technically reviewed results with respect to project Data Quality Objectives and site chemistry knowledge, is included in the Data Validation/Usability Report.

<sup>\*</sup> All criteria were met for this parameter.

# **CALIBRATION:**

Low-level calibration standards (CRI) providing recoveries not within 90-110% are tabulated below:

<u>CRI ID.</u> 8-3/00:25	ELEMENT cadmium potassium	RECOVERY (%) 123.4 84.8
8-7/03:20	selenium	83.8
8-7/14:31	selenium	85.2

Associated samples requiring action: (cadmium) - 507166, 507113, 507168, 507104; (selenium) - 507156, 507601, 507157

### Action:

- For recovery above the upper limit positive results reported <2 PQL for the element are flagged as estimated with the potential for high bias (J+).
- For recovery below the lower limit results reported <2 PQL for the element are flagged as estimated with the potential for low bias (J-).

### Comment:

Only calibrations bracketing samples associated with this SDG are evaluated.

# **BLANKS**:

Blanks providing positive results and their associated action levels (AL) are tabulated below:

BLANK ID.	ELEMENT potassium	CONC. (mg/L)	AL (mg/L)
CCB 8-3/01:06		0.245	1.23
CCB 8-3/01:55	cadmium	0.00068	0.0034
	potassium	0.521	2.61
CCB 8-10/09:34	potassium	0.710	3.55

BLANK ID. CCB 8-10/10:12	ELEMENT potassium	CONC. (mg/L) 0.600	AL (mg/L) 3.00
507CDI	potassium	0.28	1.4
507701	potassium	0.14	0.70

Associated samples with positive results reported <u>below</u> the action level: (cadmium) - 507166, 507113, 507168, 507104

#### Action:

• Positive results are flagged as not-detected at the reported value (U).

### Comments:

Only calibration blanks bracketing samples associated with the SDG were evaluated.

# MATRIX SPIKE ANALYSIS:

#### Comments:

For sample 507157 the native level of potassium exceeded four times the spiking level, therefore, this parameter could not be evaluated.

# **DUPLICATE SAMPLE ANALYSIS:**

### Comments:

For this SDG sample 507601 is collocated with sample 507156. For this collocated sample pair all precision limits specified in the QAPP were met.

### **DETECTION LIMITS:**

For this SDG, the laboratory was required to report results to their method detection limit (MDL). The MDL (described in 40CFR Part 136, Appendix B and incorporated by reference in SW-846), provides an error band, by definition, of  $\pm$  100 percent. The Estimated Quantitation Limit (EQL), is established at 5-10X the MDL in SW-846.

### Action:

Positive results reported between the MDL and PQL are flagged as estimated (J).

# Comments:

The data user is cautioned that these results may not be analytically reproducible or statistically valid.

# **OVERALL ASSESSMENT:**

The positive results reported <2 PQL for cadmium in samples 507166, 507113, 507168, and 507104 are flagged as estimated with the potential for high bias (J+) due to non-compliant CRI stability.

The results reported <2 PQL for selenium in samples 507156, 507601, and 507157 are flagged as estimated with the potential for low bias (J-) due to non-compliant CRI stability.

The positive results reported for cadmium in samples 507166, 507113, 507168, and 507104 are flagged as not-detected at the reported value (U) due to blank contamination.

Positive results reported <PQL are flagged as estimated (J) due to uncertainty at the low level.

All additional QC results reviewed were within specification and no further actions or qualifiers were necessary.

### TABLE A-2.

# TECHNICAL REVIEW ACTION SUMMARY SDG 10316268

Arsen	1	C

Cadmium

J1, J+1, U1

Potassium

Selenium

J-1

# Phosphorus

If the field is left blank no actions or qualifications were necessary.

J1	_	Positive result <pql (j)="" as="" at<="" due="" estimated="" flagged="" is="" th="" to="" uncertainty=""></pql>
		the low level.

- J+1 Positive results <2 PQL are flagged as estimated with the potential for high bias (J+) due to non-compliant CRI stability.
- J-1 Results <2 PQL are flagged as estimated with the potential for low bias (J-) due to non-compliant CRI stability.
- U1 Positive result is flagged as not-detected at the reported value (U) due to blank contamination.

# TECHNICAL REVIEW REPORT

SDG 10316058

WET CHEMISTRIES

### TECHNICAL REVIEW REPORT

### SDG 10316058

### WET CHEMISTRIES

The data evaluation was based on the procedures set forth in the Methods and included the following parameters:

- \* holding times
- \* calibration
- \* blanks
  - matrix spike sample analysis
- \* standard reference material analysis
  - duplicate sample analysis
  - detection limits
  - overall assessment
- \* All criteria were met for this parameter.

Data validation, described in SW-846 and the Guidelines, which includes an evaluation of the usability of technically reviewed results with respect to project Data Quality Objectives and site chemistry knowledge, is included in the Data Validation/Usability Report.

A glossary of data qualifier definitions is presented in Appendix B.

# MATRIX SPIKE SAMPLE ANALYSIS:

Samples providing matrix spike (MS)/MS duplicate (MSD) precision or recoveries not within the laboratory default limits when the native level is reported at less than four times the spiking level are tabulated below:

<u>SAMPLE ID.</u> 507172	PARAMETER o-phosphate-P	MS/MSD RECOVERY (%) 16/
507114	fluoride (IC)	82/55

#### Action:

• For both MS and MSD recoveries below the lower limit sample results reported for the parameter are flagged as estimated with the potential for low bias (J-).

### Comments:

For recovery no action is applied when only one of the MS/MSD pairs is out of specification.

The above actions are applied to <u>all</u> environmental samples associated with the laboratory group in the SDG.

For sample 507114 the native levels of chloride and sulfate exceeded four times the spiking level, therefore, this parameter could not be evaluated.

For sample 507172 the native levels of chloride, nitrate-N, and sulfate exceeded four times the spiking level, therefore, this parameter could not be evaluated.

### **DUPLICATE SAMPLE ANALYSIS**:

1. Field Duplicates:

#### Comments:

For this SDG sample 507600 is collocated with sample 507177. For this collocated sample pair all precision limits specified in the QAPP were met.

2. Samples analyzed for fluoride by IC and ISE:

Samples 507131 and 507114 were analyzed for fluoride by both IC and ISE Methods. For these samples the ISE Method provided results considerably lower than the IC Method. Only the results from the ISE Method should be used.

# **DETECTION LIMITS**:

For this SDG, the laboratory was required to report results to their method detection limit (MDL). The MDL (described in 40CFR Part 136, Appendix B and incorporated by reference in SW-846), provides an error band, by definition, of  $\pm$  100 percent. The Estimated Quantitation Limit (EQL) is established at 5-10X the MDL in SW-846.

### Action:

• Positive values reported between the MDL and PQL are flagged as estimated (J).

### Comments:

Any values below the PQL contain inherently increasing error bands as the numbers become smaller. It is essential that the data user considers these statistical impacts on data quality at the low levels.

### OVERALL ASSESSMENT:

Sample 507114 provided MS/MSD recoveries of fluoride (IC) below the lower limit. The results reported for this parameter in samples 507147, 507148, 507149, 507128, 507127, 507126, 507124, 507131, and 507114 associated with the Batch are flagged as estimated with the potential for low bias (J-).

Any values reported positive between the MDL and PQL are flagged as estimated (J) due to uncertainty at the low levels.

All additional QC criteria evaluated were within specification and no further actions or flagging were required or deemed necessary.

# TECHNICAL REVIEW REPORT

SDG 10316268

**WET CHEMISTRIES** 

# TECHNICAL REVIEW REPORT

### SDG 10316268

### WET CHEMISTRIES

The data evaluation was based on the procedures set forth in the Methods and included the following parameters:

- \* holding times
- \* calibration
- \* blanks
  - matrix spike sample analysis
- \* standard reference material analysis
  - duplicate sample analysis
  - detection limits
  - overall assessment
- \* All criteria were met for this parameter.

Data validation, described in SW-846 and the Guidelines, which includes an evaluation of the usability of technically reviewed results with respect to project Data Quality Objectives and site chemistry knowledge, is included in the Data Validation/Usability Report.

A glossary of data qualifier definitions is presented in Appendix B.

# MATRIX SPIKE SAMPLE ANALYSIS:

Samples providing matrix spike (MS)/MS duplicate (MSD) recoveries or precision not within the laboratory default limits when the native level is reported at less than four times the spiking level are tabulated below:

SAMPLE ID.	<u>PARAMETER</u>	MS/MSD RECOVERY (%)
507123	ammonia-N	/80
	fluoride (IC)	85/85
	nitrate-N	72/73
507157	chloride	57/56
	nitrate-N	88/89

### Action:

• For both MS and MSD recoveries below the lower limit sample results reported for the parameter are flagged as estimated with the potential for low bias (J-).

### Comments:

The above action is applied to <u>all</u> samples associated with the SDG.

For recovery no action is applied when only one of the MS/MSD pairs is out of specification.

For chloride and sulfate the native levels in sample 507123 and sulfate in sample 507157 exceeded four times the spiking level, therefore, this parameter could not be evaluated.

### **DUPLICATE SAMPLE ANALYSIS**:

1. Field Duplicates.

### Comments:

For this SDG sample 507601 is collocated with sample 507156. For this collocated sample pair all precision limits specified in the QAPP were met.

2. Samples analyzed for fluoride by IC and ISE methods:

Samples 507155, 507156, 507601, and 507157 were analyzed by both methods and the ISE result was lower than the IC method. For all except 507155 only the results from the ISE method should be used since they were significantly lower than the IC value.

### **DETECTION LIMITS:**

For this SDG, the laboratory was required to report results to their method detection limit (MDL). The MDL (described in 40CFR Part 136, Appendix B and incorporated by reference in SW-846), provides an error band, by definition, of  $\pm$  100 percent. The Estimated Quantitation Limit (EQL) is established at 5-10X the MDL in SW-846.

### Action:

• Positive values reported between the MDL and PQL are flagged as estimated (J).

#### Comments:

Any positive values below the PQL contain inherently increasing error bands as the numbers become smaller. It is essential that the data user considers these statistical impacts on data quality at the low levels.

### OVERALL ASSESSMENT:

Sample 507123 provided MS/MSD recoveries of fluoride IC and nitrate-N and sample 507157 provided MS/MSD recoveries of chloride and nitrate-N below the lower limit. The results reported for these parameters in all samples associated with the SDG are flagged as estimated with the potential for low bias (J-).

Samples 507155, 507156, 507601, and 507157 were analyzed by both methods and the ISE result was lower than the IC method. For all except 507155 only the results from the ISE method should be used since they were significantly lower than the IC value.

Any values reported positive between the MDL and PQL are flagged as estimated (J) due to uncertainty at the low levels.

All additional QC criteria evaluated were within specification and no further actions or flagging were required or deemed necessary.

# APPENDIX B

**DEFINITION OF DATA QUALIFIERS** 

# GLOSSARY OF DATA QUALIFIERS

- J The associated value is an estimated quantity.
- R The data are unusable.
- U The parameter is not detected at the reported value.
- B The value is above the MDL or IDL but below the RL, or CRDL

# APPENDIX C

**GLOSSARY OF ACRONYMS** 

### **GLOSSARY OF ACRONYMS**

SDG - Sample Delivery Group

USEPA - Unites States Environmental Protection Agency

DQO - Data Quality Objectives

QAPjP - Quality Assurance Project Plan

RPD - Relative Percent Difference

CRDL - Contract Required Detection Limit

RL - Reporting Limit

IDL - Instrument Detection Limit

MDL - Method Detection Limit

CLP - Contract Laboratory Program

ICP - Ion Coupled Plasma

MS - Matrix Spike

MSD - Matrix Spike Duplicate

DATA PACKAGE REPORT
SAMPLE DELIVERY GROUP
RCRA SDG
10316058



Project:

Orthophosphate as P

Date: 08/11/2015 03:30 PM

1.6

mg/L

**RCRA** 

Pace Project No.: 10316058

10010008									
Sample: 507114 A,B,C	Lab ID:	10316058019	Collecte	ed: 07/29/1	5 11:10	Received: 07/	/30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical	Method: EPA 6	010 Prepa	ration Meth	od: EPA	A 3010			
Cadmium Potassium	0.0048 √ 37.4 √	子 mg/L 子 mg/L	0.0030 2.5	0.00065 0.13	1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:42 08/03/15 02:42		M1
6020 MET ICPMS	Analytical	Method: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic :	0.12 0.0021	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 05:10 08/07/15 05:10		
SM4500F-C Fluoride	Analytical	Method: SM 45	500F/C						
Fluoride	0.95①	mg/L	1.0	0.051	1		08/08/15 13:51	16984-48-8	
300.0 IC Anions	Analytical	Method: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	135 -3:30 ND 100	mg/L mg/L mg/L mg/L	2.4 0.10 0.10 2.4	1.2 0.0073 0.050 1.2	2 2 1 2		07/31/15 02:03 07/31/15 02:03 07/30/15 16:31 07/31/15 02:03	16984-48-8 14797-55-8	M1 M1
350.1 Ammonia	Analytical	Method: EPA 3	50.1						
Nitrogen, Ammonia	1.9	mg/L	0.040	0.020	1		08/10/15 10:40	7664-41-7	
Phosphate, Ortho Low Level	Analytical	Method: SM 45	600-P E						

0.035

20

07/30/15 16:27

0.10

M6



Project:

**RCRA** 

Pace Project No.:	10316058

Sample: 507124	Lab ID: 1	0316058017	Collecte	d: 07/29/1	09:00	Received: 07/	30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical M	lethod: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 16.6 H	mg/L mg/L	0.0030 2.5	0.00065 0.13	1 1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:25 08/03/15 02:25		
6020 MET ICPMS	Analytical M	lethod: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0086 0.0034	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:52 08/07/15 04:52		
300.0 IC Anions	Analytical M	lethod: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	189 0.76 <i>J</i> - 3.2 88.9	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1 1		07/31/15 04:24 07/30/15 20:18 07/30/15 20:18 07/30/15 20:18	16984-48-8 14797-55-8	
350.1 Ammonia	Analytical M	lethod: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/10/15 10:36	7664-41-7	
Phosphate, Ortho Low Level	Analytical M	lethod: SM 45	500-P E						
Orthophosphate as P	0.10	mg/L	0.0050	0.0017	1		07/30/15 16:13		



Project:

**RCRA** 

Date: 08/11/2015 03:30 PM

Pace Project No.: 10316058

Sample: 507126	Lab ID: 1	0316058016	Collecte	d: 07/29/15	5 08:20	Received: 07/	30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical M	lethod: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 12.4 J	mg/L mg/L	0.0030 2.5	0.00065 0.13	1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:22 08/03/15 02:22		
6020 MET ICPMS	Analytical N	1ethod: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0075 0.0023	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:47 08/07/15 04:47	Contractor of the contractor	
300.0 IC Anions	Analytical N	1ethod: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	93.1 0.90 5 2.2 88.2	mg/L mg/L mg/L mg/L	1.2 0.050 0.10 1.2	0.60 0.0036 0.050 0.60	1 1 1 1		07/30/15 20:03 07/30/15 20:03 07/30/15 20:03 07/30/15 20:03	16984-48-8 14797-55-8	
350.1 Ammonia	Analytical N	fethod: EPA 3	50.1		*				
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/10/15 10:35	7664-41-7	
Phosphate, Ortho Low Level	Analytical N	Method: SM 45	500-P E						
Orthophosphate as P	0.083	mg/L	0.0050	0.0017	1		07/30/15 16:12		



Project:

**RCRA** 

Pace Project No.: 10316058

Sample: 507127	Lab ID: 1	0316058015	Collecte	d: 07/29/1	07:45	Received: 07/	30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical M	lethod: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 18.6 47	mg/L r mg/L	0.0030 2.5	0.00065 0.13	1 1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:16 08/03/15 02:16		
6020 MET ICPMS	Analytical M	lethod: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0071 0.0059	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:43 08/07/15 04:43		
300.0 IC Anions	Analytical M	lethod: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	298 0.56 5.7 217	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 6.0	3.0 0.0036 0.050 3.0	5 1 1 5	×	07/31/15 04:06 07/30/15 19:48 07/30/15 19:48 07/31/15 04:06	16984-48-8 14797-55-8	
350.1 Ammonia	Analytical M	lethod: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/10/15 10:34	7664-41-7	
Phosphate, Ortho Low Level	Analytical M	lethod: SM 45	500-P E						
Orthophosphate as P	0.092	mg/L	0.0050	0.0017	1		07/30/15 16:11		



Project:

RCRA

Pace Project No.: 10316058

Sample: 507128	Lab ID: 1	0316058014	Collected	d: 07/28/15	5 18:20	Received: 07/	30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical M	ethod: EPA 6	010 Prepar	ation Meth	od: EPA	3010			
Cadmium Potassium	ND 22.0 T	mg/L mg/L	0.0030 2.5	0.00065 0.13	1 1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:10 08/03/15 02:10		
6020 MET ICPMS	Analytical M	ethod: EPA 6	020 Prepai	ation Meth	od: EPA	3020			
Arsenic Selenium	0.014 0.0037	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:38 08/07/15 04:38		
300.0 IC Anions	Analytical M	ethod: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	297 0.43 7.5 124	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 6.0	3.0 0.0036 0.050 3.0	5 1 1 5		07/31/15 01:44 07/30/15 16:14 07/30/15 16:14 07/31/15 01:44	16984-48-8 14797-55-8	
350.1 Ammonia	Analytical M	ethod: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/10/15 10:33	7664-41-7	
Phosphate, Ortho Low Level	Analytical M	ethod: SM 45	500-P E						
Orthophosphate as P	0.19	mg/L	0.0050	0.0017	1		07/30/15 16:08		



Project:

**RCRA** 

Pace Project No.: 10316058

Sample: 507131	Lab ID: 10316058018	Lab ID: 10316058018 Collected: 07/29/15 10:00 Received: 07/30/15 10:00 Matrix: Water								
Parameters	Results Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual		
6010 MET ICP	Analytical Method: EPA	6010 Prepa	ration Meth	od: EPA	3010					
Cadmium Potassium	0.0031	0.0030 2.5	0.00065 0.13	1 1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:37 08/03/15 02:37				
6010 MET ICP, Dissolved	Analytical Method: EPA	Analytical Method: EPA 6010 Preparation Method: EPA 3010								
Cadmium, Dissolved Potassium, Dissolved	<b>0.0025Û)</b> mg/L <b>17.7 √∤</b> mg/L	0.0030 2.5	0.00065 0.13	1 1	07/31/15 10:55 07/31/15 10:55	08/03/15 00:58 08/03/15 00:58	0 0 0 0 0 1000 10			
6020 MET ICPMS	Analytical Method: EPA	6020 Prepa	ration Meth	od: EPA	3020					
Arsenic Selenium	0.047 mg/L 0.00081 ♣ mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:56 08/07/15 04:56				
6020 MET ICPMS, Dissolved	Analytical Method: EPA	6020 Prepa	ration Meth	od: EPA	3020					
Arsenic, Dissolved Selenium, Dissolved	<b>0.049</b> mg/L <b>0.00078</b> mg/L	0.00050 0.00050	0.00011 0.00020	1 1	07/31/15 11:39 07/31/15 11:39	08/03/15 10:51 08/03/15 10:51				
SM4500F-C Fluoride	Analytical Method: SM 4	1500F/C								
Fluoride	<b>0.19</b> 0) mg/L	1.0	0.051	1		08/08/15 13:47	16984-48-8			
300.0 IC Anions	Analytical Method: EPA	300.0								
Chloride Fluoride Nitrate as N Sulfate	201 mg/L -76:05 mg/L ND mg/L 171 mg/L	6.0 5.0 0.10 6.0	3.0 0.36 0.050 3.0	5 100 1 5		07/30/15 22:52 07/31/15 04:59 07/30/15 20:33 07/30/15 22:52	16984-48-8 14797-55-8			
350.1 Ammonia	Analytical Method: EPA	350.1								
Nitrogen, Ammonia	<b>0.028</b> mg/L	0.040	0.020	1		08/10/15 10:38	7664-41-7			
Phosphate, Ortho Low Level	Analytical Method: SM 4	1500-P E								
Orthophosphate as P	<b>7.0</b> mg/L	0.20	0.070	40	,	07/30/15 16:26				

07/30/15 15:33



# **ANALYTICAL RESULTS**

Project:

**RCRA** 

Pace Project No.:

Orthophosphate as P

Date: 08/11/2015 03:30 PM

10316058

race Project No 10316056									
Sample: 507147	Lab ID: 1	0316058011	Collected	d: 07/28/15	16:05	Received: 07/	30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical M	lethod: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 14.0 1	mg/L mg/L	0.0030 2.5	0.00065 0.13	1	08/01/15 14:53 08/01/15 14:53	08/03/15 01:59 08/03/15 01:59		
6020 MET ICPMS	Analytical M	lethod: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0045 0.0040	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:10 08/07/15 04:10		
300.0 IC Anions	Analytical M	lethod: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	157 0.67 4.3 65.1	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1 1		07/31/15 00:51 07/30/15 15:28 07/30/15 15:28 07/30/15 15:28	14797-55-8	
350.1 Ammonia	Analytical M	lethod: EPA 3	350.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/10/15 10:31	7664-41-7	
Phosphate, Ortho Low Level	Analytical M	lethod: SM 4	500-P E						

0.0050

0.0017

1

0.043

mg/L

07/30/15 16:06



#### **ANALYTICAL RESULTS**

Project:

**RCRA** 

Pace Project No.: 10316058

Orthophosphate as P

Date: 08/11/2015 03:30 PM

0.078

mg/L

Sample: 507148 Lab ID: 10316058012 Collected: 07/28/15 16:45 Received: 07/30/15 10:00 **Parameters** Results Units **PQL** MDL Analyzed CAS No. Qual DF Prepared 6010 MET ICP Analytical Method: EPA 6010 Preparation Method: EPA 3010 ND 0.0030 0.00065 08/01/15 14:53 08/03/15 02:03 7440-43-9 Cadmium mg/L 16.1 J+ mg/L 0.13 08/01/15 14:53 08/03/15 02:03 7440-09-7 Potassium 2.5 1 Analytical Method: EPA 6020 Preparation Method: EPA 3020 **6020 MET ICPMS** Arsenic 0.0060 mg/L 0.00050 0.00011 0.0041 mg/L 0.00050 0.00020 Selenium 300.0 IC Anions Analytical Method: EPA 300.0 07/31/15 01:09 16887-00-6 5 Chloride 182 6.0 3.0 mg/L 0.74 J 07/30/15 15:43 16984-48-8 0.0036 Fluoride 0.050 mg/L 1 0.050 07/30/15 15:43 14797-55-8 Nitrate as N 3.5 0.10 1 mg/L 85.5 mg/L 1.2 0.60 1 07/30/15 15:43 14808-79-8 Sulfate 350.1 Ammonia Analytical Method: EPA 350.1 0.020 08/10/15 10:31 7664-41-7 Nitrogen, Ammonia ND mg/L 0.040 1 Analytical Method: SM 4500-P E Phosphate, Ortho Low Level

0.0050

0.0017

1

07/30/15 16:17



# **ANALYTICAL RESULTS**

Project:

Orthophosphate as P

**RCRA** 

Pace Project No.: 10316058

Sample: 507149	Lab ID: 1	0316058013	Collecte	d: 07/28/1	5 17:40	Received: 07/	30/15 10:00 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical M	ethod: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 14.8 J	mg/L mg/L	0.0030 2.5	0.00065 0.13	1 1	08/01/15 14:53 08/01/15 14:53	08/03/15 02:06 08/03/15 02:06		
6020 MET ICPMS	Analytical M	lethod: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0070 0.0025	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	08/01/15 14:37 08/01/15 14:37	08/07/15 04:34 08/07/15 04:34		
300.0 IC Anions	Analytical M	lethod: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	141 0.96 F 2.4 64.7	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1		07/31/15 01:26 07/30/15 15:58 07/30/15 15:58 07/30/15 15:58	16984-48-8 14797-55-8	
350.1 Ammonia	Analytical M	lethod: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/10/15 10:32	7664-41-7	
Phosphate, Ortho Low Level	Analytical M	lethod: SM 4	500-P E						

0.0050

0.0017

0.085

mg/L



Project:

**RCRA** 

Pace Project No.: 10316058

Orthophosphate as P

Date: 08/11/2015 03:30 PM

Sample: 507154	Lab ID:	10316058004	Collecte	d: 07/28/1	09:30	Received: 07/	29/15 09:30 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical N	Method: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 13.8 J	mg/L mg/L	0.0030 2.5	0.00065 0.13	1 1	07/30/15 10:07 07/30/15 10:07	07/30/15 19:00 07/30/15 19:00		
6020 MET ICPMS	Analytical N	Method: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0045 0.0031	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	07/30/15 10:10 07/30/15 10:10	07/31/15 17:07 07/31/15 17:07		
300.0 IC Anions	Analytical N	Method: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	205 0.99 2.8 54.3	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1 1		07/29/15 20:28 07/29/15 16:46 07/29/15 16:46 07/29/15 16:46	14797-55-8	
350.1 Ammonia	Analytical N	Method: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/04/15 18:18	7664-41-7	
Phosphate, Ortho Low Level	Analytical N	Method: SM 45	500-P E						

0.0017

1

0.0050

0.039

mg/L

07/29/15 17:18



Project:

RCRA

Pace Project No.: 10316058

Sample: 507171	Lab ID:	10316058007	Collecte	d: 07/28/1	5 11:55	Received: 07/	29/15 09:30 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical	Method: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 21.2	mg/L 「	0.0030 2.5	0.00065 0.13	1 1	07/30/15 10:07 07/30/15 10:07	07/30/15 19:13 07/30/15 19:13	1 115 15 5	
6020 MET ICPMS	Analytical	Method: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.019 0.0030	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	07/30/15 10:10 07/30/15 10:10	07/31/15 17:20 07/31/15 17:20		
300.0 IC Anions	Analytical	Method: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	205 0.51 5.8 89.7	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1 1		07/29/15 21:38 07/29/15 17:31 07/29/15 17:31 07/29/15 17:31	16887-00-6 16984-48-8 14797-55-8 14808-79-8	
350.1 Ammonia	Analytical	Method: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/04/15 18:20	7664-41-7	
Phosphate, Ortho Low Level	Analytical	Method: SM 4	500-P E						
Orthophosphate as P	0.12	mg/L	0.0050	0.0017	1		07/29/15 17:20		



Project:

**RCRA** 

Pace Project No.: 10316058

Sample: 507172	Lab ID:	10316058010	Collecte	d: 07/28/1	14:25	Received: 07/	29/15 09:30 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical I	Method: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND <b>24.8</b> 4	mg/L mg/L	0.0030 2.5	0.00065 0.13	1 1	07/30/15 10:07 07/30/15 10:07	07/30/15 19:27 07/30/15 19:27		
6020 MET ICPMS	Analytical I	Method: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.022 0.0042	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	07/30/15 10:10 07/30/15 10:10	07/31/15 17:43 07/31/15 17:43		
300.0 IC Anions	Analytical I	Method: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	130 0.56 9.5 71.7	mg/L mg/L mg/L mg/L	2.4 0.050 0.20 1.2	1.2 0.0036 0.10 0.60	2 1 2 1		07/29/15 22:45 07/29/15 18:17 07/29/15 22:45 07/29/15 18:17	16984-48-8 14797-55-8	M1 M1 M1
350.1 Ammonia	Analytical I	Method: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/04/15 18:27	7664-41-7	
Phosphate, Ortho Low Level	Analytical I	Method: SM 45	500-P E						
Orthophosphate as P	0.38	mg/L	0.025	0.0087	5		07/29/15 17:31		M1



Project:

**RCRA** 

Date: 08/11/2015 03:30 PM

Pace Project No.: 10316058

Sample: 507173	Lab ID:	10316058006	Collecte	d: 07/28/1	11:05	Received: 07/	29/15 09:30 Ma	atrix: Water	
Parameters	Results	Units	PQL	MDL	DF	Prepared	Analyzed	CAS No.	Qual
6010 MET ICP	Analytical	Method: EPA 6	010 Prepa	ration Meth	od: EPA	3010			
Cadmium Potassium	ND 13.8 J	mg/L + mg/L	0.0030 2.5	0.00065 0.13	1 1	07/30/15 10:07 07/30/15 10:07	07/30/15 19:09 07/30/15 19:09		
6020 MET ICPMS	Analytical	Method: EPA 6	020 Prepa	ration Meth	od: EPA	3020			
Arsenic Selenium	0.0033 0.0044	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	07/30/15 10:10 07/30/15 10:10	07/31/15 17:16 07/31/15 17:16		
300.0 IC Anions	Analytical	Method: EPA 3	0.00						
Chloride Fluoride Nitrate as N Sulfate	258 0.80 3.3 65.9	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1 1		07/29/15 21:21 07/29/15 17:16 07/29/15 17:16 07/29/15 17:16	14797-55-8	
350.1 Ammonia	Analytical	Method: EPA 3	50.1						
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/04/15 18:20	7664-41-7	
Phosphate, Ortho Low Level	Analytical	Method: SM 4	500-P E						
Orthophosphate as P	0.032	mg/L	0.0050	0.0017	1		07/29/15 17:20		



Project:

**RCRA** 

Pace Project No.:

10316058

Sample: 507174

Date: 08/11/2015 03:30 PM

Lab ID: 10316058001

Collected: 07/28/15 08:05 Received: 07/29/15 09:30 Matrix: Water

Sample: 50/1/4	Lab ib.	10310038001	Collecte	u. 01120/13	00.00	5.05 Received. 07725/15 05.50 Wattix. Water				
Parameters	Results	Units	PQL -	MDL	DF	Prepared	Analyzed	CAS No.	Qual	
6010 MET ICP	Analytical	Method: EPA	6010 Prepa	ration Meth	od: EP	A 3010				
Cadmium Potassium	ND 11.5 √	mg/L +mg/L	0.0030 2.5	0.00065 0.13	1	07/30/15 10:07 07/30/15 10:07	07/30/15 18:28 07/30/15 18:28			
6020 MET ICPMS	Analytical	Method: EPA	6020 Prepa	ration Meth	od: EP	A 3020				
Arsenic Selenium	0.0035 0.0050	mg/L mg/L	0.00050 0.00050	0.00011 0.00020	1 1	07/30/15 10:10 07/30/15 10:10	07/31/15 16:54 07/31/15 16:54			
300.0 IC Anions	Analytical	Method: EPA	300.0							
Chloride Fluoride Nitrate as N Sulfate	206 0.74 4.7 93.4	mg/L mg/L mg/L mg/L	6.0 0.050 0.10 1.2	3.0 0.0036 0.050 0.60	5 1 1		07/29/15 19:35 07/29/15 16:01 07/29/15 16:01 07/29/15 16:01	16887-00-6 16984-48-8 14797-55-8 14808-79-8		
350.1 Ammonia	Analytical	Method: EPA	350.1							
Nitrogen, Ammonia	ND	mg/L	0.040	0.020	1		08/04/15 18:15	7664-41-7		
Phosphate, Ortho Low Level	Analytical	Method: SM 4	4500-P E							
Orthophosphate as P	0.052	mg/L	0.0050	0.0017	1		07/29/15 17:13			