



Analytical Laboratory

Page 1 of 16

13339 Hagers Ferry Road
Huntersville, NC 28078-7929
McGuire Nuclear Complex - MG03A2
Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number: J11100266

Customer Name(s): Bill Kennedy, Melonie Martin, Wayne Chapman, Tom Johnson

Customer Address: 3195 Pine Hall Rd
Mailcode: Belews Steam Station
Belews Creek, NC 28012

Lab Contact: Jason C Perkins **Phone:** 980-875-5348

Report Authorized By: _____ **Date:** 11/11/2011
(Signature)

Program Comments:

Please contact the Program Manager (Jason C Perkins) with any questions regarding this report.

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with a Qualifier indicate a deviation from the method quality system or quality control requirement. The qualifier description is found at the end of the Certificate of Analysis (sample results) under the qualifiers heading. All results are reported on a dry weight basis unless otherwise noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications : North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

Sample ID	Plant/Station	Collection Date and Time	Collected By	Sample Description
2011022589	BELEWS	26-Oct-11 7:15 AM	W. B. WORKMAN	FGD Purge Eff
2011022590	BELEWS	26-Oct-11 7:20 AM	W. B. WORKMAN	EQ TANK EFF.
2011022591	BELEWS	26-Oct-11 7:25 AM	W. B. WORKMAN	BIOREACTOR 1 INF.
2011022592	BELEWS	26-Oct-11 7:30 AM	W. B. WORKMAN	BIOREACTOR 2 INF.
2011022593	BELEWS	26-Oct-11 7:35 AM	W. B. WORKMAN	BIOREACTOR 2 EFF.
2011022594	BELEWS	26-Oct-11 7:40 AM	W. B. WORKMAN	FILTER BLANK
2011022595	BELEWS	26-Oct-11 7:45 AM	W. B. WORKMAN	Trip Blank
7 Total Samples				

Technical Validation Review

Checklist:

COC and .pdf report are in agreement with sample totals and analyses (compliance programs and procedures).

☒ Yes

☐ No

All Results are less than the laboratory reporting limits.

☐ Yes

☒ No

All laboratory QA/QC requirements are acceptable.

☒ Yes

☐ No

The Vendor Laboratories have been qualified by the Analytical Laboratory

Yes

Report Sections Included:

☒ Job Summary Report

☒ Sample Identification

☒ Technical Validation of Data Package

☒ Analytical Laboratory Certificate of Analysis

☐ Analytical Laboratory QC Report

☒ Sub-contracted Laboratory Results

☐ Customer Specific Data Sheets, Reports, & Documentation

☐ Customer Database Entries

☒ Chain of Custody

☒ Electronic Data Deliverable (EDD) Sent Separately

Reviewed By: DataBase Administrator

Date: 11/11/2011

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J11100266

Site: FGD Purge Eff
Collection Date: 26-Oct-11 7:15 AM

Sample #: 2011022589
Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>INORGANIC IONS BY IC</u>							
Bromide	89	mg/L		5	EPA 300.0	07-Nov-11 23:54	JAHERMA
<u>MERCURY (COLD VAPOR) IN WATER</u>							
Mercury (Hg)	234	ug/L		5	EPA 245.1	04-Nov-11 09:40	AGIBBS
<u>TOTAL RECOVERABLE METALS BY ICP</u>							
Boron (B)	143	mg/L		0.5	EPA 200.7	31-Oct-11 15:05	DJSULL1
<u>DISSOLVED METALS BY ICP-MS</u>							
Selenium (Se)	486	ug/L		10	EPA 200.8	02-Nov-11 11:25	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>							
Arsenic (As)	169	ug/L		10	EPA 200.8	02-Nov-11 10:06	MHH7131
Chromium (Cr)	194	ug/L		10	EPA 200.8	02-Nov-11 10:06	MHH7131
Copper (Cu)	116	ug/L		10	EPA 200.8	02-Nov-11 10:06	MHH7131
Nickel (Ni)	199	ug/L		10	EPA 200.8	02-Nov-11 10:06	MHH7131
Selenium (Se)	4570	ug/L		10	EPA 200.8	02-Nov-11 10:06	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:06	MHH7131
Zinc (Zn)	217	ug/L		20	EPA 200.8	02-Nov-11 10:06	MHH7131
<u>SELENIUM SPECIATION</u>							
Vendor Parameter	Complete				V_AS&C		
<u>TOTAL DISSOLVED SOLIDS</u>							
TDS	15000	mg/L		200	SM2540C	27-Oct-11 14:55	TJA7067

Site: EQ TANK EFF.
Collection Date: 26-Oct-11 7:20 AM

Sample #: 2011022590
Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>MERCURY (COLD VAPOR) IN WATER</u>							
Mercury (Hg)	181	ug/L		2.5	EPA 245.1	04-Nov-11 09:43	AGIBBS
<u>TOTAL RECOVERABLE METALS BY ICP</u>							
Boron (B)	150	mg/L		0.5	EPA 200.7	31-Oct-11 15:09	DJSULL1
<u>DISSOLVED METALS BY ICP-MS</u>							
Selenium (Se)	424	ug/L		10	EPA 200.8	02-Nov-11 11:25	MHH7131

Certificate of Laboratory Analysis

Page 5 of 16

*This report shall not be reproduced, except in full.***Order # J11100266**

Site: EQ TANK EFF.

Collection Date: 26-Oct-11 7:20 AM

Sample #: 2011022590

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>							
Arsenic (As)	150	ug/L		10	EPA 200.8	02-Nov-11 10:09	MHH7131
Chromium (Cr)	175	ug/L		10	EPA 200.8	02-Nov-11 10:09	MHH7131
Copper (Cu)	109	ug/L		10	EPA 200.8	02-Nov-11 10:09	MHH7131
Nickel (Ni)	185	ug/L		10	EPA 200.8	02-Nov-11 10:09	MHH7131
Selenium (Se)	4200	ug/L		10	EPA 200.8	02-Nov-11 10:09	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:09	MHH7131
Zinc (Zn)	204	ug/L		20	EPA 200.8	02-Nov-11 10:09	MHH7131

Site: BIOREACTOR 1 INF.

Collection Date: 26-Oct-11 7:25 AM

Sample #: 2011022591

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP</u>							
Boron (B)	145	mg/L		0.5	EPA 200.7	31-Oct-11 14:49	DJSULL1
<u>DISSOLVED METALS BY ICP-MS</u>							
Selenium (Se)	405	ug/L		10	EPA 200.8	02-Nov-11 11:25	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>							
Arsenic (As)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:12	MHH7131
Chromium (Cr)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:12	MHH7131
Copper (Cu)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:12	MHH7131
Nickel (Ni)	44.6	ug/L		10	EPA 200.8	02-Nov-11 10:12	MHH7131
Selenium (Se)	448	ug/L		10	EPA 200.8	02-Nov-11 10:12	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:12	MHH7131
Zinc (Zn)	< 20	ug/L		20	EPA 200.8	02-Nov-11 10:12	MHH7131

SELENIUM SPECIATION

Vendor Parameter Complete V_AS&C

Site: BIOREACTOR 2 INF.

Collection Date: 26-Oct-11 7:30 AM

Sample #: 2011022592

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP</u>							
Boron (B)	143	mg/L		0.5	EPA 200.7	31-Oct-11 14:53	DJSULL1

Certificate of Laboratory Analysis

Page 6 of 16

*This report shall not be reproduced, except in full.***Order # J11100266**

Site: BIOREACTOR 2 INF.

Collection Date: 26-Oct-11 7:30 AM

Sample #: 2011022592

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>							
Arsenic (As)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:15	MHH7131
Chromium (Cr)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:15	MHH7131
Copper (Cu)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:15	MHH7131
Nickel (Ni)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:15	MHH7131
Selenium (Se)	41.7	ug/L		10	EPA 200.8	02-Nov-11 10:15	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:15	MHH7131
Zinc (Zn)	< 20	ug/L		20	EPA 200.8	02-Nov-11 10:15	MHH7131

Site: BIOREACTOR 2 EFF.

Collection Date: 26-Oct-11 7:35 AM

Sample #: 2011022593

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>INORGANIC IONS BY IC</u>							
Bromide	81	mg/L		5	EPA 300.0	08-Nov-11 00:09	JAHERMA
<u>MERCURY (COLD VAPOR) IN WATER</u>							
Mercury (Hg)	< 1	ug/L		1	EPA 245.1	04-Nov-11 09:55	AGIBBS
<u>TOTAL RECOVERABLE METALS BY ICP</u>							
Boron (B)	130	mg/L		0.5	EPA 200.7	31-Oct-11 14:57	DJSULL1
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>							
Arsenic (As)	< 5	ug/L		5	EPA 200.8	02-Nov-11 10:18	MHH7131
Chromium (Cr)	< 5	ug/L		5	EPA 200.8	02-Nov-11 10:18	MHH7131
Copper (Cu)	< 5	ug/L		5	EPA 200.8	02-Nov-11 10:18	MHH7131
Nickel (Ni)	< 5	ug/L		5	EPA 200.8	02-Nov-11 10:18	MHH7131
Selenium (Se)	< 5	ug/L		5	EPA 200.8	02-Nov-11 10:18	MHH7131
Silver (Ag)	< 5	ug/L		5	EPA 200.8	02-Nov-11 10:18	MHH7131
Zinc (Zn)	< 10	ug/L		10	EPA 200.8	02-Nov-11 10:18	MHH7131
<u>SELENIUM SPECIATION</u>							
Vendor Parameter	Complete				V_AS&C		

Site: FILTER BLANK

Collection Date: 26-Oct-11 7:40 AM

Sample #: 2011022594

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>DISSOLVED METALS BY ICP-MS</u>							
Selenium (Se)	< 1	ug/L		1	EPA 200.8	02-Nov-11 11:25	MHH7131

Certificate of Laboratory Analysis

Page 7 of 16

This report shall not be reproduced, except in full.

Order # J11100266

Site: Trip Blank

Collection Date: 26-Oct-11 7:45 AM

Sample #: 2011022595

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP</u>							
Boron (B)	< 0.05	mg/L		0.05	EPA 200.7	31-Oct-11 14:45	DJSULL1
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>							
Arsenic (As)	< 1	ug/L		1	EPA 200.8	02-Nov-11 10:03	MHH7131
Chromium (Cr)	< 1	ug/L		1	EPA 200.8	02-Nov-11 10:03	MHH7131
Copper (Cu)	< 1	ug/L		1	EPA 200.8	02-Nov-11 10:03	MHH7131
Nickel (Ni)	< 1	ug/L		1	EPA 200.8	02-Nov-11 10:03	MHH7131
Selenium (Se)	< 1	ug/L		1	EPA 200.8	02-Nov-11 10:03	MHH7131
Silver (Ag)	< 1	ug/L		1	EPA 200.8	02-Nov-11 10:03	MHH7131
Zinc (Zn)	< 2	ug/L		2	EPA 200.8	02-Nov-11 10:03	MHH7131
<u>SELENIUM SPECIATION</u>							
Vendor Parameter	Complete				V_AS&C		



**APPLIED SPECIATION
AND CONSULTING, LLC**

18804 Northcreek Parkway Bothell, WA, 98011
Tel: (425) 483-3300 Fax: (425) 483-9818
www.appliedspeciation.com

November 3, 2011

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078
(704) 875-5245

Project: Belews – FGD WWTS Bi-Monthly Sampling) (LIMS # J11100266)

Dear Mr. Perkins,

Attached is the report associated with four (4) aqueous samples submitted for selenium speciation analysis on October 27, 2011. The samples were received in a sealed cooler at -0.5°C on October 28, 2011. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS). Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

A handwritten signature in black ink, appearing to read "Russell Gerads", written over a light blue horizontal line.

Russell Gerads
Vice President
Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078

Project: Belews – FGD WWTS Bi-Monthly Sampling) (LIMS # J11100266)

November 3, 2011

1. Sample Reception

Four (4) aqueous samples in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on October 27, 2011. The samples were received on October 28, 2011 in a sealed container at -0.5°C.

The samples were received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and designated a discrete sample identifier. An aliquot of each sample was filtered (0.45µm) and each filtrate was stored in a secure, monitored cryofreezer (maintained at a temperature of -80°C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

Selenium Speciation Analysis by IC-ICP-DRC-MS Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm) and injected directly into a sealed autosampler vial. No further sample preparation was performed as any chemical alteration of a sample may shift the equilibrium of the system, resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is preceded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of

each analytical day. All calibration curves, associated with each species of interest, are standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimal interval of every ten analytical runs.

Selenium Speciation Analysis by IC-ICP-DRC-MS Each sample for selenium speciation analysis was analyzed by ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS) on October 28, 2011. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic ($\text{pH} > 7$) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (DRC) containing a specific reactive gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went well and no significant analytical issues were encountered. All quality control parameters associated with this sample were within acceptance limits.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

A handwritten signature in black ink, appearing to read 'Russell Gerads', with a stylized, flowing script.

Russell Gerads
Vice President
Applied Speciation and Consulting, LLC

Selenium Speciation Results for Duke Energy
 Project Name: Belews - FGD WWTS Bi-Monthly Sampling)
 Contact: Jay Perkins
 LIMS #J11100266

Date: November 3, 2011
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Sample Results

Sample ID	Se(IV)	Se(VI)	SeCN	MeSe(IV)	SeMe	Unknown Se Species (n)
FGD Purge Eff	378	110	31.2	ND (<2.7)	ND (<2.7)	0 (0)
BioReactor 1 Inf	174	176	13.5	ND (<0.68)	ND (<0.68)	11.2 (1)
BioReactor 2 Eff	ND (<0.69)	ND (<0.61)	ND (<0.73)	ND (<0.68)	ND (<0.68)	0 (0)
Metals Trip Blk	ND (<0.14)	ND (<0.12)	ND (<0.15)	ND (<0.14)	ND (<0.14)	0 (0)

All results reflect the applied dilution and are reported in µg/L

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

n = number of unknown Se species observed

Selenium Speciation Results for Duke Energy
 Project Name: Belews - FGD WWTS Bi-Monthly Sampling)
 Contact: Jay Perkins
 LIMS #J11100266

Date: November 3, 2011
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (µg/L)	PBW1	PBW2	PBW3	PBW4	Mean	StdDev	eMDL*	eMDL 10x	eMDL 50x	eMDL 200x
Se(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.014	0.14	0.69	2.8
Se(VI)	0.000	0.000	0.000	0.000	0.000	0.000	0.012	0.12	0.61	2.5
SeCN	0.000	0.000	0.000	0.000	0.000	0.000	0.015	0.15	0.73	2.9
MeSe(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.014	0.14	0.68	2.7
SeMe	0.000	0.000	0.000	0.000	0.000	0.000	0.014	0.14	0.68	2.7

eMDL = Estimated Method Detection Limit

*Please see narrative regarding eMDL calculations

Quality Control Summary - Certified Reference Materials

Analyte (µg/L)	CRM	True Value	Result	Recovery
Se(IV)	LCS	9.57	9.76	101.9
Se(VI)	LCS	9.48	9.61	101.4
SeCN	LCS	8.92	8.987	100.7
MeSe(IV)	LCS	6.47	6.285	97.1
SeMe	LCS	9.32	8.93	95.8

Selenium Speciation Results for Duke Energy
 Project Name: Belews - FGD WWTS Bi-Monthly Sampling)
 Contact: Jay Perkins
 LIMS #J11100266

Date: November 3, 2011
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (µg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
Se(IV)	Batch QC	96.7	90.7	93.7	6.4
Se(VI)	Batch QC	55.4	48.4	51.9	13.4
SeCN	Batch QC	23.7	23.5	23.6	0.6
MeSe(IV)	Batch QC	ND (<2.7)	ND (<2.7)	NC	NC
SeMe	Batch QC	ND (<2.7)	ND (<2.7)	NC	NC

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (µg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
Se(IV)	Batch QC	1112	1225	101.7	1112	1203	99.7	1.8
Se(VI)	Batch QC	1009	1067	100.6	1009	1077	101.6	0.9
SeCN	Batch QC	915.0	913.0	97.2	915.0	915.0	97.4	0.2



CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM

Analytical Laboratory Use Only

Duke Energy Analytical Laboratory
Mail Code MG03A2 (Building 7405)
13339 Hagers Ferry Rd
Huntersville, N.C. 28078
(704) 875-5245
Fax: (704) 875-4349

1) Project Name	Bellevue - FGD		2) Phone No:
3) Client	WWTs Bi-Monthly Sampling		4) Fax No:
5) Business Unit	Bill Kennedy, Melonie Martin, Wayne Chapman, Tom Johnson		6) Process:
8) Oper. Unit:	9) Res. Type:	10) Reso. Center:	Mail Code:

ORDER#	31100266	DATE	10-27-11	TIME	9:23
LOGGED BY	AS&C	PO#	133241		
VEHICLE	AS&C	PO#	133241		
COOLER TEMP (C)	8.5				
15) PRESERVATIVE	1=HCL 2=H2SO4 3=HNO3 4=NONE				
SAMPLE PROGRAM	Water	GROUND	Drinking Water		
RCRA Waste					
19) Page 1 of 2					
DISTRIBUTION					
ORIGINAL TO LAB					
COPY TO CLIENT					

LAB USE ONLY	Se Speciation Bottle ID	13 Sample Description or ID	Date	Time	Signature	17 Comp.	18 Grab	TDS	Hg - 245.1	Br (Dionex)	Metals*	Se, soluble (no dig.)	Se, speciation - vendor to AS&C (Important to place filled bottle back into both baggies)
90		FGD Purge Eff	10/26/11	7:15	W. Johnson			1	1	1	1	1	1
91		EQ Tank Eff	10/26/11	7:20				1	1	1	1	1	1
92		BioReactor 1 Inf	10/26/11	7:25				1	1	1	1	1	1
93		BioReactor 2 Inf	10/26/11	7:30				1	1	1	1	1	1
94		BioReactor 2 Eff	10/26/11	7:35				1	1	1	1	1	1
95		Filter Blk	10/26/11	7:40				1	1	1	1	1	1
96		Metals Trip Blk	10/26/11	7:45				1	1	1	1	1	1

Customer to complete appropriate columns to right

Customer to sign & date below - fill out from left to right

Received at -0.5°C SPN 10/28/11

Filtering of the Se is performed in the field please provide a filter blank too.

1) Relinquished By	10/26/11	11:00am	2) Accepted By	10/27/11	8:45
3) Relinquished By	10/27/11	8:45	4) Accepted By	10/27/11	8:45
5) Relinquished By	10/27/11	13:00	6) Accepted By	10/28/11	13:30
7) Relinquished By	10/27/11		8) Accepted By	10/28/11	13:30
9) Sealed/locked By	10/27/11		10) Sealed/locked Opened By		
11) Sealed/locked By	10/27/11		12) Sealed/locked Opened By		

Customer, IMPORTANT!
Please indicate desired turnaround

22) Requested Turnaround

14 Days _____
7 Days _____
48 Hr _____
Other _____
*Add. Cost Will Apply

11-3-11

* B by ICP As, Cr, Cu, Ni, Se, Ag, Zn by IMS Digestions = TRM thomas.d.johnson@stiemens.com

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM

Page 16 of 16



Duke Energy Analytical Laboratory

Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd
Huntersville, N. C. 28078
(704) 875-5245
Fax: (704) 875-4349

Analytical Laboratory Use Only

ORDER# 311100266	MATRIX: OTHER	Samples Originating From NC <input checked="" type="checkbox"/> SC <input type="checkbox"/>
Logged By Cpk Am	Date & Time 10-27-11 9:23	SAMPLE PROGRAM Water _____ Ground NPDES Drinking Water UST RCRA Waste _____
Ver AS&C	Ver PO#133241	Cooler Temp (C) 3.5

¹⁹Page 1 of 2
DISTRIBUTION
ORIGINAL to LAB,
COPY to CLIENT

1)Project Name Belews - FGD	2)Phone No:
WWTS Bi-Monthly Sampling)	
2) Client: Bill Kennedy, Melonie Martin, Wayne Chapman, Tom Johnson **	4)Fax No:
5)Business Unit:	6)Process: Mail Code:
8)Oper. Unit:	10)Reso. Center:

MR #		¹⁵ Preserv.: 1=HCL 2=H ₂ SO ₄ 3=HNO ₃ 4=Ice 5=None		4	3,4	4	3,4				4
Customer to complete all appropriate non-shaded areas.		¹⁶ Analyses Required		TDS		Hg - 245.1	Br (Dionex)	Metals*	Se, soluble (no dig.)	Se, speciation - vendor to AS&C (Important to place filled bottle back into both baggies)	
Sampling conducted: 2nd and 4th Wednesday		¹⁷ Comp.	¹⁸ Grab								
Date	Time	Signature									
10/26/11	7:15	W. Workman			1	1	1	1	1		1
10/26/11	7:20					1		1	1		
10/26/11	7:25							1	1		1
10/26/11	7:30							1			
10/26/11	7:35					1	1	1			1
10/26/11	7:40								1		
10/26/11	7:45							1			1
Filtering of the Se is performed in the field please provide a filter blank too.											

LAB USE ONLY
¹¹ Lab ID
2011022589
90
91
92
93
94
95

Se Speciation Bottle ID	¹³ Sample Description or ID
	FGD Purge Eff
	EQ Tank Eff.
	BioReactor 1 Inf
	BioReactor 2 Inf
	BioReactor 2 Eff
	Filter Blk
	Metals Trip Blk

Customer to sign & date below - fill out from left to right.

1) Relinquished By W. Workman	Date/Time 10/26/11 11:00am	2) Accepted By	Date/Time
3) Relinquished By Colin	Date/Time 10-27-11 8:45	4) Accepted By A. Moore	Date/Time 10-27-11 8:45
5) Relinquished By	Date/Time	6) Accepted By	Date/Time
7) Relinquished By	Date/Time	8) Accepted By	Date/Time
9) Seal/Locked By	Date/Time	10) Seal/Lock Opened By	Date/Time
11) Seal/Locked By	Date/Time	12) Seal/Lock Opened By	Date/Time

Customer, IMPORTANT!
Please indicate desired turnaround.

²² Requested Turnaround
14 Days _____
*7 Days _____
*48 Hr _____
*Other _____
*Add. Cost Will Apply
11-3-11