

Oud an Nivea la ani

Analytical Laboratory

13339 Hagers Ferry Road Huntersville, NC 28078-7929 McGuire Nuclear Complex - MG03A2 Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number:	J11110294			
Customer Name(s):	Bill Kennedy, Melonie Martin, Wayne	e Chapman,	Tom Johnson	
Customer Address:	3195 Pine Hall Rd Mailcode: Belews Steam Station Belews Creek, NC 28012			
Lab Contact:	Jason C Perkins	Phone:	980-875-5348	
Report Authorized By: (Signature)		Date	e:	12/8/2011

Program Comments:

Please contact the Program Manager (Jason C Perkins) with any questions regarding this report.

144440004

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with a Qualifier indicate a deviation from the method quality system or quality control requirement. The qualifier description is found at the end of the Certificate of Analysis (sample results) under the qualifiers heading. All results are reported on a dry weight basis unless otherwise noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications: North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

Page 2 of 16

Sample ID	Plant/Station	Collection Date and Time	Collected By	Sample Description
2011024788	BELEWS	23-Nov-11 7:20 AM	W. Chapman	FGD Purge Eff
2011024789	BELEWS	23-Nov-11 7:25 AM	W. B. WORKMAN	EQ TANK EFF.
2011024790	BELEWS	23-Nov-11 7:30 AM	W. B. WORKMAN	BIOREACTOR 1 INF.
2011024791	BELEWS	23-Nov-11 7:35 AM	W. B. WORKMAN	BIOREACTOR 2 INF.
2011024792	BELEWS	23-Nov-11 7:40 AM	W. B. WORKMAN	BIOREACTOR 2 EFF.
2011024793	BELEWS	23-Nov-11 7:55 AM	W. B. WORKMAN	FILTER BLANK
2011024795	BELEWS	23-Nov-11 8:00 AM	W. B. WORKMAN	Trip Blank
7 Total Samples				

Checklist:

Reviewed By:

DataBase Administrator

COC and .pdf report are in agreement with sample and analyses (compliance programs and procedure					
All Results are less than the laboratory reporting lir	nits.	Yes	✓ No		
All laboratory QA/QC requirements are acceptable		✓ Yes	□ No		
The Vendor Laboratories have been qualified by th Analytical Laboratory	е	Yes			
Report Sections Included:					
✓ Job Summary Report	✓ Sub-conti	acted Laborate	ory Results		
✓ Sample Identification	Customer	Specific Data	Sheets, Reports, & Documentation		
✓ Technical Validation of Data Package	☐ Customer	Database Ent	tries		
✓ Analytical Laboratory Certificate of Analysis	✓ Chain of	Custody			
☐ Analytical Laboratory QC Report	✓ Electronic	: Data Delivera	able (EDD) Sent Separately		

Date:

12/8/2011

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J11110294

Site: FGD Purge Eff Sample #: 2011024788

Collection Date: 23-Nov-11 7:20 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
INORGANIC IONS BY IC							
Bromide	85	mg/L		5	EPA 300.0	30-Nov-11 16:29	JAHERMA
MERCURY (COLD VAPOR)	IN WATER						
Mercury (Hg)	243	ug/L		5	EPA 245.1	02-Dec-11 09:07	AGIBBS
TOTAL RECOVERABLE ME	TALS BY ICP						
Boron (B)	133	mg/L		0.5	EPA 200.7	01-Dec-11 09:58	MHH7131
DISSOLVED METALS BY IC	CP-MS						
Selenium (Se)	177	ug/L		10	EPA 200.8	06-Dec-11 11:48	MHH7131
TOTAL RECOVERABLE ME	TALS BY ICP-MS						
Arsenic (As)	157	ug/L		10	EPA 200.8	06-Dec-11 11:02	MHH7131
Chromium (Cr)	205	ug/L		10	EPA 200.8	06-Dec-11 11:02	MHH7131
Copper (Cu)	109	ug/L		10	EPA 200.8	06-Dec-11 11:02	MHH7131
Nickel (Ni)	172	ug/L		10	EPA 200.8	06-Dec-11 11:02	MHH7131
Selenium (Se)	4800	ug/L		10	EPA 200.8	06-Dec-11 11:02	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:02	MHH7131
Zinc (Zn)	214	ug/L		20	EPA 200.8	06-Dec-11 11:02	MHH7131
SELENIUM SPECIATION							
Vendor Parameter	Complet	te			V_AS&C		
TOTAL DISSOLVED SOLID	<u>s</u>						
TDS	14000	mg/L		200	SM2540C	01-Dec-11 11:35	TJA7067

Site: EQ TANK EFF. Sample #: 2011024789

Collection Date: 23-Nov-11 7:25 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
MERCURY (COLD VAPOR) IN WAT	<u>ER</u>						
Mercury (Hg)	190	ug/L		2.5	EPA 245.1	02-Dec-11 09:15	AGIBBS
TOTAL RECOVERABLE METALS B	Y ICP						
Boron (B)	142	mg/L		0.5	EPA 200.7	01-Dec-11 10:02	MHH7131
DISSOLVED METALS BY ICP-MS							
Selenium (Se)	157	ug/L		10	EPA 200.8	06-Dec-11 11:51	MHH7131

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J11110294

Site: EQ TANK EFF. Sample #: 2011024789

Collection Date: 23-Nov-11 7:25 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS	BY ICP-MS						
Arsenic (As)	150	ug/L		10	EPA 200.8	06-Dec-11 11:05	MHH7131
Chromium (Cr)	206	ug/L		10	EPA 200.8	06-Dec-11 11:05	MHH7131
Copper (Cu)	111	ug/L		10	EPA 200.8	06-Dec-11 11:05	MHH7131
Nickel (Ni)	173	ug/L		10	EPA 200.8	06-Dec-11 11:05	MHH7131
Selenium (Se)	4420	ug/L		10	EPA 200.8	06-Dec-11 11:05	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:05	MHH7131
Zinc (Zn)	199	ug/L		20	EPA 200.8	06-Dec-11 11:05	MHH7131

Site: BIOREACTOR 1 INF. Sample #: 2011024790

Collection Date: 23-Nov-11 7:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS B	SY ICP						
Boron (B)	132	mg/L		0.5	EPA 200.7	01-Dec-11 10:06	MHH7131
DISSOLVED METALS BY ICP-MS							
Selenium (Se)	108	ug/L		10	EPA 200.8	06-Dec-11 11:54	MHH7131
TOTAL RECOVERABLE METALS B	SY ICP-MS						
Arsenic (As)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:08	MHH7131
Chromium (Cr)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:08	MHH7131
Copper (Cu)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:08	MHH7131
Nickel (Ni)	18.5	ug/L		10	EPA 200.8	06-Dec-11 11:08	MHH7131
Selenium (Se)	122	ug/L		10	EPA 200.8	06-Dec-11 11:08	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:08	MHH7131
Zinc (Zn)	< 20	ug/L		20	EPA 200.8	06-Dec-11 11:08	MHH7131
SELENIUM SPECIATION							
Vendor Parameter	Complete	9			V_AS&C		

Site: BIOREACTOR 2 INF. Sample #: 2011024791

Collection Date: 23-Nov-11 7:35 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS	BY ICP						
Boron (B)	132	mg/L		0.5	EPA 200.7	01-Dec-11 10:09	MHH7131

2011024791

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J11110294

Site: BIOREACTOR 2 INF. Sample #:

Collection Date: 23-Nov-11 7:35 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS I	BY ICP-MS						
Arsenic (As)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:11	MHH7131
Chromium (Cr)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:11	MHH7131
Copper (Cu)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:11	MHH7131
Nickel (Ni)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:11	MHH7131
Selenium (Se)	18.6	ug/L		10	EPA 200.8	06-Dec-11 11:11	MHH7131
Silver (Ag)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:11	MHH7131
Zinc (Zn)	< 20	ug/L		20	EPA 200.8	06-Dec-11 11:11	MHH7131

Site: BIOREACTOR 2 EFF. Sample #: 2011024792

Collection Date: 23-Nov-11 7:40 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
INORGANIC IONS BY IC							
Bromide	85	mg/L		5	EPA 300.0	30-Nov-11 16:45	JAHERMA
MERCURY (COLD VAPOR) IN WAT	<u>ER</u>						
Mercury (Hg)	< 1	ug/L		1	EPA 245.1	02-Dec-11 09:17	AGIBBS
TOTAL RECOVERABLE METALS B	Y ICP						
Boron (B)	146	mg/L		0.5	EPA 200.7	01-Dec-11 10:13	MHH7131
TOTAL RECOVERABLE METALS B	Y ICP-MS						
Arsenic (As)	< 5	ug/L		5	EPA 200.8	06-Dec-11 11:14	MHH7131
Chromium (Cr)	< 5	ug/L		5	EPA 200.8	06-Dec-11 11:14	MHH7131
Copper (Cu)	< 5	ug/L		5	EPA 200.8	06-Dec-11 11:14	MHH7131
Nickel (Ni)	< 5	ug/L		5	EPA 200.8	06-Dec-11 11:14	MHH7131
Selenium (Se)	< 5	ug/L		5	EPA 200.8	06-Dec-11 11:14	MHH7131
Silver (Ag)	< 5	ug/L		5	EPA 200.8	06-Dec-11 11:14	MHH7131
Zinc (Zn)	< 10	ug/L		10	EPA 200.8	06-Dec-11 11:14	MHH7131
SELENIUM SPECIATION							
Vendor Parameter	Complete				V_AS&C		

Site: FILTER BLANK Sample #: 2011024793

Collection Date: 23-Nov-11 7:55 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
DISSOLVED METALS BY ICP-MS							
Selenium (Se)	< 1	ug/L		1	EPA 200.8	06-Dec-11 11:57	MHH7131

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J11110294

Site: Trip Blank Sample #: 2011024795

Collection Date: 23-Nov-11 8:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE MI	ETALS BY ICP						
Boron (B)	< 0.05	mg/L		0.05	EPA 200.7	01-Dec-11 09:54	MHH7131
TOTAL RECOVERABLE MI	ETALS BY ICP-MS						
Arsenic (As)	< 1	ug/L		1	EPA 200.8	06-Dec-11 10:59	MHH7131
Chromium (Cr)	< 1	ug/L		1	EPA 200.8	06-Dec-11 10:59	MHH7131
Copper (Cu)	< 1	ug/L		1	EPA 200.8	06-Dec-11 10:59	MHH7131
Nickel (Ni)	< 1	ug/L		1	EPA 200.8	06-Dec-11 10:59	MHH7131
Selenium (Se)	< 1	ug/L		1	EPA 200.8	06-Dec-11 10:59	MHH7131
Silver (Ag)	< 1	ug/L		1	EPA 200.8	06-Dec-11 10:59	MHH7131
Zinc (Zn)	< 2	ug/L		2	EPA 200.8	06-Dec-11 10:59	MHH7131
SELENIUM SPECIATION							
Vendor Parameter	Complete	e			V AS&C		



18804 Northcreek Parkway Bothell, WA, 98011 Tel: (425) 483-3300 Fax: (425) 483-9818 www.appliedspeciation.com

December 6, 2011

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078 (704) 875-5245

Project: Belews – FGD WWTS Bi-Monthly Sampling) (LIMS # J11110294)

Dear Mr. Perkins,

Attached is the report associated with four (4) aqueous samples submitted for selenium speciation analysis on November 29, 2011. The samples were received in a sealed cooler at -0.3°C on November 30, 2011. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS). Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078

Project: Belews – FGD WWTS Bi-Monthly Sampling) (LIMS # J11110294)

December 6, 2011

1. Sample Reception

Four (4) aqueous samples in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on November 29, 2011. The samples were received on November 30, 2011 in a sealed container at -0.3°C.

The samples were received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and designated a discrete sample identifier. An aliquot of each sample was filtered (0.45µm) and each filtrate was stored in a secure, monitored cryofreezer (maintained at a temperature of -80°C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

<u>Selenium Speciation Analysis by IC-ICP-DRC-MS</u> Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm) and injected directly into a sealed autosampler vial. No further sample preparation was performed as any chemical alteration of a sample may shift the equilibrium of the system, resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is preceded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of

each analytical day. All calibration curves, associated with each species of interest, are standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimal interval of every ten analytical runs.

Selenium Speciation Analysis by IC-ICP-DRC-MS Each sample for selenium speciation analysis was analyzed by ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS) on November 30, 2011. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic (pH > 7) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (DRC) containing a specific reactive gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went well and no significant analytical issues were encountered. All quality control parameters associated with this sample were within acceptance limits.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS Bi-Monthly Sampling Contact: Jay Perkins LIMS #J11110294

Date: December 6, 2011 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Sample Results

						Unknown Se
Sample ID	Se(IV)	Se(VI)	SeCN	MeSe(IV)	SeMe	Species (n)
FGD Purge Eff	57.4	71.6	ND (<3.0)	ND (<2.2)	ND (<2.2)	0 (0)
BioReactor 1 Inf	20.5	61.1	ND (<0.75)	5.8	ND (<0.55)	0 (0)
BiorReactor 2 Eff	ND (<0.63)	ND (<0.29)	ND (<0.75)	ND (<0.55)	ND (<0.55)	0 (0)
Metals Trip Blk	ND (<0.13)	ND (<0.057)	ND (<0.15)	ND (<0.11)	ND (<0.11)	0 (0)

All results reflect the applied dilution and are reported in µg/L

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

n = number of unknown Se species observed

Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS Bi-Monthly Sampling Contact: Jay Perkins LIMS #J11110294

Date: December 6, 2011
Report Generated by: Russell Gerads
Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (µg/L)	PBW1	PBW2	PBW3	PBW4	Mean	StdDev	eMDL*	eMDL 10x	eMDL 50x	eMDL 200x
Se(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.013	0.13	0.63	2.5
Se(VI)	0.000	0.000	0.000	0.000	0.000	0.000	0.006	0.057	0.29	1.1
SeCN	0.000	0.000	0.000	0.000	0.000	0.000	0.015	0.15	0.75	3.0
MeSe(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.011	0.11	0.55	2.2
SeMe	0.000	0.000	0.000	0.000	0.000	0.000	0.011	0.11	0.55	2.2

eMDL = Estimated Method Detection Limit

Quality Control Summary - Certified Reference Materials

Analyte (µg/L)	CRM	True Value	Result	Recovery
Se(IV)	LCS	9.57	10.31	107.8
Se(VI)	LCS	9.48	9.63	101.5
SeCN	LCS	8.92	8.78	98.5
MeSe(IV)	LCS	6.47	7.09	109.5
SeMe	LCS	9.32	9.55	102.4

^{*}Please see narrative regarding eMDL calculations

Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS Bi-Monthly Sampling Contact: Jay Perkins LIMS #J11110294

Date: December 6, 2011
Report Generated by: Russell Gerads
Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (µg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
Se(IV)	BiorReactor 2 Eff	ND (<0.63)	ND (<0.63)	NC	NC
Se(VI)	BiorReactor 2 Eff	ND (<0.29)	ND (<0.29)	NC	NC
SeCN	BiorReactor 2 Eff	ND (<0.75)	ND (<0.75)	NC	NC
MeSe(IV)	BiorReactor 2 Eff	ND (<0.55)	ND (<0.55)	NC	NC
SeMe	BiorReactor 2 Eff	ND (<0.55)	ND (<0.55)	NC	NC

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (µg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
Se(IV)	BiorReactor 2 Eff	278.0	272.8	98.1	278.0	264.3	95.1	3.2
Se(VI)	BiorReactor 2 Eff	252.3	245.2	97.2	252.3	247.9	98.3	1.1
SeCN	BiorReactor 2 Eff	228.8	210.3	91.9	228.8	211.0	92.3	0.4

Customer must Comp 6)Oper, Unit: ByBusiness Unit: 2) Client i)Project Name LAB USE ONLY Duke Customer to complete appropriate columns to right * B by ICP Wayne Chapman, Tom Johnson ** Se Speciation Bottle WWTS Bi-Monthly Sampling Bill Kennedy, Melonie Martin, en to sign & date below - Hil out Belews - FGD CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM 6)Process: 9)Res. Type: Duke Energy Analytical Laboratory As, Cr. Cu, Ni Se, Ag, Zn by IMS Mail Code MGO3A2 (Building 7405) 13 Sample Description or ID 13339 Hagers Ferry Rd Huntersville, N. C. 28078 1/82/1 Fax: 1704) 675-4349 (704) 875-5245 BioReactor 1 Inf BioReactor 2 Eff BioReactor 2 Inf FGD Purge Eff EQ Tank Eff Metals Trip Blk Filter Blk 4)Fax No: 2)Phone No 10)Reso. Center: Mail: Code: õ Digestions = TRM 11/23/11/7:30 appropriate non-shaded areas. 38:12.11/Edil OB! LIVEAN Sampling conducted: 2nd and 4th Wednesdes M23/11 8:00 11/83/11 7:35 11/a3/1 7:55 1/40 IVEDI AS&C PO#133241 Customer to complete all Time W. Wordman Analytical Eaboratory Use Onb thomas d.johnson@slemens.com 2=H.SO. 3=H80 Filtering of the Se is performed in the fleid please provide a filter blank too. 7Comp ¹⁶Analyses Required ¹⁸Grab TDS - 245.1 SAMPLE PROGRAM Br (Dionex) RCRA Weste Metals* Se, soluble (no dig.) AM Ground Medica Drinking Water UST Customer, IMPORTANT! Please indicate desired turnaround. 22Requested Turnaround DISTRIBUTION ORIGINAL to LAB. 14 Days COPY to CLIENT .48 H 7 Days ¹⁹Page 1 of 2 Add. Cost Will Apply Se, speciation - vendor to AS&C (important to place filled bottle back into both beggies)

Pu	ıke		lytical Laboratory A2 (Building 7405) ers Ferry Rd	Analytical Laboratory Use Only ORDER# MATRIX: OTHER Samples Originating From										NC.4		DIS	TRIE	1 of 2	N					
En	ergy _{sm}	Huntersville, (704) 8	N. C. 28078 75-5245) 875-4349	Logged By Date & Time							MPLE	PRO	GRAM Drini	Ground NPDES king Water	CO		CLIE							
1)Project Name		vs - FGD onthly Sampling)	2)Phone No:	AS&	kC			[. C)		R	CRA		ST	i								
2) Client:	Bill Kennedy	Melonie Martin,	4)Fax No:	(Control of the Cont	133241		15Presei 2=H ₂ SO, 4=Ice	rv.:1=	HNO	>	3,4		4	3.4			4							
5)Business Unit:	6)Process:	Mail Code:					10	٨		,						2 Pa 3	i i						
8)Oper. Unit:	9)Res. Type:	10)Reso. Center:			Customer to compappropriate non-sha						>	>	>	>	>	>		0		e (no dig.)			AS&C (Important to place filled
LAB USE ONLY	Wayne Chapman, Tom Johnson * usiness Unit: per. Unit: B USE ONLY Se Speciation Bottle ID 13 Sampl B 13739 F0 B 13730 Bio 92 Bio 93 Bio 94 95 96 96 97 97 98 98 98 98 98 98 98 98			Sampling conducted: 2nd		: 2nd and 4th	Wednesday	du de			- 245.1	Br (Dionex)	als*	soluble (no			c (Impor	ווב סמרי ווי						
ID.		13 Sample D	Description or ID	Date	Time	Signa	iture	17 Comp.	18 Grab	TDS	Hg.	Br (Metals*	Se,			ASS	5						
024788	B 13720	7 FGD	729 FGD	Purge Eff	11/23/11		W. Worl	man			1	1	1	1	1			1						
89	n In max	The state of the s	Tank Eff.	11/23/11							1		1	1			1		-					
90	B 13 130	BioRe	eactor 1 Inf	11/23/11	7:30								1	1										
91		BioRe	eactor 2 Inf	11/23/1	17:35								1											
92	B13733	BioRe	eactor 2 Eff	11/23/11	7:40						1	1	1				1							
93		F	ilter Blk	11/23/1										1										
95	B 13/13/	Meta	als Trip Blk	11/23/1	18:00	-							1				1							
				Filtering of the		of the	Se is	perfo	rmed	in th	e tiel	please	provide a	filter bl	ank to	5 .	T							
	Customer to sign & da	ite below - fill out from left to	right.																_					
1) Relinquished By (U), World 3) Relinquished By		Date/Ti	1 9130	2) Accepted By 4) Accepted By 6) Accepted By: Date/Tir			1							22	Reque		Turna	11						
5)Relinquished By	ams	11/20 11/20	(11 0910				11	09	15		, IMPORTANT!		14 Days											
7)Relinquished By	uuu .	Date/Ti					Time				IMPOF		· 48 Hr											
9)Seal/kocked By	ams	Pate/Ti	me /// 1300	10) Seal/Lock (Opened By				Date	Time				Customer,		*Other		Will Ap	or					
11)Seal/Locked By		Date/Ti		12)Seal/Lock C	Opened By				Date	Time				Isto		Aud	COST		1					