

Analytical Laboratory

13339 Hagers Ferry Road Huntersville, NC 28078-7929 McGuire Nuclear Complex - MG03A2 Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number:	J12010230				
Project Name:	WWTS - Biweekly				
Customer Name(s):	Bill Kennedy, Melonie Mar	tin, Wayne Chapman,	Tom Johnson		
Customer Address:	3195 Pine Hall Rd				
	Mailcode: Belews Steam S	Station			
	Belews Creek, NC 28012				
Lab Contact:	Jason C Perkins	Phone:	980-875-5348		
Report Authorized By: (Signature)		Date	e:	2/8/2012	

Program Comments:

Please contact the Program Manager (Jason C Perkins) with any questions regarding this report.

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with a Qualifier indicate a deviation from the method quality system or quality control requirement. The qualifier description is found at the end of the Certificate of Analysis (sample results) under the qualifiers heading. All results are reported on a dry weight basis unless otherwise noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications: North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

Page 2 of 16

Sample ID	Plant/Station	Collection Date and Time	Collected By	Sample Description
2012001138	BELEWS	25-Jan-12 9:00 AM	dean m	FGD Purge Eff
2012001139	BELEWS	25-Jan-12 9:00 AM	dean m	EQ TANK EFF.
2012001140	BELEWS	25-Jan-12 9:00 AM	dean m	BIOREACTOR 1 INF.
2012001141	BELEWS	25-Jan-12 9:00 AM	dean m	BIOREACTOR 2 INF.
2012001142	BELEWS	25-Jan-12 9:00 AM	dean m	BIOREACTOR 2 EFF.
2012001143	BELEWS	25-Jan-12 9:00 AM	dean m	FILTER BLANK
2012001144	BELEWS	25-Jan-12 9:00 AM	dean m	Trip Blank
7 Total Samples				

Checklist:

Reviewed By:

DataBase Administrator

		COC and .pdf report are in agreement with sample and analyses (compliance programs and procedure		✓ Yes	No
		All Results are less than the laboratory reporting lim	its.	Yes	✓ No
		All laboratory QA/QC requirements are acceptable.		✓ Yes	□ No
		The Vendor Laboratories have been qualified by the Analytical Laboratory	•	Yes	
Repo	ort S	ections Included:			
	✓ Jo	b Summary Report	✓ Sub-contr	acted Laborate	ory Results
	✓ Sa	imple Identification	Customer	Specific Data	Sheets, Reports, & Documentation
	✓ Te	chnical Validation of Data Package	Customer	Database Ent	tries
	✓ Ar	alytical Laboratory Certificate of Analysis	✓ Chain of 0	Custody	
	☐ Ar	alytical Laboratory QC Report	✓ Electronic	Data Delivera	able (EDD) Sent Separately

Date:

2/8/2012

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J12010230

Site: FGD Purge Eff Sample #: 2012001138

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
INORGANIC IONS BY IC								
Bromide	89	mg/L		5	50	EPA 300.0	31-Jan-12 13:15	JAHERMA
Fluoride	8.4	mg/L		5	50	EPA 300.0	31-Jan-12 13:15	JAHERMA
MERCURY (COLD VAPOR) IN	N WATER							
Mercury (Hg)	180	ug/L		5	100	EPA 245.1	03-Feb-12 08:48	AGIBBS
TOTAL RECOVERABLE MET	ALS BY ICP							
Boron (B)	173	mg/L		0.5	10	EPA 200.7	03-Feb-12 13:37	DJSULL1
DISSOLVED METALS BY ICP	<u>P-MS</u>							
Selenium (Se)	167	ug/L		2	2	EPA 200.8	06-Feb-12 13:26	DJSULL1
TOTAL RECOVERABLE MET	ALS BY ICP-MS							
Arsenic (As)	200	ug/L		10	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Chromium (Cr)	220	ug/L		10	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Copper (Cu)	134	ug/L		10	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Nickel (Ni)	215	ug/L		10	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Selenium (Se)	3480	ug/L		10	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Zinc (Zn)	255	ug/L		20	10	EPA 200.8	06-Feb-12 13:09	DJSULL1
Arsenic Speciation								
Vendor Parameter	Complete	•			1	V_AS&C		
TOTAL DISSOLVED SOLIDS								
TDS	14000	mg/L		200	1	SM2540C	26-Jan-12 16:00	TJA7067
Site: EQ TANK EFF.						Sample #:	2012001139	

Site: EQ TANK EFF. Sample #: 2012001139

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
MERCURY (COLD VAPOR) IN WAT	<u>ER</u>							
Mercury (Hg)	120	ug/L		2.5	50	EPA 245.1	03-Feb-12 08:50	AGIBBS
TOTAL RECOVERABLE METALS B	Y ICP							
Boron (B)	172	mg/L		0.5	10	EPA 200.7	03-Feb-12 13:41	DJSULL1
DISSOLVED METALS BY ICP-MS								
Selenium (Se)	98.4	ug/L		2	2	EPA 200.8	06-Feb-12 13:29	DJSULL1

2012001139

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J12010230

Site: EQ TANK EFF. Sample #:

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS I	BY ICP-MS							
Arsenic (As)	160	ug/L		10	10	EPA 200.8	06-Feb-12 13:12	DJSULL1
Chromium (Cr)	167	ug/L		10	10	EPA 200.8	06-Feb-12 13:12	DJSULL1
Copper (Cu)	104	ug/L		10	10	EPA 200.8	06-Feb-12 13:12	DJSULL1
Nickel (Ni)	197	ug/L		10	10	EPA 200.8	06-Feb-12 13:12	DJSULL1
Selenium (Se)	2460	ug/L		10	10	EPA 200.8	06-Feb-12 13:12	DJSULL1
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	06-Feb-12 13:12	DJSULL1
Zinc (Zn)	210	ug/L		20	10	EPA 200.8	06-Feb-12 13:12	DJSULL1

Site: BIOREACTOR 1 INF. Sample #: 2012001140

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS B	Y ICP							
Boron (B)	155	mg/L		0.5	10	EPA 200.7	03-Feb-12 13:33	DJSULL1
Strontium (Sr)	9.15	mg/L		0.05	10	EPA 200.7	03-Feb-12 13:33	DJSULL1
DISSOLVED METALS BY ICP-MS								
Selenium (Se)	88.8	ug/L		2	2	EPA 200.8	06-Feb-12 13:32	DJSULL1
TOTAL RECOVERABLE METALS BY	Y ICP-MS							
Arsenic (As)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
Chromium (Cr)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
Copper (Cu)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
Nickel (Ni)	50.9	ug/L		5	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
Selenium (Se)	92.8	ug/L		5	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
Silver (Ag)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
Zinc (Zn)	< 10	ug/L		10	5	EPA 200.8	06-Feb-12 13:58	DJSULL1
SELENIUM SPECIATION								
Vendor Parameter	Complete				1	V_AS&C		

Site: BIOREACTOR 2 INF. Sample #: 2012001141

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS BY	' ICP							
Boron (B)	152	mg/L		0.5	10	EPA 200.7	03-Feb-12 13:45	DJSULL1

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J12010230

Site: BIOREACTOR 2 INF.

Sample #:

2012001141

Collection Date: 25-Jan-12 9:00 AM

Matrix:

OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METAL	S BY ICP-MS							
Arsenic (As)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:02	DJSULL1
Chromium (Cr)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:02	DJSULL1
Copper (Cu)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:02	DJSULL1
Nickel (Ni)	9.86	ug/L		5	5	EPA 200.8	06-Feb-12 14:02	DJSULL1
Selenium (Se)	19.6	ug/L		5	5	EPA 200.8	06-Feb-12 14:02	DJSULL1
Silver (Ag)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:02	DJSULL1
Zinc (Zn)	< 10	ug/L		10	5	EPA 200.8	06-Feb-12 14:02	DJSULL1

Site: BIOREACTOR 2 EFF.

Collection Date: 25-Jan-12 9:00 AM

Sample #:

2012001142

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
INORGANIC IONS BY IC								
Bromide	80	mg/L		5	50	EPA 300.0	31-Jan-12 12:59	JAHERMA
Fluoride	10	mg/L		5	50	EPA 300.0	31-Jan-12 12:59	JAHERMA
MERCURY (COLD VAPOR) IN	N WATER							
Mercury (Hg)	< 1	ug/L		1	20	EPA 245.1	03-Feb-12 08:52	AGIBBS
TOTAL RECOVERABLE MET	ALS BY ICP							
Boron (B)	149	mg/L		0.5	10	EPA 200.7	03-Feb-12 13:49	DJSULL1
TOTAL RECOVERABLE MET	ALS BY ICP-MS							
Arsenic (As)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
Chromium (Cr)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
Copper (Cu)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
Nickel (Ni)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
Selenium (Se)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
Silver (Ag)	< 5	ug/L		5	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
Zinc (Zn)	< 10	ug/L		10	5	EPA 200.8	06-Feb-12 14:05	DJSULL1
SELENIUM SPECIATION								
Vendor Parameter	Complete)			1	V_AS&C		
Site: FILTER BLANK						Sample #:	2012001143	

Site: FILTER BLANK Sample #: 2012001143

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
DISSOLVED METALS BY ICP-MS								
Selenium (Se)	< 1	ug/L		1	1	EPA 200.8	06-Feb-12 13:06	DJSULL1

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J12010230

Site: Trip Blank Sample #: 2012001144

Collection Date: 25-Jan-12 9:00 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE META	ALS BY ICP							
Boron (B)	< 0.05	mg/L		0.05	1	EPA 200.7	03-Feb-12 13:25	DJSULL1
TOTAL RECOVERABLE META	ALS BY ICP-MS							
Arsenic (As)	<1	ug/L		1	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
Chromium (Cr)	< 1	ug/L		1	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
Copper (Cu)	< 1	ug/L		1	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
Nickel (Ni)	< 1	ug/L		1	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
Selenium (Se)	< 1	ug/L		1	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
Silver (Ag)	< 1	ug/L		1	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
Zinc (Zn)	< 2	ug/L		2	1	EPA 200.8	06-Feb-12 13:02	DJSULL1
SELENIUM SPECIATION								
Vendor Parameter	Complete	•			1	V_AS&C		



18804 Northcreek Parkway Bothell, WA, 98011 Tel: (425) 483-3300 Fax: (425) 483-9818 www.appliedspeciation.com

January 31, 2012

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078 (704) 875-5245

Project: Belews – FGD WWTS Bi-Monthly Sampling) (LIMS # J12010230)

Dear Mr. Perkins,

Attached is the report associated with four (4) aqueous samples submitted for selenium speciation analysis on January 26, 2012. The samples were received in a sealed cooler at -0.3°C on January 27, 2012. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS). Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078

Project: Belews – FGD WWTS Bi-Monthly Sampling) (LIMS # J12010230)

January 31, 2012

1. Sample Reception

Four (4) aqueous samples in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on January 26, 2012. The samples were received on January 27, 2012 in a sealed container at -0.3°C.

The samples were received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and was designated a discrete sample identifier. An aliquot of each sample was filtered (0.45 µm) and each filtrate was stored in a secure, monitored cryofreezer (maintained at a temperature of -80 °C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

<u>Selenium Speciation Analysis by IC-ICP-DRC-MS</u> Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm) and injected directly into a sealed autosampler vial. No further sample preparation was performed as any chemical alteration of a sample may shift the equilibrium of the system, resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is preceded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of each analytical day. All calibration curves, associated with each species of interest, are

standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimal interval of every ten analytical runs.

<u>Selenium Speciation Analysis by IC-ICP-DRC-MS</u> Each sample for selenium speciation analysis was analyzed by ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS) on January 30, 2012. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic (pH > 7) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (DRC) containing a specific reactive gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went well and no significant analytical issues were encountered. All quality control parameters associated with this sample were within acceptance limits.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS Bi-Monthly Sampling) Contact: Jay Perkins LIMS #J12010230

Date: January 31, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Sample Results

						Unknown Se
Sample ID	Se(IV)	Se(VI)	SeCN	MeSe(IV)	SeMe	Species (n)
FGD Purge Eff	73.7	66.6	ND (<3.6)	ND (<2.4)	ND (<2.4)	0 (0)
BioReactor 1 Inf	13.5	60.9	ND (<0.91)	1.49	ND (<0.61)	0 (0)
BioReactor 2 Eff	ND (<0.34)	ND (<0.58)	ND (<0.91)	ND (<0.61)	ND (<0.61)	0 (0)
Metals Trip Blk	ND (<0.068)	ND (<0.12)	ND (<0.18)	ND (<0.12)	ND (<0.12)	0 (0)

All results reflect the applied dilution and are reported in µg/L

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

n = number of unknown Se species observed

Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS Bi-Monthly Sampling) Contact: Jay Perkins LIMS #J12010230

Date: January 31, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (µg/L)	PBW1	PBW2	PBW3	PBW4	Mean	StdDev	eMDL*	eMDL 10x	eMDL 50x	eMDL 200x
Se(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.007	0.068	0.34	1.4
Se(VI)	0.000	0.000	0.000	0.000	0.000	0.000	0.012	0.12	0.58	2.3
SeCN	0.000	0.000	0.000	0.000	0.000	0.000	0.018	0.18	0.91	3.6
MeSe(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.012	0.12	0.61	2.4
SeMe	0.000	0.000	0.000	0.000	0.000	0.000	0.012	0.12	0.61	2.4

eMDL = Estimated Method Detection Limit

Quality Control Summary - Certified Reference Materials

Analyte (µg/L)	CRM	True Value	Result	Recovery
Se(IV)	LCS	9.57	9.39	98.1
Se(VI)	LCS	9.48	9.28	97.9
SeCN	LCS	8.92	8.21	92.1
MeSe(IV)	LCS	6.47	6.29	97.2
SeMe	LCS	9.32	9.14	98.0

^{*}Please see narrative regarding eMDL calculations

Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS Bi-Monthly Sampling) Contact: Jay Perkins LIMS #J12010230

Date: January 31, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (µg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
Se(IV)	BioReactor 2 Eff	ND (<0.34)	ND (<0.34)	NC	NC
Se(VI)	BioReactor 2 Eff	ND (<0.58)	ND (<0.58)	NC	NC
SeCN	BioReactor 2 Eff	ND (<0.91)	ND (<0.91)	NC	NC
MeSe(IV)	BioReactor 2 Eff	ND (<0.61)	ND (<0.61)	NC	NC
SeMe	BioReactor 2 Eff	ND (<0.61)	ND (<0.61)	NC	NC

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (µg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
Se(IV)	BioReactor 2 Eff	278.0	249.4	89.7	278.0	251.3	90.4	8.0
Se(VI)	BioReactor 2 Eff	252.3	236.8	93.9	252.3	236.4	93.7	0.2
SeCN	BioReactor 2 Eff	228.8	211.9	92.6	228.8	212.1	92.7	0.1

						6		واند	<u>.</u>		ا خورت	₽ Serve	7.1 7. 4	STORY.	4 1761	Ť.	~ *C	ign En			,	_	welo	mer m			150	1 10		
Commodia	9)Swall_eqited By 11)Bealf ocked By	7)Relinquisited By	The formal series	a) Mailinguistreed by	1) Refliciquished By	Cı	stomer			2007 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	× 12	OT YOU ALL AS TO A		37.37.25.25.25.25.25.25.25.25.25.25.25.25.25.			8			G CONT	THE CHILD		a)Oper. Unit:	5)Business Unit:	st Comp 2) Client:		1)Project Name		I DIS	
	aus				hetern	Customer to		_			1000 A								5	Sa Speciation Bottle		į.	9)4	£(8	Bill Kennedy, Melonie Martin, Wayne Chapman, Tom Johnson	WWTS Bi-Mor	Belews	nergy	uke	
As, Cr. Cu. NI. Se, Ag, Zn by IMS	Detail inte	Handon Til	1/260		Datos (1)	go & date below - fill out from left to right				<u></u>			1	RioRe		BioRe	EQ.		¹³ Sample D				9)Res. Type:	8)Process:	Bill Kannedy, Melonie Martin, lyne Chapman, Tom Johnson **	Bi-Monthly Sampling)	-FGD	Huntersville, N. C. 28078 (704) 875-5245 Fax: (704) 875-4349	Mail Code MGC3A2 (Building 7405) 13339 Hagers Ferry Rd	Duke Energy Analy
			72 1300	12 0935	51:60	right.			Meials Top Bik	Filter Bik		BIORBACIO 2 EFF		RioReactor 2 Inf		RioReaction and International States	EQ Tank Eff.		13 Sample Description or ID				10)Reso, Center:	Mail Code:	ay an au		2)Phone No:	N. C. 28078 5-5245 875-4349	2 (Building 7405) rs Ferry Rd	Analytical Laboratory
Digestions = TAM	Ag belied (Coxy (Bened B))	ajAdzappod By	BAccepted By:		2) Accordance By					D: 60 m/54/1	7	1/1/1/1/1/10	, , , , , , , , , , , , , , , , , , ,	1/2dm 139.4	17 100	Klaska	1/25/2009:00	Wheel he caner	Date Time		Sampling conducted: 2nd and 4th We	appropriate non-shaded a	Gustomer to complete	157. ◆		PO#133341		- Confident	1000 1000 1000 1000 1000 1000 1000 100	
thomas d John			Olexan 11	(A)	1			Filtering		209:00 Ban Matte			>	Down 1111 of			Den He	WORKEN PROPERTY	Signature		: 2nd and 4th Wednesday	on-shaded areas.	o complete all		173	i o		1 20 12 (230	Analytical Lai
d.jahnson@siemabs.com	Setel Time	Date/7 lime	1000 C/1/E	1/2012	12617			Filtering of the Se is performed				Mary assure Sansaga					1		¹⁸ G TD			Re	grif	yses	5-Nose 4 3,4	as Temp (C)	N Ö	0944	Originas	cal Laboratory Use Only
	Customer se indicate	, IMP desir	ORTA ed tu	NTI rnaro	und.			is performed in the field please provide a filter blank too		-1				-	1:00:10	Anna Maria	<u>-</u>		Me	tals	*	le (no		g.)	4 3,4		tsu man	SAMPLE PROGRAM Ground Water Drinking Water	90	7
2/2/12	* Add. Cost Will Apply	·48 Hr	*7 Days	14 Days	²² Requested Turnaround			ide a filter blank too.	1										AS	AC	(kmpc	ation priant to rate both	place	e filled	•		であってし		DISTRUBUTION ORIGINAL to LAB	19page 1 of
1-	Apply				puroveu													_								1°		に に に に に に に に に に に に に に	<u>}</u> ¥	9

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM

	Duke Energy A	Analytical Laboratory			Analyt	ical Lat	ora	tory	Us	e Or	ıly					10-				
Duke Energy	Mail Code MG	iO3A2 (Building 7405) Hagers Ferry Rd ille, N. C. 28078	ORDER#	0102	30 MAT	rrix: oth	ER			From	natin			C C	- 0	¹⁹ Page 1 of 2 DISTRIBUTAGN 16 of 10 ORIGINAL to LAB,				
	(/0	4) 875-5245 704) 875-4349	R			MPLI iter	PR	OGRA	M Ground NPDES Orinking Wate	3 1	OPY to C	CLIENT								
	elews - FGD -Monthly Sampling	2)Phone No:	PO#ISV	S&C N01.189	ے ا er Tei	O mp (C	4		R	CRA	Wast	UST								
2) Client: Bill Kenne	edy, Melonie Martin, oman, Tom Johnson	4)Fax No:	Vendor:			15Preser 2=H ₂ SO. 4=Ice	rv.:1= 4 3=H	HCL INO ₃	>	3,4		4	3,4			4				
5)Business Unit:	6)Process:	Mail Code:	MR#				Ses	ba					()			or to filled ies)				
3)Oper. Unit:	9)Res. Type:	10)Reso. Center:			o complete on-shaded		16 Analyse	Required			F		(no dig.)			Se, speciation - vendor to AS&C (Important to place filled bottle back into both baggies)				
WWTS Bi-I Client: Bill Kenner Wayne Chapn Business Unit: Oper. Unit: Se Speciation Bo ID 1200140 1200140			Sampling				245.1	onex	***	soluble			pecial (Import							
ID.		e Description or ID	Date	Time	Signat	ure	17 Comp.	18 Grab	TDS	Hg - 2	Br (Dionex)	Metals*	Se, sc			Se, si AS&C bottle i				
01200138	F	GD Purge Eff	1/25/1	209:00	Dounts	Malles			1	1	1	1	1			1				
X200H39		EQ Tank Eff.	1/25/1	09:d	Dean Mis	elle				1		1	1			1				
1/2CO11/4C =	Bi	oReactor 1 Inf	1/25/12	09:00	Noon 11	letter						1	1			-				
012001141	Bi	oReactor 2 Inf	1/256	09:a	Penell	letto	_					1								
DI2CO1142	Bi	oReactor 2 Eff	1/25/18	09:00	Rank	16th				1	1	1				1				
2/2/ X 142 #		Filter Blk	1/25/12	09:9	Paul	Valla			10.				1							
01200144 8		Metals Trip Blk										1				1				
lomer to						Filtering	of the	Se is	perfo	ormed	d in th	ne fie	eld ple	ase provide	a filter	r blank too				
Customer to sign	n & date below - fill out from	left to right										Ž.								
1) Refinquished By Chilleson 3) Refinquished By	1/25	tterTime 12 09:15 tterTime	2) Accepted B	ner				112	Time	12	2			5			urnaround			
S)Relinquished By) / Di	26 2 0936 ute/Time	6)Accepted B		rus		1/	20 Date	11	2	OC	ß	P	desired turnaro		Days				
7)Relinguished By	D _i	ute/Time	8)Accepted B	ν:				Date	/Time					desired	- 48	3 Hr				
9)Seal/Locked By	Di	ate/Time	10) Seal/Lock	Opened By				Date	/Time					Customer, Please indicate d	*Ott	her Add. Cost \	Will Apply			
11)Seal/Locked By	Di	Date/Time			12)Seál/Lock Opened By Date/Tim									ind						

Please note highlighted Changes. Per Jay Perkins.