

Analytical Laboratory

13339 Hagers Ferry Road Huntersville, NC 28078-7929 McGuire Nuclear Complex - MG03A2 Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number:	J12020341			
Customer Name(s):	Bill Kennedy, Melonie Mar	tin, Wayne Chapman, Tom Johnson		
Customer Address:	3195 Pine Hall Rd			
	Mailcode: Belews Steam S	Station		
	Belews Creek, NC 28012			
Lab Contact:	Jason C Perkins	Phone: 980-875-5348		
Report Authorized By: (Signature)		Date:	3/7/2012	

Program Comments:

Please contact the Program Manager (Jason C Perkins) with any guestions regarding this report.

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with a Qualifier indicate a deviation from the method quality system or quality control requirement. The qualifier description is found at the end of the Certificate of Analysis (sample results) under the qualifiers heading. All results are reported on a dry weight basis unless otherwise noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications: North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

Page 2 of 41

Sample ID	Plant/Station	Collection Date and Time	Collected By	Sample Description
2012004143	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	FGD Purge Eff
2012004144	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	BIOREACTOR 1 INF.
2012004145	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	BIOREACTOR 1 INF. BLANK
2012004146	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	BIOREACTOR 2 EFF.
2012004147	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	BIOREACTOR 2 EFF. BLANK
2012004148	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	FILTER BLANK
2012004149	BELEWS	18-Feb-12 12:30 AM	TRAVIS THORNTON	Trip Blank
7 Total Samples				

Checklist:

Reviewed By:

DataBase Administrator

	COC and .pdf report are in agreement with sample and analyses (compliance programs and procedure		✓ Yes	No
	All Results are less than the laboratory reporting lim	its.	Yes	✓ No
	All laboratory QA/QC requirements are acceptable.		✓ Yes	☐ No
	The Vendor Laboratories have been qualified by the Analytical Laboratory)	Yes	
Report S	Sections Included:			
✓ Jo	bb Summary Report	✓ Sub-contr	acted Laborate	ory Results
✓ Sa	ample Identification	Customer	Specific Data	Sheets, Reports, & Documentation
✓ Te	echnical Validation of Data Package	☐ Customer	Database Ent	ries
✓ Aı	nalytical Laboratory Certificate of Analysis	✓ Chain of 0	Custody	
☐ Aı	nalytical Laboratory QC Report	✓ Electronic	Data Delivera	able (EDD) Sent Separately

Date:

3/7/2012

This report shall not be reproduced, except in full.

Order # J12020341

Site: FGD Purge Eff Sample #: 2012004143

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
Carbonate, Bicarbonate, and Hy	ydroxide Alkalini	ty						
Carbonate (CO3)	Complete				1	V_PRISM		
Hydroxide (OH)	Complete				1	V_PRISM		
Bicarbonate (HCO3)	Complete				1	V_PRISM		
NITRITE + NITRATE (COLORIMI	ETRIC)							
Nitrite + Nitrate (Colorimetric)	15	mg-N/L		0.25	25	EPA 353.2	21-Feb-12 14:09	BGN9034
INORGANIC IONS BY IC								
Bromide	120	mg/L		5	50	EPA 300.0	24-Feb-12 14:58	JAHERMA
Chloride	7700	mg/L		100	1000	EPA 300.0	24-Feb-12 14:58	JAHERMA
Sulfate	1200	mg/L		100	1000	EPA 300.0	24-Feb-12 14:58	JAHERMA
MERCURY (COLD VAPOR) IN W	<u>VATER</u>							
Mercury (Hg)	225	ug/L		5	100	EPA 245.1	24-Feb-12 09:10	AGIBBS
Mercury Dissolved (cold vapor)	in Water (Filtere	<u>ed)</u>						
Mercury (Hg)	< 2.5	ug/L		2.5	50	EPA 245.1	02-Mar-12 09:48	AGIBBS
DISSOLVED METALS BY ICP								
Manganese (Mn)	7.54	mg/L		0.005	1	EPA 200.7	22-Feb-12 14:33	DJSULL1
TOTAL RECOVERABLE METAL	S BY ICP							
Boron (B)	253	mg/L		0.5	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Calcium (Ca)	4360	mg/L		0.1	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Iron (Fe)	100.0	mg/L		0.1	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Lithium (Li)	0.125	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Magnesium (Mg)	834	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Manganese (Mn)	8.22	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Potassium (K)	51.2	mg/L		1	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
Sodium (Na)	46.9	mg/L		0.5	10	EPA 200.7	22-Feb-12 12:22	DJSULL1
DISSOLVED METALS BY ICP-M	<u>ıs</u>							
Selenium (Se)	344	ug/L		10	10	EPA 200.8	22-Feb-12 14:37	MHH7131

This report shall not be reproduced, except in full.

Order # J12020341

Site: FGD Purge Eff Sample #: 2012004143

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS E	BY ICP-MS							
Arsenic (As)	154	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Cadmium (Cd)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Chromium (Cr)	191	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Copper (Cu)	89.1	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Nickel (Ni)	164	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Selenium (Se)	4160	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Zinc (Zn)	151	ug/L		10	10	EPA 200.8	23-Feb-12 12:09	KRICHAR
Speciation of an Element								
Vendor Parameter	Complete				1	V_AS&C		
TOTAL DISSOLVED SOLIDS								
TDS	21000	mg/L		200	1	SM2540C	21-Feb-12 15:13	TJA7067
TOTAL SUSPENDED SOLIDS								
TSS	3100	mg/L		250	1	SM2540D		

Site: BIOREACTOR 1 INF. Sample #: 2012004144

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
Carbonate, Bicarbonate, and Hydronic Carbonate, Bicarbonate, and Hydronic Carbonate, and Hydronic Carbonate, and Hydronic Carbonate, Bicarbonate, and Hydronic Carbonate, Bicarbonate, and Hydronic Carbonate, Bicarbonate, Bicarb	roxide Alkalinity	<u> </u>						
Bicarbonate (HCO3)	Complete				1	V_PRISM		
Carbonate (CO3)	Complete				1	V_PRISM		
Hydroxide (OH)	Complete				1	V_PRISM		
NITRITE + NITRATE (COLORIMET	RIC)							
Nitrite + Nitrate (Colorimetric)	12	mg-N/L		0.25	25	EPA 353.2	21-Feb-12 14:12	BGN9034
INORGANIC IONS BY IC								
Bromide	110	mg/L		5	50	EPA 300.0	24-Feb-12 15:14	JAHERMA
Chloride	7300	mg/L		100	1000	EPA 300.0	24-Feb-12 15:14	JAHERMA
Sulfate	1400	mg/L		100	1000	EPA 300.0	24-Feb-12 15:14	JAHERMA
MERCURY 1631								
Vendor Parameter	Complete				1	V_BRAND		
MERCURY (COLD VAPOR) IN WA	<u>TER</u>							
Mercury (Hg)	< 2.5	ug/L		2.5	50	EPA 245.1	24-Feb-12 09:12	AGIBBS

This report shall not be reproduced, except in full.

Order # J12020341

Site: BIOREACTOR 1 INF.

Collection Date: 18-Feb-12 12:30 AM

Sample #: 2012004144

Matrix:

OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
Mercury Dissolved (cold vap	or) in Water (Filtere	<u>d)</u>						
Mercury (Hg)	< 2.5	ug/L		2.5	50	EPA 245.1	02-Mar-12 09:55	AGIBBS
DISSOLVED METALS BY ICP	<u>.</u>							
Manganese (Mn)	5.48	mg/L		0.005	1	EPA 200.7	22-Feb-12 14:36	DJSULL1
TOTAL RECOVERABLE MET	ALS BY ICP							
Boron (B)	240	mg/L		0.5	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Calcium (Ca)	3520	mg/L		0.1	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Iron (Fe)	0.134	mg/L		0.1	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Lithium (Li)	< 0.05	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Magnesium (Mg)	778	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Manganese (Mn)	5.87	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Potassium (K)	22.7	mg/L		1	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
Sodium (Na)	43.5	mg/L		0.5	10	EPA 200.7	22-Feb-12 12:26	DJSULL1
DISSOLVED METALS BY ICP	<u> </u>							
Selenium (Se)	120	ug/L		10	10	EPA 200.8	22-Feb-12 14:41	MHH7131
TOTAL RECOVERABLE MET	ALS BY ICP-MS							
Arsenic (As)	17.2	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Cadmium (Cd)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Chromium (Cr)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Copper (Cu)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Nickel (Ni)	49.6	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Selenium (Se)	123	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Zinc (Zn)	< 10	ug/L		10	10	EPA 200.8	23-Feb-12 12:12	KRICHAR
Speciation of an Element								
Vendor Parameter	Complete				1	V_AS&C		

Collection Date: 18-Feb-12 12:30 AM

Matrix:

OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
MERCURY 1631								
Vendor Parameter	Complete				1	V_BRAND		

This report shall not be reproduced, except in full.

Order # J12020341

Site: BIOREACTOR 2 EFF. Sample #: 2012004146

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Collection Date. 10-1 eb-12 12:30 AWI Wattix. OTHER								
Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
Carbonate, Bicarbonate, and H	ydroxide Alkalini	ty						
Bicarbonate (HCO3)	Complete				1	V_PRISM		
Carbonate (CO3)	Complete				1	V_PRISM		
Hydroxide (OH)	Complete				1	V_PRISM		
NITRITE + NITRATE (COLORIM	ETRIC)							
Nitrite + Nitrate (Colorimetric)	0.014	mg-N/L		0.01	1	EPA 353.2	21-Feb-12 14:13	BGN9034
INORGANIC IONS BY IC								
Bromide	110	mg/L		5	50	EPA 300.0	24-Feb-12 15:30	JAHERMA
Chloride	7500	mg/L		100	1000	EPA 300.0	24-Feb-12 15:30	JAHERMA
Sulfate	1500	mg/L		100	1000	EPA 300.0	24-Feb-12 15:30	JAHERMA
MERCURY 1631								
Vendor Parameter	Complete				1	V_BRAND		
MERCURY (COLD VAPOR) IN V	<u>VATER</u>							
Mercury (Hg)	< 1	ug/L		1	20	EPA 245.1	24-Feb-12 09:15	AGIBBS
DISSOLVED METALS BY ICP								
Manganese (Mn)	5.58	mg/L		0.005	1	EPA 200.7	22-Feb-12 14:40	DJSULL1
TOTAL RECOVERABLE METAL	S BY ICP							
Boron (B)	232	mg/L		0.5	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Calcium (Ca)	3530	mg/L		0.1	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Iron (Fe)	< 0.1	mg/L		0.1	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Lithium (Li)	< 0.05	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Magnesium (Mg)	800	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Manganese (Mn)	5.99	mg/L		0.05	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Potassium (K)	27.8	mg/L		1	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
Sodium (Na)	44.0	mg/L		0.5	10	EPA 200.7	22-Feb-12 12:30	DJSULL1
TOTAL RECOVERABLE METAL	S BY ICP-MS							
Arsenic (As)	18.5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Cadmium (Cd)	< 5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Chromium (Cr)	< 5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Copper (Cu)	< 5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Nickel (Ni)	6.76	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Selenium (Se)	< 5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Silver (Ag)	< 5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Zinc (Zn)	< 5	ug/L		5	5	EPA 200.8	23-Feb-12 12:15	KRICHAR
Speciation of an Element								
Vendor Parameter	Complete				1	V_AS&C		

This report shall not be reproduced, except in full.

Order # J12020341

Site: BIOREACTOR 2 EFF. BLANK Sample #: 2012004147

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte Result Units Qualifiers RDL DF Method Analysis Date/Time Analyst

MERCURY 1631

Vendor Parameter Complete 1 V_BRAND

Site: FILTER BLANK Sample #: 2012004148

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
Mercury Dissolved (cold vapor) in V	later (Filtered)	<u>)</u>						
Mercury (Hg)	< 0.05	ug/L		0.05	1	EPA 245.1	02-Mar-12 09:57	AGIBBS
DISSOLVED METALS BY ICP								
Manganese (Mn)	0.019	mg/L		0.005	1	EPA 200.7	22-Feb-12 13:37	DJSULL1
DISSOLVED METALS BY ICP-MS								
Selenium (Se)	<1	ug/L		1	1	EPA 200.8	22-Feb-12 13:01	MHH7131

Site: Trip Blank Sample #: 2012004149

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS B	Y ICP							
Boron (B)	< 0.05	mg/L		0.05	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Calcium (Ca)	< 0.01	mg/L		0.01	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Iron (Fe)	< 0.01	mg/L		0.01	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Lithium (Li)	< 0.005	mg/L		0.005	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Magnesium (Mg)	< 0.005	mg/L		0.005	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Manganese (Mn)	< 0.005	mg/L		0.005	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Potassium (K)	< 0.1	mg/L		0.1	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
Sodium (Na)	< 0.05	mg/L		0.05	1	EPA 200.7	22-Feb-12 11:51	DJSULL1
TOTAL RECOVERABLE METALS B	Y ICP-MS							
Arsenic (As)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Cadmium (Cd)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Chromium (Cr)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Copper (Cu)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Nickel (Ni)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Selenium (Se)	1.45	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Silver (Ag)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR
Zinc (Zn)	< 1	ug/L		1	1	EPA 200.8	23-Feb-12 11:35	KRICHAR

This report shall not be reproduced, except in full.

Order # J12020341

Site: Trip Blank Sample #: 2012004149

Collection Date: 18-Feb-12 12:30 AM Matrix: OTHER

Analyte Result Units Qualifiers RDL DF Method Analysis Date/Time Analyst

Speciation of an Element

Vendor Parameter Complete 1 V_AS&C



NC Certification No. 402 SC Certification No. 99012 NC Drinking Water Cert No. 37735 VA Certification No. 1287

Gase Marrative

02/27/2012

Duke Energy Corporation (04) Jay Perkins 13339 Hagers Ferry Road Huntersville, NC 28078

Project: HAPS/MACT Testing Belews Creek

Project No.: J12020341

Lab Submittal Date: 02/21/2012 Prism Work Order: 2020470

This data package contains the analytical results for the project identified above and includes a Case Narrative, Sample Results and Chain of Custody. Unless otherwise noted, all samples were received in acceptable condition and processed according to the referenced methods.

Data qualifiers are flagged individually on each sample. A key reference for the data qualifiers appears at the end of this case narrative.

Please call if you have any questions relating to this analytical report.

Respectfully,

PRISM LABORATORIES, INC.

VP Laboratory Services

Reviewed By

Steva H. Sytill

Data Qualifiers Key Reference:

HT Sample received and analyzed outside of the hold time.

BRL Below Reporting Limit MDL Method Detection Limit **RPD** Relative Percent Difference

Results reported to the reporting limit. All other results are reported to the MDL with values between MDL and

reporting limit indicated with a J.



Sample Receipt Summary

02/27/2012

Prism Work Order: 2020470

Client Sample ID	Lab Sample ID	Matrix	Date Sampled	Date Received
2012004143/FGD Purge Eff	2020470-01	Water	02/18/12	02/21/12
2012004144/BioReactor 1 Inf	2020470-02	Water	02/18/12	02/21/12
2012004146/BioReactor 2 Eff	2020470-03	Water	02/18/12	02/21/12

Samples received in good condition at 2.5 degrees C unless otherwise noted.



Duke Energy Corporation (04) Attn: Jay Perkins 13339 Hagers Ferry Road

Huntersville, NC 28078

Project: HAPS/MACT Testing Belews

Creek

Project No.: J12020341 Sample Matrix: Water Client Sample ID: 2012004143/FGD Purge Eff

Prism Sample ID: 2020470-01 Prism Work Order: 2020470 Time Collected: 02/18/12 00:30 Time Submitted: 02/21/12 15:05

Parameter	Result	Units	Report Limit	MDL	Dilution Factor	Method	Analysis Date/Time	Analyst	Batch ID
General Chemistry Parameters									
рН	7.0 HT	pH Units			1	*SM4500-H B	2/22/12 14:00	JAB	P2B0426
Total Alkalinity	66	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0484
Carbonate Alkalinity	BRL	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0485
Bicarbonate Alkalinity	66	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0487



Laboratory Report
Page 13 of 41 02/27/2012

Duke Energy Corporation (04) Attn: Jay Perkins

13339 Hagers Ferry Road Huntersville, NC 28078 Project: HAPS/MACT Testing Belews

Creek

Project No.: J12020341 Sample Matrix: Water Client Sample ID: 2012004144/BioReactor 1 Inf

Prism Sample ID: 2020470-02 Prism Work Order: 2020470 Time Collected: 02/18/12 00:30 Time Submitted: 02/21/12 15:05

Parameter	Result	Units	Report Limit	MDL	Dilution Factor	Method	Analysis Date/Time	Analyst	Batch ID
General Chemistry Parameters									
рН	7.0 HT	pH Units			1	*SM4500-H B	2/22/12 14:00	JAB	P2B0426
Total Alkalinity	49	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0484
Carbonate Alkalinity	BRL	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0485
Bicarbonate Alkalinity	49	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0487



Laboratory Report
Page 14 of 41 02/27/2012

Duke Energy Corporation (04) Attn: Jay Perkins 13339 Hagers Ferry Road Huntersville, NC 28078 Project: HAPS/MACT Testing Belews

Creek

Project No.: J12020341 Sample Matrix: Water Client Sample ID: 2012004146/BioReactor 2 Eff

Prism Sample ID: 2020470-03 Prism Work Order: 2020470 Time Collected: 02/18/12 00:30 Time Submitted: 02/21/12 15:05

Parameter	Result	Units	Report Limit	MDL	Dilution Factor	Method	Analysis Date/Time	Analyst	Batch ID
General Chemistry Parameters									
pH	6.9 HT	pH Units			1	*SM4500-H B	2/22/12 14:00	JAB	P2B0426
Total Alkalinity	120	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0484
Carbonate Alkalinity	BRL	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0485
Bicarbonate Alkalinity	120	mg/L	5.0	0.66	1	*SM2320 B	2/24/12 11:00	JAB	P2B0487

Duke Energy Corporation (04) Attn: Jay Perkins 13339 Hagers Ferry Road Huntersville, NC 28078 Project: HAPS/MACT Testing Belews

Creek

Project No: J12020341

Prism Work Order: 2020470

Time Submitted: 2/21/2012 3:05:00PM

General Chemistry Parameters - Quality Control

		Reporting		Spike	Source		%REC		RPD	
Analyte	Result	Limit	Units	Level	Result	%REC	Limits	RPD	Limit	Notes
Batch P2B0426 - NO PREP										
LCS (P2B0426-BS1)				Prepared	& Analyze	d: 02/22/1	12			
pH	6.85		pH Units	6.860		100	99-101			
Batch P2B0484 - NO PREP										
Blank (P2B0484-BLK1)				Prepared	& Analyze	d: 02/24/1	12			
Total Alkalinity	BRL	5.0	mg/L							
LCS (P2B0484-BS1)				Prepared	& Analyze	d: 02/24/1	12			
Total Alkalinity	260	5.0	mg/L	250.0		104	90-110			
LCS Dup (P2B0484-BSD1)				Prepared	& Analyze	ed: 02/24/1	12			
Total Alkalinity	259	5.0	mg/L	250.0		103	90-110	0.4	200	
Batch P2B0485 - NO PREP										
Blank (P2B0485-BLK1)				Prepared	& Analyze	d: 02/24/1	12			
Carbonate Alkalinity	BRL	5.0	mg/L							
LCS (P2B0485-BS1)				Prepared	& Analyze	d: 02/24/1	12			
Carbonate Alkalinity	260	5.0	mg/L				90-110			
LCS Dup (P2B0485-BSD1)				Prepared	& Analyze	ed: 02/24/1	12			
Carbonate Alkalinity	259	5.0	mg/L				90-110	0.4	200	
Batch P2B0487 - NO PREP										
Blank (P2B0487-BLK1)				Prepared	& Analyze	ed: 02/24/1	12			
Bicarbonate Alkalinity	BRL	5.0	mg/L							





Duke Energy Corporation (04) Attn: Jay Perkins 13339 Hagers Ferry Road Huntersville, NC 28078 Project: HAPS/MACT Testing Belews

Creek

Project No: J12020341

Prism Work Order: 2020470

Time Submitted: 2/21/2012 3:05:00PM

General Chemistry Parameters - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch P2B0487 - NO PREP										
LCS (P2B0487-BS1)				Prepared	& Analyze	ed: 02/24/1	2			
Bicarbonate Alkalinity	260	5.0	mg/L	250.0		104	90-110			
LCS Dup (P2B0487-BSD1)				Prepared	& Analyze	ed: 02/24/1	2			
Bicarbonate Alkalinity	259	5.0	mg/L	250.0		103	90-110	0.4	200	_



February 29, 2012

Duke Energy
ATTN: Jay Perkins
Scientific Support-Laboratory
13339 Hagers Ferry Road
Huntersville NC 28078
jcperkins@duke-energy.com
labcustomer@duke-energy.com

RE: Project DUK-HV1201 Client Project: J12020341

Dear Mr. Perkins,

On February 22, 2012, Brooks Rand Labs (BRL) received two (2) wastewater samples and two (2) corresponding field blanks. Samples were logged-in for total mercury (Hg) analysis. All samples were received, prepared, analyzed, and stored according to BRL SOPs and EPA methodology.

The results were blank-corrected as described in the calculations section of the applicable SOP(s) and may be evaluated using adjusted reporting limits to account for sample aliquot size. Please refer to the *Sample Results* page for sample-specific detection limits and other details.

No qualification of the data was warranted, aside from concentration qualifiers, and all associated quality control sample results met the acceptance criteria.

BRL, an accredited laboratory, certifies the reported results of all analyses for which BRL is NELAP accredited meet all NELAP requirements. For more details, see the *Report Information* page of the report. Please feel free to contact me if you have any questions regarding this report.

Sincerely,

Tiffany Stilwater Project Manager

tiffany@brooksrand.com

tilwate



Page 19 of 41 Client PM: Jay Perkins Client PO: 141391

Report Information

Laboratory Accreditation

BRL is accredited by the *National Environmental Laboratory Accreditation Program* (NELAP) through the State of Florida Department of Health, Bureau of Laboratories (E87982) and is certified to perform many environmental analyses. BRL is also certified by many other states to perform environmental analyses. For a current list of our accreditations/certifications, please visit our website at http://www.brooksrand.com/default.asp?contentID=586. Results reported relate only to the samples listed in the report.

Field Quality Control Samples

Please be notified that certain EPA methods require the collection of field quality control samples of an appropriate type and frequency; failure to do so is considered a deviation from some methods and for compliance purposes should only be done with the approval of regulatory authorities. Please see the specific EPA methods for details regarding required field quality control samples.

Common Abbreviations

BLK	method blank	MS	matrix spike
BRL	Brooks Rand Labs	MSD	matrix spike duplicate
BS	laboratory fortified blank	ND	non-detect
CAL	calibration standard	NR	non-reportable
CCV	continuing calibration verification	PS	post preparation spike
COC	chain of custody record	REC	percent recovery
CRM	certified reference material	RPD	relative percent difference
D	dissolved fraction	RSD	relative standard deviation
DUP	duplicate	SCV	secondary calibration verification
ICV	initial calibration verification	SOP	standard operating procedure
MDL	method detection limit	SRM	standard reference material
MRL	method reporting limit	Т	total recoverable fraction

Definition of Data Qualifiers

(Effective 9/23/09)

- B Detected by the instrument, the result is > the MDL but ≤ the MRL. Result is reported and considered an estimate.
- **E** An estimated value due to the presence of interferences. A full explanation is presented in the narrative.
- **H** Holding time and/or preservation requirements not met. Result is estimated.
- **J** Estimated value. A full explanation is presented in the narrative.
- J-M Duplicate precision (RPD) for associated QC sample was not within acceptance criteria. Result is estimated.
- J-N Spike recovery for associated QC sample was not within acceptance criteria. Result is estimated.
- M Duplicate precision (RPD) was not within acceptance criteria. Result is estimated.
- N Spike recovery was not within acceptance criteria. Result is estimated.
- **R** Rejected, unusable value. A full explanation is presented in the narrative.
- U Result is ≤ the MDL or client requested reporting limit (CRRL). Result reported as the MDL or CRRL.
- X Result is not BLK-corrected and is within 10x the absolute value of the highest detectable BLK in the batch. Result is estimated.

These qualifiers are based on those previously utilized by Brooks Rand, Ltd., those found in the EPA <u>SOW ILM03.0</u>, Exhibit B, Section III, pg. B-18, and the <u>USEPA Laboratory Data Validation Functional Guidelines for Evaluating Inorganic Analyses; USEPA; July 2002. These supersede all previous qualifiers ever employed by BRL.</u>



Page 20 of 41 Client PM: Jay Perkins Client PO: 141391

Sample Information

Sample	Lab ID	Report Matrix	Type	Sampled	Received
BioReactor 1 Inf	1208013-01	Water	Sample	02/18/2012	02/22/2012
BioReactor 1 Inf Hg Blk	1208013-02	Water	Sample	02/18/2012	02/22/2012
BioReactor 2 Eff	1208013-03	Water	Sample	02/18/2012	02/22/2012
BioReactor 2 Eff Hg Blk	1208013-04	Water	Sample	02/18/2012	02/22/2012

Batch Summary

Analyte	Lab Matrix	Method	Prepared	Analyzed	Batch	Sequence
Hg	Water	EPA 1631	02/25/2012	02/27/2012	B120297	1200129

Sample Results

Sample	Analyte	Report Matrix	Fraction	Result	Qualifier	MDL	MRL	Unit	Batch	Sequence
BioReactor 1 In 1208013-01	f Hg	Water	Т	230		15.2	40.4	ng/L	B120297	1200129
BioReactor 1 In 1208013-02	f Hg Blk Hg	Water	Т	0.15	U	0.15	0.40	ng/L	B120297	1200129
BioReactor 2 Ef 1208013-03	f Hg	Water	Т	15.1		0.58	1.54	ng/L	B120297	1200129
BioReactor 2 Ef 1208013-04	f Hg Blk Hg	Water	Т	0.15	U	0.15	0.40	ng/L	B120297	1200129



Page 21 of 41 Client PM: Jay Perkins Client PO: 141391

Accuracy & Precision Summary

Batch: B120297 Lab Matrix: Water Method: EPA 1631

Sample B120297-SRM1	Analyte Certified Reference Materia	Native al (1209009	Spike , NIST 1641d	Result 1000x dilut	Units ion)	REC & Limits	RPD & Limits
	Hg		15.68	14.73	ng/L	94% 85-115	
B120297-MS1	Matrix Spike (1208004-01) Hg	758.5	3535	4800	ng/L	114% 71-125	
	J				J		
B120297-MSD1	Matrix Spike Duplicate (120 Hg	758.5	3535	4565	ng/L	108% 71-125	5% 24
B120297-MS2	Matrix Spike (1208004-03) Hg	29.10	139.0	168.1	ng/L	100% 71-125	
B120297-MSD2	Matrix Spike Duplicate (120 Hg	29.10	140.2	177.0	ng/L	105% 71-125	5% 24



Page 22 of 41 Client PM: Jay Perkins Client PO: 141391

Method Blanks & Reporting Limits

Batch: B120297 Matrix: Water Method: EPA 1631

Analyte: Hg

Sample	Result	Units
B120297-BLK1	0.11	ng/L
B120297-BLK2	0.04	ng/L
B120297-BLK3	0.04	ng/L
B120297-BLK4	0.04	ng/L

 Average: 0.06
 Standard Deviation: 0.04
 MDL: 0.15

 Limit: 0.50
 Limit: 0.10
 MRL: 0.40



Page 23 of 41 Client PM: Jay Perkins Client PO: 141391

Instrument Calibration

Sequence: 1200129 Total Mercury Speciation by CVAFS

Instrument: THG-10 Method: EPA 1631

Date: 02/27/2012 **Analyte:** Hg

Lab ID 1200129-IBL1 1200129-IBL2 1200129-IBL3 1200129-IBL4	True Value	Result 4.20 6.75 4.72 5.95	Units pg of Hg pg of Hg pg of Hg pg of Hg	REC	C & Limits
1200129-CAL1	25.00	24.83	pg of Hg	99%	
1200129-CAL2	100.0	90.79	pg of Hg	91%	
1200129-CAL3	500.0	481.7	pg of Hg	96%	
1200129-CAL4	2500	2727	pg of Hg	109%	
1200129-CAL5	10000	10670	pg of Hg	107%	
1200129-ICV1	1568	1473	pg of Hg	94%	85-115
1200129-CCB1		4.56	pg of Hg		
1200129-CCV1	500.0	512.9	pg of Hg	103%	77-123
1200129-CCV2	500.0	512.7	pg of Hg	103%	77-123
1200129-CCV3	500.0	444.8	pg of Hg	89%	77-123



Page 24 of 41 Client PM: Jay Perkins Client PO: 141391

Sample Containers

Lab ID: 1208013-01 Report Matrix: Water Collected: 02/18/2012 Sample: BioReactor 1 Inf Received: 02/22/2012 Sample Type: Sample Des Container Size Lot **Preservation** P-Lot Ship. Cont. Bottle FLPE Hg-T 250mL 71470160 none n/a Cooler 10 Lab ID: 1208013-02 Collected: 02/18/2012 Report Matrix: Water Sample: BioReactor 1 Inf Hg Blk Sample Type: Sample Received: 02/22/2012 Des Container **Size** Lot **Preservation** P-Lot pН Ship. Cont. Bottle FLPE Hg-T 250mL 71470160 none n/a Cooler 10 Lab ID: 1208013-03 Collected: 02/18/2012 Report Matrix: Water Sample: BioReactor 2 Eff Sample Type: Sample Received: 02/22/2012 Des Container Size Preservation P-Lot Ship. Cont. Lot pН Bottle FLPE Hg-T 250mL 71470160 none n/a Cooler 10 Lab ID: 1208013-04 Report Matrix: Water Collected: 02/18/2012 Sample: BioReactor 2 Eff Hg Blk Received: 02/22/2012 Sample Type: Sample Container Size Lot **Preservation** P-Lot Hq Ship. Cont. Bottle FLPE Hq-T 500mL 71490157 none n/a Cooler 0

Shipping Containers

Cooler

Received: February 22, 2012 9:00 Tracking No: 472679668573 via FedEx

Coolant Type: Ice Temperature: 0.4 °C Description: Cooler
Damaged in transit? No
Returned to client? No

Custody seals present? No Custody seals intact? No COC present? Yes

D En	ike ergy		2 (Building 7405) rs Ferry Rd N. C. 28078 5-5245	LIMS#	2120	A	nalytical senx: OT	Labo	rato	ry U	Se O Sample Origina From	ily s	NC. SC	G	round Water	D OR	¹⁹ Page ISTRII IGINA	e 1 of 2 BUTIO L to LA CLIE	N AB,
1)Project Name		ACT Testing ws Creek	2)Phone No:	Vend PO#	PRIS			2.4	1 1	<i>y</i>	Drinki	ng Water V	Vaste		UST RCRA			•	X
	Vayne Chapman	n Laws, Allen Stowe, , Melonie Martin, Tom hnson	4)Fax No:	Vent PO#		144725		-	HCL HNO3		3 3			None					NaOH
5)Business Unit:		B)Process: 3500	Mail Code:		\S&C 'O#133	241	4-82	9	N		3 3		ASC 4		4	4	2,4	4	
8)Oper, Unit:	BC00	9)Res. Type: 69400	10)Project ID: MACTCAR		Brooks I	ole	ete all d areas.	16Analyse	Required			ICP=Mn	> 2	an	ate alkalinity, ate alkalinity, total (4.5), pH	ite,	C_NO3/NO	(not preserved	(w NaOH)
LAB USE ONLY	Se Speciation Bot	de			O#141			1		TDS, TSS	Hg - 245.1 Metals*	Hg,IMS=Se,	Se, Speciation,	1631, V_	Carbonate al bicarbonate al alkalinity, total	Chloride, Sulfate, Bromide - Díonex	Nittrate-nitrite, C_N03/N02	and S ₂ O ₂ ²	and Sob2
¹¹ Lab ID	ID		escription or ID	Date	Time	Sign	ature	7Сошр.	18Grab	Ĕ	Ε Į φ	H H	Se,	모	Car Bicar Valka Par	용	THE STATE OF	Mno.	MnO 4 and
1/2004/43		FGD I	Purge Eff	2/18	0030	Trais	The			1	1 1	1 1	1	ļ	1	1	1	2	
12004144 E		RioPos	actor 1 Inf	0.44	20.36		771					 	-	_		ļ	4	tc	AS
			or 1 Inf Hg Blk		0036		11 1	-			1 1	1	1	1	1	1	1	+	
45 45 of mm to	· · · · · · · · · · · · · · · · · · ·		actor 2 Eff		0030	1/2	1/m, 52	-			1 1	1**	1	1	1		1	-	-
47 g			or 2 Eff Hg Blk		0030	Tou .	12	-		-	<u> </u>	+	1	1	<u> </u>	1	\vdash		
Ğ							, , , , , , , , , , , , , , , , , , , 					11	╁┈	Ė	-			+	-
e e			39.044917404																
48		Fil	ter Blk	2/18	0030	Trans-	That					1							
49 8		Metal	s Trip Blk	_		-					_ 1		1						
o G					<u> </u>			-			_								_
ğ	instance to sign # de	te below - fill out from left to ri																	H
1) Relinquished By S) Relinquished By	Thorata	Date/Time	1/12	2) Accepted B	P W	Mas		2	Date/T	レノ	2	13:35) ju		²² Rec	quest	ed Tur	narou	nd
5)Reilingshied By	UN	2-2/-/2 Date/Time	/ /300	6)Accepted By	725	Se H	4		Date/T 22/ Date/T		09	<i>10</i> 6	IMPORTANT!			Days _ Days	·		
7)Relinguished By		Date/Time		8)Accepted By					Date/1	ime			MPO			, 8 Hr			
9)Seal/Locked By	iel	2-2/12 Date/Time		10) Séál/Lock (12)Seál/Lock (Date/T				Customer,		*Other		st Will /		



18804 Northcreek Parkway Bothell, WA, 98011 Tel: (425) 483-3300 Fax: (425) 483-9818 www.appliedspeciation.com

March 6, 2012

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078 (704) 875-5245

Project: HAPS/MACT Testing Belews Creek (LIMS # J12020341)

Dear Mr. Perkins,

Attached is the report associated with one (1) aqueous sample submitted for permanganate and persulfate analyses on February 21, 2012. The samples were received in a sealed cooler at -0.3°C on February 22, 2012. Permanganate and persulfate analyses were performed via spectrophotometry. Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078

Project: HAPS/MACT Testing Belews Creek (LIMS # J12020341)

March 6, 2012

1. Sample Reception

One (1) aqueous sample in two 125mL HDPE bottles and two 125mL borosilicate glass bottles (provided by Applied Speciation and Consulting) was submitted for permanganate and persulfate analyses on February 21, 2012. The sample was received on February 22, 2012 in a sealed container at -0.3°C.

The sample was received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and was designated a discrete sample identifier. All sample containers were placed in a secure refrigerator maintained at a temperature of 4°C until analysis could be performed.

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

 $\underline{S_2O_8}^2$ and $\underline{MnO_4}$ Analysis by Spectrophotometry Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm). Permanganate standards of known concentrations were filtered using the identical filtration apparatus to confirm that filtration does not induce loss of the target analyte.

Filtration is a requirement for samples containing suspended solids due to the light scattering properties of particulates.

3. Sample Analysis

All sample analysis is preceded by a minimum of a four-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of each analytical day. All calibration curves, associated with each species of interest, are standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimal interval of every ten analytical runs.

<u>MnO₄</u> Analysis by Spectrophotometry Each sample for permanganate analysis was analyzed by spectrophotometry on February 29, 2012. An aliquot of each sample was transferred to a cuvette with a 1cm light path. The permanganate complex was quantified by measuring the light absorbance at a wavelength of 545nm.

 $\underline{S_2O_8}^2$ Analysis by Spectrophotometry Each sample for persulfate analysis was analyzed by spectrophotometry on March 1, 2012. An aliquot of each sample was transferred to a 15mL polyethylene centrifuge tube. A starch iodide solution was added to each sample which induces conversion of iodide to $I_{2(aq)}$. The I_2 complex then reacts with starch to form a blue complex which is measured at a wavelength of 525nm.

4. Analytical Issues

The permanganate and persulfate recoveries for the matrix spike and matrix spike duplicate were below the control limit of 75%. The target analytes are efficient oxidizing agents which are amenable to reaction with most compounds. The low recoveries confirm that the sample matrix does not support the existence of strong oxidizing agents such as permanganate or persulfate. Approximately 2 minutes passed between the time of amending the sample matrix with the spikes and measurements which suggests that the low sample concentrations are not attributed to the variable of sample holding times.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

> Date: March 6, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Sample Results

Sample ID	MnO ₄	S ₂ O ₈ ⁻²
FGD Purge Eff	ND (<0.50)	ND (<100)
All regulte reflect the applied	dilution and are	reported in ma/l

All results reflect the applied dilution and are reported in mg/L ND = Not detected at the applied dilution

Date: March 6, 2012
Report Generated by: Russell Gerads
Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (mg/L)	PBW1	eMDL
MnO ₄	0.00	0.50
$S_2O_8^{-2}$	12	100

eMDL = Estimated Method Detection Limit

Quality Control Summary - Certified Reference Materials

Analyte (mg/L)	CRM	True Value	Result	Recovery
MnO ₄	LCS	0.500	0.581	116.3
S ₂ O ₈ ⁻²	LCS	100	123	123.4

Date: March 6, 2012
Report Generated by: Russell Gerads
Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (mg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
MnO ₄	Batch QC	ND (<0.50)	ND (<0.50)	NC	NC
$S_2O_8^{-2}$	Batch QC	129	116	122.2	10.5

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (mg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
MnO ₄	Batch QC	0.500	0.052	10.5*	0.500	0.052	10.5*	0.0
$S_2O_8^{-2}$	Batch QC	500	167	9.0*	500	137	3.0*	19.7

^{*}Low recovery is attributed to matrix induced species conversion

7	- -	•		•	•					
presentation by repeal could be specified by specific order by specific order by specific by specific order by specific	1) Railingulaheed By (Cu') 3) Railing Briand By	Customer to com	C	S Column	inthoore	Solvanting	TAB USE ONLY	Customer fix 5)Business Unit:	2) Client:	1)Project Name
20 100	Manutan						Se Speciation Bottle	20003	Belew Bill Kennedy, Ron Vayne Chapman,	Duke Energy.
Detertions Detertions Detertions Detertions Desertions 100 Security cars Opened By Desertions Desertions 120 Security cars Opened By	to sign & date below. Ill out from left to right. Bright Brig	Meta	F	BioReach	BioReact	FGD		e)Process: 3500	Bill Kennedy, Ron Laws, Allen Stowe, Wayne Chapman, Melonie Martin, Tom	Duke Energy Analytical Laboratory Mail Code MGO3A2 (Bullding 7405) 13339 Hagers Ferry Rd Humbersville, N. C. 26078 (704) 875-5245 Fax: (704) 875-5349 HAPS/MACT Testing Duke Energy Analytical Laboratory 13339 Hagers Ferry Rd 1405 1
	8/ 72 3	Metals Trip Blk	Filter Blk	BioReactor 2 Eff BioReactor 2 Eff Ho Blk	BioReactor 1 Inf BioReactor 1 Inf Hg Bik	FGD Purge Eff	13Sample Description or ID	Mail Code: 10)Project ID:	4)Fax No:	uke Energy Analytical Laboratory Mail Code MG03A2 (Bullding 7405) 13339 Hagers Ferry Rd Huntersville, N.C. 28078 (704) 875-5245 Fax: [704] 875-3249 1 Testing 2 Phone No: PC# PRISM
SJAccepted By: SJAccepted By: 10) Seault cork Opened By 12)Seault cork Opened By	2) Accepting By			-1	2/18 00	2/ 18 00	Data PO#	PO#	2	Longe day
ned By	Julias		Timo The	0030 7- 7	0030 / 76	7/25	Brooks Rand ded areas PO#141391 Time Signature	PO#133241 viete all	144725	
3	7 X 4 Y 2 Y 3 Y 3 Y 3 Y 3 Y 3 Y 3 Y 3 Y 3 Y 3		9	37	79		¹⁷ Comp. (6	Arialyses equired	"Preserv.:1=HCL 2=H,SO, 3+H00, 4+fce. 5=Note	Analytical Laboratory Use Only Lacent: OTHER Shreets Originating ATT LLI Community Directory Community Com
	0-/2 3:	-3		<u>-</u>			TDS, TSS Hg - 245.1 Metals* Hg,IMS=Se, 10	^D=Mn	ω ω ω	allytical Laboratory Use Only any: OTHER Sample PROGRAM (1) Sample PROGRAM (2) Util Sample PROGRAM (3) Wester (4) Wester
Customer, IMPORTAL Please indicate desired turi	NT!			- ; 		-	(filtered by station) Se, Speciation Hg 1631, V_B	ı, V_ASC	None	3
t of t	22 R 0			-	_	_	Carbonate alka bicarbonate alka alkalinity, total (V_Prism	alinity, alinity,	4	Ground Mater DES UST ACRA
T Days -48 Hr Add. Cost Will Apply -06-4	²² Requested Turnaround			-		1	Chloride, Sulfate Bromide - Dione Nittrate-nitrite, C	ex	4 2,4	napage 1 of 2 DISTRIBUTION ORIGINAL to LAB COPY to CLIENT
7 App.	! ಹೆ	 	- 	\vdash	 	ਰ 2	MinO , and S ₂ O ₂ ⁻²		 	드린크의



18804 Northcreek Parkway Bothell, WA, 98011 Tel: (425) 483-3300 Fax: (425) 483-9818 www.appliedspeciation.com

February 28, 2012

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078 (704) 875-5245

Project: HAPS/MACT Testing Belews Creek (LIMS # J12020341)

Dear Mr. Perkins,

Attached is the report associated with four (4) aqueous samples submitted for selenium speciation analysis on February 21, 2012. The samples were received in a sealed cooler at -0.3°C on February 22, 2012. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS). Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078

Project: HAPS/MACT Testing Belews Creek (LIMS # J12020341)

February 28, 2012

1. Sample Reception

Four (4) aqueous samples in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on February 21, 2012. The samples were received on February 22, 2012 in a sealed container at -0.3°C.

The samples were received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and was designated a discrete sample identifier. An aliquot of each sample was filtered (0.45 µm) and each filtrate was stored in a secure, monitored cryofreezer (maintained at a temperature of -80°C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

<u>Selenium Speciation Analysis by IC-ICP-CRC-MS</u> Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45μm) and injected directly into a sealed autosampler vial. No further sample preparation was performed as any chemical alteration of a sample may shift the equilibrium of the system, resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is preceded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of each analytical day. All calibration curves, associated with each species of interest, are

standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimal interval of every ten analytical runs.

<u>Selenium Speciation Analysis by IC-ICP-CRC-MS</u> Each sample for selenium speciation analysis was analyzed by ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS) on February 23, 2012. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic (pH > 7) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (CRC) containing hydrogen gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went well and no significant analytical issues were encountered. All quality control parameters associated with this sample were within acceptance limits.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

> Date: February 28, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Sample Results

						Unknown Se
Sample ID	Se(IV)	Se(VI)	SeCN	MeSe(IV)	SeMe	Species (n)
FGd Purge Eff	310	75.1	ND (<1.6)	ND (<9.4)	ND (<9.4)	0 (0)
BioReactor 1 Inf	40.2	65.5	ND (<0.39)	5.7	ND (<2.4)	0 (0)
BioReactor 2 Eff	ND (<2.0)	ND (<4.7)	ND (<0.39)	ND (<2.4)	ND (<2.4)	0 (0)
Metals Trip Blk	ND (<0.079)	ND (<0.19)	ND (<0.016)	ND (<0.094)	ND (<0.094)	0 (0)

All results reflect the applied dilution and are reported in µg/L

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

n = number of unknown Se species observed

Date: February 28, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (µg/L)	PBW1	PBW2	PBW3	PBW4	Mean	StdDev	eMDL*	eMDL 10x	eMDL 250x	eMDL 1000x
Se(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.008	0.079	2.0	7.9
Se(VI)	0.019	0.000	0.000	0.000	0.005	0.009	0.019	0.188	4.7	19
SeCN	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.016	0.39	1.6
MeSe(IV)	0.000	0.000	0.095	0.000	0.024	0.048	0.009	0.094	2.4	9.4
SeMe	0.000	0.000	0.000	0.000	0.000	0.000	0.009	0.094	2.4	9.4

eMDL = Estimated Method Detection Limit

Quality Control Summary - Certified Reference Materials

Analyte (µg/L)	CRM	True Value	Result	Recovery
Se(IV)	LCS	9.57	9.38	98.0
Se(VI)	LCS	9.48	9.09	95.9
SeCN	LCS	8.92	8.54	95.7
MeSe(IV)	LCS	6.47	5.79	89.4
SeMe	LCS	9.32	8.48	91.0

^{*}Please see narrative regarding eMDL calculations

Date: February 28, 2012 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (µg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
Se(IV)	Batch QC	ND (<2.0)	ND (<2.0)	NC	NC
Se(VI)	Batch QC	ND (<4.7)	ND (<4.7)	NC	NC
SeCN	Batch QC	ND (<0.39)	ND (<0.39)	NC	NC
MeSe(IV)	Batch QC	ND (<2.4)	ND (<2.4)	NC	NC
SeMe	Batch QC	ND (<2.4)	ND (<2.4)	NC	NC

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (µg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
Se(IV)	Batch QC	1390	1592	114.6	1390	1594	114.7	0.1
Se(VI)	Batch QC	1261	1279	101.4	1261	1284	101.8	0.4
SeCN	Batch QC	1144	812.1	71.0*	1144	821.9	71.9*	1.2

^{*}Low recovery is attributed to matrix induced species conversion

7																																	
Committee	THE PLOCE OF THE PARTY.	e)South of the se	7)Relinguished By	SIRelindation By	/ / Growing was (s	1) Relinguished By		Custo	mer to	Com	CZ pete	appro	priate	col			TO DOI DOVE JU	CANAL MAN	20/1/20/20/20	3	LAB USE ONLY			S)Oper. Unit:	5)Business Unit:		2) Client:	lage 4	-	-·· , (フロロ	
	•					Thereta	ŧL.													5	Se Speciation Bottle		всоо	1	20003	/ayne Chapman, Job	3ili Kennedy, Ron	HAPS/MA Belew			TOPROV	Duke	
* MATTE MANYS = At Col Cr Cii Ni Se Ag Zn TRWICP = B. Ca, FE K. Li Mo	A STORY	-0	Date/Time	Dandston	2.22.7	Batariira 2/18/	tomer to sign & date below - fill out from left to right.			Meta	FI		DioNeach	Dia Donat	BioRe	BioReact	BioRe		FGD		•		69400	9)Res. Type:	s)Process: 3500	Wayne Chapman, Welonie Martin, Tom Johnson	Bill Kennedy, Ron Laws, Allen Stowe,	HAPS/MACT Testing Belews Creek	21Phone No	(704) 875-5245 Fax: (704) 875-43	13339 Hagers Ferry Rd Huntersville, N. C. 2807	Mail Code MGO3A2 (Building 7405)	Duke Energy Analytical Laboratory
Ni Sa Ao Zn TRA		, 3			138	8/12	right.			Metals Trip Blk	Filter Blk		Diometrical 7 Cit Lig on	1 DE LA DIF	BioReactor 2 Eff	BioReactor 1 Inf Hg Blk	BioReactor 1 Inf	C	FGD Purge Eff	¹³ Sample Description or ID			MACTCAR	10)Project ID:	Mail Code:		4)Flix No:	1	21Phone No:	5-5245 875-4349	9 Ferry Rd N. C. 26078	2 (Bulkling 7405)	uke Energy Analytical Laboratory
MICP = B. Ca. F	12)Seal/Lock Opened 59	10) Sealth oak Opened By	Spaceapted By:	Sphooded By	A Accepted By	al woodsled giv.					2/18 0030	1 1	•			i	2/18 0036	- 1	-	Date Time		PO#141391	a Brook	Ţ		AS		·	Vend	00			
E K Li Mg Mn Na,	ÿ	a #9				Mallex					so Trus The		1	7/1/1/195	50 Tr-766	30 The That	36-Th- Th		Thirty	Signature			Brooks Rand ded areas.	-6-4	33241		FO#144//23 "Fn		ш	2-20-12		7.7.2.// wester O	
		•	•	9	て作され	رار • الا		 		<u> </u>	7		-	<i>/</i>] :	1	1	V)		P	¹⁷ Cor			· {	naly	/393 90	e 5=Nose	"Presery.:1=HCL	Coler Temp	7/	(4		WHITO WHE	Analytical Laboratory Use Only
vice un	Darray Trays	Odnacii intera	Date/Time	reft inde	(1.7 ₀	20/2					-									TDS	3, TS:			_		4	*/	G			Tr.	\$.	ory Use
					· 0.3			_	+				_		-				_	Met	als*					u			MINERAL BUTHULICA	SAMPLE PROGRAM	From	Bulgatelet Satisfants	Only
Customer, IMPORTANT!							_		1	1		_		*				<u>-</u>	(filtere	IMS=	ation	ı)					W/easte	1	PROGRAM		8 X		
Please Indicate desired turnar				ound.	$\ \cdot\ $	+	+		+-			_	1		<u></u>			-	Spec 1631			_		No	пė			₹.	- []	1			
۲		*Other		7	14	²² Re											_		_	bica alka	rbona rbona linity, rism	te a	alkali	nity	<i>t</i> ,	4			RCRA.	1 2			
₹	2-28-	Add. Cost Will Apply	8 ∓	7 Days	14 Days_	²² Requested Turnaround									-		_			Bron	oride, mide -	Die	onex	·		4				Ş	2 2 3 3 6	DIS	iğ K
	₩	*¥				d Turr			+	+	-	_			-	-	-		-	Nitt	rate-ni	trite	, G_N	103/	NO2	2,4		-			Ž		Ĭ
	7	₽ F				Jarour			_	+		<u> </u>					<u> </u>	ਰ	2	-	, and	_		_				٥	X	֓֞֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓	ORIGINAL to LAB	DISTRIBUTION	Š
						đ			-	-		+-			-	-	-	AS&C	2	MnO	• and	820) _a -2 (y	v Na	OH)	Næ	ОН	┤	W 4	•			

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM **Analytical Laboratory Use Only Duke Energy Analytical Laboratory** DISTRIBUTION 41 Matrix: OTHER Duke Energy_{ss} Mail Code MGO3A2 (Building 7405) SC: 13339 Hagers Ferry Rd ORIGINAL to LAB. Huntersville, N. C. 28078 Date & Time COPY to CLIENT SAMPLE PROGRAM Ground Water (704) 875-5245 2-20-12 Fax: (704) 875-4349 Drinking Water Vend RCRA **HAPS/MACT Testing** PO# 1)Project Name PRISM Cooler Temp (C **Belews Creek** PO#144725 Bill Kennedy, Ron Laws, Allen Stowe, 4)Fax No: Ven None 2=H2SO4 3=HNO 2) Client: Wayne Chapman, Melonie Martin, Tom PO# 4 3 4=lce 5=None 4 AS&C Johnson V_ASC MR (not preserved Mail Code: Carbonate alkalinity, bicarbonate alkalinity, alkalinity, total (4.5), pH - V_Prism Nittrate-nitrite, C_NO3/NO2 PO#133241 3500 16 Analyse Required (w NaOH) 5)Business Unit: ICP=Mn 20003 Hg 1631, V_BRand 10)Project ID: 9)Res. Type: olete all Chloride, Sulfate, Bromide - Dionex 8)Oper. Unit: Se, Speciation, BC00 69400 MACTCAR ded areas. S208-2 S208-2 **Brooks Rand** Hg,IMS=Se, PO#141391 TDS, TSS Hg - 245.1 Mno , and and Metals* LAB USE ONLY 18Grab Se Speciation Bottle Mno. ¹³Sample Description or ID Date Time Signature 2 2 0030 FGD Purge Eff to AS&C 1 1 1 1 1 2/18 0036 BioReactor 1 Inf 20/2004/40 2/18/0030 BioReactor 1 Inf Hg Blk 2118 0030 1 1 1 1 1 BioReactor 2 Eff 0030 BioReactor 2 Eff Hg Blk 2/18 0030 Trave That Filter Blk Metals Trip Blk 2) Accepted By ²²Requested Turnaround desired turnaround 2/18/12 4) Accepted By 14 Days 7)Relinquished By indicate 10) Seal/Lock Opened By Date/Time Date/Time Add. Cost Will Apply Date/Time 12)Seal/Lock Opened By 11)Seal/Locked By * Metals=TRM/IMS = As, Cd, Cr, Cu, Ni, Se, Ag, Zn TRM/ICP = B, Ca, FE, K, Li, Mg, Mn, Na, Comments 1** Mn only