



Analytical Laboratory

Page 1 of 16

13339 Hagers Ferry Road
Huntersville, NC 28078-7929
McGuire Nuclear Complex - MG03A2
Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number: J13020369

Project Name: WWTS - Biweekly (2)

Customer Name(s): Bill Kennedy, Melonie Martin, Wayne Chapman, Travis Thornton

Customer Address: 3195 Pine Hall Rd
Mailcode: Belews Steam Station
Belews Creek, NC 28012

Lab Contact: Jason C Perkins Phone: 980-875-5348

Report Authorized By: _____ **Date:** 3/26/2013
(Signature) Jason C Perkins

Program Comments:

Please contact the Program Manager (Jason C Perkins) with any questions regarding this report.

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with a Qualifier indicate a deviation from the method quality system or quality control requirement. The qualifier description is found at the end of the Certificate of Analysis (sample results) under the qualifiers heading. All results are reported on a dry weight basis unless otherwise noted. Subcontracted data included on the Duke Certificate of Analysis is to be used as information only. Certified vendor results can be found in the subcontracted lab final report. Duke Energy Analytical Laboratory subcontracts analyses to other vendor laboratories that have been qualified by Duke Energy to perform these analyses except where noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications : North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

Sample ID	Plant/Station	Collection Date and Time	Collected By	Sample Description
2013004289	BELEWS	27-Feb-13 7:30 AM	TO	FGD Purge Eff
2013004290	BELEWS	27-Feb-13 7:30 AM	TO	EQ TANK EFF.
2013004291	BELEWS	27-Feb-13 7:30 AM	TO	BIOREACTOR 1 INF.
2013004292	BELEWS	27-Feb-13 7:30 AM	TO	BIOREACTOR 2 INF.
2013004293	BELEWS	27-Feb-13 7:30 AM	TO	BIOREACTOR 2 EFF.
2013004294	BELEWS	27-Feb-13 7:30 AM	TO	FILTER BLANK
2013004295	BELEWS	27-Feb-13 7:30 AM	TO	Trip Blank
7 Total Samples				

Technical Validation Review

Checklist:

- COC and .pdf report are in agreement with sample totals and analyses (compliance programs and procedures). ☒ Yes ☐ No
- All Results are less than the laboratory reporting limits. ☐ Yes ☒ No
- All laboratory QA/QC requirements are acceptable. ☒ Yes ☐ No

The following vendor labs are Pending Qualifi Applied Speciation

Report Sections Included:

- | | |
|---|---|
| <input checked="" type="checkbox"/> Job Summary Report | <input checked="" type="checkbox"/> Sub-contracted Laboratory Results |
| <input checked="" type="checkbox"/> Sample Identification | <input type="checkbox"/> Customer Specific Data Sheets, Reports, & Documentation |
| <input checked="" type="checkbox"/> Technical Validation of Data Package | <input type="checkbox"/> Customer Database Entries |
| <input checked="" type="checkbox"/> Analytical Laboratory Certificate of Analysis | <input checked="" type="checkbox"/> Chain of Custody |
| <input type="checkbox"/> Analytical Laboratory QC Report | <input checked="" type="checkbox"/> Electronic Data Deliverable (EDD) Sent Separately |

Reviewed By: DBA Account

Date: 3/26/2013

Certificate of Laboratory Analysis

Page 4 of 16

*This report shall not be reproduced, except in full.***Order # J13020369**

Site: FGD Purge Eff

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004289

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>INORGANIC IONS BY IC</u>								
Bromide	110	mg/L		5	50	EPA 300.0	03/15/2013 21:36	BGN9034
<u>MERCURY (COLD VAPOR) IN WATER</u>								
Mercury (Hg)	282	ug/L		5	100	EPA 245.1	03/07/2013 14:17	AGIBBS
<u>DISSOLVED METALS BY ICP</u>								
Manganese (Mn)	9.35	mg/L		0.05	10	EPA 200.7	03/18/2013 15:15	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP</u>								
Boron (B)	205	mg/L		0.5	10	EPA 200.7	03/12/2013 11:22	MHH7131
Manganese (Mn)	10.9	mg/L		0.05	10	EPA 200.7	03/12/2013 11:22	MHH7131
<u>DISSOLVED METALS BY ICP-MS</u>								
Selenium (Se)	410	ug/L		10	10	EPA 200.8	03/20/2013 12:51	DJSULL1
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>								
Arsenic (As)	350	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
Chromium (Cr)	300	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
Copper (Cu)	171	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
Nickel (Ni)	252	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
Selenium (Se)	4630	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
Zinc (Zn)	305	ug/L		10	10	EPA 200.8	03/08/2013 15:16	KRICAR
<u>SELENIUM SPECIATION - (Analysis Performed by Applied Speciation and Consulting, LLC)</u>								
Vendor Parameter	Complete					Vendor Method	V_AS&C	
<u>TOTAL DISSOLVED SOLIDS</u>								
TDS	19000	mg/L		200	1	SM2540C	03/05/2013 15:35	SWILLI3

Site: EQ TANK EFF.

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004290

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>MERCURY (COLD VAPOR) IN WATER</u>								
Mercury (Hg)	169	ug/L		2.5	50	EPA 245.1	03/07/2013 14:19	AGIBBS
<u>DISSOLVED METALS BY ICP</u>								
Manganese (Mn)	9.02	mg/L		0.05	10	EPA 200.7	03/18/2013 15:19	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP</u>								
Boron (B)	212	mg/L		0.5	10	EPA 200.7	03/12/2013 11:26	MHH7131
Manganese (Mn)	9.85	mg/L		0.05	10	EPA 200.7	03/12/2013 11:26	MHH7131

Certificate of Laboratory Analysis

Page 5 of 16

*This report shall not be reproduced, except in full.***Order # J13020369**

Site: EQ TANK EFF.

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004290

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>DISSOLVED METALS BY ICP-MS</u>								
Selenium (Se)	247	ug/L		10	10	EPA 200.8	03/20/2013 12:54	DJSULL1
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>								
Arsenic (As)	242	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR
Chromium (Cr)	216	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR
Copper (Cu)	127	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR
Nickel (Ni)	202	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR
Selenium (Se)	3310	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR
Zinc (Zn)	227	ug/L		10	10	EPA 200.8	03/08/2013 15:20	KRICHR

Site: BIOREACTOR 1 INF.

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004291

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>DISSOLVED METALS BY ICP</u>								
Manganese (Mn)	3.44	mg/L		0.05	10	EPA 200.7	03/18/2013 15:23	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP</u>								
Boron (B)	210	mg/L		0.5	10	EPA 200.7	03/12/2013 11:30	MHH7131
Manganese (Mn)	4.97	mg/L		0.05	10	EPA 200.7	03/12/2013 11:30	MHH7131
<u>DISSOLVED METALS BY ICP-MS</u>								
Selenium (Se)	95.3	ug/L		10	10	EPA 200.8	03/20/2013 12:57	DJSULL1
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>								
Arsenic (As)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR
Chromium (Cr)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR
Copper (Cu)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR
Nickel (Ni)	40.4	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR
Selenium (Se)	114	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR
Zinc (Zn)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:23	KRICHR

SELENIUM SPECIATION - (Analysis Performed by Applied Speciation and Consulting, LLC)

Vendor Parameter

Complete

Vendor Method

V_AS&C

Certificate of Laboratory Analysis

Page 6 of 16

*This report shall not be reproduced, except in full.***Order # J13020369**

Site: BIOREACTOR 2 INF.

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004292

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP</u>								
Boron (B)	217	mg/L		0.5	10	EPA 200.7	03/12/2013 11:34	MHH7131
Manganese (Mn)	4.97	mg/L		0.05	10	EPA 200.7	03/12/2013 11:34	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>								
Arsenic (As)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR
Chromium (Cr)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR
Copper (Cu)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR
Nickel (Ni)	12.9	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR
Selenium (Se)	12.0	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR
Zinc (Zn)	< 10	ug/L		10	10	EPA 200.8	03/08/2013 15:27	KRICHR

Site: BIOREACTOR 2 EFF.

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004293

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>INORGANIC IONS BY IC</u>								
Bromide	120	mg/L		5	50	EPA 300.0	03/15/2013 21:55	BGN9034
<u>MERCURY (COLD VAPOR) IN WATER</u>								
Mercury (Hg)	< 1	ug/L		1	20	EPA 245.1	03/07/2013 14:21	AGIBBS
<u>TOTAL RECOVERABLE METALS BY ICP</u>								
Boron (B)	236	mg/L		0.5	10	EPA 200.7	03/12/2013 11:38	MHH7131
Manganese (Mn)	5.01	mg/L		0.05	10	EPA 200.7	03/12/2013 11:38	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>								
Arsenic (As)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR
Chromium (Cr)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR
Copper (Cu)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR
Nickel (Ni)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR
Selenium (Se)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR
Silver (Ag)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR
Zinc (Zn)	< 5	ug/L		5	5	EPA 200.8	03/08/2013 15:30	KRICHR

SELENIUM SPECIATION - (Analysis Performed by Applied Speciation and Consulting, LLC)

Vendor Parameter

Complete

Vendor Method

V_AS&C

Certificate of Laboratory Analysis

Page 7 of 16

This report shall not be reproduced, except in full.

Order # J13020369

Site: FILTER BLANK

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004294

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>DISSOLVED METALS BY ICP</u>								
Manganese (Mn)	0.023	mg/L		0.005	1	EPA 200.7	03/18/2013 15:07	MHH7131
<u>DISSOLVED METALS BY ICP-MS</u>								
Selenium (Se)	< 1	ug/L		1	1	EPA 200.8	03/20/2013 12:44	DJSULL1

Site: Trip Blank

Collection Date: 27-Feb-13 7:30 AM

Sample #: 2013004295

Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
<u>TOTAL RECOVERABLE METALS BY ICP</u>								
Boron (B)	< 0.05	mg/L		0.05	1	EPA 200.7	03/12/2013 11:18	MHH7131
Manganese (Mn)	< 0.005	mg/L		0.005	1	EPA 200.7	03/12/2013 11:18	MHH7131
<u>TOTAL RECOVERABLE METALS BY ICP-MS</u>								
Arsenic (As)	< 1	ug/L		1	1	EPA 200.8	03/08/2013 15:13	KRICHA
Chromium (Cr)	< 1	ug/L		1	1	EPA 200.8	03/08/2013 15:13	KRICHA
Copper (Cu)	< 1	ug/L		1	1	EPA 200.8	03/08/2013 15:13	KRICHA
Nickel (Ni)	< 1	ug/L		1	1	EPA 200.8	03/08/2013 15:13	KRICHA
Selenium (Se)	< 1	ug/L		1	1	EPA 200.8	03/08/2013 15:13	KRICHA
Silver (Ag)	< 1	ug/L		1	1	EPA 200.8	03/08/2013 15:13	KRICHA
Zinc (Zn)	< 2	ug/L		2	1	EPA 200.8	03/08/2013 15:13	KRICHA

SELENIUM SPECIATION - (Analysis Performed by Applied Speciation and Consulting, LLC)

Vendor Parameter	Complete	Vendor Method	V_AS&C
------------------	----------	---------------	--------



**APPLIED SPECIATION
AND CONSULTING, LLC**

18804 Northcreek Parkway Bothell, WA, 98011
Tel: (425) 483-3300 Fax: (425) 483-9818
www.appliedspeciation.com

March 8, 2013

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078
(704) 875-5245

Project: Belews - FGD WWTS Bi-Monthly Sampling) (LIMS #J13020369)

Dear Mr. Perkins,

Attached is the report associated with four (4) aqueous samples submitted for selenium speciation on February 28, 2013. The samples were received in a sealed cooler at 1.7°C on March 1, 2013. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS). Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

A handwritten signature in black ink, appearing to read "Russell Gerads", with a stylized flourish at the end.

Russell Gerads
Vice President
Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078

Project: Belews - FGD WWTS Bi-Monthly Sampling) (LIMS #J13020369)

March 8, 2013

1. Sample Reception

Four (4) aqueous samples in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on February 28, 2013. The samples were received on March 1, 2013 in a sealed container at 1.7°C.

The samples were received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and were designated discrete sample identifiers. An aliquot of each sample was filtered (0.45µm) and each filtrate was stored in a secure, monitored cryofreezer (maintained at a temperature of -80°C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

Selenium Speciation Analysis by IC-ICP-CRC-MS Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm) and injected directly into an autosampler vial. No further sample preparation was performed as any chemical alteration of a sample may shift the equilibrium of the system, resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is preceded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of

each analytical day. All calibration curves, associated with each species of interest, are standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimum interval of every ten analytical runs.

Selenium Speciation Analysis by IC-ICP-CRC-MS Each sample for selenium speciation analysis was analyzed by ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS) on March 7, 2013. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic ($\text{pH} > 7$) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (CRC) containing a reaction gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went well and no significant analytical issues were encountered. All quality control parameters associated with the samples were within acceptance limits.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

A handwritten signature in black ink, appearing to read 'Russell Gerads', with a stylized, sweeping flourish extending to the right.

Russell Gerads
Vice President
Applied Speciation and Consulting, LLC

Selenium Speciation Results for Duke Energy
 Project Name: Belews - FGD WWTS Bi-Monthly Sampling)
 Contact: Jay Perkins
 LIMS #J13020369

Date: March 8, 2013
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Sample Results

Sample ID	Se(IV)	Se(VI)	SeCN	MeSe(IV)	SeMe	Unknown Se Species (n)
FGD Purge Eff	330	79.1	ND (<2.6)	8.2	ND (<4.1)	0.0 (0)
BioReactor 1 Inf	24.5	62.8	ND (<0.65)	5.5	ND (<1.0)	10.4 (1)
BioReactor 2 Eff	ND (<1.7)	ND (<0.73)	ND (<0.65)	ND (<1.0)	ND (<1.0)	0.0 (0)
Metals Trip Blk	0.162	0.043	ND (<0.026)	ND (<0.041)	ND (<0.041)	0.0 (0)

All results reflect the applied dilution and are reported in µg/L

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

Selenium Speciation Results for Duke Energy
 Project Name: Belews - FGD WWTS Bi-Monthly Sampling)
 Contact: Jay Perkins
 LIMS #J13020369

Date: March 8, 2013
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (µg/L)	PBW1	PBW2	PBW3	PBW4	Mean	StdDev	eMDL*	eMDL 10x	eMDL 250x	eMDL 1000x
Se(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.007	0.068	1.7	6.8
Se(VI)	0.000	0.000	0.000	0.000	0.000	0.000	0.003	0.029	0.73	2.9
SeCN	0.000	0.000	0.000	0.000	0.000	0.000	0.003	0.026	0.65	2.6
MeSe(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.004	0.041	1.0	4.1
SeMe	0.000	0.000	0.000	0.000	0.000	0.000	0.004	0.041	1.0	4.1

eMDL = Estimated Method Detection Limit

*Please see narrative regarding eMDL calculations

Quality Control Summary - Certified Reference Materials

Analyte (µg/L)	CRM	True Value	Result	Recovery
Se(IV)	LCS	4.79	4.89	102.2
Se(VI)	LCS	4.74	4.59	96.9
SeCN	LCS	4.46	4.40	98.6
MeSe(IV)	LCS	3.24	3.05	94.3
SeMe	LCS	4.66	4.48	96.0

Selenium Speciation Results for Duke Energy
 Project Name: Belews - FGD WWTS Bi-Monthly Sampling)
 Contact: Jay Perkins
 LIMS #J13020369

Date: March 8, 2013
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (µg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
Se(IV)	Batch QC	ND (<6.8)	ND (<6.8)	NC	NC
Se(VI)	Batch QC	ND (<2.9)	ND (<2.9)	NC	NC
SeCN	Batch QC	ND (<2.6)	ND (<2.6)	NC	NC
MeSe(IV)	Batch QC	ND (<4.1)	ND (<4.1)	NC	NC
SeMe	Batch QC	ND (<4.1)	ND (<4.1)	NC	NC

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (µg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
Se(IV)	Batch QC	5560	5658	101.8	5560	5534	99.5	2.2
Se(VI)	Batch QC	5045	5009	99.3	5045	4890	96.9	2.4
SeCN	Batch QC	4575	4462	97.5	4575	4451	97.3	0.3

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM



Duke Energy Analytical Laboratory
 Mail Code MGO3A2 (Building 7406)
 13339 Hagers Ferry Rd
 Huntersville, N.C. 28078
 (704) 875-5245
 Fax: (704) 875-4349

1) Project Name: **Belwets - FGD**
 2) Client: **WWTS Bi-Monthly Sampling**
 3) Business Unit: **Bill Kennedy, Melonie Martin, Wayne Chapman, Travis Thornton ****
 4) Process: **WWTS**
 5) Res. Type: **WWTS**
 6) Mail Code: **WWTS**

ORDER# **513020369**
 MATRIX: OTHER

Logged By: **CPK**
 Date & Time: **2-28-13 1003**

AS&C
 PO#133241

MR #

Customer to complete all appropriate non-shaded areas.

Sampling conducted: 2nd and 4th Wednesday

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

Signature

Date

Time

LAB USE ONLY

11) Lab ID: **2013004289**
90
91
92
93
94
95

13) Sample Description or ID

Se Spec Bottle ID

FGD Purge Eff

EQ Tank Eff.

BioReactor 1 Inf

BioReactor 2 Inf

BioReactor 2 Eff

Filter Blk

Metals Trip Blk

Customer to sign & date below - fill out from left to right.

1) Relinquished By: **CPK**

3) Relinquished By: **CPK**

5) Relinquished By: **CPK**

7) Relinquished By: **CPK**

9) Seal/Locked By: **CPK**

11) Seal/Locked By: **CPK**

12) Seal/Locked By: **CPK**

13) Seal/Locked By: **CPK**

14) Seal/Locked By: **CPK**

15) Seal/Locked By: **CPK**

16) Seal/Locked By: **CPK**

17) Seal/Locked By: **CPK**

18) Seal/Locked By: **CPK**

19) Seal/Locked By: **CPK**

20) Seal/Locked By: **CPK**

2) Accepted By: **CPK** Date/Time: **2-28-13**

4) Accepted By: **CPK** Date/Time: **2-28-13**

6) Accepted By: **CPK** Date/Time: **2-28-13**

8) Accepted By: **CPK** Date/Time: **2-28-13**

10) Seal/Locked By: **CPK** Date/Time: **2-28-13**

12) Seal/Locked By: **CPK** Date/Time: **2-28-13**

14) Seal/Locked By: **CPK** Date/Time: **2-28-13**

16) Seal/Locked By: **CPK** Date/Time: **2-28-13**

18) Seal/Locked By: **CPK** Date/Time: **2-28-13**

20) Seal/Locked By: **CPK** Date/Time: **2-28-13**

* B, Mn by TRM/ICP As, Cr, Cu, Ni, Se, Ag, Zn by TRM/IMS 1**=No Hg ** travis.thornton@siemens.com

19) Page 1 of 2
 DISTRIBUTION
 ORIGINAL to LAB,
 COPY to CLIENT

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

1.8

22) Requested Turnaround

14 Days

*7 Days

*48 Hr

*Other: **3-14-13**

*Add. Cost Will Apply

Please indicate desired turnaround.

Customer, IMPORTANT!

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)

Se, Speciation - Vendor to bottle back into both baggies)



Duke Energy Analytical Laboratory

Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd
Huntersville, N. C. 28078
(704) 875-5245
Fax: (704) 875-4349

1) Project Name Belews - FGD WWTS Bi-Monthly Sampling)	2) Phone No:
2) Client: Bill Kennedy, Melonie Martin, Wayne Chapman, Travis Thornton **	4) Fax No:
5) Business Unit:	6) Process: Mail Code:
8) Oper. Unit:	9) Res. Type: 10) Reso. Center:

Analytical Laboratory Use Only	
ORDER# J13020369	MATRIX: OTHER
Logged By cpk	Date & Time 2-28-13 1003
AS&C PO#133241	Cooler Temp (C) 1.8
Preserv.: 1=HCL 2=H ₂ SO ₄ 3=HNO ₃ 4=Ice 5=None	

Page 1 of 2
Page 16 of 16
DISTRIBUTION
ORIGINAL to LAB,
COPY to CLIENT

LAB USE ONLY
¹¹ Lab ID 2013004289
90
91
92
93
94
95

Se Speciation Bottle		Sampling conducted: 2nd and 4th Wednesday			¹⁶ Analyses Required	¹⁷ Comp.	¹⁸ Grab	TDS	Br (Dionex)	Metals* + Hg**	Mn (ICP) Se (IMS), sol	Se, speciation - vendor to AS&C (important to place filled bottle back into both baggies)
ID	¹³ Sample Description or ID	Date	Time	Signature								
	FGD Purge Eff	2/27/13	7:30am	TO				1	1	1		1
	EQ Tank Eff.									1	1	
	BioReactor 1 Inf									1**	1	1
	BioReactor 2 Inf									1**		
	BioReactor 2 Eff								1	1		1
	Filter Blk										1	
	Metals Trip Blk	2/27/13	730am	TO						1**		1
Filtering of the Se is performed in the field please provide a filter blank too.												
								1	264			4

1) Relinquished By TO	Date/Time 2/27/13	2) Accepted By cpk	Date/Time 2-28-13
3) Relinquished By	Date/Time	4) Accepted By	Date/Time
5) Relinquished By	Date/Time	6) Accepted By:	Date/Time
7) Relinquished By cpk	Date/Time 2-28-13	8) Accepted By:	Date/Time
9) Seal/Locked By cpk	Date/Time 2-28-13	10) Seal/Lock Opened By	Date/Time
11) Seal/Locked By	Date/Time	12) Seal/Lock Opened By	Date/Time

Comments
* B, Mn by TRM/ICP As, Cr, Cu, Ni, Se, Ag, Zn by TRM/IMS 1**=No Hg ** travis.thornton@siemens.com

Customer, IMPORTANT!
Please indicate desired turnaround.

²² Requested Turnaround
14 Days _____
*7 Days _____
*48 Hr _____
*Other 3-14-13
* Add. Cost Will Apply