

Analytical Laboratory

13339 Hagers Ferry Road Huntersville, NC 28078-7929 McGuire Nuclear Complex - MG03A2 Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number:	J13050469				
Project Name:	WWTS FGD-Routine 2013				
Customer Name(s):	Bill Kennedy, Wayne Chap	man, Melonie Martin			
Customer Address:	3195 Pine Hall Rd				
0.00.00.00.00.00.00.00.00.00.00.00.00.0	Mailcode: Belews Steam S	tation			
	Belews Creek, NC 28012				
Lab Contact:	Jason C Perkins	Phone:	980-875-5348		
Report Authorized By: (Signature)		Dat	e:	6/27/2013	
(Oignature)	Jason C Perkins				

Program Comments:

Please contact the Program Manager (Jason C Perkins) with any questions regarding this report.

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with a Qualifier indicate a deviation from the method quality system or quality control requirement. The qualifier description is found at the end of the Certificate of Analysis (sample results) under the qualifiers heading. All results are reported on a dry weight basis unless otherwise noted. Subcontracted data included on the Duke Certificate of Analysis is to be used as information only. Certified vendor results can be found in the subcontracted lab final report. Duke Energy Analytical Laboratory subcontracts analyses to other vendor laboratories that have been qualified by Duke Energy to perform these analyses except where noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications: North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

Page 2 of 16

Sample ID	Plant/Station	Collection Date and Time	Collected By	Sample Description
2013012126	BELEWS	28-May-13 7:30 AM	TRAVIS THORNTON	FGD Purge Eff
2013012127	BELEWS	28-May-13 7:35 AM	TRAVIS THORNTON	EQ Tank Eff
2013012128	BELEWS	28-May-13 7:40 AM	TRAVIS THORNTON	BioReactor 1 Inf
2013012129	BELEWS	28-May-13 7:45 AM	TRAVIS THORNTON	BioReactor 2 Inf
2013012130	BELEWS	28-May-13 7:50 AM	TRAVIS THORNTON	BioReactor 2 Eff
2013012131	BELEWS	28-May-13 8:10 AM	TRAVIS THORNTON	Filter Blk
2013012132	BELEWS	21-May-13 10:30 AM	CPK	TRIP BLANK
7 Total Samples				

Technical Validation Review

Checklist:

COC and .pdf report are in agreement with sample totals and analyses (compliance programs and procedures).

All Results are less than the laboratory reporting limits. □ Yes ✓ No

All laboratory QA/QC requirements are acceptable. ✓ Yes □ No

Report Sections Included:

Reviewed By:

DBA Account

✓ Job Summary Report	✓ Sub-contracted Laboratory Results
✓ Sample Identification	☐ Customer Specific Data Sheets, Reports, & Documentation
✓ Technical Validation of Data Package	☐ Customer Database Entries
✓ Analytical Laboratory Certificate of Analysis	✓ Chain of Custody
☐ Analytical Laboratory QC Report	✓ Electronic Data Deliverable (EDD) Sent Separately

Date:

6/27/2013

 $V_AS&C$

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J13050469

Site: FGD Purge Eff Sample #: 2013012126

Collection Date: 28-May-13 7:30 AM Matrix: OTHER

Analyte	Result	Units Q	ualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
NITRITE + NITRATE (COLORIMETR	IC)						•	•
Nitrite + Nitrate (Colorimetric)	14	mg-N/L		0.1	10	EPA 353.2	06/03/2013 12:02	BGN9034
INORGANIC IONS BY IC								
Bromide	110	mg/L		5	50	EPA 300.0	06/03/2013 15:55	JAHERMA
MERCURY (COLD VAPOR) IN WATI	<u>ER</u>							
Mercury (Hg)	248	ug/L		5	100	EPA 245.1	05/31/2013 12:47	AGIBBS
TOTAL RECOVERABLE METALS B	Y ICP							
Boron (B)	224	mg/L		0.5	10	EPA 200.7	06/07/2013 11:54	DJSULL1
DISSOLVED METALS BY ICP-MS								
Selenium (Se)	130	ug/L		10	10	EPA 200.8	06/12/2013 11:24	KRICHAR
TOTAL RECOVERABLE METALS B	Y ICP-MS							
Arsenic (As)	249	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Cadmium (Cd)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Chromium (Cr)	261	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Copper (Cu)	128	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Nickel (Ni)	227	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Selenium (Se)	3410	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
Zinc (Zn)	275	ug/L		10	10	EPA 200.8	06/12/2013 13:47	KRICHAR
SELENIUM SPECIATION - (Analysis	Performed	by Applied Sp	eciation and	d Cons	ulting, LLC)	1		

Vendor Parameter Complete Vendor Method

Site: EQ Tank Eff Sample #: 2013012127

Collection Date: 28-May-13 7:35 AM Matrix: OTHER

Analyte	Result	Units Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
MERCURY (COLD VAPOR) IN WAT	<u>ER</u>						
Mercury (Hg)	179	ug/L	2.5	50	EPA 245.1	05/31/2013 12:50	AGIBBS
TOTAL RECOVERABLE METALS B	Y ICP						
Boron (B)	226	mg/L	0.5	10	EPA 200.7	06/07/2013 11:58	DJSULL1
DISSOLVED METALS BY ICP-MS							
Selenium (Se)	73.0	ug/L	10	10	EPA 200.8	06/12/2013 11:27	KRICHAR

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J13050469

Site: EQ Tank Eff Sample #: 2013012127

Collection Date: 28-May-13 7:35 AM Matrix: OTHER

Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
(ICP-MS							
171	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
220	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
102	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
212	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
2420	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
218	ug/L		10	10	EPA 200.8	06/12/2013 13:50	KRICHAR
	171 <10 220 102 212 2420 <10	171 ug/L < 10 ug/L 220 ug/L 102 ug/L 212 ug/L 2420 ug/L < 10 ug/L	171 ug/L <10 ug/L 220 ug/L 102 ug/L 212 ug/L 2420 ug/L <10 ug/L	171 ug/L 10 < 10	171 ug/L 10 10 < 10	(ICP-MS 171 ug/L 10 10 EPA 200.8 < 10	(ICP-MS 171 ug/L 10 10 EPA 200.8 06/12/2013 13:50 < 10

Site: BioReactor 1 Inf Sample #: 2013012128

Collection Date: 28-May-13 7:40 AM Matrix: OTHER

SELENIUM SPECIATION - (Analysis Performed by Applied Speciation and Consulting, LLC)

Complete

Vendor Parameter

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
NITRITE + NITRATE (COLORIMET	RIC)							
Nitrite + Nitrate (Colorimetric)	17	mg-N/L		0.1	10	EPA 353.2	06/03/2013 12:03	BGN9034
Mercury by EPA 200.8 - (Analysis	Performed by A	Applied Sp	eciation and	Consultin	a. LLC)			
Vendor Parameter	Complete	ug/l			<u> </u>	Vendor Method		V_AS&C
TOTAL RECOVERABLE METALS	BY ICP							
Boron (B)	207	mg/L		0.5	10	EPA 200.7	06/07/2013 12:01	DJSULL1
DISSOLVED METALS BY ICP-MS								
Selenium (Se)	78.9	ug/L		10	10	EPA 200.8	06/12/2013 11:30	KRICHAR
TOTAL RECOVERABLE METALS	BY ICP-MS							
Arsenic (As)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Cadmium (Cd)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Chromium (Cr)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Copper (Cu)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Nickel (Ni)	15.7	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Selenium (Se)	80.9	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR
Zinc (Zn)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:54	KRICHAR

Vendor Method

V_AS&C

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J13050469

Site: BioReactor 2 Inf Sample #: 2013012129

Collection Date: 28-May-13 7:45 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
Mercury by EPA 200.8 - (Analysis	Performed by A	pplied Sp	eciation and	Consult	ing, LLC)			
Vendor Parameter	Complete	ug/l				Vendor Method		V_AS&C
TOTAL RECOVERABLE METALS	BY ICP							
Boron (B)	200	mg/L		0.5	10	EPA 200.7	06/07/2013 12:05	DJSULL1
TOTAL RECOVERABLE METALS	BY ICP-MS							
Arsenic (As)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Cadmium (Cd)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Chromium (Cr)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Copper (Cu)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Nickel (Ni)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Selenium (Se)	12.8	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Silver (Ag)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR
Zinc (Zn)	< 10	ug/L		10	10	EPA 200.8	06/12/2013 13:57	KRICHAR

Site: BioReactor 2 Eff Sample #: 2013012130

Collection Date: 28-May-13 7:50 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
NITRITE + NITRATE (COLORIMET	RIC)							
Nitrite + Nitrate (Colorimetric)	< 0.01	mg-N/L		0.01	1	EPA 353.2	06/03/2013 12:04	BGN9034
INORGANIC IONS BY IC								
Bromide	100	mg/L		5	50	EPA 300.0	06/03/2013 16:14	JAHERMA
Mercury by EPA 200.8 - (Analysis	Performed by I	Applied Sp	eciation and	Consulti	ng, LLC)			
Vendor Parameter	Complete	ug/l				Vendor Method		V_AS&C
TOTAL RECOVERABLE METALS	BY ICP							
Boron (B)	203	mg/L		0.5	10	EPA 200.7	06/07/2013 12:08	DJSULL1
TOTAL RECOVERABLE METALS	BY ICP-MS							
Arsenic (As)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Cadmium (Cd)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Chromium (Cr)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Copper (Cu)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Nickel (Ni)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Selenium (Se)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Silver (Ag)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR
Zinc (Zn)	< 5	ug/L		5	5	EPA 200.8	06/12/2013 14:01	KRICHAR

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J13050469

Site: BioReactor 2 Eff Sample #: 2013012130

Collection Date: 28-May-13 7:50 AM Matrix: OTHER

Analyte Result Units Qualifiers RDL DF Method Analysis Date/Time Analyst

SELENIUM SPECIATION - (Analysis Performed by Applied Speciation and Consulting, LLC)

Vendor Parameter Complete Vendor Method V_AS&C

TOTAL DISSOLVED SOLIDS

TDS **17000** mg/L 25 1 SM2540C 06/03/2013 15:03 JDTALLE

Site: Filter Blk Sample #: 2013012131

Collection Date: 28-May-13 8:10 AM Matrix: OTHER

Analyte Result Units Qualifiers RDL DF Method Analysis Date/Time Analyst DISSOLVED METALS BY ICP-MS

Selenium (Se) <1 ug/L 1 1 EPA 200.8 06/12/2013 10:38 KRICHAR

Site: TRIP BLANK Sample #: 2013012132

Collection Date: 21-May-13 10:30 AM Matrix: OTHER

Analyte	Result	Units	Qualifiers	RDL	DF	Method	Analysis Date/Time	Analyst
TOTAL RECOVERABLE METALS BY	ICP							
Boron (B)	< 0.05	mg/L		0.05	1	EPA 200.7	06/07/2013 11:47	DJSULL1
TOTAL RECOVERABLE METALS BY	ICP-MS							
Arsenic (As)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Cadmium (Cd)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Chromium (Cr)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Copper (Cu)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Nickel (Ni)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Selenium (Se)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Silver (Ag)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR
Zinc (Zn)	< 1	ug/L		1	1	EPA 200.8	06/12/2013 13:40	KRICHAR



18804 Northcreek Parkway Bothell, WA, 98011
Tel: (425) 483-3300 Fax: (425) 483-9818
www.appliedspeciation.com

June 11, 2013

Jay Perkins Duke Energy Analytical Laboratory Mail Code MGO3A2 (Building 7405) 13339 Hagers Ferry Rd. Huntersville, NC 28078 (704) 875-5245

Project: Belews - FGD WWTS (Bi-Monthly Routine 2013) (LIMS #J13050469)

Mr. Perkins,

Attached is the report associated with four (4) aqueous samples submitted for total mercury and selenium speciation analysis on May 30, 2013. The samples were received in a sealed cooler at -0.3°C on May 31, 2013. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS). Mercury quantitation was performed via cold vapor inductively coupled plasma mass spectrometry (CV-ICP-MS). Any issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078

Project: Belews - FGD WWTS (Bi-Monthly Routine 2013) (LIMS #J13050469)

June 11 2013

1. Sample Reception

Three (3) aqueous samples in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on May 30, 2013. Three (3) additional samples in 40ml borosilicate glass bottles (provided by Applied Speciation and Consulting) were submitted for total mercury quantitation. All samples were received in acceptable condition on May 31, 2013 in a sealed container at -0.3°C.

All samples were received in a laminar flow clean hood, void of trace metals contamination and ultra-violet radiation, and were designated discrete sample identifiers. The 40mL borosilicate glass vials submitted for total mercury were preserved with bromine monochloride (BrCl) solution. The resulting samples were stored in a secure polyethylene container, known to be free from trace metals contamination, until the analyses could be performed.

An aliquot of each sample requiring selenium speciation evaluation was filtered ($0.45\mu m$) and each filtrate was stored in a secure, monitored cryofreezer (maintained at a temperature of -80°C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

<u>Total Mercury Quantitation by CV-ICP-MS</u> All samples and preparation blanks for total mercury quantitation were preserved with 2% (v/v) BrCl. The resulting samples were analyzed for mercury via cold vapor inductively coupled plasma mass spectrometry (CV-ICP-MS).

<u>Selenium Speciation Analysis by IC-ICP-CRC-MS</u> Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm) and injected directly into a sealed autosampler vial. No further sample preparation was performed as any chemical alteration of a sample may shift the equilibrium of the system, resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is preceded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of each analytical day. All calibration curves, associated with each species of interest, are standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimum interval of every ten analytical runs.

<u>Total Mercury Quantitation by CV-ICP-MS</u> The sample fractions for total mercury quantitation were analyzed by cold vapor inductively coupled plasma mass spectrometry (CV-ICP-MS) on May 31, 2013. Aliquots of each sample are reacted with a reductant in-line and transported to a gas-liquid separator. The volatile elemental mercury that is formed is then swept by a stream of argon gas into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and separated on the basis of their mass-to-charge ratio (m/z) by a mass spectrometer. A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

<u>Selenium Speciation Analysis by IC-ICP-CRC-MS</u> Each sample for selenium speciation analysis was analyzed by ion chromatography inductively coupled plasma collision reaction cell mass spectrometry (IC-ICP-CRC-MS) on June 7, 2013. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic (pH > 7) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (CRC) containing a reaction gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went well and no significant analytical issues were encountered. All quality control parameters associated with these samples were within acceptance limits.

A miscommunication between the ion chromatography unit and the eluent pump caused a delay in the eluent gradient during the analysis of the matrix spike duplicate performed on the sample identified as batch QC. Consequently the retention time for the selenocyanate peak in the matrix spike duplicate sample was shifted to a larger value (from approximately 10.2 minutes to 11.6 minutes). This shift was confirmed by measurement of an internal standard (roxarsone), which typically falls within the same late eluting retention time range. The roxarsone peak experienced a similar retention time shift due to the delay in the eluent gradient. The selenocyanate peak occurring at 11.6 minutes in the matrix spike sample was integrated and the value produced an acceptable selenocyanate recovery.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

The eMDL for mercury has been calculated using the standard deviation of the preparation blanks preserved and analyzed concurrently with the submitted samples.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

Russell Gerads Vice President

Applied Speciation and Consulting, LLC

Total Mercury & Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS (Bi-Monthly Routine 2013) Contact: Jay Perkins LIMS #J13050469

> Date: June 11, 2013 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Sample Results

Sample ID	Total Hg	Se(IV)	Se(VI)	SeCN	MeSe(IV)	SeMe	Unknown Se Species (n)
FGD Purge Eff	NR	92.9	58.2	ND (< 5.0)	ND (< 5.6)	ND (< 5.6)	0 (0)
BioReactor 1 Inf	0.101	28.2	52.7	ND (< 1.2)	ND (< 1.4)	ND (< 1.4)	0 (0)
BioReactor 2 Inf	0.0156	NR	NR	NR	NR	NR	NR
BioReactor 2 Eff	0.0045	ND (< 1.3)	ND (< 1.6)	ND (< 1.2)	ND (< 1.4)	ND (< 1.4)	0 (0)

All results reflect the applied dilution and are reported in µg/L

NR = Analysis not requested

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

n = number of unknown Se species observed

Total Mercury & Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS (Bi-Monthly Routine 2013) Contact: Jay Perkins

LIMS #J13050469

Date: June 11, 2013 Report Generated by: Russell Gerads Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

Analyte (µg/L)	PBW1	PBW2	PBW3	PBW4	Mean	StdDev	eMDL*	eMDL 5x	eMDL 250x	eMDL 1000x
Hg	0.0007	0.0016	0.0016	0.0016	0.0014	0.0005	0.0003	0.0014	-	-
Se(IV)	0.000	0.000	0.144	0.000	0.036	0.072	0.005	-	1.3	5.4
Se(VI)	0.000	0.000	0.000	0.000	0.000	0.000	0.006	-	1.6	6.4
SeCN	0.000	0.000	0.000	0.000	0.000	0.000	0.005	-	1.2	5.0
MeSe(IV)	0.000	0.000	0.000	0.000	0.000	0.000	0.006	-	1.4	5.6
SeMe	0.000	0.000	0.049	0.000	0.012	0.024	0.006	-	1.4	5.6

eMDL = Estimated Method Detection Limit

Quality Control Summary - Certified Reference Materials

Analyte (µg/L)	CRM	True Value	Result	Recovery
Hg	NIST 1641d	1568	1580	100.8
Se(IV)	LCS	4.79	5.23	109.2
Se(VI)	LCS	4.74	4.87	102.8
SeCN	LCS	4.46	4.75	106.6
MeSe(IV)	LCS	3.24	3.37	104.1
SeMe	LCS	4.66	4.56	97.9

^{*}Please see narrative regarding eMDL calculations

Total Mercury & Selenium Speciation Results for Duke Energy Project Name: Belews - FGD WWTS (Bi-Monthly Routine 2013) Contact: Jay Perkins LIMS #J13050469

Date: June 11, 2013
Report Generated by: Russell Gerads
Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

Analyte (µg/L)	Sample ID	Rep 1	Rep 2	Mean	RPD
Hg	Batch QC	0.0682	0.0671	0.0677	1.6
Se(IV)	Batch QC	ND (< 1.3)	ND (< 1.3)	NC	NC
Se(VI)	Batch QC	ND (< 1.6)	ND (< 1.6)	NC	NC
SeCN	Batch QC	ND (< 1.2)	ND (< 1.2)	NC	NC
MeSe(IV)	Batch QC	ND (< 1.4)	ND (< 1.4)	NC	NC
SeMe	Batch QC	ND (< 1.4)	ND (< 1.4)	NC	NC

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

Analyte (µg/L)	Sample ID	Spike Conc	MS Result	Recovery	Spike Conc	MSD Result	Recovery	RPD
Hg	Batch QC	2.000	2.159	104.6	2.000	2.169	105.1	0.4
Se(IV)	Batch QC	1390	1535	110.4	1390	1530	110.1	0.3
Se(VI)	Batch QC	1261	1377	109.2	1261	1358	107.7	1.4
SeCN *	Batch QC	1144	1232	107.7	1144	1222	106.9	0.8

^{*} Please see narrative regarding MSD selenocyanate result.

		CHAIN OF CUSTO	JDY REC	ORD A	ND A	DY RECORD AND ANALYSIS F	REQUEST FORM	ST	ORA	_		0	Whos is	5
		Duke Energy Analytical Laboratory	Laboratory			Analytical Laboratory Use Only	aboratory	Use Or	À			30	2	_
DUKE	ZE SE	Mail Code MG03A2 (Building 7405) 13339 Hagers Ferry Rd	ling 7405) Rd	CLARER W	0808	OUBS MATRIX. OTHER	THER	Samples Originati From	Samples Originating From	NC		DISTR	Page 1 of 2 DISTRIBUTION	
	IEKGY.	(704) 875-5245 Fax: (704) 875-4349	9/00	Logged By	-0	Date & Time 9-13	093	~	SAMPLE PROGRAM Water	GRAM	CAM Ground NPDES	COPY t	COPY to CLIENT	
1)Project Name	Belews WWTS (Bi-Month)	WWTS (Bi-Monthly Routine 2013)	» No:	Vendol A	AS&C		3		Pr RCRA Waste	Drinking UST Naste	ig Water	V ₂		
2) Client:	Bill Kennedy Wayne	Bill Kennedy, Melonie Martin, Wayne Chapman	ö	l Vendor:		18 Pres 2=4,50	5 5 4	_ ^				A		
5)Business Unit:	20003	6)Process: BMCEFGD	Mail Code:	MR#		4=ICE	Sa	4		3,4 2,4				T
Cuato	BC00	9)Res. Type:	10)Reso. Center:	Cus	tomer to	Customer to complete all appropriate non-shaded areas.	Required		**1.345 g	iltered	(088A_	On - vendor t	polh baggies	
LAB USE ONLY				Sampling	conducted:	Sampling conducted: 2nd and 4th Wednesday			H + :	20	V) 8.		ak into	
"Lab ID	Se Speciation Bottle	13 Sample Description or ID	tion or ID	Date	Time	Signature	Comp.	SQT		N-80V	007 BL		bolile ba	
0/80/2126		FGD Purge E	Eff	5/28/13	0730	The Shit			-			-		
77		EQ Tank Eff	Eff.		0935		せ	-	+	+-				T
2 7		BioReactor 11	Inf		24/10		2		1**	-		-		
ol sur								-						
S COUNT	STATE OF THE PARTY	BioReactor 2	2 Inf	-	346	Statement of the State of the S	iv		*	l)	-			
X Ox		Crotocodoia) C#		N) P.4	TOTAL PROPERTY.	r					+		
Sporo		חוסטפמרוסו			001			-	*	-	_	-		
W		Filter Blk			210		-	+	+	-				T
) M		Metals Trip BI	SIK	5-21	æal	Longo	ч		1**					
net i					-	() Filtering	Filtering of the Se is performed in the field please provide a filter blank too	nformed	n the field	please pr	ovide a filt	er blank to	0.	
otsuO									3	7	_	n		
	Customer to sign & dai	te below - fill out from left to right.							Retu	Return Kit to	Travis		Thorton @ Belews	WS
1) Rejunquished By	note	Date/Time 5/28/13	15.30	2) Accepted By	g	5.30	-/ Spate/Time	ne		,b	22Re	quested	22Requested Turnaround	P
3) Refinquished By		Date/Пля		4) Accepted By	٠	/> 5.00	7 1 Date Time	30	en		21	21 Days		
5)Relinquished By		Date/Time	10	6)Accepted By	3)		, , ,	2,2		1	7 Davs		Page
7)Relinquished By	2	S - SO-13	े हैं -	8)Accepted By:			Date/Time	8		MPOR	4	-48 Hr		15 of
9) Sealft, ocked By /		S - 3 Date/Time / 3	9	10) Seal/Lock Opened By	ened By		Date/Time	De			0.	Other Cost Will Apply	N	16
11)Seal/Locked BY		Date/Time	12	12)Seal/Lock Opened By	ened By		Date(Time	ae Be				Aud. coor	riddy IIIA	
Comments * B	* B by TRM/ICP	As, Cd, Cr, Cu, Ni, Se, Ag,	g, Zn by TRM/IMS		1**=No Hg					Pleas				7

- DI	IVE	Duke Energy Anal	lytical Laboratory	ORD	ER#		Analytical L	abor			Only	1				19,	Page P	age 16 of				
DUKE ENERGY.		13339 Hage Huntersville, (704) 87 Fax: (704)	rs Ferry Rd N. C. 28078 75-5245	Cogged By Date & Time								mating SC AMPLE PROGRAM Ground					DISTRIBUTION ORIGINAL to LAB, COPY to CLIENT					
1)Project Name 2) Client:		ews - FGD nthly Routine 2013)	2)Phone No:	Vend	AS&C			S/soler T			Water		A Wa	(NPDES king Water JST							
		y, Melonie Martin, e Chapman	4)Fax No:	IVend	lor:		¹⁵ Pre 2=H ₂ S	serv.:1	=HCL													
5)Business Unit:	20003	6)Process: BMCEFGD	Mail Code:	MR#			4=10	e 5=l	m 1	4		4 3,4	1 3,4	2,4			4					
8)Oper. Unit:	BC00	9)Res. Type:	10)Reso. Center:		Custome propriate		aplete all	16 A malina	Required			9 245,1**	filtered		AS&C)	On - vendor to	AS&C (Important to place filled bottle back into both baggies)					
LAB USE ONLY	Se Speciation Bot			San	npling conduc	ed: 2nd an	d 4th Wednesday		qe		Br (Dionex)	als* + Hg	100	NO3-NO2	200.8 (V	speciation	(Importar e back into					
"Lab ID	ID		escription or ID	Da			Signature	17Comp.	18 Grab	TDS	Br (C	Metals*	Se	NO3	Hg 2	Se	AS&C					
012129			Purge Eff	5/2	8/13 0730		isthet	7			1	1	1	1		1						
	5		Tank Eff. actor 1 Inf	803	0735	5		14				1	1									
		Diorres	actor 1 mi		0741	/		6				1**	1	1	1	1						
		BioRea	actor 2 Inf		0743			3				1**			1							
		BioRea	actor 2 Eff	1/	0750	j		7		1	1	1**		1	1	1						
9		Filt	er Blk		0810			1		+				4								
		Metals	s Trip Blk	5-3	21 1030		bnox	2		1		1**	1									
						V	Filtering	of the S	Se is p	erform	ed in th	e fiel	d plea	ase p	rovide a filt		too.					
Ö	Customer to sign & da	ite below - fill out from left to rig							1	11	2	Retu	y.	Sit t	o Travis	Thor	ton @) Belews				
1) Relinquished By You's	nombe	Date/Time		2) Accepted	rob		5-29	-13	-hydrodentes					nd.	1 -			naround				
5)Relinquished By		Date/Time.		6)Accepted					Date/Ti				ANT	turnarou		Days _						
7)Relinquished By 9)Seal/Locked By	k,	5 - 30 Date/Time	/3	8)Accepted	Ву:			ı	Date/Tir	ne			MPORT	desired turnard		Days 8 Hr						
CP	6	5 - 3 Date/Time	13	10) Seal/Loc	k Opened By			· · · · · ·	Date/Tir	ne			ner, I	ate de	*01	6- her_	12-	-/3				
11)Seal/Locked By		Date/Time		12)Seal/Loc	k Opened By			C)ate/Tin	ne			stor	Please indicate of	*	Add. Co:	st Will A	pply				