



Analytical Laboratory

13339 Hagers Ferry Road
Huntersville, NC 28078-7929
McGuire Nuclear Complex - MG03A2
Phone: 980-875-5245 Fax: 980-875-4349

Order Summary Report

Order Number: J10090181

Customer Name(s): Don Scruggs, Robbin Jolly, Ray Lidke, Bill Kennedy

Customer Address: 253 Plant Allen Rd.
Mail Code: ASS01
Belmont, NC 28012

Lab Contact: Jason C Perkins **Phone:** 704-875-5348

Report Authorized By: _____ **Date:** 10/21/2010
(Signature)

Program Comments:

Allen Test Burn #1: Se Speciation

Sampled: 10/8

Data Flags & Calculations:

Any analytical tests or individual analytes within a test flagged with an "X" or "1" indicate a deviation from the method quality system or quality control requirement. All results are reported on a dry weight basis unless otherwise noted.

Data Package:

This data package includes analytical results that are applicable only to the samples described in this narrative. An estimation of the uncertainty of measurement for the results in the report is available upon request. This report shall not be reproduced, except in full, without the written consent of the Analytical Laboratory. Please contact the Analytical laboratory with any questions. The order of individual sections within this report is as follows:

Job Summary Report, Sample Identification, Technical Validation of Data Package, Analytical Laboratory Certificate of Analysis, Analytical Laboratory QC Reports, Sub-contracted Laboratory Results, Customer Specific Data Sheets, Reports & Documentation, Customer Database Entries, Test Case Narratives, Chain of Custody (COC)

Certification:

The Analytical Laboratory holds the following State Certifications : North Carolina (DENR) Certificate #248, South Carolina (DHEC) Laboratory ID # 99005. Contact the Analytical Laboratory for definitive information about the certification status of specific methods.

Sample ID's & Descriptions:

| Sample ID | Plant/Station | Collection Date and Time | Collected By | Sample Description |
|-----------------|---------------|-----------------------------|--------------|--------------------|
| 2010008548 | ALLEN | 08-Oct-10 10:18 AM | Jeff Womack | FGD Purge Eff |
| 2010008549 | ALLEN | 08-Oct-10 9:51 AM | Jeremy D. | BioReactor 1 Inf |
| 2010008550 | ALLEN | 08-Oct-10 9:42 AM | Jeremy D. | BioReactor 2 Eff |
| 2010008551 | ALLEN | 30-Sep-10 1:45 PM | L. Davis | Metals Trip Blank |
| 4 Total Samples | | | | |

Technical Validation Review

Checklist:

COC and .pdf report are in agreement with sample totals and analyses (compliance programs and procedures).

☒ Yes

☐ No

All Results are less than the laboratory reporting limits.

☐ Yes

☒ No

All laboratory QA/QC requirements are acceptable.

☒ Yes

☐ No

The Vendor Laboratories have been qualified by the Analytical Laboratory

Yes

Report Sections Included:

☒ Job Summary Report

☒ Sample Identification

☒ Technical Validation of Data Package

☒ Analytical Laboratory Certificate of Analysis

☐ Analytical Laboratory QC Report

☒ Sub-contracted Laboratory Results

☐ Customer Specific Data Sheets, Reports, & Documentation

☐ Customer Database Entries

☐ Test Case Narratives

☒ Chain of Custody

☐ Electronic Data Deliverable (EDD) Sent Separately

Reviewed By: Jenny A Herman

Date: 10/21/2010

Certificate of Laboratory Analysis

This report shall not be reproduced, except in full.

Order # J10090181

Site: FGD Purge Eff

Collection Date: 08-Oct-10 10:18 AM

Sample #: 2010008548

Matrix: OTHER

| Analyte | Result | Units | Qualifiers | RDL | Method | Analysis Date/Time | Analyst |
|----------------------------|----------|-------|------------|-----|--------|--------------------|---------|
| SELENIUM SPECIATION | | | | | | | |
| Vendor Parameter | Complete | | | | V_AS&C | | |

Site: BioReactor 1 Inf

Collection Date: 08-Oct-10 9:51 AM

Sample #: 2010008549

Matrix: OTHER

| Analyte | Result | Units | Qualifiers | RDL | Method | Analysis Date/Time | Analyst |
|----------------------------|----------|-------|------------|-----|--------|--------------------|---------|
| SELENIUM SPECIATION | | | | | | | |
| Vendor Parameter | Complete | | | | V_AS&C | | |

Site: BioReactor 2 Eff

Collection Date: 08-Oct-10 9:42 AM

Sample #: 2010008550

Matrix: OTHER

| Analyte | Result | Units | Qualifiers | RDL | Method | Analysis Date/Time | Analyst |
|----------------------------|----------|-------|------------|-----|--------|--------------------|---------|
| SELENIUM SPECIATION | | | | | | | |
| Vendor Parameter | Complete | | | | V_AS&C | | |

Site: Metals Trip Blank

Collection Date: 30-Sep-10 1:45 PM

Sample #: 2010008551

Matrix: OTHER

| Analyte | Result | Units | Qualifiers | RDL | Method | Analysis Date/Time | Analyst |
|----------------------------|----------|-------|------------|-----|--------|--------------------|---------|
| SELENIUM SPECIATION | | | | | | | |
| Vendor Parameter | Complete | | | | V_AS&C | | |



October 17, 2010

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078
(704) 875-5245

Project: Allen – FGD Alternate Fuels Test Burn #1 - Se (LIMS # J10090181)

Dear Mr. Perkins,

Attached is the report associated with three (3) aqueous samples and one associated blank submitted for selenium speciation analysis on October 12, 2010. The samples were received on October 13, 2010 in a sealed cooler at 0.2°C. Selenium speciation analysis was performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS). Any analytical issues associated with the analysis are addressed in the following report.

If you have any questions, please feel free to contact me at your convenience.

Sincerely,

A handwritten signature in black ink, appearing to read "Russell Gerads".

Russell Gerads
Vice President
Applied Speciation and Consulting, LLC

Applied Speciation and Consulting, LLC

Report prepared for:

Jay Perkins
Duke Energy Analytical Laboratory
Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd.
Huntersville, NC 28078

Project: Allen – FGD Alternate Fuels Test Burn #1 - Se (LIMS # J10090181)

October 17, 2010

1. Sample Reception

Three (3) aqueous samples and one associated blank in 125mL HDPE bottles (provided by Applied Speciation and Consulting) were submitted for selenium speciation analysis on October 12, 2010. The samples were received on October 13, 2010 in a sealed container at 0.2°C.

The samples were received in a laminar flow clean hood void of trace metals contamination and ultra-violet radiation. Upon reception, the samples were designated discrete sample identifiers. An aliquot of each sample was filtered (0.45µm) and these filtrates were stored in a secure, monitored cryofreezer (maintained at a temperature of -80°C) until selenium speciation analysis could be performed via ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS).

2. Sample Preparation

All sample preparation is performed in laminar flow clean hoods known to be free from trace metals contamination. All applied water for dilutions and sample preservatives are monitored for contamination to account for any biases associated with the sample results.

Selenium Speciation Analysis by IC-ICP-DRC-MS Prior to analysis, an aliquot of each sample was filtered with a syringe filter (0.45µm) and injected directly into a sealed autosampler vial. No further sample preparation was performed as any chemical alteration of the samples may shift the equilibrium of the system resulting in changes in speciation ratios.

3. Sample Analysis

All sample analysis is precluded by a minimum of a five-point calibration curve spanning the entire concentration range of interest. Calibration curves are performed at the beginning of each analytical day. All calibration curves, associated with each species of interest, are standardized by linear regression resulting in a response factor. All sample results are **instrument blank corrected** to account for any operational biases associated with the analytical platform.

Prior to sample analysis, all calibration curves are verified using second source standards which are identified as initial calibration verification standards (ICV).

Ongoing instrument performance is identified by the analysis of continuing calibration verification standards (CCV) and continuing calibration blanks (CCB) at a minimal interval of every ten analytical runs.

Selenium Speciation Analysis by IC-ICP-DRC-MS All samples for selenium speciation analysis were analyzed by ion chromatography inductively coupled plasma dynamic reaction cell mass spectrometry (IC-ICP-DRC-MS) on October 15, 2010. An aliquot of each sample is injected onto an anion exchange column and mobilized by a basic ($\text{pH} > 7$) gradient. The eluting selenium species are then introduced into a radio frequency (RF) plasma where energy-transfer processes cause desolvation, atomization, and ionization. The ions are extracted from the plasma through a differentially-pumped vacuum interface and travel through a pressurized chamber (DRC) containing a specific reactive gas which preferentially reacts with interfering ions of the same target mass to charge ratios (m/z). A solid-state detector detects ions transmitted through the mass analyzer and the resulting current is processed by a data handling system.

Retention times for each eluting species are compared to known standards for species identification.

4. Analytical Issues

The overall analyses went very well and no analytical issues were encountered. All quality control parameters associated with these samples were within acceptance limits.

The estimated method detection limits (eMDLs) for selenite, selenate, and selenocyanate are generated from replicate analyses of the lowest standard in the calibration curve. Not all selenium species are present in preparation blanks; therefore, eMDL calculations based on preparation blanks are artificially biased low.

The eMDL for methylseleninic acid and selenomethionine is calculated from the average eMDL of selenite, selenate, and selenocyanate. The calibration does not

contain methylseleninic acid or selenomethionine due to impurities in these standards which would bias the results for other selenium species.

If you have any questions or concerns regarding this report, please feel free to contact me.

Sincerely,

A handwritten signature in black ink, appearing to read 'Russell Gerads', with a large, sweeping flourish extending to the right.

Russell Gerads
Vice President
Applied Speciation and Consulting, LLC

Selenium Speciation Results for Duke Energy
Project Name: Allen - FGD Alternate Fuels Test Burn #1 - Se
Contact: Jay Perkins
LIMS #J10090181

Date: October 17, 2010
Report Generated by: Russell Gerads
Applied Speciation and Consulting, LLC

Sample Results

| Sample ID | Se(IV) | Se(VI) | SeCN | MeSe(IV) | SeMe | Unknown Se Species (n) |
|------------------|------------|-------------|------------|------------|------------|------------------------|
| FGD Purge Eff | 13.1 | 236 | ND (<3.0) | ND (<2.4) | ND (<2.4) | 0 (0) |
| BioReactor 1 Inf | 5.48 | 574 | ND (<0.75) | ND (<0.60) | ND (<0.60) | 0 (0) |
| BioReactor 2 Eff | 0.92 | ND (<0.42) | ND (<0.75) | ND (<0.60) | ND (<0.60) | 0 (0) |
| Metals Trip Blk | ND (<0.13) | ND (<0.084) | ND (<0.15) | ND (<0.12) | ND (<0.12) | 0 (0) |

All results reflect the applied dilution and are reported in µg/L

ND = Not detected at the applied dilution

SeCN = Selenocyanate

MeSe(IV) = Methylseleninic acid

SeMe = Selenomethionine

Unknown Se Species = Total concentration of all unknown Se species observed by IC-ICP-MS

n = number of unknown Se species observed

Selenium Speciation Results for Duke Energy
 Project Name: Allen - FGD Alternate Fuels Test Burn #1 - Se
 Contact: Jay Perkins
 LIMS #J10090181

Date: October 17, 2010
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Quality Control Summary - Preparation Blank Summary

| Analyte (µg/L) | PBW1 | PBW2 | PBW3 | PBW4 | Mean | StdDev | eMDL* | eMDL 10x | eMDL 50x | eMDL 200x |
|----------------|-------|-------|-------|-------|-------|--------|-------|----------|----------|-----------|
| Se(IV) | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.013 | 0.13 | 0.63 | 2.5 |
| Se(VI) | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.008 | 0.084 | 0.42 | 1.7 |
| SeCN | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.015 | 0.15 | 0.75 | 3.0 |
| MeSe(IV) | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.012 | 0.12 | 0.60 | 2.4 |
| SeMe | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 | 0.012 | 0.12 | 0.60 | 2.4 |

eMDL = Estimated Method Detection Limit

*Please see narrative regarding eMDL calculations

Quality Control Summary - Certified Reference Materials

| Analyte (µg/L) | CRM | True Value | Result | Recovery |
|----------------|-----|------------|--------|----------|
| Se(IV) | ICV | 9.57 | 9.73 | 101.7 |
| Se(VI) | ICV | 9.48 | 9.23 | 97.3 |
| SeCN | ICV | 8.92 | 9.45 | 105.9 |
| MeSe(IV) | ICV | 6.47 | 6.24 | 96.4 |
| SeMe | ICV | 9.32 | 10.01 | 107.4 |

Selenium Speciation Results for Duke Energy
 Project Name: Allen - FGD Alternate Fuels Test Burn #1 - Se
 Contact: Jay Perkins
 LIMS #J10090181

Date: October 17, 2010
 Report Generated by: Russell Gerads
 Applied Speciation and Consulting, LLC

Quality Control Summary - Matrix Duplicates

| Analyte (µg/L) | Sample ID | Rep 1 | Rep 2 | Mean | RPD |
|----------------|-----------|------------|------------|------|-----|
| Se(IV) | Batch QC | ND (<0.63) | 0.86 | NC | NC |
| Se(VI) | Batch QC | ND (<0.42) | ND (<0.42) | NC | NC |
| SeCN | Batch QC | ND (<0.75) | ND (<0.75) | NC | NC |
| MeSe(IV) | Batch QC | ND (<0.60) | ND (<0.60) | NC | NC |
| SeMe | Batch QC | ND (<0.60) | ND (<0.60) | NC | NC |

ND = Not detected at the applied dilution

NC = Value was not calculated due to one or more concentrations below the eMDL

Quality Control Summary - Matrix Spike/ Matrix Spike Duplicate

| Analyte (µg/L) | Sample ID | Spike Conc | MS Result | Recovery | Spike Conc | MSD Result | Recovery | RPD |
|----------------|-----------|------------|-----------|----------|------------|------------|----------|-----|
| Se(IV) | Batch QC | 278.0 | 231.4 | 83.2 | 278.0 | 224.3 | 80.7 | 3.1 |
| Se(VI) | Batch QC | 252.3 | 222.2 | 88.1 | 252.3 | 217.4 | 86.2 | 2.2 |
| SeCN | Batch QC | 228.8 | 200.1 | 87.5 | 228.8 | 200.3 | 87.6 | 0.1 |

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM



Duke Energy Analytical Laboratory
 Mail Code MGO3A2 (Building 7405)
 13339 Hagers Ferry Rd
 Huntersville, N.C. 28078
 (704) 875-5245
 Fax: (704) 875-4349

Customer must Complete

1) Project Name: **Allen - FGD** Alternative Fuels Test Burn # 1 - Se

2) Client: **Don Scruggs, Robbin Jolly, Ray Lidke, Bill Kennedy** 4) Fax No:

5) Business Unit: 6) Process: Mail Code:

8) Oper. Unit: 9) Res. Type: 10) Resp. Center:

LAB USE ONLY

| Lab ID |
|-------------|
| 20100085548 |
| 20100085549 |
| 20100085550 |
| 20100085551 |

Customer to complete appropriate columns to right

| Se Speciation Bottle ID | Sample Description or ID |
|-------------------------|--------------------------|
| BD09410 | FGD Purge Eff |
| BD09410 | BioReactor 1 Inf |
| BD09488 | BioReactor 2 Eff |
| BD05809 | Metals Trip Bk |

Analytical Laboratory Use Only

Order # **J10090181** Matrix: **OTHER**

Logged By: **J. Herman** Date & Time: **9/28/10 17:18**

Vendor: **AS&C** PO# **ISM01-1894**

15) Preserv: 1=HCl, 2=H₂SO₄, 3=HNO₃, 4=Ice, 5=None

16) Analyses Required: **Se, speciation - vendor to AS&C (Important to place filled bottle back into both baggies)**

17) Comp. 18) Grab

Customer to complete all appropriate non-shaded areas.

Sampling conducted: 2nd and 4th Monday

19) Page 1 of 2 DISTRIBUTION ORIGINAL TO LAB, COPY TO CLIENT

Customer to sign & date below - fill out from left to right.

1) Relinquished By: **Paul C. [Signature]** Date/Time: **10/11/10 11:00**

3) Relinquished By: **[Signature]** Date/Time: **10/11/10 16:05**

5) Relinquished By: **[Signature]** Date/Time: **10-13-10 10:30**

7) Relinquished By: **[Signature]** Date/Time: **10-13-10 10:00**

9) Seal/locked By: **[Signature]** Date/Time: **10-13-10 10:00**

11) Seal/locked By: **[Signature]** Date/Time: **10-13-10 10:00**

2) Accepted By: **[Signature]** Date/Time: **10-11-10 11:00**

4) Accepted By: **[Signature]** Date/Time: **10-14-10 10:05**

6) Accepted By: **[Signature]** Date/Time: **10-14-10 10:05**

8) Accepted By: **[Signature]** Date/Time: **10-14-10 10:05**

10) Seal/locked By: **[Signature]** Date/Time: **10/13/10 9:15**

12) Seal/locked By: **[Signature]** Date/Time: **10/13/10 9:15**

Comments: **Metals=As, Ag, B, Cu, Cr, Ni, Se, Zn**

Customer, IMPORTANT! Please indicate desired turnaround.

10-21

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST FORM



Duke Energy Analytical Laboratory

Mail Code MGO3A2 (Building 7405)
13339 Hagers Ferry Rd
Huntersville, N. C. 28078
(704) 875-5245
Fax: (704) 875-4349

Analytical Laboratory Use Only

| | | |
|-------------------------------------------------|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Order # J10090181 | Matrix OTHER | Samples Originating From NC <input type="checkbox"/> SC <input type="checkbox"/> |
| Logged By J. Herman | Date & Time 9/28/10 17:18 | SAMPLE PROGRAM Water <input type="checkbox"/> Ground NPDES <input type="checkbox"/> Drinking Water UST <input type="checkbox"/> RCRA Waste <input type="checkbox"/> |
| Vendor AS&C PO# ISW01.1894 | 17.8 (10/12) Cooler Temp (C) | |

19Page 1 of 2
DISTRIBUTION
ORIGINAL to LAB,
COPY to CLIENT

| | |
|------------------------------------------------------------------------------|------------------|
| 1)Project Name Allen - FGD Alternative Fuels Test Burn # 1 - Se | 2)Phone No: |
| 2) Client: Don Scruggs, Robbin Jolly, Ray Lidke, Bill Kennedy | 4)Fax No: |
| 5)Business Unit: | 6)Process: |
| 8)Oper. Unit: | 10)Resp. Center: |
| 3)Mail Code: | 7)Res. Type: |

| | | | | | |
|---------------------------------------|--------------------------------------------------------|---------------------|---------|--------|-------------------------------------------------------------------------------------------|
| MR # | Customer to complete all appropriate non-shaded areas. | 16Analyses Required | 17Comp. | 18Grab | Se, speciation - vendor to fill (Important to place filled bottle back into both baggies) |
| Sampling conducted 2nd and 4th Monday | | | | | |
| Date | Time | Signature | | | |
| 10/8 | 1018 | SEFFWOMACK | | | 1 |
| 10/8 | 0951 | Tony D... | | | 1 |
| 10/8 | 0942 | Tony D... | | | 1 |
| 9/30 | 1345 | R. Lewis | | | 1 |

| LAB USE ONLY |
|--------------|
| 11Lab ID |
| 2010008548 |
| 2010008549 |
| 2010008550 |
| 2010008551 |

| Se Speciation Bottle ID | 13Sample Description or ID |
|-------------------------|----------------------------|
| BD0940 | FGD Purge Eff |
| BD0901 | BioReactor 1 Inf |
| BD0988 | BioReactor 2 Eff |
| BD5869 | Metals Trip Blk |

| | | | |
|----------------------------------------------------|----------------------------|--------------------------------------|---------------------------|
| 1) Relinquished By <i>[Signature]</i> | Date/Time 10/1/10 11:00 | 2) Accepted By <i>[Signature]</i> | Date/Time 10-1-10 1100 |
| 3) Relinquished By <i>[Signature]</i> | Date/Time 10-1-10 1605 | 4) Accepted By <i>[Signature]</i> | Date/Time 10-1-10 1605 |
| 5) Relinquished By <i>[Signature]</i> | Date/Time 10-1-10 10:10 | 6) Accepted By | Date/Time |
| 7) Relinquished By | Date/Time | 8) Accepted By | Date/Time |
| 9) Seal/Locked By <i>[Signature]</i> | Date/Time 10-1-10 1000 | 10) Seal/Lock Opened By | Date/Time |
| 11) Seal/Locked By | Date/Time | 12) Seal/Lock Opened By | Date/Time |
| Comments * Metals=As, Ag, B, Cu, Cr, Ni, Se, Zn | | | |

Customer IMPORTANT!
Please indicate desired turnaround

10-21