

From: [Donrich Ebuén](#)
To: [Branson, Eric](#)
Cc: [Brown, Tim](#); [Potter, Dolly](#); [Brian Rezek](#); [Walt Bastron](#); [Juan Martinez](#)
Subject: RE: Solvay CERMS HMI Program
Date: Wednesday, November 15, 2006 1:44:12 PM

CiSCO Job: 21018
Solvay: CERMS

Eric,
The PLC changes are complete, we are still working on the DARS software changes. We estimate that the DARS changes will complete by the end of the week.
Regards,
Don Ebuén

Donrich Ebuén
Project Engineer
Custom Instrumentation Services Corp.-CiSCO
7325 S. Revere Parkway
Centennial, CO 80112
Phone: (303) 790-7827 ext. 126
Fax: (303) 790-7292
debuén@ciscocems.com

From: Branson, Eric [mailto:Eric.Branson@solvay.com]
Sent: Wednesday, November 15, 2006 1:32 PM
To: Donrich Ebuén
Cc: Brown, Tim; Potter, Dolly
Subject: RE: Solvay CERMS HMI Program

Hello Don,

Do you know if the all PLC/DARS softwares have been updated so that both flow meters are used for the air flow calculation?

Eric

From: Brown, Tim
Sent: Wednesday, November 15, 2006 10:53 AM
To: Branson, Eric; Potter, Dolly
Subject: FW: Solvay CERMS HMI Program

From: Donrich Ebuén [mailto:debuén@ciscocems.com]
Sent: Wednesday, November 15, 2006 10:45 AM
To: Brown, Tim
Cc: Juan Martinez
Subject: FW: Solvay CERMS HMI Program

CiSCO Job: 21018
Solvay: CERMS

Tim,
I believe the PLC changes are done for the additional flow monitor. Here are instructions to update the OIT panel on the CERMS rack.
Regards,
Don Ebuén

From: Juan Martinez
Sent: Tuesday, November 14, 2006 3:44 PM
To: Donrich Ebuén
Cc: Brian Rezek; Walt Bastron; Clif Petersen
Subject: Solvay CERMS HMI Program

Don,

I don't have the email address for Tim Brown. So can you forward this email to him? The following is an explanation on how to install the program to the HMI. If he has any questions have him give me a call.
Thanks!!!

Copy it to a Compact Flash memory card as follows:
If the Compact Flash is the "E" drive, copy the file to the path:
"E:\Rockwell Software\RsViewME\Runtime\Solvay_CERMS.mer"
Then place the compact flash card in the slot on the PanelView
Use the "Select" screen to "Exit to System"
Select "Terminal Settings" (F4)
Select "File Management" and Press "Enter"
Select "Copy File" and Press "Enter"
Select "Copy Application" and Press "Enter"
For the "Source" (F1) select "External Storage 1"
The highlight the "MER" file that should be loaded into your panel; that is "Solvay_CERMS.mer"
Select "Destination" (F2)
Select "Internal Storage" using "Destination" (F1)
Select "Copy" (F2)
Press "Yes" (F7) to answer "The file '\Storage Card\Rockwell Software\RsView\Runtime\Solvay_CERMS.mer already exists. Overwrite?"
Select "Cancel" (F8)
Select "Close" (F8)
Select "Close" (F8)
Select "Close" (F8)
Select "Load Application" (F1)
For the "Source" (F1) select "Internal Storage" and highlight the correct "Solvay_CERMS.mer".
Select "Load" (F2)
Press "Yes" (F7) to answer "Do you want to replace the terminal's current communication configuration with the application's communication configuration?"
Select "Run Application" (F2)

Juan C. Martinez
PLC Programmer
Custom Instrumentation Services Corporation - CiSCO
7325 S. Revere Parkway
Centennial, Colorado 80112
(303) 790-7827 Ext. 155

This e-mail is confidential.

SOLVAY2016_1.3_001480

If you are not the addressee or an authorized recipient of this message,
any distribution, copying, publication or use of this information for any
purpose is prohibited.
Please notify the sender immediately by e-mail and then delete this message.
Ce message est confidentiel.
Si vous n'etes pas le destinataire designe de ce message ou une personne
autorisee a l'utiliser, toute distribution, copie, publication ou usage a
quelques fins que ce soit des informations contenues dans ce message sont
interdits.
Merci d'informer immediatement l'expediteur par messagerie electronique et
d'ensuite detruire ce message.
