

Sic 3840

ROUTING RECORD

DATE	FROM	TO	ACTION
9-20-91	SKT	PLS	PLC
AUG 4 '93	A1	G1	TRANSPON
8-13-93	JMT	CHJ	TRANSFER
1-19-96	JMT	GCR	TRANSFER
3-18-97	GCR	TMT	CANCELLED (Inactive status)
3-25-97			→ RECORDS

REFERENCE TO OTHER APCD
RECORDS FOLLOWING DISTANCES:


085085

4
49

3/18/97
CANCELLED

247254

CAPPS





APPLICATION FOR PERMIT TO CONSTRUCT AND PERMIT TO OPERATE
SOUTHERN COAST AIR QUALITY MANAGEMENT DISTRICT
9150 Flair Drive, El Monte, CA 91731

FORM 400A

COMPANY INFORMATION

LEGAL NAME OF APPLICANT Pacesetter Systems, Inc.		NC/NOV NUMBER INSPECTOR ISSUE DATE
PERMIT TO BE ISSUED TO: (SEE INSTRUCTIONS) Pacesetter Systems, Inc.		<input checked="" type="checkbox"/> IRS OR <input type="checkbox"/> S.S. NUMBER 9 53 9 8 4 1 4 8
BUSINESS MAILING ADDRESS 12884 Bradley Avenue, Sylmar, CA 91342		
TYPE OF ORGANIZATION <input checked="" type="checkbox"/> CORPORATION <input type="checkbox"/> LIMITED PARTNERSHIP <input type="checkbox"/> GOVERNMENT ENTITY <input type="checkbox"/> INDIVIDUAL <input type="checkbox"/> GENERAL PARTNERSHIP <input type="checkbox"/> OTHER		
ARE YOU A SMALL BUSINESS? (SEE INSTRUCTIONS) <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO	AVERAGE ANNUAL GROSS RECEIPTS: 200 M NUMBER OF EMPLOYEES: 800	IS YOUR BUSINESS 51 PERCENT OR MORE WOMAN/MINORITY OWNED? (OPTIONAL) <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO
ARE ALL FACILITIES UNDER SAME OWNERSHIP IN CALIFORNIA IN COMPLIANCE WITH FEDERAL, STATE AND LOCAL AIR POLLUTION CONTROL RULES? <input checked="" type="checkbox"/> YES <input type="checkbox"/> NO		
ARE YOU THE OWNER OF THE EQUIPMENT UNDER THIS APPLICATION? <input checked="" type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/> IRS OR <input type="checkbox"/> S.S. NUMBER OF THE OWNER		
IF NO, ENTER LEGAL NAME OF OWNER		

FACILITY INFORMATION

EQUIPMENT ADDRESS/LOCATION 15900 Valley View Court NUMBER / STREET Sylmar CITY OR COMMUNITY	CA 91342 ZIP CODE	FACILITY NAME Pacesetter Systems, Inc. FACILITY ID NUMBER (SEE INSTRUCTIONS) 085085 4/12/91
CONTACT PERSON AND TITLE Stephen R. Walters, AQC Inc.	CONTACT TELEPHONE NUMBER (714) 894-5252	NUMBER OF EMPLOYEES AT THIS FACILITY: 800
TYPE OF BUSINESS AT THIS FACILITY Pacemaker Manufacturing	BUSINESS TYPE CODE (SEE INSTRUCTIONS) 3 8 4 0	IS THERE A SCHOOL WITHIN 1,000 FEET OF YOUR PROPERTY? YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>

EQUIPMENT INFORMATION

EQUIPMENT DESCRIPTION (SEE INSTRUCTIONS) Ethylene Oxide Sterilizer #1, Getinge Model 8440AR1 (refer to supplemental for additional information)		
APPLICATION FOR: (SEE INSTRUCTIONS) <input checked="" type="checkbox"/> NEW CONSTRUCTION <input type="checkbox"/> MODIFICATION <input type="checkbox"/> CHANGE OF LOCATION <input type="checkbox"/> EXISTING EQUIPMENT OPERATING WITHOUT PERMIT <input type="checkbox"/> CHANGE OF PERMITTEE <input type="checkbox"/> CHANGE OF PERMIT CONDITION <input type="checkbox"/> EXISTING EQUIPMENT WITH EXPIRED PERMIT	ARE YOU SUBMITTING MULTIPLE APPLICATIONS FOR EQUIPMENT IDENTICAL TO THAT DESCRIBED ABOVE? <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO	
HAVE YOU BEEN ISSUED A NOTICE TO COMPLY (NC) OR A NOTICE OF VIOLATION (NOV) FOR THIS EQUIPMENT? <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO	NUMBER OF EMPLOYEES NEEDED TO OPERATE THIS EQUIPMENT: 1	
NC NUMBER: NOV NUMBER: NOTICE ISSUE DATE:	PREVIOUS PERMIT NUMBER:	
IF THE EQUIPMENT HAS A PREVIOUS WRITTEN PERMIT, STATE NAME OF PERMITTEE:		
FOR NEW CONSTRUCTION OR MODIFICATION, ENTER ESTIMATED COST OF: BASIC EQUIPMENT \$ 225,000 AIR POLLUTION CONTROL EQUIPMENT \$ 90,000		
FOR NEW CONSTRUCTION OR MODIFICATION, ENTER ESTIMATED START DATE: 4/05/91 ESTIMATED COMPLETION DATE: 8/1/91		
FOR CHANGE OF PERMITTEE, LOCATION OR CONDITION, ENTER DATE OF OCCURRENCE:		
FOR EXISTING EQUIPMENT IN OPERATION WITHOUT PRIOR PERMIT, ENTER INITIAL OPERATION DATE:		
FOR THIS PROJECT, HAS A CALIFORNIA ENVIRONMENTAL QUALITY ACT (CEQA) DOCUMENT BEEN REQUIRED BY ANOTHER GOVERNMENTAL AGENCY? <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO		
IF YES, ENTER NAME: AND SUBMIT A COPY IF APPROVED		
DO YOU CLAIM CONFIDENTIALITY OF DATA? (SEE INSTRUCTIONS) <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO		

I HEREBY CERTIFY, UNDER PENALTY OF PERJURY, THAT ALL INFORMATION CONTAINED HEREIN AND INFORMATION SUBMITTED WITH THIS APPLICATION ARE TRUE AND CORRECT		OFFICIAL TITLE OF SIGNER Director, Facility&Maintenance	
SIGNATURE <i>Charles K. Stoddard</i>		DATE 3/26/91	
TYPE OR PRINT NAME OF SIGNER Charles K. Stoddard		TELEPHONE NUMBER (818) 362-6822	
APPLICATION NUMBER 247254	TYPE Q C D	EQUIPMENT CATEGORY NUMBER 00028905	ASSIGNMENT UNIT 1 ENGINEER
ENGR. 4-12-91	ENGR.	FEE SCHEDULE \$1700	CHECK OR MONEY ORDER NUMBER 16764
AR DATE 4/11/91	AR DATE INITIAL SK 1/8	VALIDATION 4/11/91	AMOUNT 7100



PERMIT TO CONSTRUCT

9150 FLAIR DRIVE, EL MONTE, CALIFORNIA 91731

Application No.

247254

Page 1

Granted as of October 4, 1991

**Legal Owner
or Operator:**

**PACSETTER SYSTEMS, INC.
12884 BRADLEY AVENUE
SYLMAR, CALIFORNIA 91342
ATTN: STEPHEN R. WALTERS**

ID 85085

Equipment Location: 15900 VALLEY VIEW COURT, SYLMAR, CA. 91341

The equipment described below and as shown on the approved plans and specifications are subject to the special condition, or conditions listed.

Equipment Description:

ETHYLENE OXIDE STERILIZATION SYSTEM NO. 1 CONSISTING OF:

1. STERILIZER NO. 1, GETINGE, MODEL NO. 8440AR1, 2' -11" W. X 4' -9" H. X 5' -0" L.
2. STEAM GENERATOR, 60 KW, WITH 201,000 BTU PER HR OUTPUT.

Conditions:

1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN COMPLIANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.
2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
3. THIS EQUIPMENT SHALL NOT BE OPERATED UNLESS THE STERILIZER EXHAUST IS VENTED TO AN AIR POLLUTION CONTROL DEVICE WHICH IS IN FULL USE AND WHICH HAS BEEN ISSUED A PERMIT TO CONSTRUCT BY THE EXECUTIVE OFFICER.
4. NO MORE THAN 16 POUNDS OF ETHYLENE OXIDE GAS SHALL BE CHARGED TO THE STERILIZERS AT THIS FACILITY IN ANY ONE DAY.
5. NO MORE THAN 4000 POUNDS OF ETHYLENE OXIDE GAS SHALL BE USED IN THIS FACILITY IN ANY ONE CALENDER YEAR.

FILE COPY



PERMIT TO CONSTRUCT

9150 FLAIR DRIVE, EL MONTE, CALIFORNIA 91731

Application No.

247254

Page 2

Approval or denial of this application for permit to operate the above equipment will be made after an inspection to determine if the equipment has been constructed in accordance with the approved plans and specifications and if the equipment can be operated in compliance with all Rules of the South Coast Air Quality Management District.

Please notify S. K. TSAI 818/307-3564 when construction of equipment is complete.

This Permit to Construct is based on the plans, specifications, and data submitted as it pertains to the release of air contaminants and control measures or reduce air contaminants. No approval or opinion concerning safety and other factors in design, construction or operation of the equipment is expressed or implied.

This Permit to Construct shall serve as a temporary Permit to Operate provided the Executive Officer is given prior notice of such intent to operate.

This Permit to Construct will become invalid if the Permit to Operate is denied or if this application is cancelled. THIS PERMIT TO CONSTRUCT SHALL EXPIRE ONE YEAR FROM THE DATE OF ISSUANCE unless an extension is granted by the Executive Officer.

Dorris M. Bailey

By

DORRIS M. BAILEY

Principal Office Assistant

DMB/eb

FILE COPY

SCAQL COMPUTER ASSISTED PERMIT PROCESSING (CAPPS)

FEE DATA - SUMMARY SHEET

Application No : 247254
Previous Permit No:

IRS/SS No: 000-00-0000
Previous Application No:

Company Name : SIEMENS PACESETTER INC Facility ID: 085085
Equipment Street: 15900 VALLEY VIEW CT, SYLMAR, CA 91392
Equipment Desc. : STERILIZING EQUIPMENT

Equipment Type : BASIC Fee Charged by: B-CAT
B-CAT NO. : 000289 C-CAT NO. : 00 Schedule: C
Facility Zone : 7 Deemed Compl. Date: 5/15/1991 PUBLIC NOTICE: NO

APPLICATION FILING FEE (PRIOR TO 7/1/90 & PLANS FEE) \$ 0.00
EVALUATION FEE PRE-PAID (POST 7/1/90) \$ 0.00

Evaluation Type: PERMIT TO OPERATE (PO) Small Business?: NO
Disposition : CANCEL PO - DON'T REFUND FEE P/O NO P/C Penalty?: NO
Reference App. No: Similar Permit Unit?: NO

1. PERMIT PROC. FEE* (APPL FILED PRIOR TO 7/1/90) SUMMARY PERMIT		
FEE RATES * \$ 1,700.00 LESS FILING FEE PAID \$	\$ 0.00
2. EIR		\$ 0.00
3. AIR QUALITY ANALYSIS (TABLE II FEE)		\$ 0.00
4. HEALTH RISK ASSESSMENT (TABLE II FEE)		\$ 0.00
5. SIGNIFICANT PROJECT REVIEW (TABLE II FEE)		\$ 0.00
6. SOURCE TEST REVIEW: (RULE 306(i) FEE) \$1600 +		
[NO HRS @ \$75/HR]		\$ 0.00
7. CEMS REVIEW (TABLE II FEE)		\$ 0.00
8. TIME AND MATERIALS (FOR PLAN APPLICATIONS ONLY)		
0.00 HRS @ \$ 75.00/HR		\$ 0.00
9. PERMIT PROCESSING FEE ADJUSTMENT** ADDITIONAL FEE		
TABLE I FEE* \$ 1,700.00 LESS EVAL. FEE PAID \$...	\$ 1,700.00
10. OTHER FEES** (INCLUDING CANCELLATION)		\$ -1,700.00

TOTAL:		\$ 0.00

COMMENTS: FEE WAS PAID WHEN A/N SUBMITTED. A/N IS ALREADY INACTIVATED BY
CUSTOMER SERVICE. A NEW I.D. #103609 WAS ASSIGNED AND EQUIP
PERMITTED UNDER A/N 298971 OR A/N 298972.

Recommended By: GCR DATE: 3/18/1997 REVIEWING ENG: _____ DATE: _____

* ADJUSTED FOR SMALL BUSINESS, IDENTICAL EQUIPMENT, AND P/O NO P/C PENALTY

** ADJUSTED FOR INCORRECT FEE SUBMITTAL, SMALL BUSINESS, IDENTICAL EQUIPMENT, AND P/O NO P/C PENALTY

South Coast Air Quality Management District
Follow Up Report

03/18/97

Facility ID : 85085
Name : SIEMENS PACESETTER INC
Address: 15900 VALLEY VIEW CT
SYLMAR, CA 91392-9221

Customer: C. K. STODDARD
Phone : (818)362-6822

Follow Up Transaction Number: 48637

Complaint:

Entered by: BC2773
Entered on: 10/24/94

Assigned to: BC2773

Complaint Type: C

AN ACQUISITION AGREEMENT:
NAME IS PACESETTER, INC
A ST. JUDE MEDICAL C

Resolution:

[Handwritten signature]
Resolved.

South Coast Air Quality Management District

Facility Equipment List Report

Contact: C. K. STODDARD (818) 3828822
 Quarter: 0001 - Inspected in 4th quarter, every year
 On Hold: _____
 Team: _____

MR: 0801
 TS: NONE
 Assignment No. _____

Facility: 85065 SIEMENS PACESETTER INC
 Last Inspection: 02/19/1993
 SIC: 3845

Location Address: 15900 VALLEY VIEW CT, SYLMAR 91392-9221
 Mailing Address: 15900 VALLEY VIEW CT, SYLMAR 91392-9221
 Comment: _____

Application No.	Permit No.	Permit Issue Date	Permit Status	Equipment Category	BCAT/CCAT Description	Application Date	Application Status
278881	D71408	03/19/1993	INACTIVE	000321 BCAT	TANK, SURFACE PREPARATION - OTHER ACIDS	03/02/1993	PERMIT TO OPERATE GRANTED
259031	D46563	01/14/1992	INACTIVE	44 CCAT	DRY FILTER (>100-500 SQ FT)	12/04/1991	PERMIT TO OPERATE GRANTED
259032	D46565	01/14/1992	INACTIVE	000284 BCAT	ABRASIVE BLASTING (CABINET/MACHINE/ROOM)	12/04/1991	PERMIT TO OPERATE GRANTED
258822	D46387	01/06/1992	INACTIVE	000241 BCAT	DEGREASER 111 TRICHLOROETHANE <=1lb/dVOC	12/02/1991	PERMIT TO OPERATE GRANTED
254025	D46372	01/06/1992	INACTIVE	000241 BCAT	DEGREASER 111 TRICHLOROETHANE <=1lb/dVOC	07/24/1991	PERMIT TO OPERATE GRANTED
254026	D46384	01/06/1992	INACTIVE	000241 BCAT	DEGREASER 111 TRICHLOROETHANE <=1lb/dVOC	07/24/1991	PERMIT TO OPERATE GRANTED
254027	D46311	01/02/1992	INACTIVE	000241 BCAT	DEGREASER 111 TRICHLOROETHANE <=1lb/dVOC	07/24/1991	PERMIT TO OPERATE GRANTED
254967	D45011	11/06/1991	INACTIVE	000411 BCAT	SOLDERING MACHINE	07/24/1991	PERMIT TO OPERATE GRANTED
255051	D43549	10/02/1991	INACTIVE	043901 BCAT	I C E (50-500 HP) EM ELEC GEN-DIESEL	08/15/1991	PERMIT TO OPERATE GRANTED
247254		00/00/0000		000289 BCAT	STERILIZING EQUIPMENT	08/16/1991	APPLICATION CANCELLED, REFUND ALL FEES
247255		00/00/0000		000289 BCAT	STERILIZING EQUIPMENT	04/12/1991	APPLICATION CANCELLED, REFUND ALL FEES
247256		00/00/0000		06 CCAT	AFTERBURNER, CATALYTIC	04/12/1991	APPLICATION CANCELLED, REFUND ALL FEES

New Alerts were filed under ID 103609 and Permitted.
 See ID # 103609

South Coast Air Quality Management District

Facility Equipment List Report

Facility: 103609 PACESETTER INC, A ST JUDE MEDICAL CO
 Last Inspection: 02/19/1993
 SIC: 3845
 Inspector:

MR: 0801
 TS: NONE
 Assignment No.

Contact: C. K. STODDARD (818) 3626822
 Quarrier: 0100 - inspect in 2nd quarter, every year
 On Hold:
 Suspended:
 Team:

Location Address: 15600 VALLEY VIEW CT, SYLMAR 91362-9221
 Mailing Address: 15600 VALLEY VIEW CT, SYLMAR 91362-9221
 Comment:

Application No.	Permit No.	Permit Issue Date	Permit Status	Equipment Category	BCAT/CCAT Description	Application Date	Application Status
298970	D87020	12/06/1994	ACTIVE	06 CCAT	AFTERBURNER, CATALYTIC	12/06/1994	PERMIT TO OPERATE GRANTED
298971	D87021	12/06/1994	ACTIVE	000289 BCAT	STERILIZING EQUIPMENT	12/06/1994	PERMIT TO OPERATE GRANTED
298972	D87022	12/06/1994	ACTIVE	000289 BCAT	STERILIZING EQUIPMENT	12/06/1994	PERMIT TO OPERATE GRANTED
298985	D88084	12/07/1994	ACTIVE	000321 BCAT	TANK, SURFACE PREPARATION - OTHER ACIDS	12/06/1994	PERMIT TO OPERATE GRANTED
298988	D88085	12/07/1994	ACTIVE	043901 BCAT	I C E (50-500 HP) EM ELEC GEN-DIESEL	12/06/1994	PERMIT TO OPERATE GRANTED
298989	D88086	12/07/1994	INACTIVE	000411 BCAT	SOLDERING MACHINE	12/06/1994	PERMIT TO OPERATE GRANTED

South Coast Air Quality Management District
Engineering Division
New Source Review Regulation XIII Data Sheet

APPLICATION NUMBER : 247254
FACILITY I.D. NUMBER: 085085
FACILITY NAME : PACESETTER SYSTEMS INC
FACILITY ADDRESS : 15900 VALLEYVIEW CT
CITY : SYLMAR **STATE**: CA **ZIP**: 91342-0000

PERMIT TYPE : PC
DEEMED COMPLETE: 5/15/1991

PREVIOUS APPLICATION NUMBER:

PROCESSING DECISION FOR APPLICATION:
TRANSACTION CODE: INSTALL
ENGINEER: SUSAN K TSAI


EMISSION DATA: ETHOXIDE

Max Daily (Uncontrolled)	:		lbs/day
Max Daily (Controlled)	:		lbs/day
Positive Balance	:	0	lbs/day
30 Day Average (Controlled)	:		lbs/day
Annual (Controlled)	:	2.088000	lbs/year

EMISSION DATA: ROG

Max Daily (Uncontrolled)	:	8	lbs/day
Max Daily (Controlled)	:		lbs/day
Positive Balance	:	0	lbs/day
30 Day Average (Controlled)	:		lbs/day
Annual (Controlled)	:	2.088000	lbs/year

SUPERVISOR'S APPROVAL:



SUPERVISOR'S REVIEW DATE:

OCT 1 '90

FEE DATA - SUMMARY SHEET

Application No : 247254

IRS/SS No:

Previous Permit No:

Previous Application No:

Company Name : PACESETTER SYSTEMS INC

Facility ID: 085085

Equipment Street: 15900 VALLEYVIEW CT, SYLMAR, CA 91342

Equipment Desc. : STERILIZING EQUIPMENT


B-CAT NO. : 000289 C-CAT NO. : 00 Schedule: C PUBLIC NOTICE REQUIRED: NO

APPLICATION FILING FEE (PRIOR TO 7/1/90 & PLANS FEE) \$
 EVALUATION FEE PRE-PAID (POST 7/1/90) \$ 1,700.00
 Evaluation Type: PERMIT TO CONSTRUCT (PC) Small Business?: NO
 Disposition: APPROVE PC P/O NO P/C Penalty?: NO
 Reference App. No: Identical Permit Unit?: NO

1. PERMIT PROC. FEE* (APPL FILED PRIOR TO 7/1/90)	1. \$	0.00
2. EIR	2. \$	0.00
3. AIR QUALITY ANALYSIS	3. \$	0.00
4. HEALTH RISK ASSESSMENT	4. \$	0.00
5. SIGNIFICANT PROJECT REVIEW	5. \$	0.00
6. SOURCE TEST REVIEW	6. \$	0.00
7. CEMS REVIEW	7. \$	0.00
8. TIME AND MATERIALS (FOR PLAN APPLICATIONS ONLY)	8. \$	0.00
9. PERMIT PROCESSING FEE ADJUSTMENT**		
ADDITIONAL FEE	9. \$	0.00
10. OTHER FEES** (INCLUDING CANCELLATION)	10. \$	0.00

TOTAL: \$ 0.00

COMMENTS: FOR PERMIT WORDING AND CONDITIONS SEE PAGE 1 & 2 OF PROCESSING SHEETS.

Recommended By: SKT DATE: 9/30/1991 REVIEWING ENG:  DATE: OCT 1 1991

* ADJUSTED FOR SMALL BUSINESS, IDENTICAL EQUIPMENT, AND P/O NO P/C PENALTY

** ADJUSTED FOR INCORRECT FEE SUBMITTAL, SMALL BUSINESS, IDENTICAL EQUIPMENT, AND P/O NO P/C PENALTY

SCAQMD COMPUTER ASSISTED PERMIT PROCESSING (CAPPS)

AEIS DATA SHEET

(For P/C Only)

Company Name **PACSETTER SYSTEMS INC**

Facility ID **085085**

Equipment Address **15900 VALLEYVIEW CT, SYLMAR CA 91342**

APPLICATION NUMBER	247254
ESTIMATED COMPLETION DATE	12/01/1991
EQUIPMENT B-CAT	000289
EQUIPMENT C-CAT	00
EQUIPMENT DESCRIPTION	STERILIZING EQUIPMENT
EQUIPMENT TYPE	B
SCHEDULE/STEP	3/C

Supervisor's Name: _____



Engineers Name: **SUSAN K TSAI**

Date: **9/30/1991**

Review Date: 09 / 1 '91

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS**

PAGES	PAGE
7	1
APPL. NO.	DATE
247254-6	9-25-91
PROCESSED BY	CHECKED BY
AOC	SKT

PACESETTER SYSTEMS, INC.
12884 BRADLEY AVENUE
SYLMAR, CA 91342

**EQUIPMENT LOCATION:**

15900 VALLEY VIEW COURT, SYLMAR, CA 91342

EQUIPMENT DESCRIPTIONS:**APPLICATION NO. 247254**

ETHYLENE OXIDE STERILIZATION SYSTEM NO. 1 CONSISTING OF :

1. STERILIZER NO. 1, GETINGE, MODEL NO. 8440AR1, 2'-11" W. X 4'-9" H. X 5'-0" L.
2. STEAM GENERATOR, 60 KW, WITH 201,000 BTU PER HR OUTPUT.

APPLICATION NO. 247255

ETHYLENE OXIDE STERILIZATION SYSTEM NO. 2 CONSISTING OF :

1. STERILIZER NO. 2, GETINGE, MODEL NO. 8430AR1, 2'-2" W. X 3'-0" H. X 5'-0" L.
2. STEAM GENERATOR, 60 KW, WITH 201,000 BTU PER HR OUTPUT.

APPLICATION NO. 247256

AIR POLLUTION CONTROL SYSTEM CONSISTING OF :

1. CATALYTIC OXIDIZER/ABATOR, DONALDSON, 7' W. X 5' H. X 21' L., WITH A 80 KW PREHEATER, A HEAT EXCHANGER, A PREFILTER, AND FOUR DCI SURE-SORBER CATALYTIC FILTERS.
2. EXHAUST SYSTEM WITH A 1000 SCFM CENTRIFUGAL AIR BLOWER VENTING TWO ETHYLENE OXIDE STERILIZING SYSTEMS.

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS****PAGES****7****PAGE****2****APPL. NO.****247254-6****DATE****9-25-91****PROCESSED BY****AQC****CHECKED BY****SKT****CONDITIONS****APPLICATIONS NO. 247254 & 247255**

1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THIS APPLICATION UNDER WHICH A PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.
2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
3. THIS EQUIPMENT SHALL NOT BE OPERATED UNLESS THE STERILIZER EXHAUST IS VENTED TO AN AIR POLLUTION CONTROL DEVICE WHICH IS IN FULL USE AND WHICH HAS BEEN ISSUED AN PERMIT TO CONSTRUCT BY THE EXECUTIVE OFFICER.
4. NO MORE THAN 16 POUNDS OF ETHYLENE OXIDE GAS SHALL BE CHARGED TO THE STERILIZERS AT THIS FACILITY IN ANY ONE DAY.
5. NO MORE THAN 4000 POUNDS OF ETHYLENE OXIDE GAS SHALL BE USED IN THIS FACILITY IN ANY ONE CALENDER YEAR.

APPLICATION NO. 247256

1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THIS APPLICATION UNDER WHICH A PERMIT IS ISSUED UNLESS OTHERWISE NOTED.
2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
3. ONLY ONE STERILIZER MAY VENT ITS PRIMARY ETHYLENE OXIDE EXHAUST TO THE CATALYTIC OXIDIZER/ABATOR AT ANY ONE TIME.
4. THE TEMPERATURE OF THE EXHAUST FROM THE CATALYST BED SHALL BE MAINTAINED BETWEEN 300°F AND 500°F AS INDICATED BY A PROPER TEMPERATURE GAGE.
5. RECORDS SHALL BE MAINTAINED TO PROVE COMPLIANCE WITH CONDITION NO. 4. THE RECORDS SHALL BE MADE AVAILABLE TO THE DISTRICT UPON REQUEST.

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS**

PAGES	PAGE
7	3
APPL. NO.	DATE
247254-6	9-25-91
PROCESSED BY	CHECKED BY
AQC	SKT

BACKGROUND

Pacesetter Systems, Inc. manufactures heart pacemakers and their facility is presently located at 12884 Bradley Avenue in Sylmar, CA. Their operations will be completely moved to another facility at 15900 Valley View Court in Sylmar, CA. Pacesetter plans to purchase two new sterilizers and abator system (catalytic oxidizer) to conduct their sterilization operations in this new facility.

These new sterilizers will be constructed in a fire-proof sterilization room at the Valley View facility, and utilize 100% ethylene oxide (EtO) to sterilize components of the pacemakers, pacers and leads. The abator system will control all EtO emissions from the operation of the sterilizers, and has an expected efficiency of 99.9%. Complete aeration of the product loads will be conducted inside the sterilizers, so any EtO residue left upon completion of sterilization will be vented to the abator. The room in which the sterilizers are situated will be continuously vented to the abator as well to control any fugitive EtO.

A typical load of product will contain equal quantities of pacers and leads. Pacers are constructed of a Titanium can with an epoxy connector top. Leads are made of silicone tubing over a metal conductor with a connector that fits into the pacer connector on one end and a metal electrode on the other. Each pacer or lead is packaged in two 0.025" thick, vacuum formed XT Polymer trays; the inner tray measures 4.25" x 7.25", and the outer one is 5" x 8". The 32 cubic foot sterilizer will typically hold 400 packages, and the 69 cubic foot unit will hold 1400 packages.

Ethylene oxide is a carcinogenic air contaminant. Permitting and operation of the sterilizers are subject to the requirements of Rules 1401 and 1405, respectively.

Applications for Permits to Construct the sterilizers and abator system were submitted on April 10, 1991.

PROCESS DESCRIPTION

The sterilizers use 100% ethylene oxide (EtO) to sterilize components of heart pacemakers: pacers and leads. The total EtO usage is projected to be 5.65 pounds per day for both sterilizers.

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS**

PAGES 7	PAGE 4
APPL. NO. 247254-6	DATE 9-25-91
PROCESSED BY AQC	CHECKED BY SKT

Batch loads of pacers and leads are placed in the sterilizers, and experience a 22 hour sterilization cycle. The sequence of operation of the sterilization cycles is as follows:

- a. The load is heated by recirculating the chamber air for a pre-set time period of approximately 20 minutes.
- b. The chamber is evacuated by the vacuum pump at a pre-set rate until a pre-set vacuum level is achieved.
- c. The chamber is held under vacuum for 10 minutes to determine if any leaks exist.
- d. Compressed nitrogen gas is admitted to the chamber at a pre-set pressure. Chamber is re-evacuated, and charged again with nitrogen gas for a pre-set number of pulses.
- e. The load is humidified with pulse injections of steam to a pre-set absolute pressure level.
- f. The load is held at temperature and humidity for a pre-selected pre-conditioning time.
- g. Ethylene oxide (EtO) gas is admitted to the chamber at a pre-set rate until a pre-set pressure is achieved. Nitrogen gas is admitted to chamber at a pre-set rate until a pre-set pressure is achieved. A subsequent charge of nitrogen gas into chamber purges gas lines of EtO.
- h. Chamber pressure is maintained for the pre-selected sterilizing time period.
- i. Primary exhaust of the chamber gases commences through the ventilation system at a pre-set rate to an abator (a catalytic control device) where 99.9% of EtO in the primary chamber exhaust is oxidized to carbon dioxide and water.
- j. Chamber is evacuated to pre-set vacuum level. Nitrogen gas is admitted to chamber at a pre-set rate until pre-set pressure is attained (Steps i & j are repeated at least 2 additional times).
- k. Complete chamber aeration commences by alternating a pre-set number of vacuum and air purges.
- l. Air is admitted to the chamber through the bacterial retentive air filter until ambient atmospheric pressure is achieved.

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS**

PAGES	PAGE
7	5
APPL. NO.	DATE
247254-6	9-25-91
PROCESSED BY	CHECKED BY
AOC	SKT

The sterilization chamber is heated by recirculating water through a jacket lining the ceiling, walls, and floor. The water is heated by steam provided by a 60 KW electric steam generator. A centrifugal-type fan is fitted to the roof of the chamber to circulate internal air and gases, and powered by an external electric motor. All chamber air and gases are exhausted through a ventilation system ducted to the ethylene oxide abator system.

In the abator system, the ethylene oxide contaminated air is passed through 4 catalytic filters containing a catalyst made up of a manganese dioxide and copper oxide mixture. The ethylene oxide adsorbs to the catalyst, and is oxidized to carbon dioxide and water according to the following equation:



Prior to introducing EtO to the abator system, there is a preheat cycle of approximately 45 minutes to bring the system to an operating temperature of 300 degrees Fahrenheit (after initial start up, the abator will operate continuously). The fan motor and heater are energized and the dampers are positioned in the preheat mode. The warm air heats up the catalytic beds. When the sensor on the catalytic beds senses a temperature of 300 degrees Fahrenheit, the system will end the preheat cycle and open the EtO feed valve. Due to the release of heat during the oxidation of ethylene oxide, the heater is used very little once the catalytic beds have reached the operating temperature.

Air from the sterilizer chambers and sterilization room are pulled into the abator system by a 1000 scfm centrifugal fan. Any particulate in the incoming air is removed by the Dustfoe prefilters. The air then passes through a recuperative heat exchanger, heating coils, and then into the catalytic beds. The EtO free air proceeds through the fans, and a portion of the discharge is recirculated to the hot side of the recuperative heat exchanger to preheat incoming air. The amount of flow directed to the heat exchanger is controlled depending upon the temperature of the catalytic beds. In addition, a temperature control switch will close the EtO feed valve should the catalytic bed temperature rise above 550 degrees Fahrenheit.

Safety mechanisms are provided to restrict the EtO feed valve from opening unless the following criteria are satisfied:

1. Catalytic bed temperature at a minimum of 300 degrees Fahrenheit
2. Catalytic bed temperature below 550 degrees Fahrenheit
3. Minimum air flow rate of 900 cfm
4. Safety blow-out pan properly sealed

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS**

PAGES 7	PAGE 6
APPL. NO. 247254-6	DATE 9-25-91
PROCESSED BY AQC	CHECKED BY SKT

EMISSION AND RISK CALCULATIONS**Ethylene Oxide Emission Calculations:**

Operating Schedule: 8 hrs/day, 5 days/week, 52 weeks/yr

Maximum Amount of EtO usage: 16 lb/day

$$R1 = \text{uncontrolled emissions} = 16 \text{ lbs/day}$$

$$R2 = \text{controlled emissions} = 16 \text{ lbs/day} \times (1 - 0.999) \\ = 0.016 \text{ lbs/day}$$

$$\text{Yearly average emission} = 0.016 \text{ lbs/day} \times (261/365) \\ = 0.011 \text{ lb/day}$$

Risk Assessment Calculation:

$$\text{MICR} = Q \times (X/Q) \times U \times \text{MP}$$

MICR - Maximum Individual Cancer Risk

Q - Emission Rate of EtO in lb/day

X/Q - EtO Concentration (Tables 3 & 4, Rule 1401)

U - Unit Risk Factor for EtO (Table 1, Rule 1401)

MP - Multiple Pathway Adjustment Factor

Risk at the Nearest Residential Area:

$$Q = 0.011 \text{ lb/day} \\ X/Q = 0.673 \text{ [ug/m}^3\text{]} / \text{[lb/day]} \\ U = 0.000088 \text{ [1/(ug/m}^3\text{)]} \\ \text{MP} = 1$$

$$\text{MICR} = 0.011 \times 0.673 \times 0.000088 \times 1 \\ = 0.65 \times 10^{-6}$$

Risk at the Commercial/Industrial Locations:

$$Q = 0.011 \text{ lb/day} \\ X/Q = 3.01 \text{ [ug/m}^3\text{]} / \text{[lb/day]} \\ U = 0.000088 \text{ [1/(ug/m}^3\text{)]} \\ \text{MP} = 1$$

$$\text{MICR} = 0.011 \times 3.01 \times 0.000088 \times 1 \\ = 2.9 \times 10^{-6}$$

Multiplication factor for adjustment for land use considerations at commercial/industrial locations is 0.15.

$$\text{Adjusted Risk} = 2.9 \times 10^{-6} \times 0.15 = 0.44 \times 10^{-6}$$

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT**ENGINEERING DIVISION****APPLICATION PROCESSING AND CALCULATIONS**

PAGES	PAGE
7	7
APPL. NO.	DATE
247254-6	9-25-91
PROCESSED BY	CHECKED BY
AOC	SKT

The off-site commercial/industrial risk times 0.15 is less than one-in-one million and the nearest residential area risk is also less than one-in-one million, therefore, the facility is considered to have passed the screening assessment.

RULE EVALUATION

Rule 212 Compliance with this rule is expected.

The maximum individual cancer risk is less than one-in-one million.

Rule 401 No visible emissions expected.

Rule 402 No nuisance expected.

Reg. XIII Compliance with this regulation is expected.

The air pollution control system satisfied the BACT requirement.

Rule 1401 The maximum individual cancer risk (MICR) is less than one-one in million, compliance with this rule is expected.

Rule 1405 Compliance with this rule is expected.

All exhaust of EtO must be vented an control device with 99.6% efficiency. The abator system is expected to achieve 99.9% efficiency.

RECOMMENDATIONS

Based on the above evaluation, conditional Permits to Construct are recommended for Applications No. 247254, 247255, and 247256.

RISK APPLICATION TRACKING FORM

COMPANY NAME

PACESETTER SYSTEMS INC.

FACILITY LOCATION

15900 VALLEYVIEW CT, SYLMAR, CA 91342

FACILITY I.D. NO.

85085

EQUIPMENT LOCATION WITHIN FACILITY

WEST SIDE OF BUILDING, 260 FT FROM ROXFORD STREET PROPERTY LINE

EQUIPMENT DESCRIPTION

ETHYLENE OXIDE STERILIZER, #1 GETTING, MODEL NO 8440 AR1

APPLICATION NO.

RELATED APPLICATION NOS.

247254 247256

CARCINOGENIC EMISSIONS EVALUATED: (attach additional sheets as necessary)

COMPOUNDS EMITTED	EMISSION RATE (#/YR)	CONTROL EQUIPMENT	C-CAT NO.	CONTROL EFFICIENCY
ETHYLENE OXIDE	1401 212	2.088	CATALYTIC OXIDIZER/ABSORB 16	99.9%
	1401 212			
	1401 212			
	1401 212			

TYPE OF ANALYSIS PERFORMED:

SCREENING ☒

DETAILED MODELING ☐

BOTH ☐

NONE ☐

T-BACT REQUIRED YES ☒

NO ☐

212 P/U RISK:

1401 P/U RISK:

0.3340

1401 CUM RISK:

CANCER BURDEN CALCULATED

YES ☐

NO ☒

IF YES CANCER BURDEN

CEQA PROCESS REQUIRED

YES ☐

NO ☒

PERMIT CONDITIONED TO EXPIRE ON JUNE 1, 1995

YES ☐

NO ☐

EXEMPTION APPLIED

NO ☒

YES ☐

IF YES, SECTION APPLIED: 1401(g)(1)(C)

PERMIT ISSUED

YES ☒

NO ☐

RESOLUTION DATE:

COMMENT / REASON FOR DENIAL:

PROCESS ENGINEER NAME

Susan K Tsai

DATE

9/30/91

APPROVED BY

DATE

OCT 1 '91

ENGINEERING DIVISION...MEMORANDUM

TO FILE	FROM SKT	DATE 9-26-91
REFERENCE (Pacesetter) AOC		PERMIT APPL. NO.
SUBJECT ↓		

TC Steve Walters

- Informed him that the grade of the location of the facility can not be considered when performing the screening analysis.
- Since the facility is in an industrial location adjustment for land use consideration can be applied.
- The maximum allowable EtO per day is 16 lb/day.
- Condition will include daily and yearly EtO use limits.
- Will call back after checking with clients.

9-26-91

TC Steve Walters

- Have confirmed with client that 16 lb/day of EtO use limit is achievable.



A N E N V I R O N M E N T A L E N G I N E E R I N G C O N S U L T I N G F I R M

September 18, 1991

Susan Tsai
South Coast AQMD
9150 Flair Drive
El Monte, CA 91731

Re: Sterilizer and Abator System Permit Application
#247254, 247255, and 247256 for:
Pacesetter Systems, Inc.
15900 Valley View Court
Sylmar, CA 91342

Dear Susan:

Per our discussion, we have re-evaluated the initial MICR calculations submitted with the Engineering Evaluations on 20 August 1991 for the above permit applications. Our evaluation took into account the provisions for dispersion factors outlined in the Air Toxic Rules Risk Assessment Guidelines.

Subsequently, we have attached a revised MICR screening which has taken into consideration the horizontal distance from the EtO Abator to the nearest residential receptor. In addition, the stack height parameter was revised taking into account the grade from the property fenceline to ground level of this residential receptor. We have attached maps which will serve as support documentation for our calculations.

The MICR screening revealed the risk to the nearest residential receptor will not exceed one in one million for ethylene oxide usages up to 31 pounds per day. Please revise the Engineering Evaluations to allow for this usage as a facility limit. It is recommended the sterilizers' permit condition #6 read as the following: "The total quantity of ethylene oxide gas used in the sterilization equipment at this facility shall not exceed 31 pounds on any one day."

In light of the approaching move-in date, we appreciate any expeditious action taken to issue the Permits to Construct. If there are any questions, please do not hesitate to call.

Sincerely,

Steve Walters
Project Engineer

cc: G. Rhett, SCAQMD
C. Stoddard, Pacesetter Systems

3230 FALLOW FIELD DRIVE
SUITE 200, DIAMOND BAR
CA 91765-3479
TEL (714) 468 - 1700
FAX (714) 468 - 1704

Attachment 1

Maximum Individual Cancer Risk Calculations

The nearest residential receptor is located at 15906 Roxford Street. The horizontal distance from the EtO Abator System to this receptor is 420 ft +/- 20 ft. The stack height, the vertical distance from the EtO Abator System to ground level of this receptor, is 59 ft +/- 5 ft. This value takes into account the building height (39 ft) and the grade of the grassy hill which separates the property fenceline and Roxford Street (20 ft +/- 5 ft). This stack height parameter does not exceed the limit of 2.5 times the height of the nearest building (which is approximately equal in height to the Pacesetter building).

MICR Screening:

$$\text{Eqn (1)} \quad \text{MICR} = Q \times (X/Q) \times U \times \text{MP}$$

MICR - Maximum Individual Cancer Risk
Q - Emission Rate of EtO in lb/day
X/Q - EtO Concentration (Tables 3 & 4, Rule 1401)
U - Unit Risk Factor for EtO (Table 1, Rule 1401)
MP - Multiple Pathway Adjustment Factor

Calculations-

$$\text{MICR} = 9.9 \times 10^{-7} \text{ (less than one in one million)}$$

$$X/Q = 0.358 \text{ [ug/m}^3\text{] / [lb/day]}$$


$$U = 0.000088 \text{ [1/(ug/m}^3\text{)]}$$

$$\text{MP} = 1$$

$$9.9 \times 10^{-7} = Q \times 0.358 \times 0.000088 \times 1$$

$$Q = 0.0314 \text{ lbs/day (emissions after control)}$$


$$\text{Usage} = 31.4 \text{ lbs/day}$$



COPYRIGHT © 1987 BY THE BUREAU OF MAPS

SEE MAP

SEE MAP



A 11.6.81 SCALE 1/8" = 1'-0"
 A 11.6.81 BULLETIN #10
 A 11.6.81 BULLETIN #10
 A 11.6.81 BULLETIN #10
 A 11.6.81 BULLETIN #10

PRINTED
 DEC 12 1980
 FEOLA DEENIHAN
 ARCHITECT




**Pacesetter
 Systems, Inc.**

Sylmar, California


Job No.	11.6.81
Drawn By	11.6.81
Checked By	11.6.81
Project No.	11.6.81
Scale	1/8" = 1'-0"

ELEVATIONS


A 3.1



WEST ELEVATION



SOUTH ELEVATION



EAST ELEVATION

ENGINEERING DIVISION...MEMORANDUM

ENGINEERING DIVISION			DATE
TO	FILE	FROM	8-22-91
REFERENCE	AOC.	ST	PERMIT APPL. NO.
SUBJECT			
Pacasetter Systems, Inc. ETO			
TIC Steve Walters.			
The risk of 1.4×10^{-6} is too high, modeling is required.			
Gave him a copy of risk assessment package, wait for his decision.			



A N E N V I R O N M E N T A L E N G I N E E R I N G C O N S U L T I N G F I R M

August 19, 1991

George Rhett
South Coast AQMD
9150 Flair Drive
El Monte, CA 91731

Re: Sterilizer and Abator System Permit Application
#247254, 247255, and 247256 for:
Pacesetter Systems, Inc.
15900 Valley View Court
Sylmar, CA 91342

Dear Mr. Rhett:

Attached is the completed preliminary engineering evaluation for the sterilizers and abator system permit applications for Pacesetter Systems. Per your request, we have provided the report on your computer disk as well. We hope this will help expedite your review of these applications.

If there are any questions, please do not hesitate to call.

Sincerely,

A handwritten signature in cursive script that reads 'Steve Walters'.

Steve Walters
Project Engineer

cc: Chuck Stoddard, Pacesetter Systems
Terry Williams, Pacesetter Systems

3230 FALLOW FIELD DRIVE

SUITE 200, DIAMOND BAR

CA 91765-3479

TEL (714) 468 - 1700

FAX (714) 468 - 1704

CONTENTS

1.0	FACILITY AND EQUIPMENT INFORMATION	2
2.0	BACKGROUND	3
3.0	PROCESS DESCRIPTION	4
4.0	EMISSIONS AND RISK CALCULATIONS	7
5.0	RULE EVALUATIONS	8
6.0	RECOMMENDATIONS	9

1.0 FACILITY AND EQUIPMENT INFORMATION

Applicant: Pacesetter Systems, Inc.

Mailing Address: 12884 Bradley Avenue
Sylmar, CA 91342

Equipment Address: 15900 Valley View Court
Sylmar, CA 91342

Equipment Descriptions:

Application #247254

Ethylene Oxide gas sterilizing system consisting of :

1. Sterilizer, Getinge, Model 8440AR1, with internal chamber dimensions of 35" W x 57" H x 60" L
2. 60 KW electric steam generator with 201,000 Btu/hr output

Application #247255

Ethylene Oxide gas sterilizing system consisting of :

1. Sterilizer, Getinge, Model 8430AR1, with internal chamber dimensions of 26" W x 36" H x 60" L
2. 60 KW electric steam generator with 201,000 Btu/hr output

Application #247256

Air Pollution Control System consisting of :

1. Catalytic Oxidizer - Abator System; Donaldson Company, external dimensions of 7' W x 5' H x 21' L, 80 KW preheater, 1000 scfm centrifugal air blower, and 4 DCI Sure-Sorber catalytic filters with outer dimensions of 24" W x 24" H x 12" L each.

2.0 BACKGROUND

Pacesetter Systems, Inc. manufactures heart pacemakers and their facility is presently located at 12884 Bradley Avenue in Sylmar, CA. Their operations will be completely moved to another facility at 15900 Valley View Court in Sylmar, CA. Pacesetter plans to purchase two new sterilizers and abator system (catalytic oxidizer) to conduct their sterilization operations in this new facility.

These new sterilizers will be constructed in a fire-proof sterilization room at the Valley View facility, and utilize 100% ethylene oxide (EtO) to sterilize components of the pacemakers, pacers and leads. The abator system will control all EtO emissions from the operation of the sterilizers, and has a manufactured efficiency of 99.9%. Complete aeration of the product loads will be conducted inside the sterilizers, so any EtO residue left upon completion of sterilization will be vented to the abator. The room in which the sterilizers are situated will be continuously vented to the abator as well to control any fugitive EtO.

A typical load of product will contain equal quantities of pacers and leads. Pacers are constructed of a Titanium can with an epoxy connector top. Leads are made of silicone tubing over a metal conductor with a connector that fits into the pacer connector on one end and a metal electrode on the other. Each pacer or lead is packaged in two 0.025" thick, vacuum formed XT Polymer trays; the inner tray measures 4.25" x 7.25", and the outer one is 5" x 8". The 32 cubic foot sterilizer will typically hold 400 packages, and the 69 cubic foot unit will hold 1400 packages.

Ethylene oxide is a carcinogenic air contaminant. Permitting and operation of the sterilizers are subject to the requirements of Rules 1401 and 1405, respectively.

Applications for permits to construct/operate the sterilizers and abator system were submitted on April 10, 1991.

3.0 PROCESS DESCRIPTION

The sterilizers use 100% ethylene oxide (EtO) to sterilize components of heart pacemakers: pacers and leads. The total EtO usage is projected to be 5.65 pounds per day for both sterilizers.


Batch loads of pacers and leads are placed in the sterilizers, and experience a 22 hour sterilization cycle. The sequence of operation of the sterilization cycles is as follows:

- a. The load is heated by recirculating the chamber air for a pre-set time period of approximately 20 minutes.
- b. The chamber is evacuated by the vacuum pump at a pre-set rate until a pre-set vacuum level is achieved.
- c. The chamber is held under vacuum for 10 minutes to determine if any leaks exist.
- d. Compressed nitrogen gas is admitted to the chamber at a pre-set pressure. Chamber is re-evacuated, and charged again with nitrogen gas for a pre-set number of pulses.
- e. The load is humidified with pulse injections of steam to a pre-set absolute pressure level.
- f. The load is held at temperature and humidity for a pre-selected pre-conditioning time.
- g. Ethylene oxide (EtO) gas is admitted to the chamber at a pre-set rate until a pre-set pressure is achieved. Nitrogen gas is admitted to chamber at a pre-set rate until a pre-set pressure is achieved. A subsequent charge of nitrogen gas into chamber purges gas lines of EtO.
- h. Chamber pressure is maintained for the pre-selected sterilizing time period.
- i. Primary exhaust of the chamber gases commences through the ventilation system at a pre-set rate to an abator (a catalytic control device) where 99.9% of EtO in the primary chamber exhaust is oxidized to carbon dioxide and water.
- j. Chamber is evacuated to pre-set vacuum level. Nitrogen gas is admitted to chamber at a pre-set rate until pre-set pressure is attained (Steps i & j are repeated at least 2 additional times).
- k. Complete chamber aeration commences by alternating a pre-set number of vacuum and air purges.

1. Air is admitted to the chamber through the bacterial retentive air filter until ambient atmospheric pressure is achieved.

The sterilization chamber is heated by recirculating water through a jacket lining the ceiling, walls, and floor. The water is heated by steam which is provided by a 60 KW electric steam generator with 201,000 Btu/hr output. A centrifugal-type fan is fitted to the roof of the chamber to circulate internal air and gases, and powered by an external electric motor. All chamber air and gases are exhausted through a ventilation system ducted to the ethylene oxide abator system.

In the abator system, the ethylene oxide contaminated air is passed through 4 catalytic filters containing a catalyst made up of a manganese dioxide and copper oxide mixture. The ethylene oxide adsorbs to the catalyst, and is oxidized to carbon dioxide and water according to the following equation:



Prior to introducing EtO to the abator system, there is a preheat cycle of approximately 45 minutes to bring the system to an operating temperature of 300 degrees Fahrenheit (after initial start up, the abator will operate continuously). The fan motor and heater are energized and the dampers are positioned in the preheat mode. The warm air heats up the catalytic beds. When the sensor on the catalytic beds senses a temperature of 300 degrees Fahrenheit, the system will end the preheat cycle and open the EtO feed valve. Due to the release of heat during the oxidation of ethylene oxide, the heater is used very little once the catalytic beds have reached the operating temperature.

Air from the sterilizer chambers and sterilization room are pulled into the abator system by a 1000 scfm centrifugal fan. Any particulate in the incoming air is removed by the Dustfoe prefilters. The air then passes through a recuperative heat exchanger, heating coils, and then into the catalytic beds. The EtO free air proceeds through the fans, and a portion of the discharge is recirculated to the hot side of the recuperative heat exchanger to preheat incoming air. The amount of flow directed to the heat exchanger is controlled depending upon the temperature of the catalytic beds. In addition, a temperature control switch will

close the EtO feed valve should the catalytic bed temperature rise above 550 degrees Fahrenheit.

Safety mechanisms are provided to restrict the EtO feed valve from opening unless the following criteria are satisfied:

1. Catalytic bed temperature at a minimum of 300 degrees Fahrenheit
2. Catalytic bed temperature below 550 degrees Fahrenheit
3. Minimum air flow rate of 900 cfm
4. Safety blow-out pan properly sealed

4.0 EMISSION AND RISK CALCULATIONS

Ethylene Oxide Emission Calculations:

Projected Usage = 1,475 lbs/yr

R1 = uncontrolled emissions
= 5.65 lbs/day (based upon 261 days per year)

R2 = controlled emissions
= 5.65 lbs/day (1 - 0.999)
= 5.65×10^{-3} lbs/day

MICR Screening:

$$\text{Eqn (1)} \quad \text{MICR} = Q \times (X/Q) \times U \times \text{MP}$$

MICR - Maximum Individual Cancer Risk
Q - Emission Rate of EtO in lb/day
X/Q - EtO Concentration (Tables 3 & 4, Rule 1401)
U - Unit Risk Factor for EtO (Table 1, Rule 1401)
MP - Multiple Pathway Adjustment Factor

Calculations-

Q = EtO Usage x (1-abator efficiency)
= 1475 lb/year x 0.1%
= 1.475 lb/year x (1 year/261 days)
= 0.00565 lb/day of EtO emission

X/Q = 3.01 [ug/m3] / [lb/day]

U = 0.000088 [1/(ug/m3)]

MP = 1

MICR = $0.00565 \times 3.01 \times 0.000088 \times 1$
= 1.4×10^{-6}
= 1 in One Million

5.0 RULE EVALUATION

Rule 401. No visible emissions expected.

Rule 402. No nuisance expected.

Rule 1401 Since ethylene oxide is considered a carcinogenic air contaminant, the permitting of the sterilizers is subject to District Rule 1401. The abator system will be considered T-BACT for control of the ethylene oxide emissions from the sterilizers. In order for the Executive Officer to accept the construction of these sterilizers, the maximum individual cancer risk (MICR) resulting from the ethylene oxide emissions can not exceed ten in one million (1×10^{-5}) at any receptor location. The MICR was estimated to be one in one million.

Rule 1405 Per Section d (2), for ethylene oxide usages of more than 400 and less than or equal to 4,000 pounds per calendar year, all exhaust of EtO must be vented an control device with 99.9% efficiency. The abator system is expected to achieve 99.9% efficiency. Provisions of Section d(4) will be met in advance since the sterilizers will utilize 100% ethylene oxide.

Leak tests shall be conducted every six months as specified in paragraph (f), Test Methods. Additionally, records shall be maintained on the results of leak tests, and either the number of sterilizer cycles and the pounds of ethylene oxide used per cycle for each sterilizer each day; or the total pounds of ethylene oxide purchased and used per calendar year, provided that monthly totals are also kept.

Reg XIII The abator system will be considered T-BACT for the sterilizers. The modeling requirement per Rule 1303 for the new facility will not apply since modeling for ROG is currently not required. Additionally, per Rule 1304, offset emissions will not be required given the relocation to the new facility is expected to result in an overall net emission decrease of ROG, and that BACT is applied.

6.0 RECOMMENDATIONS

Sterilizers

Issuance of permits to construct the sterilizers is recommended with the following conditions:

1. Operation of this equipment shall be conducted in accordance with all data and specifications submitted with this application under which a permit is issued unless otherwise noted.
2. This equipment shall be properly maintained and kept in good operating condition at all times.
3. Only one sterilizer may vent its primary chamber exhaust to the abator system at any one time.
4. This equipment must not be operated unless the sterilizer exhaust is vented to an air pollution control device which is in full use and has been issued an permit to construct and/or permit to operate by the Executive Officer.
5. This equipment shall operate in accordance with the requirements of Rule 1405.
6. During the safety qualification trials of the sterilizers, the total quantity of sterilant gas used in this equipment shall not exceed 12 pounds on any one day. Upon completion of the qualification trials, the total quantity of sterilant gas used in this equipment shall not exceed 6 pounds on any one day.
7. The operator shall keep adequate records to verify daily usage of sterilant gas, daily sterilizer cycles, and results of leak tests in a manner approved by the Director of Enforcement in writing. Such records shall be retained at the facility for a period of two years and be made available upon request of the Executive Officer or his representative.

Abator System

Issuance of permits to construct the abator system is recommended with the following conditions:

1. Operation of this equipment shall be conducted in accordance with all data and specifications submitted with this application under which a permit is issued unless otherwise noted.
2. This equipment shall be properly maintained and kept in good operating condition at all times.
3. Within ⁶⁰90 calendar days of initial operation, Pacesetter Systems shall conduct performance tests in accordance with SCAQMD test procedures and furnish the SCAQMD a written result of such performance tests within 30 days of testing. Written notice of the performance tests shall be provided to the SCAQMD 7 days prior to testing so that an observer may be present. A proposal of source testing and analytical methods to be used shall be submitted in writing to the SCAQMD for approval at least 60 prior to testing.

The performance tests shall consist of, but may not be limited to, a test of the inlet and exit streams to the abator system for:

- A. Ethylene oxide in ppm and lbs/hr.
- B. Destruction efficiency.
- C. Flow rate.

The performance tests shall be conducted under maximum loading conditions of the sterilizers. In addition, the usage rates of ethylene oxide shall be recorded, and the abator temperature monitored during the tests.

4. The abator shall be equipped with a gage to verify the catalytic bed temperature is at least 300 degrees Fahrenheit during the operation of the system.



South Coast
AIR QUALITY MANAGEMENT DISTRICT

9150 FLAIR DRIVE, EL MONTE, CA 91731 (818) 572-6200

DATE: 5-15-91

FACESETTER SYSTEMS, INC.
12884 BRADLEY AVENUE
SYLMAR CA 91342

ATTENTION: MR. STEPHEN R. WATERS

The South Coast Air Quality Management District has received your applications and made the following determination:

Appl. No.	Determination Number	Equipment Description
247254	(2)	ETHYLENE OXIDE STERILIZER NO. 1
247255	(2)	ETHYLENE OXIDE STERILIZER NO. 2
247256	(2)	ETO CATALYTIC INCINERATOR

TO BE LOCATED AT

Deter. No. 15900 VALLEY VIEW COURT
SYLMAR CA 91342

- (1) The information you submitted with this application or in your latest submittal is complete; however, some clarifying data may still be needed. The acceptance of your application as complete indicates that sufficient information is on file to begin an evaluation, but does not imply that a permit has been approved.
- (2) The information you submitted with this application or in your latest submittal, is NOT complete. Specific details of the information required to process your application are enclosed. Please submit the requested information by the date shown on the attached form.
- (3) The information submitted with this application is not complete. Additional information was previously requested per District letter dated _____ (copy attached). If specific detailed information as outlined on the attached Additional Information Request Sheet is not submitted by _____, your application may be denied pursuant to Rule 210.

If you have any questions concerning your application, please contact MILTON CHEN at (818) 572-6229.

Very truly yours,

for Dave Schwien
Senior Engineering Manager

MN:ai

SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT

MEMORANDUM

DATE: 5-15-91

TO: MR. STEPHEN R. WALTERS, RQC INC.

FROM: MILTON COHEN, SCAQMD

SUBJECT: ADDITIONAL INFORMATION REQUIRED IN REGARD
TO PALGSETTEN SYSTEMS, INC.

AS PER TELEPHONE CONVERSATION ON 5-15-91
PLEASE SUBMIT THE FOLLOWING:

1. DIMENSIONS OF THE CATALYTIC BED
2. CHEMICAL COMPOSITION OF CATALYTIC BED.
3. MATERIAL COMPOSITION OF STERILIZED PRODUCT AND PACKAGING.
4. STERILIZED PRODUCT AERATION ROOM, DETAILS AND OPERATION, PROVIDED SUCH ROOM IS REQUIRED.
5. INDICATE MAXIMUM NUMBER OF CYCLES ANY ONE STERILIZER WILL OPERATE IN ANY ONE DAY.
6. STATE THE INSTALLATION AND OPERATIONAL STATUS OF AN INOCULATED THING (30 CUBIC FOOT) STERILIZED.

IT

PRESCRIPTION FEE ASSESSMENT SHEET

Company Name : <u>Pacesetter Systems Inc</u>		Small Business ? <u>Yes</u> <input checked="" type="checkbox"/> No <input type="checkbox"/>				
Unit No.	Equipment Description (BEAT or CCAT)	App'l Type	Mult Equip (✓)	50% Penal (✓)	Fee	Comment
7	000289	10			1700	
7	000287	10			1700	
7	06	10			3700	
TOTAL					7100	

Application Type :	50% Penalty Fee
10 P/C (New Construction)	No
15 Banking (ERC)	No
20 P/O (Equip did not need P/C)	No
25 Plan	No
30 P/O no P/C	Yes
40 Change of Ownership	No
50 Alter/Mod - Class I	No
50 Alter/Mod - Class III	Yes
60 Change of Condition	No

REVIEWED BY: R. Kelly UNIT #: 7
 Date Reviewed: 4-14-91 Ext #: 6280

April 10, 1991

South Coast Air Quality Management District
9150 Flair Drive
El Monte, CA 91731

Re: Two Sterilizers and One Abator System Permit Application for
Pacesetter Systems, Inc.
12884 Bradley Avenue
Sylmar, CA 91342

Dear Air Quality Engineer:

Pacesetter Systems manufactures heart pacemakers and is relocating their operation to a new facility site in the same sensitive zone at 15900 Valley View Court, Sylmar. At this facility, there will be a fire proof sterilization room suited for two ethylene oxide (EtO) sterilizers with chamber volumes of 69 and 32 cubic feet. In compliance with the most current rule 1405, Pacesetter will utilize non-CFC base EtO (100% EtO). In addition, all sterilizer emissions and sterilization room air will be vented to a manufacturer guaranteed 99.9% efficient catalytic abator system. This abator system will run continuously, while the sterilizers operate on alternating days throughout the 5 day business week. The EtO usage is projected to be 5.65 pounds per day. After control, this amounts to a maximum of 0.0057 pounds of emission on any given day. ✓

The enclosed application package contains all the necessary information and fees to process the permits. Pacesetter Systems wishes to begin full operation by June 1, 1991, so any effort to expedite the issuance of the Permits to Construct will be appreciated. Please do not hesitate to call with any questions.

Sincerely,
Steve R. Walters
Steve Walters
Environmental Engineer

cc: file

Pacesetter Systems, Inc.

Sterilizer #1 Permit Application Supplemental

1. Equipment Location Drawings: Refer to Attachment #1

2. Equipment Description:

Ethylene Oxide Sterilizer #1, Getinge Model 8440AR1,
35" x 57" x 60" chamber

3. Process Description:

Batch loads of pacemakers and accessories are placed inside a vacuum chamber and experience a 22 hour sterilization cycle:

- a. The load is heated by recirculating the chamber air for a pre-set time period of 20 minutes.
- b. The chamber is evacuated by the vacuum pump at a pre-set rate until a pre-set vacuum level is achieved.
- c. The chamber is held under vacuum for 10 minutes to determine if any leaks exist.
- d. Compressed nitrogen gas is admitted to the chamber at a pre-set pressure. Chamber is re-evacuated, and charged again with nitrogen gas for a pre-set number of pulses.
- e. The load is humidified with pulse injections of steam to a pre-set absolute pressure level.
- f. The load is held at temperature and humidity for a pre-selected pre-conditioning time.
- g. Ethylene oxide (EtO) gas is admitted to the chamber at a pre-set rate until a pre-set pressure is achieved. Nitrogen gas is admitted to chamber at a pre-set rate until a pre-set pressure is achieved. A subsequent charge of nitrogen gas into chamber purges gas lines of EtO.
- h. Chamber pressure is maintained for the pre-selected sterilizing time period.

Pacesetter Systems, Inc.

- i. Chamber gases are exhausted through the ventilation system at a pre-set rate to an abator (a catalytic control device) where 99.9% of EtO is oxidized to carbon dioxide and water.
 - j. Chamber is evacuated to pre-set vacuum level. Nitrogen gas is admitted to chamber at a pre-set rate until pre-set pressure is attained (Steps i & j are repeated at least 2 additional times).
 - k. Complete chamber aeration commences by alternating a pre-set number of vacuum and air purges.
 - l. Air is admitted to the chamber through the bacterial retentive air filter until ambient atmospheric pressure is achieved.
4. Operating Schedule:
Cycle run time of each load is approximately 22 hours; estimate hours for EtO stage is 2 hours.
5. Process Rate:
Nitrogen and EtO gas flow rates are to be determined as appropriate for specific loads.
6. Fuels and Burners Used: N/A
7. Flow Diagram: N/A
8. Equipment Drawings: Refer to Attachment #2
9. Emissions Data:
All EtO emissions from sterilizer and sterilization room are vented to abator. 99.9% of EtO is oxidized to carbon dioxide and water.
10. Air Quality Impact: Risk Screening Analysis

$$\text{Eqn (1) MICR} = Q \times (X/Q) \times U \times MP$$

MICR - Maximum Individual Cancer Risk

Q - Emission Rate of EtO in lb/day

X/Q - EtO Concentration (Tables 3 & 4, Rule 1401)

U - Unit Risk Factor for EtO (Table 1, Rule 1401)

MP - Multiple Pathway Adjustment Factor

Pacesetter Systems, Inc.

Calculations -

$$\begin{aligned} Q &= \text{EtO Usage} \times (\text{1-abator efficiency}) \\ &= 1475 \text{ lb/year} \times 0.1\% \\ &= 1.475 \text{ lb/year} \times (1 \text{ year}/261 \text{ days}) \\ &= 0.0057 \text{ lb/day of EtO emission} \end{aligned}$$

$$X/Q = 3.01 \text{ [ug/m}^3\text{]} / \text{[lb/day]}$$

$$U = 0.000088 \text{ [1/(ug/m}^3\text{)]}$$

$$MP = 1$$

$$\begin{aligned} \text{MICR} &= 0.0057 \times 3.01 \times 0.000088 \times 1 \\ &= 0.000001 \\ &= \underline{1 \text{ in one million}} \end{aligned}$$

Note - the Q value is the projected maximum emission from this facility on any given day given the sterilizers operate on alternate days. Same calculation appears on Sterilizer #2 Supplemental.

NO NEW SOURCE RECORDS FOR THIS CO ID
ENG930 EMISSION THRESHOLD / NEWSOURCE

name: PACESETTER SYSTEMS INC
address: 15900 VALLEY VIEW CT
city: SYLMAR


company id: 085085
date: 04/18/91
user: NS37

INCREASE (+) DECREASE (-) SUBSEQUENT TO 10-8-76



L#	I	M	date	appl	p/o	rl	13	RHC	NOX	SO2	CO	PART	LEAD	UNRHC
								#/day	#/day	#/day	#/day	#/day	#/day	#/day

f1	f2	f3	f4	CN	CONTINUE REFRESH	f7	MAIN
----	----	----	----	----	------------------	----	------

Pacesetter Systems
15900 Valley View Court
Sylmar, CA 91342



Site Plan
SCALE 1" = 80'-0"



SERVICE REQUIREMENTS	
A STEAM	550 LB/HR MAX. 160-80 PSIG 1 1/2" NPT
B COLD WATER	20 GPM MAX. <60°F 40-60 PSIG 1" NPT
C COMP. AIR	3 SCFM MAX. 80-100 PSIG 3/8" NPT
D DRAIN	1 1/2" NPT
E ₁ ELECTRIC CONTROL	120V, 1PH, 60HZ, 5A
E ₂ ELECTRIC POWER	208V, 3PH, 60HZ, 13A 240V, 3PH, 60HZ, 11.8A 480V, 3PH, 60HZ, 5.9A

NOTES

1. If Seismic Restraints are required, (4) 3/4" UNC x 8" LG. SA325 Bolts should be secured (by others) to the floor, through the 7/8" Dia. holes provided in the frame at the indicated locations; suitable anchors must be provided and installed (b/o) to satisfy the following strength requirements:
MAX. TENSILE LOAD (per bolt/anchor) = 2845 Lb.
MAX. SHEAR LOAD (per bolt/anchor) = 2586 Lb.
2. If Seismic Restraints are required, (4) 1/2" - 13 UNC x 8" LG. SA325 Bolts should be secured (by others) to the floor, through the 1" NPT pipe studs provided on the frame at the indicated locations; suitable anchors must be provided and installed (b/o) to satisfy the following strength requirements:
MAX. TENSILE LOAD (per bolt/anchor) = 1968 Lb.
MAX. SHEAR LOAD (per bolt/anchor) = 758 Lb.

GETINGE INTERNATIONAL INC. 1100 TOWBIN AVE. LUXFORD, NJ 08701	
CUTSHEET 35"x57"x60" ARI HI/VAC STERILIZER	
DATE	12/15/97
BY	12/15/97
CHKD	12/15/97
APP'D	12/15/97
REV	1
4444-S80-05	A