

**REPORT OF
AIR POLLUTION SOURCE TESTING
OF AN ETHYLENE OXIDE EMISSION-CONTROL SYSTEM
OPERATED BY STERIGENICS, INC.
IN GRAND PRAIRIE, TEXAS
ON JUNE 9, 2015**

Submitted to:

**TEXAS COMMISSION ON ENVIRONMENTAL QUALITY
P, O. Box 13087
Austin, Texas 78711-3087**

Submitted by:

**STERIGENICS, INC.
1302 Avenue T
Grand Prairie, Texas 75050**

Permit Number 51907

Prepared by:

**ECSi
PO Box 848
San Clemente, California 92674-0848**

Prepared on:

July 9, 2015

ECSi

CONTACT SUMMARY

CLIENT

Ms. Sue Reinhardt
Manager, Environmental Health and Safety
STERIGENICS, INC.
2015 Spring Road, Suite 650
Oak Brook, Illinois 60523

Phone: (630)928-1768
FAX: (630)928-1701
email: sreinhardt@sterigenics.com

FACILITY

Mr. Chris Bonilla
General Manager
STERIGENICS, INC.
1302 Avenue T
Grand Prairie, Texas 75050

Phone: (972)602-9430
FAX: (972)602-7446
email: cbonilla@sterigenics.com

TEST DATE

June 9, 2015

REGULATORY AGENCY

Ms. Sarah Fuchs
Air Permits Division
TEXAS COMMISSION ON ENVIRONMENTAL QUALITY
P. O. Box 13087, MC-163
Austin, Texas 78711-3087

Phone: (512)239-1346
FAX: (512)239-1300
email: sarah.fuchs@tceq.texas.gov

TESTING CONTRACTOR

Daniel P. Kremer
Project Manager
ECSi, Inc.
PO Box 848
San Clemente, California 92674-0848

Phone: (949)400-9145
FAX: (949)281-2169
email: dankremer@ecsi1.com

ECSi

TABLE OF CONTENTS

	<u>PAGE NO.</u>
CONTACT SUMMARY	i
TABLE OF CONTENTS	ii
LIST OF TABLES	iii
LIST OF APPENDICES	iv
1.0 INTRODUCTION	1
2.0 EQUIPMENT	2
3.0 TESTING	3
4.0 RULE/COMPLIANCE REQUIREMENTS	4
5.0 TEST METHOD REFERENCE	5
5.1 Summary/Introduction	5
5.2 Volumetric Flow Measurement	5
5.3 EtO Mass-Emissions Measurement	6
5.4 Sample Transport	6
5.5 GC Injection	6
5.6 GC Conditions	6
5.7 Calibration Standards	7
5.8 Sampling Duration	7
5.9 Mass-Emissions Calculations	8
6.0 TEST SCENARIO	9
7.0 QA/QC	10
7.1 Field Testing Quality Assurance	10
7.2 Calibration Procedures	10
8.0 TEST RESULTS	11
TABLES	12
APPENDICES	15

LIST OF TABLES

<u>TABLE</u>	<u>DESCRIPTION</u>	<u>PAGE NO.</u>
1	Ethylene Oxide Control Efficiency – Backvent	13
2	Ethylene Oxide Control Efficiency – Aeration	14

LIST OF APPENDICES

<u>APPENDIX</u>	<u>DESCRIPTION</u>	<u>PAGE NO.</u>
A	Calibration Data	A-1
B	Run #1 Chromatograms - Backvent	B-1
C	Run #1 Chromatograms - Aeration	C-1
D	Run #2 Chromatograms - Backvent	D-1
E	Run #2 Chromatograms - Aeration	E-1
F	Run #3 Chromatograms - Backvent	F-1
G	Run #3 Chromatograms - Aeration	G-1
H	Field Data and Calculation Worksheets	H-1
I	Calibration Gas Certificates	I-1
J	Process Data	J-1

1.0 INTRODUCTION

On Tuesday, June 9, 2015, ECSi performed air pollution source testing of an ethylene oxide (EtO) emission-control system operated by Sterigenics, Inc. in Grand Prairie, Texas. The control system tested was a Maxon Catalytic Oxidizer, which is used to control emissions from five commercial EtO sterilizer backvents, and one aeration room. The purpose of the testing program was to evaluate continued compliance with the conditions established in the Air Quality Permit granted to Sterigenics, Inc. by the Texas Commission on Environmental Quality (TCEQ).

2.0 EQUIPMENT

The gas-sterilization system is comprised of five commercial sterilizers, all discharging through liquid-ring vacuum pumps to an Advanced Air Technologies packed-tower acid scrubber emission control device. One aeration room and five sterilization chamber backvents are all discharged to a Maxon catalytic oxidizer emission-control device. The gas-sterilization and emission-control equipment currently consists of the following:

- Three Vacudyne commercial ethylene oxide gas sterilizers, each comprised of a steam-heated sterilization chamber (30 pallet capacity), and a Dekker 3-pump oil-sealed liquid ring recirculating vacuum pump skid (two 50 hp liquid ring pumps, plus one 25 hp booster pump);
- Two Trumbo commercial ethylene oxide gas sterilizers, each comprised of a steam-heated sterilization chamber (30 pallet capacity), and a Dekker 3-pump oil-sealed liquid ring recirculating vacuum pump skid (one 50 hp liquid ring pump, plus one 25 hp booster pump);
- One 12,200 square foot aeration room, comprised of a heated aeration chamber and an exhaust system.

Sterilizer vacuum pump emissions are controlled by:

- One Advanced Air Technologies Safe Cell I emission-control system, comprised of a packed-tower chemical scrubber, equipped with a packed reaction/interface column, a scrubber fluid recirculation system (2 recirculation pumps - 1 primary and 1 backup - each @ 350 gpm and 15 hp), and two scrubber fluid reaction/storage tanks.

Aeration and backvent emissions are controlled by:

- One Maxon catalytic oxidizer, 15,000 SCFM, equipped with a prefilter, a gas-fired heater, a reactive catalyst bed, and an exhaust blower.

3.0 TESTING

EtO source testing was conducted in accordance with the procedures outlined in USEPA CFR40, Part 63.365. EtO emissions monitoring for each test run was conducted simultaneously at the inlet and outlet of the catalytic oxidizer during chamber backvent, and during a one-hour interval of the 24-hour aeration process. A total of three chamber backvent test runs, and three one-hour aeration test runs, were performed.

During backvent and aeration testing, EtO emissions at the inlet and the outlet of the catalytic oxidizer were determined using direct source sample injection into the gas chromatograph (GC). All backvent and aeration testing was performed using freshly sterilized product. The testing program was conducted in accordance with the procedures outlined in the following sections.

4.0 RULE/COMPLIANCE REQUIREMENTS

The EtO gas-sterilization system at Sterigenics, Inc. was tested to evaluate compliance with the requirements specified in the TCEQ Permit. The current testing was performed to demonstrate continued compliance with the following requirement:

- Aeration and backvent emissions must be discharged to control equipment which achieves an EtO emission-reduction efficiency of at least 99.0% by weight, or an outlet EtO concentration of no greater than 1 ppmv.

Testing is required to demonstrate compliance with these requirements. Source testing of the emission-control device is required initially, and may be required periodically thereafter.

5.0 TEST METHOD REFERENCE

5.1 INTRODUCTION

The testing procedures outlined herein are based on USEPA source-sampling methods. EtO control efficiency and mass-emissions testing were conducted by USEPA CFR40, Part 63.365, and in accordance with TCEQ requirements. EtO emissions monitoring for each test run was conducted simultaneously at the inlet and outlet of the catalytic oxidizer during chamber backvent, and during a one-hour interval of the 24-hour aeration process. A total of three chamber backvent test runs, and three one-hour aeration test runs, were performed.

During backvent and aeration testing, EtO emissions at the inlet and the outlet of the catalytic oxidizer were determined using direct source sample injection into the gas chromatograph (GC). All backvent and aeration testing was performed using freshly sterilized product.

Operation and documentation of process conditions was performed by personnel from Sterigenics, Inc. using existing monitoring instruments installed by the manufacturer of the equipment to be tested. In accordance with TCEQ requirements, and the procedures established in USEPA CFR40, Part 63, Subpart O, the following parameter was recorded: catalyst bed operating temperature. This data is attached to this report as Appendix J.

5.2 VOLUMETRIC FLOW MEASUREMENT

Exhaust gas flow at the outlet of the catalytic oxidizer was determined by EPA Method 2C using a standard pitot tube and an inclined-oil manometer. Sampling ports were installed in accordance with EPA Method 1, and were located far enough from any flow disturbances to permit accurate flow measurement.

Temperature measurements were obtained from a type K thermocouple and thermometer attached to the sampling probe. Exhaust gas composition was assumed to be air and small amounts of water vapor. Water vapor was negligible, at about 3 percent.

5.3

CONTROL EFFICIENCY AND MASS EMISSIONS MEASUREMENT

During backvent and aeration testing, EtO emissions at the inlet and outlet of the catalytic oxidizer were determined using direct source sample injection into the GC. The mass of EtO emitted to the inlet and from the outlet was determined using the equation shown below in Section 5.9. Mass-mass control-efficiency of EtO during the backvent and aeration phases was calculated by comparing the mass of EtO vented to the system inlet to the mass of EtO vented from the system outlet.

During the backvent and aeration phases, vented gas was analyzed by an SRI, Model 8610, portable gas chromatograph (GC), equipped with the following: dual, heated sample loops and injectors; dual columns; and dual detectors. A flame ionization detector (FID) was used to quantify inlet EtO emissions, and a photoionization detector (PID) was used to quantify low-level EtO emissions at the emission-control device outlet.

5.4

SAMPLE TRANSPORT

Source gas was pumped to the GC at approximately 1000 cubic centimeters per minute (cc/min) from the sampling ports through two lengths of Teflon® sample line, each with a nominal volume of approximately 75 cubic centimeters (cc) and an outer diameter of 0.25 inch. At the inlet, the sampling port was located in the common backvent/aeration discharge duct, upstream of the oxidizer. At the outlet of the catalytic oxidizer, sampling ports were located in the exhaust stack downstream of the catalyst bed.

5.5

GC INJECTION

Source-gas samples were then injected into the GC which was equipped with two heated sampling loops, each containing a volume of approximately 2cc and maintained at 100 degrees Celsius (C). Injections occurred at approximately five minute intervals during the aeration-phase testing. Helium was the carrier gas for both the FID and PID.

5.6

GC CONDITIONS

The packed columns for the GC were both operated at 80 degrees C. The columns were stainless steel, 6 feet long, 0.125 inch outer diameter, packed with 1 percent SP-1000 on 60/80 mesh Carbopack B.

During the analysis, the FID was operated at 250 degrees C. The support gases for the FID were helium (99.999% pure), hydrogen (99.995% pure) and air (99.9999% pure). Any unused sample gas was vented from the GC system back to the inlet of the control device being tested.

5.7 CALIBRATION STANDARDS

The FID was calibrated for mid-range part-per-million-by-volume (ppmv) level analysis using gas proportions similar to the following:

- 1) 100 ppmv EtO, balance nitrogen
- 2) 50 ppmv EtO, balance nitrogen (audit gas)
- 3) 10 ppmv EtO, balance nitrogen
- 4) 1 ppmv EtO, balance nitrogen

The PID was calibrated for low-range ppmv level analyses using gas proportions similar to the following:

- 1) 100 ppmv EtO, balance nitrogen
- 2) 50 ppmv EtO, balance nitrogen (audit gas)
- 3) 10 ppmv EtO, balance nitrogen
- 4) 1 ppmv EtO, balance nitrogen

Each of these calibration standards was in a separate, certified manufacturer's cylinder. Copies of the calibration gas laboratory certificates are attached as Appendix I.

5.8 SAMPLING DURATION

Backvent testing was performed in conjunction with normal production operations, during the chamber exhaust venting which is conducted for each sterilization chamber upon conclusion of the sterilization cycle, immediately prior to and during chamber unloading. Backvent sampling duration was 15 minutes for each of the three test runs.

Since aeration is a 24-hour process at this facility, with constant discharge flow from the aeration chambers to the emission-control system, aeration testing consisted of three 1-hour test runs. Each test run was performed with freshly sterilized product in the aeration chambers.

5.9

CONTROL-EFFICIENCY/MASS-EMISSIONS CALCULATIONS

Mass emissions of EtO during aeration were calculated using the following equation:

$$\text{MassRate} = (\text{VolFlow})(\text{MolWt})(\text{ppmv EtO}/10^6)/(\text{MolVol})$$

Where:

- MassRate = EtO mass flow rate, pounds per minute
VolFlow = Corrected volumetric flow rate, standard cubic feet per minute at 68 degrees F
MolWt = 44.05 pounds EtO per pound mole
ppmv EtO = EtO concentration, parts per million by volume
 10^6 = Conversion factor, ppmv per "cubic foot per cubic foot"
MolVol = 385.32 cubic feet per pound mole at one atmosphere and 68 degrees F

Mass-mass control efficiency of EtO was calculated for backvent and aeration. Results of the control-efficiency testing are presented in Tables 1 and 2.

6.0 TEST SCENARIO

The backvent and aeration testing was performed during normal process load conditions. Three backvent and three aeration test runs were conducted in series to verify the performance of the emission-control device. The testing schedule was as follows:

- 1) Testing equipment was set up and calibrated.
- 2) Backvent Phase Test Run #1 was conducted with one freshly sterilized production load. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 3) Aeration Phase Test Run #1 was conducted with freshly sterilized product in aeration. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 4) Backvent Phase Test Run #2 was conducted with one freshly sterilized production load. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 5) Aeration Phase Test Run #2 was conducted with freshly sterilized product in aeration. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 6) Backvent Phase Test Run #3 was conducted with one freshly sterilized production load. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 7) Aeration Phase Test Run #3 was conducted with freshly sterilized product in aeration. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 8) Post calibration check was performed, testing equipment was packed.

7.0 QA/QC

7.1 FIELD TESTING QUALITY ASSURANCE

At the beginning of the test, the sampling system was leak checked at a vacuum of 15 inches of mercury. The sampling system was considered leak free when the flow indicated by the rotameters fell to zero.

At the beginning of the test, a system blank was analyzed to ensure that the sampling system was free of EtO. Ambient air was introduced at the end of the heated sampling line and drawn through the sampling system line to the GC for analysis. The resulting chromatogram also provided a background level for non-EtO components (i.e. ambient air, carbon dioxide, water vapor) which are present in the source gas stream due to the ambient dilution air which is drawn into the emission-control device, and due to the destruction of EtO by the emission-control device which produces carbon dioxide and water vapor. This chromatogram, designated AMB, is included with the calibration data in Appendix A.

7.2 CALIBRATION PROCEDURES

The GC system was calibrated at the beginning and conclusion of each day's testing. Using the Peaksimple II analytical software, a point-to-point calibration curve was constructed for each detector. A gas cylinder of similar composition as the calibration gases, but certified by a separate supplier, was used to verify calibration gas composition and GC performance.

All calibration gases and support gases used were of the highest purity and quality available. A copy of the laboratory certification for each calibration gas is attached as Appendix I.

8.0 TEST RESULTS

The catalytic oxidizer was found to have an average EtO control efficiency of 99.96 percent for backvent, and an average EtO control efficiency of 99.93 percent for aeration. In accordance with state and federal requirements, backvent and aeration discharge streams must be vented to control equipment with an EtO emission-reduction efficiency of at least 99 percent by weight. The catalytic oxidizer met this requirement.

The test results are summarized in Tables 1 and 2. These tables include results for EtO control efficiency of the emission-control device. Chromatograms and chromatographic supporting data are attached as Appendices A through G. Copies of field data and calculation worksheets are attached as Appendix H.

TABLES

TABLE 1
ETHYLENE OXIDE CONTROL EFFICIENCY - BACKVENT
OF AN ETHYLENE OXIDE EMISSION CONTROL DEVICE
OPERATED BY STERIGENICS, INC.
IN GRAND PRAIRIE, TEXAS
ON JUNE 9, 2015

RUN NUMBER	INJECTION TIME	INLET ETO CONC. (PPM)(1)	OUTLET ETO CONC. (PPM)(2)	ETO CONTROL EFFICIENCY
1(3)	1339	18.3	0.01	99.9454
1	1340	118	0.01	99.9915
1	1342	80.2	0.01	99.9875
1	1343	46.8	0.01	99.9786
1	1344	32.1	0.01	99.9688
1	1345	23.8	0.01	99.9580
1	1346	23.7	0.01	99.9578
1	1347	21.1	0.01	99.9526
1	1349	19.5	0.01	99.9487
1	1350	18.9	0.01	99.9471
1	1351	12.1	0.01	99.9174
1	1353	9.99	0.01	99.8999
2(4)	1528	15.9	0.01	99.9371
2	1529	96.2	0.01	99.9896
2	1531	58.7	0.01	99.9830
2	1532	40.9	0.01	99.9756
2	1533	29.0	0.01	99.9655
2	1534	25.0	0.01	99.9600
2	1535	22.6	0.01	99.9558
2	1537	21.1	0.01	99.9526
2	1538	18.4	0.01	99.9457
2	1539	19.1	0.01	99.9476
2	1541	11.8	0.01	99.9153
2	1542	11.5	0.01	99.9130
3(5)	1659	17.5	0.01	99.9429
3	1700	53.6	0.01	99.9813
3	1701	85.0	0.01	99.9882
3	1702	61.6	0.01	99.9838
3	1703	43.6	0.01	99.9771
3	1704	38.1	0.01	99.9738
3	1705	31.3	0.01	99.9681
3	1706	28.1	0.01	99.9644
3	1708	25.9	0.01	99.9614
3	1709	25.7	0.01	99.9611
3	1710	24.8	0.01	99.9597
3	1711	<u>22.3</u>	<u>0.01</u>	<u>99.9552</u>
TIME-WEIGHTED AVERAGE:		34.78	0.0100	99.9586
NYDEQ REQUIRED CONTROL EFFICIENCY:				99%

Notes:

- (1) - PPM = parts per million by volume
- (2) - 0.01 ppm is the quantification limit for the detector used at the outlet.
- (3) - Backvent Phase Test Run #1 started at 13:39, ended at 13:54.
- (4) - Backvent Phase Test Run #2 started at 15:27, ended at 15:42.
- (5) - Backvent Phase Test Run #3 started at 16:57, ended at 17:12.
- (6) - During backvent testing, the average recorded catalyst bed temperature was 305 deg F

ECSi

TABLE 2
ETHYLENE OXIDE CONTROL EFFICIENCY - AERATION
OF AN ETHYLENE OXIDE EMISSION CONTROL DEVICE
OPERATED BY STERIGENICS, INC.
IN GRAND PRAIRIE, TEXAS
ON JUNE 9, 2015

RUN NUMBER	INJECTION TIME	INLET ETO CONC. (PPM)(1)	OUTLET ETO CONC. (PPM)(2)	ETO CONTROL EFFICIENCY
1(3)	1357	11.2	0.01	99.9107
1	1402	10.8	0.01	99.9074
1	1407	11.8	0.01	99.9153
1	1412	11.8	0.01	99.9153
1	1417	12.7	0.01	99.9213
1	1422	12.5	0.01	99.9200
1	1427	12.9	0.01	99.9225
1	1432	12.9	0.01	99.9225
1	1437	13.4	0.01	99.9254
1	1442	14.5	0.01	99.9310
1	1447	13.4	0.01	99.9254
1	1452	14.8	0.01	99.9324
2(4)	1545	12.3	0.01	99.9187
2	1550	13.2	0.01	99.9242
2	1555	13.4	0.01	99.9254
2	1600	12.9	0.01	99.9225
2	1605	13.6	0.01	99.9265
2	1610	14.9	0.01	99.9329
2	1615	15.3	0.01	99.9346
2	1620	15.7	0.01	99.9363
2	1625	17.9	0.01	99.9441
2	1630	16.6	0.01	99.9398
2	1635	17.1	0.01	99.9415
2	1640	16.4	0.01	99.9390
3(5)	1715	21.9	0.01	99.9543
3	1720	19.5	0.01	99.9487
3	1725	19.5	0.01	99.9487
3	1730	20.2	0.01	99.9505
3	1735	17.5	0.01	99.9429
3	1740	18.2	0.01	99.9451
3	1745	20.0	0.01	99.9500
3	1750	19.6	0.01	99.9490
3	1755	19.4	0.01	99.9485
3	1800	20.3	0.01	99.9507
3	1805	20.1	0.01	99.9502
3	1810	21.0	0.01	<u>99.9524</u>
TIME-WEIGHTED AVERAGE:		15.81	0.0100	99.9340
NYDEQ REQUIRED CONTROL EFFICIENCY:				99%

Notes:

- (1) - PPM = parts per million by volume
- (2) - 0.01 ppm is the quantification limit for the detector used at the outlet.
- (3) - Aeration Phase Test Run #1 started at 13:55, ended at 14:55.
- (4) - Aeration Phase Test Run #2 started at 15:43, ended at 16:43.
- (5) - Aeration Phase Test Run #3 started at 17:13, ended at 18:13.
- (6) - During aeration testing, the average recorded catalyst bed temperature was 305 deg F

ECSI


APPENDICES

APPENDIX A

Calibration Data

ak	Name	Start	End	Calibration	Int.Std	Units
	Dead Vol / Air	0.000	0.350		0.000	
	Ambient H2O	0.350	0.480		0.000	
	Ethylene Oxide	0.480	0.600	C:\peak359\1Ster	0.00015	.ppm
	Acetaldehyde	0.600	0.800		0.000	
	CO2	0.800	1.000		0.000	

AREA



slope of curve: 0.09

axis intercept: 0.00

earity: 1.00

nber of levels: 4

/rel SD of CF's: 0.0/66.7

0.0861X


1.0000

t calibrated: Tue Jun 09 08:22:18 2015

Area/ht.	Amount	CF	Current	Previous #1	Previous #2
0.000	0.000	0.000	0.000	N/A	N/A
0.096	1.100	0.087	0.096	N/A	N/A
0.880	10.100	0.087	0.880	N/A	N/A
8.380	100.000	0.084	8.380	N/A	N/A

ak	Name	Start	End	Calibration	Int.Std	Units
	Dead Vol / Air	0.000	0.350		0.000	
	Ambient H2O	0.350	0.480		0.000	
	Ethylene Oxide	0.480	0.600	C:\peak359\2Ster	0.00015	.ppm
	Acetaldehyde	0.600	0.800		0.000	
	CO2	0.800	1.000		0.000	

AREA



; slope of curve: 1.59

xis intercept: -0.00

earity: 1.00

nber of levels: 4

'rel SD of CF's: 0.8/66.8


1.5915X

1.0000

t calibrated: Tue Jun 09 08:21:39 2015


Area/ht.	Amount	CF	Current	Previous #1	Previous #2
0.000	0.000	0.000	0.000	N/A	N/A
1.750	1.100	1.591	1.750	N/A	N/A
16.600	10.100	1.644	16.600	N/A	N/A
154.000	100.000	1.540	154.000	N/A	N/A

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:51:49
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-Amb.CHR (c:\peak359)
 Sample: Ambient Background
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.1340	0.0000	
		1.1340	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:51:49
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-Amb.CHR (c:\peak359)
 Sample: Ambient Background
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.133	14.2240	0.0000	
Ambient H2O	0.400	43.6690	0.0000	
		57.8930	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:54:35
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C01.CHR (c:\peak359)
 Sample: 1.10 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	0.0670	0.0000	
Ethylene Oxide	0.500	0.0970	0.0000	ppm
		0.1640	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:54:35
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C01.CHR (c:\peak359)
 Sample: 1.10 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.300	14.6495	0.0000	
Ethylene Oxide	0.516	1.7495	0.0000	ppm
Acetaldehyde	0.766	0.1175	0.0000	
CO2	0.866	0.0085	0.0000	
		16.5250	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:55:56
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.term
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C02.CHR (c:\peak359)
 Sample: 1.10 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	0.0560	0.0000	
Ethylene Oxide	0.516	0.0950	0.0000	ppm
		0.1510	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:55:56
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.term
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C02.CHR (c:\peak359)
 Sample: 1.10 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	0.2570	0.0000	
Ethylene Oxide	0.533	1.7485	0.0000	ppm
Acetaldehyde	0.750	0.0650	0.0000	
		2.0705	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:58:28
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C03.CHR (c:\peak359)
 Sample: 10.1 ppm EtO std
 Operator: D. Kremer



Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:58:28
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C03.CHR (c:\peak359)
 Sample: 10.1 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External Units
Ethylene Oxide	0.500	0.8695	0.0000 ppm
		0.8695	0.0000

Component	Retention	Area	External Units
Dead Vol / Air	0.300	0.2280	0.0000
Ethylene Oxide	0.533	16.4560	0.0000 ppm
Acetaldehyde	0.700	0.0580	0.0000
CO2	0.833	0.0565	0.0000


16.7985 0.0000

Lab Name: ECOI
 Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:59:50
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C04.CHR (c:\peak359)
 Sample: 10.1 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	0.0600	0.0000	
Ethylene Oxide	0.516	0.8835	0.0000	ppm
		0.9435	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 07:59:50
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C04.CHR (c:\peak359)
 Sample: 10.1 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	1.8370	0.0000	
Ethylene Oxide	0.533	16.6100	0.0000	ppm
Acetaldehyde	0.683	0.2460	0.0000	
unknown	0.883	0.0280	0.0000	
CO2			18.7210	0.0000

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 08:02:02
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carboback B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C05.CHR (c:\peak359)
 Sample: 100 ppm EtO std
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 08:02:02
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carboback B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C05.CHR (c:\peak359)
 Sample: 100 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.500	8.3160	0.0000	ppm
		8.3160	0.0000	

Component	Retention	Area	External	Units
Dead Vol / Air	0.150	0.4560	0.0000	
Ethylene Oxide	0.516	150.6320	0.0000	ppm
Acetaldehyde	0.783	0.2130	0.0000	
CO2	0.883	0.1900	0.0000	
		151.4910	0.0000	

Lab name: ECO
 Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 08:05:19
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C06.CHR (c:\peak359)
 Sample: 100 ppm EtO std
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 08:05:19
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C06.CHR (c:\peak359)
 Sample: 100 ppm EtO std
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.066	0.1380	0.0000	
Ethylene Oxide	0.516	8.4345	0.0000 ppm	
		8.5725	0.0000	


Component	Retention	Area	External	Units
Dead Vol / Air	0.100	0.2250	0.0000	
Ethylene Oxide	0.533	157.0555	0.0000 ppm	
Acetaldehyde	0.766	0.1230	0.0000	
CO2	0.883	0.2450	0.0000	
		157.6485	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 08:20:46
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto1-100.cpt
 Data file: 1SterGP2015-C07.CHR (c:\peak359)
 Sample: 48.8 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	0.0870	0.0000	
Ethylene Oxide	0.516	4.2340	49.1941	ppm
Total	4.3210	49.1941		

Client: Sterigenics - Grand Prairie
 Client ID: PreCal
 Analysis date: 06/09/2015 08:20:46
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: C:\peak359\eto-100.tem
 Components: eto2-100.cpt
 Data file: 2SterGP2015-C07.CHR (c:\peak359)
 Sample: 48.8 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	3.0715	0.0000	
Ethylene Oxide	0.533	77.8065	48.8891	ppm
Acetaldehyde	0.733	1.3115	0.0000	
CO2	0.900	0.1980	0.0000	
Total	82.3875	48.8891		

Client: Sterigenics - Grand Prairie
 Client ID: PostCal
 Analysis date: 06/09/2015 17:39:21
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-C08.CHR (c:\peak359)
 Sample: 48.8 ppm EtO std
 Operator: D. Kremer



Component	Retention	Area	External	Units
Ethylene Oxide	0.183	0.1510	0.0000	
Ethylene Oxide	0.533	4.1905	48.6887	ppm
		4.3415	48.6887	

Client: Sterigenics - Grand Prairie
 Client ID: PostCal
 Analysis date: 06/09/2015 17:39:21
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-C08.CHR (c:\peak359)
 Sample: 48.8 ppm EtO std
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	7.9350	0.0000	
Ambient H2O	0.433	0.2010	0.0000	
Ethylene Oxide	0.550	77.3785	48.6201	ppm
Acetaldehyde	0.750	0.2920	0.0000	
CO2	0.883	0.2600	0.0000	
		86.0665	48.6201	

APPENDIX B


Run #1 Chromatograms - Backvent

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:39:49
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B01.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0130	0.0000	
ethylene Oxide	0.516	1.5730	18.2764 ppm	
		2.5860	18.2764	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:39:49
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B01.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.066	5.8695	0.0000	
Ambient H2O	0.416	78.2180	0.0000	
		84.0875	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:40:55
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B02.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
ad Vol / Air	0.250	0.9370	0.0000	
Ethylene Oxide	0.533	10.1560	118.0009	ppm
		11.0930	118.0009	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:40:55
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B02.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	71.2335	0.0000	
		71.2335	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:42:01
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B03.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
ad Vol / Air	0.233	1.0025	0.0000	
Ethylene Oxide	0.516	6.9060	80.2397 ppm	
		7.9085	80.2397	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:42:01
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B03.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	12.3020	0.0000	
Acetaldehyde	0.600	4.1245	0.0000	
		16.4265	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:43:07
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B04.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:43:07
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B04.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Vol / Air	0.233	1.0310	0.0000	
Ethylene Oxide	0.533	4.0320	46.8471 ppm	
		5.0630	46.8471	


Component	Retention	Area	External	Units
Ambient H2O	0.416	12.1600	0.0000	
Acetaldehyde	0.600	3.7540	0.0000	
CO2	0.883	0.1150	0.0000	
		16.0290	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:44:12
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B05.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.233	1.0095	0.0000	
	0.516	2.7610	32.0796 ppm	
		3.7705	32.0796	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:44:12
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B05.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	13.8950	0.0000	
Acetaldehyde	0.600	3.8860	0.0000	
		17.7810	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 nalysis date: 06/09/2015 13:45:31
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbo pack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B06.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.250	1.0115	0.0000	
	0.516	2.0460	23.7721	ppm
	3.0575	23.7721		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 nalysis date: 06/09/2015 13:45:31
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbo pack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B06.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	73.0860	0.0000	
	73.0860	73.0860	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:46:37
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B07.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	0.9960	0.0000	
Ethylene Oxide	0.516	2.0365	23.6618 ppm	
	3.0325	23.6618		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:46:37
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B07.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	69.9290	0.0000	
	69.9290	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:47:45
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B08.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0080	0.0000	
Ethylene Oxide	0.533	1.8145	21.0824	ppm
	2.8225	21.0824		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:47:45
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B08.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.4240	0.0000	
Ambient H2O	0.416	9.4340	0.0000	
	16.8580	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:49:11
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B09.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.216	1.4000	0.0000	
Ethylene Oxide	0.516	1.6800	19.5196	ppm
	3.0800	19.5196		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:49:11
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B09.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	6.3920	0.0000	
Ambient H2O	0.400	63.9990	0.0000	
	70.3910	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:50:35
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B10.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.233	1.4010	0.0000	
	0.533	1.6300	18.9387	ppm
		3.0310	18.9387	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:50:35
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B10.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	6.7360	0.0000	
Ambient H2O	0.416	68.4950	0.0000	
		75.2310	0.0000	

Lab Name: ECO
 Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:51:49
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: etc-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B11.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	0.9660	0.0000	
Ethylene Oxide	0.516	1.0440	12.1301	ppm
	2.0100	2.0100	12.1301	

Lab Name: ECO
 Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:51:49
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: etc-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B11.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	6.9200	0.0000	
Ambient H2O	0.450	73.3035	0.0000	
	80.2235	80.2235	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:53:29
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1B12.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0110	0.0000	
Ethylene Oxide	0.516	0.8600	9.9922	ppm
		1.8710	9.9922	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1BV
 Analysis date: 06/09/2015 13:53:29
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1B12.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.6655	0.0000	
Ambient H2O	0.416	62.2150	0.0000	
		69.8805	0.0000	


APPENDIX C

Run #1 Chromatograms - Aeration

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 13:57:13
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A01.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 13:57:13
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A01.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Vol / Air	0.233	1.0475	0.0000	
Ethylene Oxide	0.516	0.9610	11.1657	ppm
		2.0085	11.1657	


Component	Retention	Area	External	Units
Ambient H2O	0.416	69.1280	0.0000	
External Units	0.0000	69.1280	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:02:38
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A02.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.233	0.9960	0.0000	
Ethylene Oxide	0.516	0.9270	10.7707	ppm
	1.9230	10.7707		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:02:38
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A02.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	5.8570	0.0000	
Ambient H2O	0.416	67.5880	0.0000	
	5.8570	0.8570	73.4450	0.0000

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:07:08
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A03.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0230	0.0000	
Ethylene Oxide	0.516	1.0170	11.8164 ppm	
		2.0400	11.8164	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:07:08
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A03.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	6.2760	0.0000	
Ambient H2O	0.416	70.3690	0.0000	
		76.6450	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:12:11
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carboback B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A04.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	0.9850	0.0000	
Ethylene Oxide	0.516	1.0195	11.8454	ppm
		2.0045	11.8454	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:12:11
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carboback B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A04.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	9.3160	0.0000	
Ambient H2O	0.400	70.9190	0.0000	
		80.2350	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:17:37
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carboback B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A05.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.2860	0.0000	
Ethylene Oxide	0.516	1.0960	12.7342 ppm	
	2.3820	12.7342		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:17:37
 Method: Direct injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carboback B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A05.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	7.2230	0.0000	
Ambient H2O	0.400	71.4670	0.0000	
	78.6900	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:22:46
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A06.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9820	0.0000	
Ethylene Oxide	0.516	1.0780	12.5251	ppm
		2.0600	12.5251	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:22:46
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A06.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	6.8830	0.0000	
Ambient H2O	0.416	70.4990	0.0000	
		77.3820	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:27:05
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A07.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.250	1.0125	0.0000	
Ethylene Oxide	0.533	1.1080	12.8737	ppm
	2.1205	12.8737		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:27:05
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A07.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.116	7.0480	0.0000	
Ambient H2O	0.433	70.9820	0.0000	
	78.0300	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 nalysis date: 06/09/2015 14:32:06
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbo pack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A08.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 nalysis date: 06/09/2015 14:32:06
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbo pack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A08.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Ethylene Oxide	0.216	1.3810	0.0000	
Ethylene Oxide	0.516	1.1110	12.9085 ppm	
		2.4920	12.9085	


Component	Retention	Area	External	Units
Ambient H2O	0.066	6.5800	0.0000	
Ambient H2O	0.416	70.0090	0.0000	
		76.5890	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:37:06
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A09.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ethylene Oxide	0.233	1.0135	0.0000	
	0.516	1.1530	13.3965 ppm	
		2.1665	13.3965	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:37:06
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A09.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	8.5010	0.0000	
Ambient H2O	0.416	71.9060	0.0000	
		80.4070	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:42:46
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A10.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:42:46
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbpak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A10.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9870	0.0000	
Ethylene Oxide	0.516	1.2520	14.5468 ppm	
		2.2390	14.5468	


Component	Retention	Area	External	Units
Dead Vol / Air	0.150	8.7550	0.0000	
Ambient H2O	0.416	72.7760	0.0000	
		81.5310	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:47:05
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A11.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9990	0.0000	
Ethylene Oxide	0.516	1.1520	13.3849	ppm
	2.1510	13.3849		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:47:05
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A11.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	15.2655	0.0000	
Ambient H2O	0.416	71.0450	0.0000	
		86.3105	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:52:04
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-1A12.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0080	0.0000	
Ethylene Oxide	0.516	1.2700	14.7559 ppm	
	2.2780	14.7559		

Client: Sterigenics - Grand Prairie
 Client ID: Run#1Aer
 Analysis date: 06/09/2015 14:52:04
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-1A12.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.033	12.6990	0.0000	
Ambient H2O	0.416	73.7150	0.0000	
	86.4140	0.0000		

APPENDIX D


Run #2 Chromatograms - Backvent

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:28:14
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B01.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0885	0.0000	
Ethylene Oxide	0.516	1.3685	15.9004	ppm
		2.4570	15.9004	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:28:14
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B01.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	7.3590	0.0000	
Ambient H2O	0.416	76.1560	0.0000	
		83.5150	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:29:23
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B02.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
ad Vol / Air	0.233	1.0560	0.0000	
Ethylene Oxide	0.516	8.2835	96.2446	ppm
		9.3395	96.2446	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:29:23
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B02.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	6.2180	0.0000	
		6.2180	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:31:03
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B03.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0210	0.0000	
Ethylene Oxide	0.516	5.0480	58.6519 ppm	
		6.0690	58.6519	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:31:03
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPak B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B03.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.050	20.8805	0.0000	
Ambient H2O	0.416	68.1500	0.0000	
		89.0305	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:32:08
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B04.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External Units
Vol / Air	0.233	1.0470	0.0000
Ethylene Oxide	0.516	3.5205	40.9041 ppm
		4.5675	40.9041

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:32:08
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B04.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External Units
Ambient H2O	0.416	72.2560	0.0000
		72.2560	0.0000

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 analysis date: 06/09/2015 15:33:23
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B05.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
1 Vol / Air	0.250	1.0300	0.0000	
Ethylene Oxide	0.516	2.4920	28.9541 ppm	
	3.5220	3.5220	28.9541	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:33:23
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B05.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.450	76.1810	0.0000	
	76.1810	76.1810	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:34:37
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B06.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:34:37
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B06.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Total Vol / Air	0.233	1.0290	0.0000	
ethylene Oxide	0.516	2.1500	24.9805 ppm	
		3.1790	24.9805	


Component	Retention	Area	External	Units
Ambient H2O	0.466	75.1460	0.0000	
		75.1460	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:35:51
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B07.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	1.0170	0.0000	
Ethylene Oxide	0.533	1.9430	22.5754	ppm
	2.9600	22.5754		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:35:51
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B07.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.450	72.1000	0.0000	
	72.1000	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:37:02
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B08.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.1120	0.0000	
Ethylene Oxide	0.500	1.8140	21.0766	ppm
	2.9260	21.0766		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:37:02
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B08.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.2260	0.0000	
Ambient H2O	0.400	75.4135	0.0000	
	82.6395	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:38:19
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B09.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0410	0.0000	
Ethylene Oxide	0.516	1.5875	18.4449 ppm	
	2.6285	2.6285	18.4449	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:38:19
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B09.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.7740	0.0000	
Ambient H2O	0.433	74.5940	0.0000	
	82.3680	82.3680	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:39:33
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B10.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9985	0.0000	
Ethene Oxide	0.516	1.6430	19.0897 ppm	
	2.6415	2.6415	19.0897	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:39:33
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B10.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.2975	0.0000	
Ambient H2O	0.433	74.8395	0.0000	
	82.1370	82.1370	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 alysis date: 06/09/2015 15:41:01
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B11.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.1330	0.0000	
Ethene Oxide	0.516	1.0155	11.7989	ppm
	2.1485	2.1485	11.7989	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:41:01
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B11.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	6.3410	0.0000	
Ambient H2O	0.400	69.8250	0.0000	
	76.1660	76.1660	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 alysis date: 06/09/2015 15:42:10
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2B12.CHR (c:\peak359)
 Sample: Oxidizer inlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Vol / Air	0.233	1.0450	0.0000	
Ethene Oxide	0.516	0.9920	11.5259	ppm
		2.0370	11.5259	


Client: Sterigenics - Grand Prairie
 Client ID: Run#2BV
 Analysis date: 06/09/2015 15:42:10
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2B12.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Ambient H2O	0.433	4.5290	0.0000	
		4.5290	0.0000	


APPENDIX E
Run #2 Chromatograms - Aeration

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 15:45:21
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A01.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0375	0.0000	
Ethylene Oxide	0.516	1.0550	12.2579 ppm	
	2.0925	12.2579		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 15:45:21
 Method: Direct injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A01.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.100	7.3630	0.0000	
Ambient H2O	0.416	73.5110	0.0000	
		80.8740	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 analysis date: 06/09/2015 15:50:53
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A02.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0315	0.0000	
Ethylene Oxide	0.516	1.1370	13.2106 ppm	
	2.1685	2.1685	13.2106	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 15:50:53
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A02.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.116	6.6545	0.0000	
Ambient H2O	0.400	73.8020	0.0000	
	80.4565	80.4565	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 15:55:11
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A03.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0470	0.0000	
Ethylene Oxide	0.533	1.1570	13.4430	ppm
	2.2040	13.4430		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 15:55:11
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A03.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.050	7.4150	0.0000	
Ambient H2O	0.416	71.6710	0.0000	
		79.0860	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 alysis date: 06/09/2015 16:00:17
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tern
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A04.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0180	0.0000	
Ethylene Oxide	0.516	1.1100	12.8969 ppm	
	2.1280	2.1280	12.8969	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:00:17
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tern
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A04.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	6.6670	0.0000	
Ambient H2O	0.400	74.7755	0.0000	
	81.4425	81.4425	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 alysis date: 06/09/2015 16:05:37
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A05.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9450	0.0000	
Ethylene Oxide	0.516	1.1710	13.6057	ppm
	2.1160	13.6057		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:05:37
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A05.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	6.4100	0.0000	
Ambient H2O	0.416	74.4360	0.0000	
		80.8460	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:10:06
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A06.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9865	0.0000	
Ethene Oxide	0.516	1.2865	14.9476	ppm
	2.2730	2.2730	14.9476	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:10:06
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A06.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.133	7.5480	0.0000	
Ambient H2O	0.400	74.1650	0.0000	
	81.7130	81.7130	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 alysis date: 06/09/2015 16:15:12
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A07.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	0.9950	0.0000	
Ethylene Oxide	0.516	1.3160	15.2904	ppm
	2.3110	15.2904		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:15:12
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A07.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.133	9.2500	0.0000	
Ambient H2O	0.400	76.8865	0.0000	
	86.1365	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:20:41
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A08.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0180	0.0000	
Ethene Oxide	0.516	1.3485	15.6680 ppm	
		2.3665	15.6680	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:20:41
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A08.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	28.3655	0.0000	
Ambient H2O	0.416	79.6200	0.0000	
		107.9855	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:25:45
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A09.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.1410	0.0000	
Ethylene Oxide	0.516	1.5440	17.9395 ppm	
	2.6850	17.9395		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:25:45
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A09.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.150	8.6190	0.0000	
Ambient H2O	0.416	78.5520	0.0000	
	87.1710	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 alysis date: 06/09/2015 16:30:28
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A10.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0350	0.0000	
Ethylene Oxide	0.516	1.4315	16.6324	ppm
	2.4665	16.6324		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:30:28
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A10.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.066	8.8545	0.0000	
Ambient H2O	0.416	81.4050	0.0000	
		90.2595	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 alysis date: 06/09/2015 16:35:08
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A11.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0800	0.0000	
Ethylene Oxide	0.533	1.4730	17.1145 ppm	
	2.5530	17.1145		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:35:08
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A11.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.066	10.0950	0.0000	
Ambient H2O	0.433	79.3810	0.0000	
	89.4760	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 alysis date: 06/09/2015 16:40:08
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-2A12.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0100	0.0000	
Ethylene Oxide	0.516	1.4120	16.4058	ppm
	2.4220	16.4058		

Client: Sterigenics - Grand Prairie
 Client ID: Run#2Aer
 Analysis date: 06/09/2015 16:40:08
 Method: Direct injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-2A12.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	7.5570	0.0000	
Ambient H2O	0.416	82.5740	0.0000	
	90.1310	0.0000		

APPENDIX F


Run #3 Chromatograms - Backvent

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 16:59:10
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B01.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0420	0.0000	
Ethylene Oxide	0.533	1.5040	17.4747 ppm	
	2.5460	17.4747		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 16:59:10
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.term
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B01.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.150	8.7405	0.0000	
Ambient H2O	0.416	87.2960	0.0000	
	96.0365	0.0000		

Lab Name: ECO
 Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:00:15
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B02.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	1.0585	0.0000	
Ethylene Oxide	0.516	4.6115	53.5803	ppm
	5.6700	53.5803		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:00:15
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B02.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Acetaldehyde	0.600	87.2020	0.0000	
	87.2020	0.600		

Lab Name: ECO
 Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:01:22
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B03.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	1.0210	0.0000	
Ethylene Oxide	0.533	7.3185	85.0324	ppm
	8.3395	85.0324		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:01:22
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B03.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	85.1620	0.0000	
	85.1620	85.1620	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:02:28
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B04.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	1.0025	0.0000	
alpha Oxide	0.516	5.2975	61.5508 ppm	
	6.3000	61.5508		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:02:28
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B04.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	84.0420	0.0000	
	84.0420	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:03:34
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B05.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	0.9915	0.0000	
Ethylene Oxide	0.533	3.7510	43.5823	ppm
	4.7425	43.5823		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:03:34
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B05.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	82.3610	0.0000	
	82.3610	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:04:40
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B06.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0840	0.0000	
Ethylene Oxide	0.516	3.2815	38.1272 ppm	
		4.3655	38.1272	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:04:40
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B06.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.4920	0.0000	
Ambient H2O	0.416	83.2700	0.0000	
		90.7620	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:05:46
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B07.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0290	0.0000	
Ethylene Oxide	0.516	2.6960	31.3244	ppm
	3.7250	31.3244		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:05:46
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B07.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	8.0270	0.0000	
Ambient H2O	0.416	10.6955	0.0000	
Acetaldehyde	0.583	4.5200	0.0000	
CO2	0.883	0.0680	0.0000	
	23.3105	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:06:53
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B08.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:06:53
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B08.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0140	0.0000	
Acrolein	0.516	2.4190	28.1060 ppm	
		3.4330	28.1060	


Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.3770	0.0000	
Ambient H2O	0.416	12.4670	0.0000	
Acetaldehyde	0.583	4.6960	0.0000	
		24.5400	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:08:15
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B09.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0610	0.0000	
Ethylene Oxide	0.516	2.2280	25.8868	ppm
		3.2890	25.8868	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:08:15
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B09.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.6910	0.0000	
Ambient H2O	0.416	81.3270	0.0000	
		89.0180	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:09:31
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B10.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9840	0.0000	
Ethene Oxide	0.516	2.2150	25.7357	ppm
	3.1990	25.7357		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:09:31
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B10.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.4500	0.0000	
Ambient H2O	0.466	82.4820	0.0000	
	89.9320	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:10:36
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B11.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0145	0.0000	
ylene Oxide	0.516	2.1320	24.7714	ppm
		3.1465	24.7714	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:10:36
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B11.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	7.7105	0.0000	
Ambient H2O	0.400	80.1510	0.0000	
		87.8615	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:11:49
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3B12.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9820	0.0000	
Ethylene Oxide	0.533	1.9170	22.2733	ppm
	2.8990	22.2733		


Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:11:49
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3B12.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.016	8.1780	0.0000	
Ambient H2O	0.433	2.1565	0.0000	
	10.3345	0.0000		


APPENDIX G
Run #3 Chromatograms - Aeration

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:15:26
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A01.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0260	0.0000	
Ethylene Oxide	0.516	1.8890	21.9480	ppm
	2.9150	21.9480		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:15:26
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A01.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.066	8.1405	0.0000	
Ambient H2O	0.416	81.8500	0.0000	
	89.9905	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:20:42
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A02.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.233	1.0400	0.0000	
Ethene Oxide	0.516	1.6820	19.5429 ppm	
	2.7220	2.7220	19.5429	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:20:42
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A02.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	85.4710	0.0000	
	85.4710	85.4710	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:25:20
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A03.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	1.0010	0.0000	
Ethylene Oxide	0.516	1.6770	19.4848	ppm
		2.6780	19.4848	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:25:20
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A03.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.033	8.3150	0.0000	
Ambient H2O	0.400	79.2220	0.0000	
		87.5370	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:30:08
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A04.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	0.9890	0.0000	
ethylene Oxide	0.516	1.7420	20.2400	ppm
	2.7310	20.2400		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:30:08
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A04.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.050	10.5675	0.0000	
Ambient H2O	0.416	76.2200	0.0000	
	86.7875	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:35:10
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A05.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0220	0.0000	
Ethene Oxide	0.533	1.5060	17.4980	ppm
	2.5280	2.5280	17.4980	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:35:10
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A05.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.116	7.8330	0.0000	
Ambient H2O	0.416	79.7890	0.0000	
	87.6220	87.6220	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:40:16
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A06.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Val / Air	0.233	1.0365	0.0000	
Ethylene Oxide	0.516	1.5640	18.1719	ppm
	2.6005	2.6005	18.1719	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:40:16
 Method: Direct injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A06.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	81.4990	0.0000	
	81.4990	81.4990	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:45:07
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A07.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0350	0.0000	
Ethylene Oxide	0.516	1.7175	19.9553	ppm
	2.7525	2.7525	19.9553	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:45:07
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A07.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.016	6.8190	0.0000	
Ambient H2O	0.416	82.9680	0.0000	
		89.7870	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 17:50:31
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A08.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
id Vol / Air	0.250	1.1060	0.0000	
Ethylene Oxide	0.533	1.6880	19.6126	ppm
	2.7940	19.6126		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:50:31
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A08.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.416	77.7790	0.0000	
	77.7790	0.0000		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:55:12
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A09.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.0570	0.0000	
Ethene Oxide	0.516	1.6710	19.4151	ppm
	2.7280	19.4151		

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 17:55:12
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A09.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.166	15.0900	0.0000	
Ambient H2O	0.400	76.8990	0.0000	
		91.9890	0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 alysis date: 06/09/2015 18:00:17
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A10.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Vol / Air	0.216	1.0590	0.0000	
Ethylene Oxide	0.516	1.7440	20.2632	ppm
	2.8030		20.2632	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 18:00:17
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbopack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A10.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer




Component	Retention	Area	External	Units
Ambient H2O	0.400	83.4595	0.0000	
	83.4595		0.0000	

Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 18:05:14
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, Carbo pack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A11.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer




Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 18:05:14
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, Carbo pack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A11.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.250	1.0455	0.0000	
Ethylene Oxide	0.533	1.7315	20.1180	ppm


Component	Retention	Area	External	Units
Dead Vol / Air	0.133	16.3890	0.0000	
Ambient H2O	0.416	76.4020	0.0000	

Lab name: ECSI
 Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 18:10:40
 Method: Direct Injection
 Description: CHANNEL 1 - FID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 1SterGP2015.cpt
 Data file: 1SterGP2015-3A12.CHR (c:\peak359)
 Sample: Oxidizer Inlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.1750	0.0000	
Ethylene Oxide	0.516	1.8090	21.0185	ppm
	2.9840		21.0185	

Lab name: ECSI
 Client: Sterigenics - Grand Prairie
 Client ID: Run#3BV
 Analysis date: 06/09/2015 18:10:40
 Method: Direct Injection
 Description: CHANNEL 2 - PID
 Column: 1% SP-1000, CarboPack B
 Carrier: HELIUM
 Temp. prog: eto-100.tem
 Components: 2SterGP2015.cpt
 Data file: 2SterGP2015-3A12.CHR (c:\peak359)
 Sample: Oxidizer Outlet
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.166	13.2450	0.0000	
Ambient H2O	0.400	76.5365	0.4000	
	89.7815		0.0000	

APPENDIX H
Field Data and Calculation Worksheets

ECSi, Inc.

Ethylene Oxide Mass Emissions Data and Calculations

Sterigenics, Inc. - Grand Prairie, Texas

6/9/15 - Backvent Runs 1-3

<u>DeltaP</u>	<u>SqRtDeltaP</u>	<u>Temp (F)</u>	<u>ppm EtO</u>	<u>mw =</u>	28.51
		Run #1		<u>stack area =</u>	5.585
0.56	0.7483	183	0.01	<u>press =</u>	29.30
0.56	0.7483	182	0.01	<u>Tstd =</u>	528
0.56	0.7483	180	0.01	<u>Pstd =</u>	29.92
0.56	0.7483	179	0.01	<u>Cp =</u>	0.99
0.56	0.7483	179	0.01	<u>Kp =</u>	85.49
0.56	0.7483	179	0.01		
0.56	0.7483	179	0.01	<u>Velocity =</u>	55.2 ft/sec
0.56	0.7483	179	0.01	<u>Flow =</u>	14622 dscfm
0.56	0.7483	180	0.01		
0.56	0.7483	180	0.01	<u>MWeto =</u>	44.05
0.56	0.7483	181	0.01	<u>MolVol =</u>	385.32
0.56	0.7483	180	0.01	<u>ppmv/ft3 =</u>	1000000
		Run #2			
0.56	0.7483	176	0.01	<u>EtO Mass Flow =</u>	0.000017 lbs/min
0.56	0.7483	175	0.01	<u>EtO Mass Flow =</u>	0.001003 lbs/hr
0.56	0.7483	174	0.01		
0.56	0.7483	174	0.01		
0.56	0.7483	174	0.01		
0.56	0.7483	174	0.01		
0.56	0.7483	174	0.01		
0.56	0.7483	174	0.01		
0.56	0.7483	174	0.01		
0.56	0.7483	173	0.01		
0.56	0.7483	173	0.01		
0.56	0.7483	173	0.01		
		Run #3			
0.56	0.7483	168	0.01		
0.56	0.7483	168	0.01		
0.56	0.7483	168	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	170	0.01		
Average =					
0.56	0.7483	174.4	0.0100		
		=	634	degR	

ECSi, Inc.

Ethylene Oxide Mass Emissions Data and Calculations

Sterigenics, Inc. - Grand Prairie, Texas

6/9/15 - Aeration Runs 1-3

<u>DeltaP</u>	<u>SqRtDeltaP</u>	<u>Temp (F)</u>	<u>ppm EtO</u>	<u>mw =</u>	28.51
		Run #1		<u>stack area =</u>	5.585
0.56	0.7483	178	0.01	<u>press =</u>	29.30
0.56	0.7483	179	0.01	<u>Tstd =</u>	528
0.56	0.7483	179	0.01	<u>Pstd =</u>	29.92
0.56	0.7483	177	0.01	<u>Cp =</u>	0.99
0.56	0.7483	177	0.01	<u>Kp =</u>	85.49
0.56	0.7483	178	0.01		
0.56	0.7483	178	0.01	<u>Velocity =</u>	55.1 ft/sec
0.56	0.7483	177	0.01	<u>Flow =</u>	14644 dscfm
0.56	0.7483	178	0.01		
0.56	0.7483	178	0.01	<u>MWeto =</u>	44.05
0.56	0.7483	176	0.01	<u>MolVol =</u>	385.32
0.56	0.7483	177	0.01	<u>ppmv/ft3 =</u>	1000000
		Run #2			
0.56	0.7483	173	0.01	<u>EtO Mass Flow =</u>	0.000017 lbs/min
0.56	0.7483	172	0.01	<u>EtO Mass Flow =</u>	0.001004 lbs/hr
0.56	0.7483	171	0.01		
0.56	0.7483	171	0.01		
0.56	0.7483	171	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	168	0.01		
0.56	0.7483	167	0.01		
0.56	0.7483	166	0.01		
0.56	0.7483	166	0.01		
0.56	0.7483	166	0.01		
		Run #3			
0.56	0.7483	171	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	171	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	169	0.01		
0.56	0.7483	170	0.01		
0.56	0.7483	171	0.01		
0.56	0.7483	172	0.01		
0.56	0.7483	172	0.01		
0.56	0.7483	171	0.01		
0.56	0.7483	171	0.01		
Average =					
0.56	0.7483	172.6	0.0100		
		=	633 degR		

ETHYLENE OXIDE SOURCE TEST/CALIBRATION DATA

Client: Sterigenics - Grand Prairie, TX
 Source Tested: Catalytic Oxidizer - 15,000 CFM Date: 6/9/15

P R E C A L I B R A T I O N							
	Calibration Gas Conc. (ppmv)	1.10 ppm EtO	10.1 ppm EtO	100 ppm EtO	1000 ppm EtO	10080 ppm EtO	
Inlet (FID)	Area Counts #1	.097	.87	8.32			
	Area Counts #2	.095	.88	8.43			
	Average Area	.096	.88	8.38			
Audit Standard (48.8 ppmv) Result						49.2 ✓	
	Calibration Gas Conc. (ppmv)	1.10 ppm EtO	10.1 ppm EtO	100 ppm EtO			
Outlet (PID)	Area Counts #1	1.75	16.5	151			
	Area Counts #2	1.75	16.6	157			
	Average Area	1.75	16.6	154			
Audit Standard (48.8 ppmv) Result						48.9 ✓	

Backvent start/stop: 1339/1554 Run #1 Run #2 Run #3
1555/1455 1542/1642 1657/1712 P_{bar}: 29.30
 Aeration start/stop: 1555/1455 %H₂O: 3 EtO Usage (lbs/yr):
1543/1643 1713/1813 Cycles Per Week:

P O S T C A L I B R A T I O N							
	Calibration Gas Conc. (ppmv)	1.10 ppm EtO	10.1 ppm EtO	100 ppm EtO	1000 ppm EtO	10080 ppm EtO	
Inlet (FID)	Area Counts #1						
	Area Counts #2						
	Average Area						
Audit Standard (48.8 ppmv) Result						48.7 ✓	
	Calibration Gas Conc. (ppmv)	1.10 ppm EtO	10.1 ppm EtO	100 ppm EtO			
Outlet (PID)	Area Counts #1						
	Area Counts #2						
	Average Area						
Audit Standard (48.8 ppmv) Result						48.6 ✓	

ECSi

ECSI, INC. - VELOCITY TRAVERSE DATA

Client: Sterigenics, Inc. Run #: 1 Date: 10/22/2014 Port Sketch:
 Location: Grand Prairie, Texas Plant Probe Type: Std. Baro Press: 29.30
 Source: Ethylene Oxide Emission Control System Outlet Stack I.D.: 32in. DSCFM: '14,500



APPENDIX I
Gas Certifications



Scott Specialty Gases

500 CAJON BLVD., SAN BERNARDINO, CA 92411

CERTIFIED WORKING CLASS

Single-Certified Calibration Standard

Phone: 909-887-2571 Fax: 909-887-0549

CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

Product Information

Project No.: 02-57164-001
Item No.: 02020001310TCL
P.O. No.: VBL - D. KREMER

Cylinder Number: CAL4448
Cylinder Size: CL
Certification Date: 14Apr2014

Customer

ECSI, INC
PO BOX 848
SAN CLEMENTE, CA 92672

CERTIFIED CONCENTRATION

Component Name

ETHYLENE OXIDE
NITROGEN

Concentration (Moles)

1.10 PPM
BALANCE

Accuracy (+/-%)

5

TRACEABILITY

Traceable To

Scott Reference Standard

APPROVED BY:

M7
MT

DATE: 4-14-14

SPECIFICATIONS

Component Name	Requested Concentration (Moles)	Certified Concentration (Moles)	Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE NITROGEN	1. BAL	1.10 BAL	10.0	5.00

TRACEABILITY

Traceable To
Scott Reference Standard

PHYSICAL PROPERTIES

Cylinder Size: CL Pressure: 1400 PSIG
Expiration Date: 14Apr2016

SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

COMMENTS



Scott Specialty Gases

100 CAJON BLVD., SAN BERNARDINO, CA 92411

CERTIFIED WORKING CLASS

Single-Certified Calibration Standard

Phone: 909-887-2571 Fax: 909-887-0549

CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

Product Information

Project No.: 02-57164-003
Item No.: 02020001320TCL
P.O. No.: VBL - D. KREMER

Cylinder Number: CLM003232
Cylinder Size: CL
Certification Date: 14Apr2014

Customer

ECSI, INC
PO BOX 848
SAN CLEMENTE, CA 92672

CERTIFIED CONCENTRATION

<u>Component Name</u>	<u>Concentration (Moles)</u>	<u>Accuracy (+/-%)</u>
ETHYLENE OXIDE NITROGEN	10.1 PPM BALANCE	5

TRACEABILITY

Traceable To

Scott Reference Standard

APPROVED BY:

MT

MT

DATE: 4-14-14

SPECIFICATIONS

Component Name	Requested Concentration (Moles)	Certified Concentration (Moles)	Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	10.	PPM BAL	10.1	PPM BAL
NITROGEN			1.0	5.00

TRACEABILITY

Traceable To
Scott Reference Standard

PHYSICAL PROPERTIES

Cylinder Size: CL Pressure: 1600 PSIG
Expiration Date: 14Apr2016

SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

COMMENTS



Scott Specialty Gases

500 CAJON BLVD., SAN BERNARDINO, CA 92411

CERTIFIED WORKING CLASS

Single-Certified Calibration Standard

Phone: 909-887-2571 Fax: 909-887-0549

CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

Product Information

Project No.: 02-57164-004
Item No.: 02020001330TCL
P.O. No.: VBL - D. KREMER

Cylinder Number: CLM011385
Cylinder Size: CL
Certification Date: 14Apr2014

Customer

ECSI, INC
PO BOX 848
SAN CLEMENTE, CA 92672

CERTIFIED CONCENTRATION

Component Name	Concentration (Moles)	Accuracy (+/-%)
ETHYLENE OXIDE NITROGEN	100. PPM BALANCE	5

TRACEABILITY

Traceable To:

Scott Reference Standard

APPROVED BY:

B. McCully
BLM

DATE: 4-14-14

SPECIFICATIONS

Component Name	Requested Concentration (Moles)	Certified Concentration (Moles)	Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	100.	PPM	.0	5.00
NITROGEN		BAL		

TRACEABILITY

Traceable To
Scott Reference Standard

PHYSICAL PROPERTIES

Cylinder Size: CL

Pressure: 1500 PSIG
Expiration Date: 14Apr2016

Valve Connection: CGA 350

SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

COMMENTS



Scott Specialty Gases

300 CAJON BLVD., SAN BERNARDINO, CA 92411

CERTIFIED WORKING CLASS

Single-Certified Calibration Standard

Phone: 909-887-2571 Fax: 909-887-0549

CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

Product Information

Project No.: 02-57164-005
Item No.: 02020001340TCL
P.O. No.: VBL - D. KREMER

Cylinder Number: CLM002810
Cylinder Size: CL
Certification Date: 14Apr2014

Customer

ECSI, INC
PO BOX 848
SAN CLEMENTE, CA 92672

CERTIFIED CONCENTRATION

<u>Component Name</u>	<u>Concentration (Moles)</u>	<u>Accuracy (+/-%)</u>
ETHYLENE OXIDE	1,000.	PPM
NITROGEN		BALANCE

TRACEABILITY

Traceable To:

Scott Reference Standard

APPROVED BY:


BLM

DATE: 4-14-14

SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)		Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	1,000.	PPM	1,000.	PPM	.0	5.00
NITROGEN		BAL		BAL		

TRACEABILITY

Traceable To
Scott Reference Standard

PHYSICAL PROPERTIES

Cylinder Size: CL

Pressure: 1400 PSIG
Expiration Date: 14Apr2016

Valve Connection: CGA 350

SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

COMMENTS



Scott Specialty Gases

100 CAJON BLVD., SAN BERNARDINO, CA 92411

CERTIFIED WORKING CLASS

Single-Certified Calibration Standard

Phone: 909-887-2571 Fax: 909-887-0549

CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

Product Information

Project No.: 02-57164-006
Item No.: 02020001340TCL
P.O. No.: VBL - D. KREMER

Cylinder Number: CLM005787
Cylinder Size: CL
Certification Date: 14Apr2014

Customer

ECSI, INC
PO BOX 848
SAN CLEMENTE, CA 92672

CERTIFIED CONCENTRATION

<u>Component Name</u>	<u>Concentration (Moles)</u>	<u>Accuracy (+/-%)</u>
ETHYLENE OXIDE NITROGEN	10,080. PPM BALANCE	5

TRACEABILITY

Traceable To:

Scott Reference Standard

APPROVED BY:

B. McAllister
BLM

DATE: 4-14-14

SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)	Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	10,000.	PPM BAL	10,080.	PPM BAL	.8
NITROGEN					5.00

TRACEABILITY

Traceable To
Scott Reference Standard

PHYSICAL PROPERTIES

Cylinder Size: CL

Pressure: 900 PSIG
Expiration Date: 14Apr2016

Valve Connection: CGA 350

SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.


Use of calibration standards at or below dew point temperature may result in calibration error.

COMMENTS

MESA**CERTIFICATE OF ANALYSIS**

Customer Name:	ECSi, Inc.	Cylinder Number:	SA25925
Stock or Analyzer Tag Number:	N/A	Product Class:	Certified Standard
Customer Reference:	Verbal- Dan	Cylinder - Contents ¹ :	28 CF @ 2000 PSI
MESA Reference:	104448	Cylinder-CGA:	A006-HP-BR/350
Date of Certification:	4/15/2014	Analysis Method:	GC-TCD/FID
Recommended Shelf Life:	2 Years	Preparation Method:	Gravimetric

Component	Requested Concentration ²	Reported Concentration ^{2,3}
Ethylene Oxide	50 ppm	48.8 ppm
Nitrogen	Balance	Balance

Authorized Signature: 

1. The fill pressure shown on the COA is as originally quoted. The fill pressure measured by the customer may differ from the fill pressure originally quoted due to temperature effects, compressibility of the individual components when blended together in the cylinder, gauge accuracy or reduction in content volume before shipping as a result of samples withdrawn for laboratory QC necessary to ensure product quality.
2. Unless otherwise stated, concentrations are given in molar units.
3. Vapor pressure mixes are blended at a sufficiently low pressure so as to eliminate phase separation under most low temperature conditions encountered during transport or storage. However, it is generally recommended that cylinders containing vapor pressure restricted mixes be placed on the floor in a horizontal position and rolled back and forth to improve homogeneity of the gas phase mixture before being put into service.

Analytical Gas Standards are prepared and analyzed using combinations of NIST traceable weights, SRM's provided by NIST, or internal gas standards that have been verified for accuracy using procedures published by the US-EPA. Pure gases are analyzed and certified for purity using minor component Analytical Gas Standards prepared according to the methods specified above. Balances are calibrated to NIST test weights covered by NIST test number 822/256175/96. Reference Certification #'s: 163/W, 830/N and 3280. Calibration methods are in conformance with MIL-STD 45662A.

MESA Specialty Gases & Equipment

division of MESA International Technologies, Inc.
3619 Pendleton Avenue, Suite C ♦ Santa Ana, California 92704 ♦ USA
TEL: 714-434-7102 ♦ FAX: 714-434-8006 ♦ E-mail: mail@mesagas.com
On-line Catalog at www.mesagas.com

APPENDIX J

Process Data

STERIGENICS Grand Prairie

Pollution Systems Catalytic Oxidizer / DAILY OPERATING REPORT

ITEM	Date / Initials	AS 06 Jun 15	BS 07 Jun 15	BS 08 Jun 15	BS 09 Jun 15	BS 10 Jun 15	BS 11 Jun 15	AC 12 Jun 15
	DESCRIPTION	SAT	SUN	MON	TUE	WED	THUR	FRI
1	PT1 "W.C. >-1.0"	-1.7	-1.7	-1.7	-1.7	-1.7	-1.7	-1.7
2	TE1 Deg F >300.0 F	299 F	300 F	300 F	299 F	315 F	315 F	315
3	F1 % fan speed	78%	85%	98%	85%	87%	89%	89%
4	Gas Consumption Scf	NA						

INSTRUCTIONS

Verify that the Abator Panel corresponds to the above checklist. Report any damage or deficiency to Maintenance Supervisor via Demand Work Order (On Site Request).

Corrective Action / Comments (Include Item # and action; i.e. WO# or other):


Reviewed by:

Date: 22 Jun 15

UNCONTROLLED

03/16/2015

Oxidizer Operating log		Date	09 Jun 15
Time	PT1 - "W.C."	TE1 - DEG F	F1 % fan Speed
6:00			
7:00	-1.7	299	78%
8:00	-1.7	300	85%
9:00	-1.7	300	88%
10:00	-1.7	300	85%
11:00	-1.7	300	87%
12:00	-1.7	301	89%
13:00	-1.7	300	89%
14:00	-1.7	300	90%
15:00	-1.7	300	89%
16:00	-1.7	300	78%
17:00	-1.7	299	85%
18:00			
19:00			
20:00			


 09 Jun 15
 NT