

**REPORT OF  
AIR POLLUTION SOURCE TESTING  
OF AN ETHYLENE OXIDE EMISSION-CONTROL SYSTEM  
OPERATED BY STERIGENICS U.S., LLC.  
IN QUEENSBURY, NEW YORK  
ON OCTOBER 24, 2017**

Submitted to:

**NEW YORK DEPARTMENT OF ENVIRONMENTAL CONSERVATION  
P.O. Box 220  
232 Hudson Street  
Warrensburg, New York 12885-0220**

Submitted by:

**STERIGENICS US, LLC.  
84 Park Road  
Queensbury, New York 12804**

**NYDEC Permit Number 5-5344-00029/00011**

Prepared by:

**ECSi  
PO Box 1498  
San Clemente, California 92674-0848**

**December 21, 2017**

*ECSi*

## CONTACT SUMMARY

### CLIENT

Mr. Kevin Wagner  
Director, Environmental Health and Safety  
STERIGENICS US, LLC.  
2015 Spring Road, Suite 650  
Oak Brook, Illinois 60523

Phone: (630)928-1771  
FAX: (630)928-1701  
email: [kwagner@sterigenics.com](mailto:kwagner@sterigenics.com)

### FACILITY

Mr. Justin Fitzpatrick  
General Manager  
STERIGENICS US, LLC.  
84 Park Road  
Queensbury, New York 12804

Phone: (518)743-9272  
FAX: (518)743-9372  
email: [jufitzpatrick@sterigenics.com](mailto:jufitzpatrick@sterigenics.com)

### TEST DATE

October 24, 2017

### REGULATORY AGENCY

Mr. Mike Sundberg  
Environmental Engineer, Division of Air Resources  
NEW YORK DEPARTMENT OF ENVIRONMENTAL CONSERVATION  
P.O. Box 220  
232 Hudson Street  
Warrensburg, New York 12885-0220

Phone: (518)623-1231  
FAX: (518)623-4193  
email: [mrsundbe@gw.dec.state.ny.us](mailto:mrsundbe@gw.dec.state.ny.us)

### TESTING CONTRACTOR

Daniel P. Kremer  
President  
ECSi, Inc.  
PO Box 1498  
San Clemente, California 92674-0848

Phone: (949)400-9145  
FAX: (949)281-2169  
email: [dankremer@ecsi1.com](mailto:dankremer@ecsi1.com)

# TABLE OF CONTENTS

	<u>PAGE NO.</u>
CONTACT SUMMARY	i
TABLE OF CONTENTS	ii
LIST OF TABLES	iii
LIST OF APPENDICES	iv
1.0 INTRODUCTION	1
2.0 EQUIPMENT	2
3.0 TESTING	3
4.0 RULE/COMPLIANCE REQUIREMENTS	4
5.0 TEST METHOD REFERENCE	5
5.1 Summary/Introduction	5
5.2 Volumetric Flow Measurement	5
5.3 EtO Mass-Emissions Measurement	6
5.4 Sample Transport	6
5.5 GC Injection	6
5.6 GC Conditions	6
5.7 Calibration Standards	7
5.8 Sampling Duration	7
5.9 Mass-Emissions Calculations	7
6.0 TEST SCENARIO	9
7.0 QA/QC	10
7.1 Field Testing Quality Assurance	10
7.2 Calibration Procedures	10
8.0 TEST RESULTS	11
TABLES	12
APPENDICES	15

## LIST OF TABLES

<u>TABLE</u>	<u>DESCRIPTION</u>	<u>PAGE NO.</u>
1	Ethylene Oxide Control Efficiency – Aeration	13
2	Ethylene Oxide Control Efficiency – Backvent	14

## LIST OF APPENDICES

<b><u>APPENDIX</u></b>	<b><u>DESCRIPTION</u></b>	<b><u>PAGE NO.</u></b>
A	Calibration Data	A-1
B	Run #1 Chromatograms – Aeration	B-1
C	Run #1 Chromatograms – Backvent	C-1
D	Run #2 Chromatograms – Aeration	D-1
E	Run #2 Chromatograms – Backvent	E-1
F	Run #3 Chromatograms – Aeration	F-1
G	Run #3 Chromatograms –Backvent	G-1
H	Field Data and Calculation Worksheets	H-1
I	Calibration Gas Certificates	I-1

## 1.0 INTRODUCTION

On Monday, October 23, 2017, ECSi performed air pollution source testing of an ethylene oxide (EtO) emission-control system operated by Sterigenics U.S., LLC. in Queensbury, New York. The control device tested is a Donaldson EtO Abator catalytic oxidizer, which is currently used to control emissions from ten EtO sterilizer backvents and five aeration rooms/cells. The purpose of the testing program was to evaluate compliance with EPA requirements under the current National Emissions Standards for Hazardous Air Pollutants (NESHAP), and with the conditions established in the permit (Number 5-5344-00029/00011) granted to Sterigenics US, LLC. by the New York Department of Environmental Conservation (NYDEC).

## 2.0 EQUIPMENT

The EtO gas-sterilization system is comprised of eleven commercial sterilizers, all discharging through liquid-ring vacuum pumps to a packed-tower acid scrubber emission control device. In compliance with NYDEC and USEPA requirements, and all aeration room vents are discharged to a Donaldson EtO Abator catalytic oxidizer emission control device. In compliance with NYDEC requirements, all chamber exhaust vents (“backvents”) are discharged to the same Donaldson EtO Abator catalytic oxidizer emission control device.

The gas-sterilization and emission-control equipment consists of the following:

- Eleven Gas Sterilizers, one 26-pallet chamber (3003 cubic feet), four 13-pallet (1333 cubic feet), four 8-pallet (two: 1155 cubic feet; two: 1200 cubic feet), and two 3-pallet (350 cubic feet) capacity, each comprised of a steam-heated sterilization chamber, a recirculating vacuum pump chamber evacuation system, a chamber backvent valve, and a fugitive emissions exhaust hood;
- Five Aeration Rooms, three 48-pallet (11,340 cubic feet), one 685-pallet (189,642 cubic feet), and one 3764 cubic feet capacity, each comprised of a heated aeration room and an aeration room exhaust system.

Sterilizer vacuum pump emissions are controlled by:

- One Ceilcote packed tower acid scrubber, Model SPT-42-120, equipped with a bed of No. 1 Tellerette packing, a 5000 gallon reaction tank/reservoir, a scrubber fluid recirculation pump, and an exhaust blower.

Sterilizer backvent and aeration emissions are controlled by:

- One Donaldson EtO Abator System, operated at approximately 6,000 SCFM, equipped with a prefilter, a steam heater, an exhaust gas heat exchanger, a reactive catalyst bed, and an exhaust blower.

### 3.0 TESTING

EtO source testing was conducted in accordance with the procedures outlined in USEPA CFR40, Part 63.365. EtO emissions monitoring for each test run was conducted simultaneously at the inlet and outlet of the catalytic oxidizer during chamber backvent, and during a one-hour interval of the 24-hour aeration process. A total of three chamber backvent test runs, and three one-hour aeration test runs, were performed.

During backvent and aeration testing, EtO emissions at the inlet and the outlet of the catalytic oxidizer were determined using direct source sample injection into the gas chromatograph (GC). All backvent and aeration testing was performed using freshly sterilized product. The testing program was conducted in accordance with the procedures outlined in the following sections.



## 4.0 RULE/COMPLIANCE REQUIREMENTS

The EtO gas-sterilization system at Sterigenics U.S., LLC. was tested to determine compliance with the current federal EPA National Emissions Standard for Hazardous Air Pollutants (NESHAP) for ethylene oxide, and with the requirements specified in the NYDEC Permit. The current testing was performed to demonstrate continued compliance with the following requirements:

- The emissions from the sterilization chamber exhaust vents (backvents) must be discharged to control equipment with an EtO emission-reduction efficiency of at least 99.0% by weight.
- The emissions from the aeration process must be discharged to control equipment with an EtO emission-reduction efficiency of at least 99.0% by weight, or which reduces the EtO concentration at the emission-control outlet to less than 1 ppm.

Testing is required to demonstrate compliance with these requirements. Source testing of the emission-control device is conducted annually.

## **5.0 TEST METHOD REFERENCE**

### **5.1 INTRODUCTION**

The testing procedures outlined herein are based on USEPA source-sampling methods. EtO control efficiency and mass-emissions testing were conducted by USEPA CFR40, Part 63.365, and in accordance with NYDEC requirements. EtO emissions monitoring for each test run was conducted simultaneously at the inlet and outlet of the catalytic oxidizer during chamber backvent, and during a one-hour interval of the 24-hour aeration process. A total of three chamber backvent test runs, and three one-hour aeration test runs, were performed.

During backvent and aeration testing, EtO emissions at the inlet and the outlet of the catalytic oxidizer were determined using direct source sample injection into the gas chromatograph (GC). All backvent and aeration testing was performed using freshly sterilized product.

Operation and documentation of process conditions were performed by personnel from Sterigenics using existing monitoring instruments installed by the manufacturer on the equipment to be tested. In accordance with the procedures established in USEPA CFR40, Part 63, Subpart O, the following parameter was recorded: catalyst bed operating temperature. Process condition data is noted in Tables 1 and 2.

### **5.2 VOLUMETRIC FLOW MEASUREMENT**

Exhaust gas flow at the outlet of the catalytic oxidizer was determined by EPA Method 2C using a standard pitot tube and an inclined-oil manometer. Sampling ports were installed in accordance with EPA Method 1, and were located far enough from any flow disturbances to permit accurate flow measurement.

Temperature measurements were obtained from a type K thermocouple and thermometer attached to the sampling probe. Exhaust gas composition was assumed to be air and small amounts of water vapor. Water vapor was negligible, at about 3 percent.

### **5.3 CONTROL EFFICIENCY AND MASS EMISSIONS MEASUREMENT**

During backvent and aeration testing, EtO emissions at the inlet and outlet of the catalytic oxidizer were determined using direct source sample injection into the GC. The mass of EtO emitted to the inlet and from the outlet was determined using the equation shown below in Section 5.9. Mass-mass control-efficiency of EtO during the backvent and aeration phases was calculated by comparing the mass of EtO vented to the system inlet to the mass of EtO vented from the system outlet.

During the backvent and aeration phases, vented gas was analyzed by an SRI, Model 8610, portable gas chromatograph (GC), equipped with the following: dual, heated sample loops and injectors; dual columns; and dual detectors. A flame ionization detector (FID) was used to quantify inlet EtO emissions, and a photoionization detector (PID) was used to quantify low-level EtO emissions at the emission-control device outlet.

### **5.4 SAMPLE TRANSPORT**

Source gas was pumped to the GC at approximately 1000 cubic centimeters per minute (cc/min) from the sampling ports through two lengths of Teflon<sup>®</sup> sample line, each with a nominal volume of approximately 75 cubic centimeters (cc) and an outer diameter of 0.25 inch. At the inlet, the sampling port was located in the common backvent/aeration discharge duct, upstream of the oxidizer. At the outlet of the catalytic oxidizer, sampling ports were located in the exhaust stack downstream of the catalyst bed.

### **5.5 GC INJECTION**

Source-gas samples were then injected into the GC which was equipped with two heated sampling loops, each containing a volume of approximately 2cc and maintained at 100 degrees Celsius (C). Injections occurred at approximately five minute intervals during the aeration-phase testing. Helium was the carrier gas for both the FID and PID.

### **5.6 GC CONDITIONS**

The packed columns for the GC were both operated at 80 degrees C. The columns were stainless steel, 6 feet long, 0.125 inch outer diameter, packed with 1 percent SP-1000 on 60/80 mesh Carbopack B.

During the analysis, the FID was operated at 250 degrees C. The support gases for the FID were helium (99.999% pure), hydrogen (99.995% pure) and air (99.9999% pure). Any unused sample gas was vented from the GC system back to the inlet of the control device being tested.

## **5.7 CALIBRATION STANDARDS**

The FID was calibrated for mid-range part-per-million-by-volume (ppmv) level analysis using gas proportions similar to the following:

- 1) 1,000 ppmv EtO, balance nitrogen
- 2) 100 ppmv EtO, balance nitrogen
- 3) 50 ppmv EtO, balance nitrogen (audit gas)
- 4) 10 ppmv EtO, balance nitrogen
- 5) 1 ppmv EtO, balance nitrogen

The PID was calibrated for low-range ppmv level analyses using gas proportions similar to the following:

- 1) 100 ppmv EtO, balance nitrogen
- 2) 50 ppmv EtO, balance nitrogen (audit gas)
- 3) 10 ppmv EtO, balance nitrogen
- 4) 1 ppmv EtO, balance nitrogen

Each of these calibration standards was in a separate, certified manufacturer's cylinder. Copies of the calibration gas laboratory certificates are attached as Appendix I.

## **5.8 SAMPLING DURATION**

Backvent testing was performed in conjunction with normal production operations, during the chamber exhaust venting which is conducted for each sterilization chamber upon conclusion of the sterilization cycle, immediately prior to and during chamber unloading. Backvent sampling duration was 15 minutes for each of the three test runs.

Since aeration is a 24-hour process at this facility, with constant discharge flow from the aeration chambers to the emission-control system, aeration testing consisted of three 1-hour test runs. Each test run was performed with freshly sterilized product in the aeration chambers.

## 5.9 CONTROL-EFFICIENCY/MASS-EMISSIONS CALCULATIONS

Mass emissions of EtO during aeration were calculated using the following equation:

$$\text{MassRate} = (\text{VolFlow})(\text{MolWt})(\text{ppmv EtO}/10^6)/(\text{MolVol})$$

Where:

MassRate	=	EtO mass flow rate, pounds per minute
VolFlow	=	Corrected volumetric flow rate, standard cubic feet per minute at 68 degrees F
MolWt	=	44.05 pounds EtO per pound mole
ppmv EtO	=	EtO concentration, parts per million by volume
$10^6$	=	Conversion factor, ppmv per "cubic foot per cubic foot"
MolVol	=	385.32 cubic feet per pound mole at one atmosphere and 68 degrees F

Mass-mass control efficiency of EtO was calculated for aeration. Results of the control-efficiency testing are presented in Tables 1 and 2.

## 6.0 TEST SCENARIO

The backvent and aeration testing was performed during normal process load conditions. Three backvent and three aeration test runs were conducted in series to verify the performance of the emission-control device. The testing schedule was as follows:

- 1) Testing equipment was set up and calibrated.
- 2) Aeration Phase Test Run #1 was conducted with freshly sterilized product in aeration. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 3) Backvent Phase Test Run #1 was conducted with one freshly sterilized production load. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 4) Backvent Phase Test Run #2 was conducted with one freshly sterilized production load. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 5) Aeration Phase Test Run #2 was conducted with freshly sterilized product in aeration. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 6) Backvent Phase Test Run #3 was conducted with one freshly sterilized production load. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 7) Aeration Phase Test Run #3 was conducted with freshly sterilized product in aeration. Sampling was performed at the inlet and the outlet of the catalytic oxidizer.
- 8) Post calibration check was performed, testing equipment was packed.

## **7.0 QA/QC**

### **7.1 FIELD TESTING QUALITY ASSURANCE**

At the beginning of the test, the sampling system was leak checked at a vacuum of 15 inches of mercury. The sampling system was considered leak free when the flow indicated by the rotameters fell to zero.

At the beginning of the test, a system blank was analyzed to ensure that the sampling system was free of EtO. Ambient air was introduced at the end of the heated sampling line and drawn through the sampling system line to the GC for analysis. The resulting chromatogram also provided a background level for non-EtO components (i.e. ambient air, carbon dioxide, water vapor) which are present in the source gas stream due to the ambient dilution air which is drawn into the emission-control device, and due to the destruction of EtO by the emission-control device which produces carbon dioxide and water vapor. This chromatogram, designated AMB, is included with the calibration data in Appendix A.

### **7.2 CALIBRATION PROCEDURES**

The GC system was calibrated at the beginning and conclusion of each day's testing. Using the Peaksimple II analytical software, a point-to-point calibration curve was constructed for each detector. A gas cylinder of similar composition as the calibration gases, but certified by a separate supplier, was used to verify calibration gas composition and GC performance.

All calibration gases and support gases used were of the highest purity and quality available. A copy of the laboratory certification for each calibration gas is attached as Appendix I.

## 8.0 TEST RESULTS

The catalytic oxidizer was found to have an average EtO control efficiency of 99.92 percent for backvent, and an average EtO control efficiency of 99.86 percent for aeration. During the testing the catalytic oxidizer was operated at 291 degrees during both backvent and aeration. In accordance with state and federal requirements, backvent and aeration discharge streams must be vented to control equipment with an EtO emission-reduction efficiency of at least 99 percent by weight. The catalytic oxidizer met this requirement.

The test results are summarized in Tables 1 and 2. These tables include results for EtO control efficiency and mass emissions of the emission-control device. Chromatograms and chromatographic supporting data are attached as Appendices A through G. Copies of field data and calculation worksheets are attached as Appendix H.



## TABLES

**TABLE 1**  
**ETHYLENE OXIDE CONTROL EFFICIENCY - AERATION**  
**OF AN ETHYLENE OXIDE EMISSION CONTROL DEVICE**  
**OPERATED BY STERIGENICS U.S., LLC.**  
**IN QUEENSBURY, NEW YORK**  
**ON OCTOBER 24, 2017**

<u>RUN NUMBER</u>	<u>INJECTION TIME</u>	<u>INLET ETO CONC. (PPM)(1)</u>	<u>OUTLET ETO CONC. (PPM)(2)</u>	<u>ETO CONTROL EFFICIENCY</u>
1(3)	847	5.25	0.01	99.8095
1	852	5.55	0.01	99.8198
1	857	5.30	0.01	99.8113
1	902	5.05	0.01	99.8020
1	907	5.11	0.01	99.8043
1	912	5.22	0.01	99.8084
1	917	4.94	0.01	99.7976
1	922	4.84	0.01	99.7934
1	927	5.35	0.01	99.8131
1	932	5.74	0.01	99.8258
1	937	5.29	0.01	99.8110
1	942	5.05	0.01	99.8020
2(4)	1027	6.32	0.01	99.8418
2	1032	6.28	0.01	99.8408
2	1037	6.76	0.01	99.8521
2	1042	6.66	0.01	99.8498
2	1047	7.36	0.01	99.8641
2	1052	7.60	0.01	99.8684
2	1057	7.92	0.01	99.8737
2	1102	8.99	0.01	99.8888
2	1107	8.00	0.01	99.8750
2	1112	8.30	0.01	99.8795
2	1117	8.02	0.01	99.8753
2	1122	7.92	0.01	99.8737
3(5)	1149	9.21	0.01	99.8914
3	1154	9.13	0.01	99.8905
3	1159	9.17	0.01	99.8909
3	1204	9.14	0.01	99.8906
3	1209	9.38	0.01	99.8934
3	1214	9.30	0.01	99.8925
3	1219	9.18	0.01	99.8911
3	1224	9.40	0.01	99.8936
3	1229	9.31	0.01	99.8926
3	1234	9.29	0.01	99.8924
3	1239	9.34	0.01	99.8929
3	1244	<u>9.06</u>	<u>0.01</u>	<u>99.8896</u>
<b>TIME-WEIGHTED AVERAGE:</b>		<b>7.326</b>	<b>0.0100</b>	<b>99.8551</b>
<b>NYDEQ REQUIRED CONTROL EFFICIENCY:</b>				<b>99%</b>

Notes:

- (1) - PPM = parts per million by volume
- (2) - 0.01 ppm is the quantification limit for the detector used at the outlet.
- (3) - Aeration Phase Test Run #1 started at 08:45, ended at 09:45.
- (4) - Aeration Phase Test Run #2 started at 10:25, ended at 11:25.
- (5) - Aeration Phase Test Run #3 started at 11:47, ended at 12:47.
- (6) - During aeration testing, the average recorded catalyst bed temperature was 291 deg F

*ECSi*

**TABLE 2**  
**ETHYLENE OXIDE CONTROL EFFICIENCY - BACKVENT**  
**OF AN ETHYLENE OXIDE EMISSION CONTROL DEVICE**  
**OPERATED BY STERIGENICS U.S., LLC.**  
**IN QUEENSBURY, NEW YORK**  
**ON OCTOBER 24, 2017**

<u>RUN NUMBER</u>	<u>INJECTION TIME</u>	<u>INLET ETO CONC. (PPM)(1)</u>	<u>OUTLET ETO CONC. (PPM)(2)</u>	<u>ETO CONTROL EFFICIENCY</u>
1(3)	1010	217	0.01	99.9954
1	1011	78.9	0.01	99.9873
1	1012	51.5	0.01	99.9806
1	1013	46.8	0.01	99.9786
1	1014	43.6	0.01	99.9771
1	1015	41.3	0.01	99.9758
1	1017	39.8	0.01	99.9749
1	1018	37.9	0.01	99.9736
1	1019	36.9	0.01	99.9729
1	1020	35.4	0.01	99.9718
1	1022	30.1	0.01	99.9668
1	1023	19.9	0.01	99.9497
2(4)	1132	9.48	0.01	99.8945
2	1133	10.3	0.01	99.9029
2	1134	9.06	0.01	99.8896
2	1136	8.93	0.01	99.8880
2	1137	9.00	0.01	99.8889
2	1138	8.91	0.01	99.8878
2	1139	8.99	0.01	99.8888
2	1140	9.12	0.01	99.8904
2	1141	9.20	0.01	99.8913
2	1142	9.28	0.01	99.8922
2	1144	9.19	0.01	99.8912
2	1145	9.21	0.01	99.8914
3(5)	1251	8.11	0.01	99.8767
3	1252	18.5	0.01	99.9459
3	1253	10.0	0.01	99.9000
3	1254	9.57	0.01	99.8955
3	1255	8.98	0.01	99.8886
3	1256	9.13	0.01	99.8905
3	1258	9.05	0.01	99.8895
3	1259	9.03	0.01	99.8893
3	1300	9.18	0.01	99.8911
3	1302	8.80	0.01	99.8864
3	1303	8.52	0.01	99.8826
3	1304	<u>8.52</u>	<u>0.01</u>	<u>99.8826</u>
<b>TIME-WEIGHTED AVERAGE:</b>		<b>25.20</b>	<b>0.0100</b>	<b>99.9200</b>
<b>NYDEQ REQUIRED CONTROL EFFICIENCY:</b>				<b>99%</b>

Notes:


- (1) - PPM = parts per million by volume
- (2) - 0.01 ppm is the quantification limit for the detector used at the outlet.
- (3) - Backvent Phase Test Run #1 started at 10:09, ended at 10:24.
- (4) - Backvent Phase Test Run #2 started at 09:53, ended at 10:08.
- (5) - Backvent Phase Test Run #3 started at 12:50, ended at 13:05.
- (6) - During backvent testing, the average recorded catalyst bed temperature was 291 deg F

## APPENDICES

**APPENDIX A**  
**Calibration Data**

Component file: data1000.txt

Peak	Name	Start	End	Calibration	Int.Std	Units
1	Dead Vol / Air	0.000	0.300		0.000	
2	Ambient H2O	0.300	0.430		0.000	
3	Ethylene Oxide	0.430	0.550	C:\peak359\1Ster	0.0007	cppm
4	Acetaldehyde	0.550	0.800		0.000	
5	CO2	0.800	1.000		0.000	



Avg slope of curve: 0.42

Y-axis intercept: -0.00

Linearity: 1.00

Number of levels: 4

SD/rel SD of CF's: 0.2/66.7

Y=0.4203X

r2: 1.0000


Last calibrated: Mon Oct 23 13:17:46 2017

Lvl.	Area/ht.	Amount	CF	Current	Previous #1	Previous #2
1	0.000	0.000	0.000	0.000	N/A	N/A
2	0.451	1.100	0.410	0.451	N/A	N/A
3	4.290	10.100	0.425	4.290	N/A	N/A
4	42.600	100.000	0.426	42.600	N/A	N/A

Component file: C:\02-100.cpt

Peak	Name	Start	End	Calibration	Int.Std	Units
1	Dead Vol / Air	0.000	0.300		0.000	
2	Ambient H2O	0.300	0.430		0.000	
3	Ethylene Oxide	0.430	0.550	C:\peak359\2Ster	0.0007	cppm
4	Acetaldehyde	0.550	0.800		0.000	
5	CO2	0.800	1.000		0.000	





Avg slope of curve: 2.32

Y-axis intercept: 0.00

Linearity: 1.00

Number of levels: 4

SD/rel SD of CF's: 1.2/66.8


Y=2.3161X

r2: 1.0000

Last calibrated: Mon Oct 23 13:17:06 2017


Lvl.	Area/ht.	Amount	CF	Current	Previous #1	Previous #2
1	0.000	0.000	0.000	0.000	N/A	N/A
2	2.620	1.100	2.382	2.620	N/A	N/A
3	23.800	10.100	2.356	23.800	N/A	N/A
4	221.000	100.000	2.210	221.000	N/A	N/A

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 12:41:24  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-Amb.CHR (c:\peak359)  
 Sample: Ambient Background  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.9370	0.0000
Ambient H2O	0.350	0.2580	0.0000
		2.1950	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 12:41:24  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-Amb.CHR (c:\peak359)  
 Sample: Ambient Background  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.166	16.8890	0.0000
Ambient H2O	0.350	144.7770	0.0000
		161.6660	0.0000

Lab name: LCC

Client: Sterigenics - Queensbury

Client ID: PreCal

Analysis date: 10/23/2017 12:44:49

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM

Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-C01.CHR (c:\peak359)

Sample: 100 ppm EtO std

Operator: D. Kremer

Lab name: LCC

Client: Sterigenics - Queensbury

Client ID: PreCal

Analysis date: 10/23/2017 12:44:49

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt


Data file: 2SterQ2017-C01.CHR (c:\peak359)

Sample: 100 ppm EtO std

Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	0.3270	0.0000
Ethylene Oxide	0.466	43.2250	0.0000 ppm
		43.5520	0.0000




Component	Retention	Area	External Units
Dead Vol / Air	0.233	3.6660	0.0000
Ethylene Oxide	0.466	220.9660	0.0000 ppm
Acetaldehyde	0.716	0.1470	0.0000
CO2	0.833	0.1325	0.0000
		224.9115	0.0000

Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 12:53:02  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C02.CHR (c:\peak359)  
 Sample: 100 ppm EtO std  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 12:53:02  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C02.CHR (c:\peak359)  
 Sample: 100 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.2580	0.0000
Ethylene Oxide	0.483	42.0340	0.0000 ppm
		42.2920	0.0000




Component	Retention	Area	External Units
Dead Vol / Air	0.133	0.2175	0.0000
Ethylene Oxide	0.483	221.4190	0.0000 ppm
Acetaldehyde	0.733	0.1530	0.0000
CO2	0.866	0.2450	0.0000
		222.0345	0.0000

Lab Name: EOC  
 Client: Stergenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 12:59:08  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C03.CHR (c:\peak359)  
 Sample: 10.1 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.2380	0.0000
Ethylene Oxide	0.483	4.2500	0.0000 ppm
		4.4880	0.0000

Lab Name: EOC  
 Client: Stergenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 12:59:08  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C03.CHR (c:\peak359)  
 Sample: 10.1 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.283	1.6980	0.0000
Ambient H2O	0.316	0.0090	0.0000
Ethylene Oxide	0.466	23.2650	0.0000 ppm
Acetaldehyde	0.733	0.2260	0.0000
CO2	0.900	0.1160	0.0000
		25.3140	0.0000

Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 13:03:06  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C04.CHR (c:\peak359)  
 Sample: 10.1 ppm EtO std  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.4320	0.0000
Ethylene Oxide	0.483	4.3340	0.0000 ppm
Acetaldehyde	0.750	0.1850	0.0000
		4.9510	0.0000

Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 13:03:06  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C04.CHR (c:\peak359)  
 Sample: 10.1 ppm EtO std  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.150	9.9345	0.0000
Ethylene Oxide	0.483	24.2020	0.0000 ppm
Acetaldehyde	0.683	0.3240	0.0000
CO2	0.866	0.1420	0.0000
		34.6025	0.0000

Lab Name: EOC

Client: Sterigenics - Queensbury

Client ID: PreCal

Analysis date: 10/23/2017 13:08:33

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM

Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-C05.CHR (c:\peak359)

Sample: 1.10 ppm EtO std

Operator: D. Kremer

Lab Name: EOC

Client: Sterigenics - Queensbury

Client ID: PreCal

Analysis date: 10/23/2017 13:08:33

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt


Data file: 2SterQ2017-C05.CHR (c:\peak359)

Sample: 1.10 ppm EtO std

Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.2080	0.0000
Ethylene Oxide	0.466	0.4590	0.0000 ppm
		0.6670	0.0000




Component	Retention	Area	External Units
Dead Vol / Air	0.183	22.5200	0.0000
Ethylene Oxide	0.466	2.6460	0.0000 ppm
Acetaldehyde	0.700	0.1220	0.0000
CO2	0.883	0.2475	0.0000
		25.5355	0.0000

Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 13:11:25  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C06.CHR (c:\peak359)  
 Sample: 1.10 ppm EtO std  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.066	0.2100	0.0000
Ethylene Oxide	0.466	0.4415	0.0000 ppm
		0.6515	0.0000


Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 13:11:25  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C06.CHR (c:\peak359)  
 Sample: 1.10 ppm EtO std  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8330	0.0000
Ethylene Oxide	0.466	2.5890	0.0000 ppm
Acetaldehyde	0.583	0.0905	0.0000
CO2	0.950	0.2385	0.0000
		4.7510	0.0000




Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 13:18:17  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C07.CHR (c:\peak359)  
 Sample: 48.8 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.4135	0.0000
Ethylene Oxide	0.466	20.9545	49.8619 ppm
		21.3680	49.8619

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: PreCal  
 Analysis date: 10/23/2017 13:18:17  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C07.CHR (c:\peak359)  
 Sample: 48.8 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	5.7840	0.0000
Ethylene Oxide	0.466	111.8110	48.2759 ppm
Acetaldehyde	0.666	0.2680	0.0000
CO2	0.866	0.1525	0.0000
		118.0155	48.2759

Lab name: EOC1  
 Client: Sterigenics - Queensbury  
 Client ID: MidCal  
 Analysis date: 10/24/2017 08:30:40  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C08.CHR (c:\peak359)  
 Sample: 48.8 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.2480	0.0000
Ethylene Oxide	0.483	20.6350	49.1016 ppm
		20.8830	49.1016

Lab name: EOC1  
 Client: Sterigenics - Queensbury  
 Client ID: MidCal  
 Analysis date: 10/24/2017 08:30:40  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C08.CHR (c:\peak359)  
 Sample: 48.8 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	1.4930	0.0000
Ethylene Oxide	0.483	114.1340	49.2789 ppm
Acetaldehyde	0.733	0.1270	0.0000
CO2	0.833	0.0950	0.0000
		115.8490	49.2789

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: PostCal  
 Analysis date: 10/24/2017 13:45:53  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-C09.CHR (c:\peak359)  
 Sample: 48.8 ppm EtO std  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.083	0.2120	0.0000
Ethylene Oxide	0.483	20.6810	49.2111 ppm
		20.8930	49.2111

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: PostCal  
 Analysis date: 10/24/2017 13:45:53  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-C09.CHR (c:\peak359)  
 Sample: 48.8 ppm EtO std  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	3.8950	0.0000
Ambient H2O	0.316	0.0330	0.0000
Ethylene Oxide	0.483	115.3670	49.8112 ppm
Acetaldehyde	0.783	0.0720	0.0000
CO2	0.866	0.1255	0.0000
		119.4925	49.8112

## **APPENDIX B**


### **Run #1 Chromatograms – Backvent**

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:10:02  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B01.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7425	0.0000
Ethylene Oxide	0.483	91.1300	216.8467 ppm
		92.8725	216.8467


Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:10:02  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B01.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	15.7820	0.0000
Ambient H2O	0.366	108.8840	0.0000
		124.6660	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:11:09  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carboxpack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B02.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:11:09  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carboxpack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B02.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7905	0.0000
Ethylene Oxide	0.466	33.1730	78.9362 ppm
		34.9635	78.9362




Component	Retention	Area	External Units
Dead Vol / Air	0.083	20.3650	0.0000
Ambient H2O	0.350	109.1170	0.0000
		129.4820	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:12:34  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B03.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:12:34  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B03.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7730	0.0000
Ethylene Oxide	0.483	21.6520	51.5216 ppm
		23.4250	51.5216




Component	Retention	Area	External Units
Dead Vol / Air	0.066	19.2010	0.0000
Ambient H2O	0.366	107.4850	0.0000
		126.6860	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:13:39  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B04.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:13:39  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B04.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7810	0.0000
Ethylene Oxide	0.483	19.6650	46.7935 ppm
		21.4460	46.7935



Component	Retention	Area	External Units
Ambient H2O	0.366	104.6830	0.0000
		104.6830	0.0000




Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:14:46  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B05.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7895	0.0000
Ethylene Oxide	0.466	18.3340	43.6263 ppm
		20.1235	43.6263


Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:14:46  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B05.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	20.1190	0.0000
Ambient H2O	0.366	106.0440	0.0000
		126.1630	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:15:52  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B06.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:15:52  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B06.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7985	0.0000
Ethylene Oxide	0.483	17.3435	41.2694 ppm
		19.1420	41.2694




Component	Retention	Area	External Units
Dead Vol / Air	0.033	21.5530	0.0000
Ambient H2O	0.366	103.9980	0.0000
		125.5510	0.0000

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:17:22  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B07.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8190	0.0000
Ethylene Oxide	0.466	16.7390	39.8310 ppm
		18.5580	39.8310

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:17:22  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B07.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	16.6340	0.0000
Ambient H2O	0.366	102.4705	0.0000
		119.1045	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:18:32  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B08.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8305	0.0000
Ethylene Oxide	0.483	15.9180	37.8774 ppm
		17.7485	37.8774

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:18:32  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B08.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	18.3310	0.0000
Ambient H2O	0.366	103.6890	0.0000
		122.0200	0.0000

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:19:40  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B09.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8845	0.0000
Ethylene Oxide	0.483	15.5240	36.9398 ppm
		17.4085	36.9398


Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:19:40  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B09.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	17.6620	0.0000
Ambient H2O	0.366	101.1570	0.0000
		118.8190	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:20:49  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B10.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:20:49  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B10.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8065	0.0000
Ethylene Oxide	0.483	14.8910	35.4336 ppm
		16.6975	35.4336




Component	Retention	Area	External Units
Ambient H2O	0.366	101.2560	0.0000
		101.2560	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:22:28  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B11.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:22:28  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B11.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8070	0.0000
Ethylene Oxide	0.483	12.6315	30.0570 ppm
		14.4385	30.0570




Component	Retention	Area	External Units
Dead Vol / Air	0.066	15.7020	0.0000
Ambient H2O	0.366	102.9150	0.0000
		118.6170	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:23:39  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1B12.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#1BV  
 Analysis date: 10/24/2017 10:23:39  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1B12.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8160	0.0000
Ethylene Oxide	0.483	8.3735	19.9250 ppm
		10.1895	19.9250



Component	Retention	Area	External Units
Dead Vol / Air	0.083	17.6000	0.0000
Ambient H2O	0.366	101.1250	0.0000
		118.7250	0.0000




## APPENDIX C


### Run #1 Chromatograms – Aeration

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 08:47:07  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A01.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 08:47:07  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A01.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7795	0.0000
Ethylene Oxide	0.466	2.2065	5.2504 ppm
		3.9860	5.2504




Component	Retention	Area	External Units
Dead Vol / Air	0.116	14.3810	0.0000
Ambient H2O	0.350	104.9075	0.0000
		119.2885	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 08:52:19  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A02.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7930	0.0000
Ethylene Oxide	0.483	2.3315	5.5479 ppm
		4.1245	5.5479


Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 08:52:19  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A02.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	15.1460	0.0000
Ambient H2O	0.350	103.7525	0.0000
		118.8985	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 08:57:04  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A03.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 08:57:04  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A03.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8055	0.0000
Ethylene Oxide	0.483	2.2260	5.2968 ppm
		4.0315	5.2968




Component	Retention	Area	External Units
Dead Vol / Air	0.083	15.3310	0.0000
Ambient H2O	0.350	102.9290	0.0000
		118.2600	0.0000

Lab name: 1001  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:02:10  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A04.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: 1001  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:02:10  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A04.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8085	0.0000
Ethylene Oxide	0.483	2.1210	5.0470 ppm
		3.9295	5.0470




Component	Retention	Area	External Units
Dead Vol / Air	0.100	17.3885	0.0000
Ambient H2O	0.366	101.1420	0.0000
		118.5305	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:07:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A05.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:07:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A05.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7930	0.0000
Ethylene Oxide	0.483	2.1460	5.1065 ppm
		3.9390	5.1065




Component	Retention	Area	External Units
Dead Vol / Air	0.116	15.9360	0.0000
Ambient H2O	0.366	100.9190	0.0000
		116.8550	0.0000

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:12:08  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A06.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:12:08  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A06.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8545	0.0000
Ethylene Oxide	0.483	2.1940	5.2207 ppm
		4.0485	5.2207




Component	Retention	Area	External Units
Dead Vol / Air	0.100	14.1310	0.0000
Ambient H2O	0.350	103.4600	0.0000
		117.5910	0.0000

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:17:06  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A07.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8065	0.0000
Ethylene Oxide	0.483	2.0770	4.9423 ppm
		3.8835	4.9423

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:17:06  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A07.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	14.1280	0.0000
Ambient H2O	0.366	100.9490	0.0000
		115.0770	0.0000




Lab name: ECOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:22:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A08.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: ECOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:22:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A08.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8305	0.0000
Ethylene Oxide	0.483	2.0330	4.8376 ppm
		3.8635	4.8376




Component	Retention	Area	External Units
Dead Vol / Air	0.066	13.3630	0.0000
Ambient H2O	0.366	102.8145	0.0000
		116.1775	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:27:22  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A09.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8175	0.0000
Ethylene Oxide	0.483	2.2480	5.3492 ppm
		4.0655	5.3492


Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:27:22  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A09.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	15.3370	0.0000
Ambient H2O	0.366	101.2565	0.0000
		116.5935	0.0000

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:32:05  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A10.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:32:05  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A10.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8055	0.0000
Ethylene Oxide	0.483	2.4140	5.7442 ppm
		4.2195	5.7442




Component	Retention	Area	External Units
Dead Vol / Air	0.100	15.1600	0.0000
Ambient H2O	0.366	101.1835	0.0000
		116.3435	0.0000

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:37:04  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A11.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8030	0.0000
Ethylene Oxide	0.466	2.2220	5.2873 ppm
		4.0250	5.2873

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:37:04  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A11.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	13.0570	0.0000
Ambient H2O	0.350	104.8110	0.0000
		117.8680	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:42:20  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-1A12.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7785	0.0000
Ethylene Oxide	0.483	2.1225	5.0506 ppm
		3.9010	5.0506

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#1Aer  
 Analysis date: 10/24/2017 09:42:20  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-1A12.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	15.3595	0.0000
Ambient H2O	0.366	101.6630	0.0000
		117.0225	0.0000

## **APPENDIX D**


### **Run #2 Chromatograms – Backvent**

Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:32:42  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B01.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7880	0.0000
Ethylene Oxide	0.466	3.9820	9.4753 ppm
		5.7700	9.4753

Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:32:42  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B01.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	16.7070	0.0000
Ambient H2O	0.350	115.9195	0.0000
		132.6265	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:33:52  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B02.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8515	0.0000
Ethylene Oxide	0.466	4.3260	10.2939 ppm
		6.1775	10.2939


Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:33:52  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B02.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.116	23.0940	0.0000
Ambient H2O	0.350	114.3530	0.0000
		137.4470	0.0000




Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:34:56  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B03.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7910	0.0000
Ethylene Oxide	0.466	3.8070	9.0589 ppm
		5.5980	9.0589

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:34:56  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B03.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	26.2230	0.0000
Ambient H2O	0.350	115.3555	0.0000
		141.5785	0.0000

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:36:07  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B04.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8045	0.0000
Ethylene Oxide	0.466	3.7535	8.9316 ppm
		5.5580	8.9316

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:36:07  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B04.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	17.5160	0.0000
Ambient H2O	0.350	119.3485	0.0000
		136.8645	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:37:12  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carboxpack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B05.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8515	0.0000
Ethylene Oxide	0.466	3.7835	9.0030 ppm
		5.6350	9.0030

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:37:12  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carboxpack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B05.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	20.5175	0.0000
Ambient H2O	0.350	118.2160	0.0000
		138.7335	0.0000

Lab name: LCS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:38:18  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B06.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8360	0.0000
Ethylene Oxide	0.466	3.7440	8.9090 ppm
		5.5800	8.9090

Lab name: LCS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:38:18  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbowack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B06.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	23.6060	0.0000
Ambient H2O	0.350	119.2550	0.0000
		142.8610	0.0000

Lab Name: 2007  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:39:26  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B07.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8855	0.0000
Ethylene Oxide	0.466	3.7785	8.9911 ppm
		5.6640	8.9911


Lab Name: 2007  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:39:26  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B07.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	26.3390	0.0000
Ambient H2O	0.350	121.4370	0.0000
		147.7760	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:40:33  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B08.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:40:33  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B08.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8440	0.0000
Ethylene Oxide	0.466	3.8340	9.1231 ppm
		5.6780	9.1231




Component	Retention	Area	External Units
Dead Vol / Air	0.116	29.5490	0.0000
Ambient H2O	0.350	118.7460	0.0000
		148.2950	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:41:41  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B09.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8285	0.0000
Ethylene Oxide	0.466	3.8650	9.1969 ppm
		5.6935	9.1969

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:41:41  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B09.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	31.7510	0.0000
Ambient H2O	0.350	128.0255	0.0000
		159.7765	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:42:53  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B10.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8270	0.0000
Ethylene Oxide	0.466	3.9020	9.2849 ppm
		5.7290	9.2849


Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:42:53  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B10.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.016	23.0990	0.0000
Ambient H2O	0.333	130.0140	0.0000
		153.1130	0.0000




Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:44:36  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B11.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8370	0.0000
Ethylene Oxide	0.450	3.8625	9.1909 ppm
		5.6995	9.1909

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:44:36  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B11.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	19.6710	0.0000
Ambient H2O	0.333	133.1405	0.0000
		152.8115	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:45:42  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2B12.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8580	0.0000
Ethylene Oxide	0.466	3.8690	9.2064 ppm
		5.7270	9.2064

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2BV  
 Analysis date: 10/24/2017 11:45:42  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2B12.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.100	24.9820	0.0000
Ambient H2O	0.350	130.8290	0.0000
		155.8110	0.0000

## **APPENDIX E**

### **Run #2 Chromatograms – Aeration**

Client: Sterigenics - Queensbury

Client ID: Run#2Aer

Analysis date: 10/24/2017 10:27:58

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM

Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-2A01.CHR (c:\peak359)

Sample: Abator Inlet

Operator: D. Kremer

Client: Sterigenics - Queensbury

Client ID: Run#2Aer

Analysis date: 10/24/2017 10:27:58

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt


Data file: 2SterQ2017-2A01.CHR (c:\peak359)

Sample: Abator Outlet

Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7720	0.0000
Ethylene Oxide	0.466	2.6540	6.3153 ppm
		4.4260	6.3153



Component	Retention	Area	External Units
Dead Vol / Air	0.066	14.3950	0.0000
Ambient H2O	0.350	107.7645	0.0000
		122.1595	0.0000

Client: Sterigenics - Queensbury

Client ID: Run#2Aer

Analysis date: 10/24/2017 10:32:14

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM

Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-2A02.CHR (c:\peak359)

Sample: Abator Inlet

Operator: D. Kremer

Client: Sterigenics - Queensbury

Client ID: Run#2Aer

Analysis date: 10/24/2017 10:32:14

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt


Data file: 2SterQ2017-2A02.CHR (c:\peak359)

Sample: Abator Outlet

Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8015	0.0000
Ethylene Oxide	0.483	2.6410	6.2843 ppm
		4.4425	6.2843




Component	Retention	Area	External Units
Dead Vol / Air	0.083	17.6050	0.0000
Ambient H2O	0.366	101.7180	0.0000
		119.3230	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:37:04  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A03.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:37:04  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A03.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8010	0.0000
Ethylene Oxide	0.483	2.8400	6.7579 ppm
		4.6410	6.7579



Component	Retention	Area	External Units
Dead Vol / Air	0.083	17.6740	0.0000
Ambient H2O	0.366	104.3350	0.0000
		122.0090	0.0000

Client: Sterigenics - Queensbury

Client ID: Run#2Aer

Analysis date: 10/24/2017 10:42:21

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM

Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-2A04.CHR (c:\peak359)

Sample: Abator Inlet

Operator: D. Kremer

Client: Sterigenics - Queensbury

Client ID: Run#2Aer

Analysis date: 10/24/2017 10:42:21

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt


Data file: 2SterQ2017-2A04.CHR (c:\peak359)

Sample: Abator Outlet

Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7875	0.0000
Ethylene Oxide	0.466	2.7975	6.6567 ppm
		4.5850	6.6567




Component	Retention	Area	External Units
Dead Vol / Air	0.100	17.3580	0.0000
Ambient H2O	0.366	103.7585	0.0000
		121.1165	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:47:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A05.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8085	0.0000
Ethylene Oxide	0.483	3.0910	7.3551 ppm
		4.8995	7.3551

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:47:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A05.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	16.6420	0.0000
Ambient H2O	0.366	104.5145	0.0000
		121.1565	0.0000




Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:52:18  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tern  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A06.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:52:18  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tern  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A06.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7830	0.0000
Ethylene Oxide	0.466	3.1930	7.5978 ppm
		4.9760	7.5978




Component	Retention	Area	External Units
Dead Vol / Air	0.066	17.2170	0.0000
Ambient H2O	0.350	102.5845	0.0000
		119.8015	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:57:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A07.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7915	0.0000
Ethylene Oxide	0.483	3.3280	7.9191 ppm
		5.1195	7.9191

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 10:57:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A07.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	16.9740	0.0000
Ambient H2O	0.366	103.2170	0.0000
		120.1910	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:02:17  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A08.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8045	0.0000
Ethylene Oxide	0.483	3.7775	8.9887 ppm
		5.5820	8.9887

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:02:17  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A08.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	18.1690	0.0000
Ambient H2O	0.366	100.5065	0.0000
		118.6755	0.0000

Lab Name: ESS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:07:02  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A09.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7965	0.0000
Ethylene Oxide	0.466	3.3610	7.9976 ppm
		5.1575	7.9976


Lab Name: ESS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:07:02  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A09.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	17.7290	0.0000
Ambient H2O	0.366	104.6195	0.0000
		122.3485	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:12:20  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A10.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:12:20  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A10.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.216	1.7945	0.0000	
Ethylene Oxide	0.483	3.4895	8.3034	ppm
		5.2840	8.3034	




Component	Retention	Area	External	Units
Dead Vol / Air	0.100	17.6650	0.0000	
Ambient H2O	0.366	99.8700	0.0000	
		117.5350	0.0000	

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:17:34  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A11.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7755	0.0000
Ethylene Oxide	0.483	3.3715	8.0226 ppm
		5.1470	8.0226

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:17:34  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A11.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	16.9850	0.0000
Ambient H2O	0.366	99.5680	0.0000
		116.5530	0.0000

Lab name: ECSI  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:22:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-2A12.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8650	0.0000
Ethylene Oxide	0.483	3.3270	7.9167 ppm
	5.1920	0.0000	7.9167

Lab name: ECSI  
 Client: Sterigenics - Queensbury  
 Client ID: Run#2Aer  
 Analysis date: 10/24/2017 11:22:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-2A12.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	16.9000	0.0000
Ambient H2O	0.366	100.8810	0.0000
		117.7810	0.0000

## **APPENDIX F**

### **Run #3 Chromatograms – Backvent**




Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:51:02  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B01.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8320	0.0000
Ethylene Oxide	0.483	3.4090	8.1118 ppm
		5.2410	8.1118

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:51:02  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B01.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.033	27.7805	0.0000
Ambient H2O	0.366	149.8390	0.0000
		177.6195	0.0000

Lab Name: 100  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:52:05  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B02.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.216	2.1960	0.0000	
Ethylene Oxide	0.483	7.7790	18.5104	ppm
Acetaldehyde	0.700	0.5120	0.0000	
		10.4870	18.5104	

Lab Name: 100  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:52:05  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B02.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.066	23.8420	0.0000	
Ambient H2O	0.350	147.0440	0.0000	
		170.8860	0.0000	

Client: Sterigenics - Queensbury

Client ID: Run#3BV

Analysis date: 10/24/2017 12:53:23

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-3B03.CHR (c:\peak359)

Sample: Abator Inlet

Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7715	0.0000
Ethylene Oxide	0.483	4.2130	10.0250 ppm
		5.9845	10.0250

Client: Sterigenics - Queensbury

Client ID: Run#3BV

Analysis date: 10/24/2017 12:53:23

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt

Data file: 2SterQ2017-3B03.CHR (c:\peak359)


Sample: Abator Outlet

Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	21.1640	0.0000
Ambient H2O	0.350	140.8165	0.0000
		161.9805	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:54:40  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B04.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8080	0.0000
Ethylene Oxide	0.483	4.0200	9.5657 ppm
		5.8280	9.5657

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:54:40  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B04.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.083	20.0240	0.0000
Ambient H2O	0.366	139.1430	0.0000
		159.1670	0.0000

Lab name: EOC

Client: Sterigenics - Queensbury

Client ID: Run#3BV

Analysis date: 10/24/2017 12:55:45

Method: Direct Injection

Description: CHANNEL 1 - FID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM

Temp. prog: eto-100.tem

Components: eto1-100.cpt

Data file: 1SterQ2017-3B05.CHR (c:\peak359)

Sample: Abator Inlet

Operator: D. Kremer

Lab name: EOC

Client: Sterigenics - Queensbury

Client ID: Run#3BV

Analysis date: 10/24/2017 12:55:45

Method: Direct Injection

Description: CHANNEL 2 - PID

Column: 1% SP-1000, Carbopack B

Carrier: HELIUM


Temp. prog: eto-100.tem

Components: eto2-100.cpt


Data file: 2SterQ2017-3B05.CHR (c:\peak359)

Sample: Abator Outlet

Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7775	0.0000
Ethylene Oxide	0.483	3.7750	8.9827 ppm
		5.5525	8.9827




Component	Retention	Area	External Units
Dead Vol / Air	0.133	20.4650	0.0000
Ambient H2O	0.366	137.6260	0.0000
		158.0910	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:56:55  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B06.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.7860	0.0000	
Ethylene Oxide	0.483	3.8360	9.1279	ppm
		5.6220	9.1279	

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:56:55  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B06.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.100	20.5895	0.0000	
Ambient H2O	0.350	137.6820	0.0000	
		158.2715	0.0000	

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:58:05  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B07.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.8015	0.0000	
Ethylene Oxide	0.483	3.8040	9.0517	ppm
		5.6055	9.0517	


Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:58:05  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B07.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	20.2100	0.0000	
Ambient H2O	0.366	138.5300	0.0000	
		158.7400	0.0000	

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:59:10  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B08.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 12:59:10  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B08.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7825	0.0000
Ethylene Oxide	0.466	3.7960	9.0327 ppm
		5.5785	9.0327



Component	Retention	Area	External Units
Dead Vol / Air	0.083	18.6850	0.0000
Ambient H2O	0.350	138.8955	0.0000
		157.5805	0.0000




Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:00:49  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B09.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7795	0.0000
Ethylene Oxide	0.483	3.8590	9.1826 ppm
		5.6385	9.1826


Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:00:49  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B09.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	19.3325	0.0000
Ambient H2O	0.350	141.1785	0.0000
		160.5110	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:02:12  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B10.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:02:12  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B10.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External	Units
Dead Vol / Air	0.233	1.7930	0.0000	
Ethylene Oxide	0.483	3.6990	8.8019	ppm
		5.4920	8.8019	




Component	Retention	Area	External	Units
Dead Vol / Air	0.083	19.9345	0.0000	
Ambient H2O	0.350	137.9355	0.0000	
		157.8700	0.0000	

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:03:36  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B11.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.7740	0.0000
Ethylene Oxide	0.483	3.5800	8.5187 ppm
		5.3540	8.5187


Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:03:36  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B11.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	19.9025	0.0000
Ambient H2O	0.350	134.7480	0.0000
		154.6505	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:04:50  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3B12.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Client: Sterigenics - Queensbury  
 Client ID: Run#3BV  
 Analysis date: 10/24/2017 13:04:50  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3B12.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7850	0.0000
Ethylene Oxide	0.466	3.5800	8.5187 ppm
		5.3650	8.5187




Component	Retention	Area	External Units
Dead Vol / Air	0.100	18.6655	0.0000
Ambient H2O	0.350	139.7530	0.0000
		158.4185	0.0000

## **APPENDIX G**


### **Run #3 Chromatograms – Aeration**

Lab Name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 11:49:24  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A01.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8440	0.0000
Ethylene Oxide	0.466	3.8690	9.2064 ppm
		5.7130	9.2064

Lab Name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 11:49:24  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A01.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	20.4420	0.0000
Ambient H2O	0.333	142.3195	0.0000
		162.7615	0.0000

Lab Name: ESS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 11:54:04  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A02.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8605	0.0000
Ethylene Oxide	0.466	3.8370	9.1303 ppm
		5.6975	9.1303

Lab Name: ESS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 11:54:04  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A02.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.066	22.6490	0.0000
Ambient H2O	0.350	135.1760	0.0000
		157.8250	0.0000

Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 11:59:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A03.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8730	0.0000
Ethylene Oxide	0.466	3.8555	9.1743 ppm
		5.7285	9.1743


Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 11:59:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A03.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.116	21.3050	0.0000
Ambient H2O	0.333	140.4745	0.0000
		161.7795	0.0000




Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:04:20  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A04.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8550	0.0000
Ethylene Oxide	0.450	3.8390	9.1350 ppm
		5.6940	9.1350


Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:04:20  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A04.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.016	21.9140	0.0000
Ambient H2O	0.333	138.5885	0.0000
		160.5025	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:09:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A05.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:09:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A05.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8790	0.0000
Ethylene Oxide	0.466	3.9425	9.3813 ppm
		5.8215	9.3813




Component	Retention	Area	External Units
Dead Vol / Air	0.083	22.7170	0.0000
Ambient H2O	0.350	134.9845	0.0000
		157.7015	0.0000

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:14:05  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tern  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A06.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8610	0.0000
Ethylene Oxide	0.483	3.9085	9.3004 ppm
		5.7695	9.3004

Lab name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:14:05  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tern  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A06.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.100	24.3650	0.0000
Ambient H2O	0.350	138.0510	0.0000
		162.4160	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:19:18  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A07.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.7805	0.0000
Ethylene Oxide	0.466	3.8570	9.1779 ppm
		5.6375	9.1779

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:19:18  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A07.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.083	25.4140	0.0000
Ambient H2O	0.350	132.6885	0.0000
		158.1025	0.0000

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:24:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A08.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8450	0.0000
Ethylene Oxide	0.466	3.9490	9.3968 ppm
		5.7940	9.3968

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:24:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A08.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.050	23.0900	0.0000
Ambient H2O	0.350	135.7875	0.0000
		158.8775	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:29:03  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A09.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8280	0.0000
Ethylene Oxide	0.450	3.9120	9.3087 ppm
		5.7400	9.3087

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:29:03  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A09.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.116	21.7760	0.0000
Ambient H2O	0.333	134.8745	0.0000
		156.6505	0.0000

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:34:25  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A10.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Dead Vol / Air	0.233	1.8385	0.0000
Ethylene Oxide	0.466	3.9045	9.2909 ppm
		5.7430	9.2909

Lab name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:34:25  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A10.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer




Component	Retention	Area	External Units
Ambient H2O	0.350	133.2710	0.0000
		133.2710	0.0000

Lab Name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:39:07  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tern  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A11.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8270	0.0000
Ethylene Oxide	0.466	3.9250	9.3397 ppm
		5.7520	9.3397


Lab Name: EOS  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:39:07  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tern  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A11.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.133	20.6150	0.0000
Ambient H2O	0.350	130.7905	0.0000
		151.4055	0.0000




Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:44:07  
 Method: Direct Injection  
 Description: CHANNEL 1 - FID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto1-100.cpt  
 Data file: 1SterQ2017-3A12.CHR (c:\peak359)  
 Sample: Abator Inlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.216	1.8635	0.0000
Ethylene Oxide	0.466	3.8090	9.0636 ppm
		5.6725	9.0636

Lab Name: EOC  
 Client: Sterigenics - Queensbury  
 Client ID: Run#3Aer  
 Analysis date: 10/24/2017 12:44:07  
 Method: Direct Injection  
 Description: CHANNEL 2 - PID  
 Column: 1% SP-1000, Carbopack B  
 Carrier: HELIUM  
 Temp. prog: eto-100.tem  
 Components: eto2-100.cpt  
 Data file: 2SterQ2017-3A12.CHR (c:\peak359)  
 Sample: Abator Outlet  
 Operator: D. Kremer



Component	Retention	Area	External Units
Dead Vol / Air	0.100	19.8280	0.0000
Ambient H2O	0.333	135.5945	0.0000
		155.4225	0.0000

## **APPENDIX H**

### **Field Data and Calculation Worksheets**

# ECSi, Inc.

## Ethylene Oxide Mass Emissions Data and Calculations

Sterigenics U.S., LLC. - Queensbury, New York

10/24/17 - Backvent Runs 1-3

<u>DeltaP</u>	<u>SqRtDeltaP</u>	<u>Temp (F)</u>	<u>ppm EtO</u>	<u>mw =</u>	28.51	
Run #1				<u>stack area =</u>	3.14	
0.29	0.5385	200	0.01	<u>press =</u>	29.75	
0.29	0.5385	200	0.01	<u>Tstd =</u>	528	
0.29	0.5385	200	0.01	<u>Pstd =</u>	29.92	
0.29	0.5385	200	0.01	<u>Cp =</u>	0.99	
0.29	0.5385	200	0.01	<u>Kp =</u>	85.49	
0.29	0.5385	201	0.01	<u>Velocity =</u>	40.2	ft/sec
0.29	0.5385	201	0.01	<u>Flow =</u>	5839	dscfm
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01	<u>MWeto =</u>	44.05	
0.29	0.5385	201	0.01	<u>MolVol =</u>	385.32	
0.29	0.5385	201	0.01	<u>ppmv/ft3 =</u>	1000000	
Run #2						
0.29	0.5385	201	0.01	<u>EtO Mass Flow =</u>	0.000007	lbs/min
0.29	0.5385	201	0.01	<u>EtO Mass Flow =</u>	0.000400	lbs/hr
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	203	0.01			
Run #3						
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01			
Average =						
0.29	0.5385	201.3	0.0100			
		= 661	degR			

# ECSi, Inc.

## Ethylene Oxide Mass Emissions Data and Calculations

**Sterigenics U.S., LLC. - Queensbury, New York**

**10/24/17 - Aeration Runs 1-3**

<u>DeltaP</u>	<u>SqRtDeltaP</u>	<u>Temp (F)</u>	<u>ppm EtO</u>	<u>mw =</u>	28.51	
<b>Run #1</b>				<b>stack area =</b>	3.14	
0.29	0.5385	200	0.01	<b>press =</b>	29.75	
0.29	0.5385	201	0.01	<b>Tstd =</b>	528	
0.29	0.5385	201	0.01	<b>Pstd =</b>	29.92	
0.29	0.5385	201	0.01	<b>Cp =</b>	0.99	
0.29	0.5385	201	0.01	<b>Kp =</b>	85.49	
0.29	0.5385	201	0.01	<b>Velocity =</b>	40.3	ft/sec
0.29	0.5385	201	0.01	<b>Flow =</b>	<b>5837</b>	<b>dscfm</b>
0.29	0.5385	202	0.01			
0.29	0.5385	202	0.01	<b>MWeto =</b>	44.05	
0.29	0.5385	202	0.01	<b>MolVol =</b>	385.32	
0.29	0.5385	202	0.01	<b>ppmv/ft3 =</b>	1000000	
<b>Run #2</b>						
0.29	0.5385	202	0.01	<b>EtO Mass Flow =</b>	<b>0.000007</b>	<b>lbs/min</b>
0.29	0.5385	201	0.01	<b>EtO Mass Flow =</b>	<b>0.000400</b>	<b>lbs/hr</b>
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
0.29	0.5385	201	0.01			
<b>Run #3</b>						
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
0.29	0.5385	203	0.01			
<b>Average =</b>						
0.29	0.5385	201.8	<b>0.0100</b>			
		<b>= 662</b>	<b>degR</b>			

# ETHYLENE OXIDE SOURCE TEST/CALIBRATION DATA

Client: Sterigenics-Queensbury, NY

Source Tested: Celkote Packed Tower Scrubber and Donaldson EtO Abator

Date: 10/23-10/24/17

## PRE CALIBRATION

	Calibration Gas Conc. (ppmv)	1.10 ppm EtO	10.1 ppm EtO	100 ppm EtO	1000 ppm EtO	10080 ppm EtO			
Inlet (FID)	Area Counts #1	459	4.25	43.2					
	Area Counts #2	442	4.33	42.0					
	Average Area	451	4.29	42.6					
	Audit Standard (48.8 ppmv) Result <u>49.9</u> ✓								
Outlet (PID)	Area Counts #1	2.65	23.3	221					
	Area Counts #2	2.59	24.2	221					
	Average Area	2.62	23.8	221					
	Audit Standard (48.8 ppmv) Result <u>48.3</u> ✓								

Ch. 9 1953 Ch. 3 Ch. 1  
 Run #1 Run #2 Run #3  
 Exh start/stop: 1325 1402 2023 2031 2104 2112  
 BV start/stop: 1009 1024 1131 1146 1250 1315  
 AEs start/stop: 0945 0945 1025 1125 1157 1247

P<sub>bar</sub>: 29.75  
 %H<sub>2</sub>O: 3

EtO Usage (lbs/yr): —  
 Cycles Per Week: —

## POST CALIBRATION

	Calibration Gas Conc. (ppmv)	1.10 ppm EtO	10.1 ppm EtO	100 ppm EtO	1000 ppm EtO	10080 ppm EtO			
Inlet (FID)	Area Counts #1								
	Area Counts #2								
	Average Area						Mid	Post	
	Audit Standard (48.8 ppmv) Result <u>49.1</u> ✓ <u>49.2</u> ✓								
Outlet (PID)	Area Counts #1								
	Area Counts #2								
	Average Area						Mid	Post	
	Audit Standard (48.8 ppmv) Result <u>49.3</u> ✓ <u>49.8</u> ✓								

ECSi

**APPENDIX I**  
**Gas Certifications**



**Scott Specialty Gases**

500 CAJON BLVD., SAN BERNARDINO, CA 92411

**CERTIFIED WORKING CLASS**

*Single-Certified Calibration Standard*

Phone: 909-887-2571 Fax: 909-887-0549

**CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard**

**Product Information**

Project No.: 02-57164-001  
Item No.: 02020001310TCL  
P.O. No.: VBL - D. KREMER

Cylinder Number: CAL4448  
Cylinder Size: CL  
Certification Date: 18Apr2016

**Customer**

ECSI, INC  
PO BOX 848  
SAN CLEMENTE, CA 92672

**CERTIFIED CONCENTRATION**

**Component Name**

**Concentration  
(Moles)**

**Accuracy  
(+/-%)**

ETHYLENE OXIDE  
NITROGEN

1.10 PPM  
BALANCE

5

**TRACEABILITY**

**Traceable To**

Scott Reference Standard

APPROVED BY:

  
MT

DATE:

4-18-16

## SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)		Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE NITROGEN	1.	PPM BAL	1.10	PPM BAL	10.0	5.00

## TRACEABILITY

Traceable To  
Scott Reference Standard

## PHYSICAL PROPERTIES

Cylinder Size: CL                      Pressure: 1300 PSIG  
Expiration Date: 18Apr2018

## SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

## COMMENTS





**Scott Specialty Gases**

100 CAJON BLVD., SAN BERNARDINO, CA 92411

**CERTIFIED WORKING CLASS**

*Single-Certified Calibration Standard*

Phone: 909-887-2571 Fax: 909-887-0549

**CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard**

**Product Information**

Project No.: 02-57164-003  
Item No.: 02020001320TCL  
P.O. No.: VBL-D. KREMER

Cylinder Number: CLM003232  
Cylinder Size: CL  
Certification Date: 18Apr2016

**Customer**

ECSI, INC  
PO BOX 848  
SAN CLEMENTE, CA 92672

**CERTIFIED CONCENTRATION**

**Component Name**

ETHYLENE OXIDE  
NITROGEN

**Concentration  
(Moles)**

10.1 PPM  
BALANCE

**Accuracy  
(+/-%)**

5

**TRACEABILITY**

**Traceable To**

Scott Reference Standard

APPROVED BY:

MT

DATE: 4-18-16

## SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)		Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	10.	PPM	10.1	PPM	1.0	5.00
NITROGEN		BAL		BAL		

## TRACEABILITY

Traceable To  
Scott Reference Standard

## PHYSICAL PROPERTIES

Cylinder Size: CL                      Pressure: 1400 PSIG  
Expiration Date: 18Apr2018

## SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

## COMMENTS



# Scott Specialty Gases

500 CAJON BLVD., SAN BERNARDINO, CA 92411

## CERTIFIED WORKING CLASS

*Single-Certified Calibration Standard*

Phone: 909-887-2571 Fax: 909-887-0549

### CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

#### Product Information

Project No.: 02-57164-004  
Item No.: 02020001330TCL  
P.O. No.: VBL-D. KREMER

Cylinder Number: CLM011385  
Cylinder Size: CL  
Certification Date: 18Apr2016

#### Customer

ECSI, INC  
PO BOX 848  
SAN CLEMENTE, CA 92672

### CERTIFIED CONCENTRATION

#### Component Name

ETHYLENE OXIDE  
NITROGEN

#### Concentration (Moles)

100. PPM  
BALANCE

#### Accuracy (+/-%)

5

### TRACEABILITY

#### Traceable To

Scott Reference Standard

APPROVED BY:

B-McCully  
BLM

DATE: 4-18-16

## SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)		Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	100.	PEM	100.	PEM	.0	5.00
NITROGEN		BAL		BAL		

## TRACEABILITY

Traceable To  
Scott Reference Standard

## PHYSICAL PROPERTIES

Cylinder Size: CL      Pressure: 1400 PSIG      Valve Connection: CGA 350  
Expiration Date: 18Apr2018

## SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

## COMMENTS



# Scott Specialty Gases

300 CAJON BLVD., SAN BERNARDINO, CA 92411

## CERTIFIED WORKING CLASS

*Single-Certified Calibration Standard*

Phone: 909-887-2571 Fax: 909-887-0549

### CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

#### Product Information

Project No.: 02-57164-005  
Item No.: 02020001340TCL  
P.O. No.: VBL - D. KREMER

Cylinder Number: CLM002810  
Cylinder Size: CL  
Certification Date: 18Apr2016

#### Customer

ECSI, INC  
PO BOX 848  
SAN CLEMENTE, CA 92672

### CERTIFIED CONCENTRATION

#### Component Name

#### Concentration (Moles)

#### Accuracy (+/-%)

ETHYLENE OXIDE  
NITROGEN

1,000. PPM  
BALANCE

5

### TRACEABILITY

#### Traceable To

Scott Reference Standard

APPROVED BY:

  
BLM

DATE: 4-18-16

## SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)		Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	1,000.	PPM	1,000.	PPM	.0	5.00
NITROGEN		BAL		BAL		

## TRACEABILITY

### Traceable To

Scott Reference Standard

## PHYSICAL PROPERTIES

Cylinder Size: CL

Pressure: 1300 PSIG  
Expiration Date: 18Apr2018

Valve Connection: CGA 350

## SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.

## COMMENTS



# Scott Specialty Gases

100 CAJON BLVD., SAN BERNARDINO, CA 92411

## CERTIFIED WORKING CLASS

*Single-Certified Calibration Standard*

Phone: 909-887-2571 Fax: 909-887-0549

### CERTIFICATE OF ACCURACY: Certified Working Class Calibration Standard

#### Product Information

Project No.: 02-57164-006  
Item No.: 02020001340TCL  
P.O. No.: VBL-D. KREMER

Cylinder Number: CLM005787  
Cylinder Size: CL  
Certification Date: 18Apr2016

#### Customer

ECSI, INC  
PO BOX 848  
SAN CLEMENTE, CA 92672

### CERTIFIED CONCENTRATION

#### Component Name

#### Concentration (Moles)

#### Accuracy (+/-%)

ETHYLENE OXIDE  
NITROGEN

10,080. PPM  
BALANCE


5

### TRACEABILITY

#### Traceable To

Scott Reference Standard

APPROVED BY:

  
BLM

DATE: 4-18-16

## SPECIFICATIONS

Component Name	Requested Concentration (Moles)		Certified Concentration (Moles)		Blend Tolerance Result (+/- %)	Certified Accuracy Result (+/- %)
ETHYLENE OXIDE	10,000.	PPM	10,080.	PPM	.8	5.00
NITROGEN		BAL		BAL		

## TRACEABILITY

Traceable To  
Scott Reference Standard

## PHYSICAL PROPERTIES

Cylinder Size: CL

Pressure: 800 PSIG  
Expiration Date: 18Apr2018

Valve Connection: CGA 350

## SPECIAL HANDLING INSTRUCTIONS

Do not use or store cylinder at or below the stated dew point temperature. Possible condensation of heavier components could result. In the event the cylinder has been exposed to temperatures at or below the dew point, place cylinder in heated area for 24 hours and then roll cylinder for 15 minutes to re-mix.

Use of calibration standards at or below dew point temperature may result in calibration error.


## COMMENTS



## CERTIFICATE OF ANALYSIS

Customer Name:	ECSi, Inc.	Cylinder Number:	SA25925
Stock or Analyzer Tag Number:	N/A	Product Class:	Certified Standard
Customer Reference:	Verbal- Dan	Cylinder - Contents <sup>1</sup> :	28 CF @ 2000 PSI
MESA Reference:	104448	Cylinder-CGA:	A006-HP-BR/350
Date of Certification:	4/20/2016	Analysis Method:	GC-TCD/FID
Recommended Shelf Life:	2 Years	Preparation Method:	Gravimetric

Component	Requested Concentration <sup>2</sup>	Reported Concentration <sup>2,3</sup>
Ethylene Oxide	50 ppm	48.8 ppm
Nitrogen	Balance	Balance

Authorized Signature: 

1. The fill pressure shown on the COA is as originally quoted. The fill pressure measured by the customer may differ from the fill pressure originally quoted due to temperature effects, compressibility of the individual components when blended together in the cylinder, gauge accuracy or reduction in content volume before shipping as a result of samples withdrawn for laboratory QC necessary to ensure product quality.
2. Unless otherwise stated, concentrations are given in molar units.
3. Vapor pressure mixes are blended at a sufficiently low pressure so as to eliminate phase separation under most low temperature conditions encountered during transport or storage. However, it is generally recommended that cylinders containing vapor pressure restricted mixes be placed on the floor in a horizontal position and rolled back and forth to improve homogeneity of the gas phase mixture before being put into service.

Analytical Gas Standards are prepared and analyzed using combinations of NIST traceable weights, SRM's provided by NIST, or internal gas standards that have been verified for accuracy using procedures published by the US-EPA. Pure gases are analyzed and certified for purity using minor component Analytical Gas Standards prepared according to the methods specified above. Balances are calibrated to NIST test weights covered by NIST test number 822/256175/96. Reference Certification #'s: 163/W, 830/N and 3280. Calibration methods are in conformance with MIL-STD 45662A.

### MESA Specialty Gases & Equipment

division of MESA International Technologies, Inc.

3619 Pendleton Avenue, Suite C ♦ Santa Ana, California 92704 ♦ USA  
TEL: 714-434-7102 ♦ FAX: 714-434-8006 ♦ E-mail: [mail@mesagas.com](mailto:mail@mesagas.com)  
On-line Catalog at [www.mesagas.com](http://www.mesagas.com)