

Table 6-6
Sample Bottle and Preservative Specifications
for Chemical and Radiochemical Analysis of Sediment Samples^a

Parameters Analyzed	Holding Time ^b	Recommended Size Sample Container ^{c,d}	Container Material	Preservative
VOCs	48 hours to extraction, 8 days until analysis	(3X) 5g EnCore™ Sampler	EnCore™ Sampler	4°C
Percent Moisture	28 days	(2 oz)	G ^e	4°C
Inorganics	6 months	16 oz	G ^e	4°C
Mercury	28 days			
Cyanide	14 days			
SVOCs	7 days to extraction, 40 days until analysis			
Aroclors, PCBs/Pesticides	7 days to extraction, 40 days until analysis			
Chlorinated Herbicides	7 days to extraction, 40 days until analysis			
TOC	14 days			
TEPH	14 days to extraction, 40 days until analysis			
Radiochemicals	3 months	16 oz	G ^e	4°C
Organotins	14 days to extraction, 40 days until analysis	4 oz ^f	G ^e	4°C
Grain Size	28 days	2 oz	G ^e	4°C
PCB Congeners and Homologues	7 days to extraction, 40 days until analysis	16 oz	G ^e	4°C
PCDDs/PCDFs	30 days to extraction, 40 days until analysis			

Notes:

- Analytical methods are specified in Table 6-8.
- Holding time is calculated from the date of sample collection to the date of sample analysis (or extraction as noted).
- Samples for analyses having identical container and preservation requirements may be combined in the same container. The noted 16-oz. container will hold sufficient mass to meet the minimum requirements specified in Table 6-5 for all specified analyses.
- Wide-mouth jars with Teflon-lined lids preferred.
- G = Amber glass.
- Two 4-oz. jars will be needed for samples identified for matrix spike and matrix spike duplicates.