

# TE-1000 Hi-Vol One-point Flow Verification Data Form

## Site Information

Full Site Name: XACT-NIPSCO

Site Abbreviation: XAC Sampler Serial No.: 49524619

Field Technician Name: Katie Healy Date: 6/2/21 Time: 13:00 CST

## Site Conditions \*allow Temperature/Pressure standard to acclimate for 10 minutes before reading

Temp/Pressure Standard Make/Model: DeltaCal DC1

Temp/Pressure Standard Serial No.: 34 Temp/Pressure Standard Certification Date: 8/18/20

T<sub>amb</sub> transfer standard (°C) 24.4 T<sub>amb</sub> (K) 297.4 T<sub>amb</sub> transfer standard (°C) + 273 = T<sub>amb</sub> (K)

P<sub>amb</sub> transfer standard (mmHg) 743

## Calibration Orifice/Manometer Information

Orifice Make/Model: Graseby Orifice Serial No.: \_\_\_\_\_

Orifice Slope "m<sub>orifice</sub>": 10.46067 Orifice Intercept "b<sub>orifice</sub>": -0.16706

Orifice Certification Date: 2/4/2021

\*if using a "U" tube manometer, write "U-tube" in Make/Model and leave the other spaces blank

Manometer Make/Model: Dwyer 475 Mark III Manometer Serial No.: 007947

Manometer Certification Date: 2/4/2021

## One-Point Flow Check Procedure

\*flow check is to be performed after the 5<sup>th</sup> scheduled sample run of each month

- Set up the sampler as if performing a flow calibration with certified orifice and manometer. No sample media should be inside the module.
- Turn on the hi-vol's motor at the Magnehelic Setpoint (found on TE-1000 Calibration Data Form) for 10-15 minutes. If the ambient Temperature and Pressure are significantly different from the day the calibration was performed, the Magnehelic Gauge Setpoint may need to be recalculated using the following equation:

$$\text{Magnehelic Setpoint (inH}_2\text{O)} = \left( \frac{P_{\text{amb}}}{T_{\text{amb}}} * \frac{298K}{760\text{mmHg}} \right) * \left[ \left( m_{\text{hivol}} * 0.225 \frac{\text{m}^3}{\text{minute}} \right) + b_{\text{hivol}} \right]^2 = \underline{39.3}$$

- Record the Magnehelic Gauge Pressure and the Manometer Pressure.

P<sub>Magnehelic</sub> (inH<sub>2</sub>O) 39 P<sub>Manometer</sub> (inH<sub>2</sub>O) 4.0

- Record m<sub>hivol</sub> and b<sub>hivol</sub> from the TE-1000 Calibration Data Form:

Hi-Vol Slope, m<sub>hivol</sub> 35.0115 Hi-Vol Intercept, b<sub>hivol</sub> -1.5447

- Calculate the Magnehelic flow rate using the following equation:

$$Q_{\text{Magnehelic}} \left( \frac{\text{m}^3}{\text{min}} \right) = \frac{1}{m_{\text{hivol}}} * \left( \sqrt{P_{\text{Magnehelic}} * \left( \frac{P_{\text{amb}} * 298K}{760\text{mmHg} * T_{\text{amb}}} \right)} - b_{\text{hivol}} \right) = \underline{0.221}$$

\*T<sub>amb</sub> should be in degrees Kelvin: T<sub>amb</sub> (°C) + 273 = T<sub>amb</sub> (K)

- Calculate the Manometer flow rate using the following equation:

$$Q_{\text{Manometer}} \left( \frac{\text{m}^3}{\text{min}} \right) = \frac{1}{m_{\text{orifice}}} * \left( \sqrt{P_{\text{Manometer}} * \left( \frac{P_{\text{amb}} * 298K}{760\text{mmHg} * T_{\text{amb}}} \right)} - b_{\text{orifice}} \right) = \underline{0.205}$$

\*T<sub>amb</sub> should be in degrees Kelvin: T<sub>amb</sub> (°C) + 273 = T<sub>amb</sub> (K)

- Calculate the percent difference between Q<sub>Magnehelic</sub> and Q<sub>Manometer</sub>:

$$\text{Percent Difference} = 100 * (1 - (Q_{\text{Manometer}} / Q_{\text{Magnehelic}})) = \underline{7.1} \%$$

- Is the Percent Difference  $\leq \pm 10\%$ ? (YES) NO (circle one)

a. If YES, flow check is complete.

b. If NO, use the TE-1000 Operator's Manual to troubleshoot and retry the flow check. If the issue persists, the sampler will need to be recalibrated. Contact the Project Leads.