

TE-1000 Hi-Vol One-point Flow Verification Data Form

Site Information

Full Site Name: Xact - NIPSO

Site Abbreviation: XAC Sampler Serial No.: 49524619

Field Technician Name: Kate Haile & Katie Healy Date: 6/25/21 Time: 13:35 CST

Site Conditions *allow Temperature/Pressure standard to acclimate for 10 minutes before reading

Temp/Pressure Standard Make/Model: delta cal DC1

Temp/Pressure Standard Serial No.: 34 Temp/Pressure Standard Certification Date: 8/18/2020

T_{amb} transfer standard (°C) 23.5 T_{amb} (K) 296.5 T_{amb} transfer standard (°C) + 273 = T_{amb} (K)

P_{amb} transfer standard (mmHg) 741

Calibration Orifice/Manometer Information

Orifice Make/Model: Graseby/Tisch Orifice Serial No.: 62K

Orifice Slope "m_{orifice}": 10.46067 Orifice Intercept "b_{orifice}": -0.16706

Orifice Certification Date: 2/4/21

*if using a "U" tube manometer, write "U-tube" in Make/Model and leave the other spaces blank

Manometer Make/Model: Dwyer 435 Mark II Manometer Serial No.: 007947

Manometer Certification Date: 2/4/21

One-Point Flow Check Procedure

*flow check is to be performed after the 5th scheduled sample run of each month

1. Set up the sampler as if performing a flow calibration with certified orifice and manometer. No sample media should be inside the module.
2. Turn on the hi-vol's motor at the Magnehelic Setpoint (found on TE-1000 Calibration Data Form) for 10-15 minutes. If the ambient Temperature and Pressure are significantly different from the day the calibration was performed, the Magnehelic Gauge Setpoint may need to be recalculated using the following equation:

$$\text{Magnehelic Setpoint (inH}_2\text{O)} = \left(\frac{P_{\text{amb}}}{T_{\text{amb}}} * \frac{298K}{760\text{mmHg}} \right) * \left[\left(m_{\text{hivol}} * 0.225 \frac{\text{m}^3}{\text{minute}} \right) + b_{\text{hivol}} \right]^2 = \underline{45.6}$$

3. Record the Magnehelic Gauge Pressure and the Manometer Pressure.

P_{Magnehelic} (inH₂O) 46 P_{Manometer} (inH₂O) 4.4

4. Record m_{hivol} and b_{hivol} from the TE-1000 Calibration Data Form:

Hi-Vol Slope, m_{hivol} 38.5293 Hi-Vol Intercept, b_{hivol} -1.8446

5. Calculate the Magnehelic flow rate using the following equation:

$$Q_{\text{Magnehelic}} \left(\frac{\text{m}^3}{\text{min}} \right) = \frac{1}{m_{\text{hivol}}} * \left(\sqrt{P_{\text{Magnehelic}} * \left(\frac{P_{\text{amb}} * 298K}{760\text{mmHg} * T_{\text{amb}}} \right)} - b_{\text{hivol}} \right) = \underline{0.214} \quad \text{KMH 6/25/21}$$

*T_{amb} should be in degrees Kelvin: T_{amb} (°C) + 273 = T_{amb} (K)

6. Calculate the Manometer flow rate using the following equation:

$$Q_{\text{Manometer}} \left(\frac{\text{m}^3}{\text{min}} \right) = \frac{1}{m_{\text{orifice}}} * \left(\sqrt{P_{\text{Manometer}} * \left(\frac{P_{\text{amb}} * 298K}{760\text{mmHg} * T_{\text{amb}}} \right)} - b_{\text{orifice}} \right) = \underline{0.222} \quad \text{KMH 6/25/21}$$

*T_{amb} should be in degrees Kelvin: T_{amb} (°C) + 273 = T_{amb} (K)

7. Calculate the percent difference between Q_{Magnehelic} and Q_{Manometer}:

$$\text{Percent Difference} = 100 * (1 - (Q_{\text{Manometer}} \div Q_{\text{Magnehelic}})) = \underline{3.6} \%$$

8. Is the Percent Difference ≤ ±10%? YES NO (circle one)

a. If YES, flow check is complete.

b. If NO, use the TE-1000 Operator's Manual to troubleshoot and retry the flow check. If the issue persists, the sampler will need to be recalibrated. Contact the Project Leads.