

checked by NT  
2/6/17

### CERTIFICATION

SDG No: JC34340 Laboratory: Accutest, New Jersey  
Site: BMS, Building 5 Area, PR Matrix: Groundwater  
Humacao, PR

**SUMMARY:** Groundwater samples (Table 1) were collected on the BMSMC facility – Building 5 Area. The BMSMC facility is located in Humacao, PR. Samples were taken December 20-22, 2016 and were analyzed in Accutest Laboratory of Dayton, New Jersey for the parameters shown in Table 1. The results were reported under SDG No.: JC34340. Results were validated using the latest validation guidelines (July, 2015) of the EPA Hazardous Waste Support Section. Individual data review worksheets are enclosed for each target analyte group. The data sample summary form shows for analytes results that were qualified.

In summary the results are valid and can be used for decision taking purposes.

Table 1. Samples analyzed and analysis performed

| SAMPLE ID  | SAMPLE DESCRIPTION | MATRIX                | ANALYSIS PERFORMED   |
|------------|--------------------|-----------------------|--|
| JC34340-1  | MW-14              | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-2  | MW-18              | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA; Inorganics; Methane |
| JC34340-3  | FB122016           | AQ- Field Blank Water | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-4  | EB122116           | AQ- Equipment Blank   | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-5  | TB122016NRB        | AQ – Trip Blank Water | VOCs   |
| JC34340-6  | TB122016RSB        | AQ – Trip Blank Water | VOCs   |
| JC34340-7  | BR-1               | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-8  | BR-1 DUP           | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-9  | BR-2               | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA; Inorganics; Methane |
| JC34340-10 | BR-3               | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-11 | BR-4               | Groundwater           | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-12 | FB122116           | AQ- Field Blank Water | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA                      |
| JC34340-13 | TB122116NR         | AQ – Trip Blank Water | VOCs   |

| SAMPLE ID   | SAMPLE DESCRIPTION | MATRIX                 | ANALYSIS PERFORMED                                      |
|-------------|--------------------|------------------------|---|
| JC34340-14  | TB122116RS         | AQ – Trip Blank Water  | VOCs  |
| JC34340-15  | EB122216           | AQ- Equipment Blank    | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA; Pesticides |
| JC34340-16  | RA-10D             | Groundwater            | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA; Pesticides |
| JC34340-16D | RA-10D MSD         | Groundwater            | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA; Pesticides |
| JC34340-16S | RA-10D MS          | Groundwater            | VOCs; SVOCs; PAHs + 1,4-Dioxane (SIM); LMWA; Pesticides |
| JC34340-17  | TB121616NRA        | AQ – Trip Blank water  | VOCs  |
| JC34340-18  | MW-20S             | Groundwater            | Pesticides  |
| JC34340-19  | MW-20D             | Groundwater            | Pesticides  |
| JC34340-20  | RA-10S             | Groundwater            | Pesticides  |
| JC34340-21  | FB122216           | AQ – Field Blank Water | Pesticides  |

Reviewer Name:

Rafael Infante  
Chemist License 1888

Signature:

Date:

*Rafael Infante*  
January 28, 2017



SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-14  
**Lab Sample ID:** JC34340-1  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8260C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68033.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 111%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 114%   |        | 78-117% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

**Client Sample ID:** MW-14  
**Lab Sample ID:** JC34340-1  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #               | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|---------------------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 <sup>a</sup> | 2M90222.D | 1  | 12/28/16 | CS | 12/27/16  | OP99497    | E2M4004          |
| Run #2              |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 980 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                               | Result | RL  | MDL  | Units | Q |
|-----------|--|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol <sup>a</sup>            | ND     | 5.1 | 0.84 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol <sup>a</sup>  | ND     | 5.1 | 0.91 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol <sup>a</sup>        | ND     | 2.0 | 1.3  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol <sup>a</sup>        | ND     | 5.1 | 2.5  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol <sup>a</sup>         | ND     | 10  | 1.6  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol <sup>a</sup>      | ND     | 5.1 | 1.3  | ug/l  |   |
| 95-48-7   | 2-Methylphenol <sup>a</sup>            | ND     | 2.0 | 0.91 | ug/l  |   |
|           | 3&4-Methylphenol <sup>a</sup>          | ND     | 2.0 | 0.90 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol <sup>a</sup>             | ND     | 5.1 | 0.98 | ug/l  |   |
| 100-02-7  | 4-Nitrophenol <sup>a</sup>             | ND     | 10  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol <sup>a</sup>         | ND     | 4.1 | 1.4  | ug/l  |   |
| 108-95-2  | Phenol <sup>a</sup>                    | ND     | 2.0 | 0.40 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol <sup>a</sup> | ND     | 5.1 | 1.5  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol <sup>a</sup>     | ND     | 5.1 | 1.4  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol <sup>a</sup>     | ND     | 5.1 | 0.94 | ug/l  |   |
| 83-32-9   | Acenaphthene                           | ND     | 1.0 | 0.19 | ug/l  |   |
| 208-96-8  | Acenaphthylene                         | ND     | 1.0 | 0.14 | ug/l  |   |
| 98-86-2   | Acetophenone                           | ND     | 2.0 | 0.21 | ug/l  |   |
| 120-12-7  | Anthracene                             | ND     | 1.0 | 0.22 | ug/l  |   |
| 1912-24-9 | Atrazine                               | ND     | 2.0 | 0.46 | ug/l  |   |
| 100-52-7  | Benzaldehyde                           | ND     | 5.1 | 0.29 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene                     | ND     | 1.0 | 0.21 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene                         | ND     | 1.0 | 0.22 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene                   | ND     | 1.0 | 0.21 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene                   | ND     | 1.0 | 0.35 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene                   | ND     | 1.0 | 0.21 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether             | ND     | 2.0 | 0.41 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate                 | ND     | 2.0 | 0.47 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl                          | ND     | 1.0 | 0.22 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene                    | ND     | 2.0 | 0.24 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline                        | ND     | 5.1 | 0.35 | ug/l  |   |
| 86-74-8   | Carbazole                              | ND     | 1.0 | 0.23 | ug/l  |   |

ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound





## Report of Analysis

**Client Sample ID:** MW-14  
**Lab Sample ID:** JC34340-1  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

4.1  
4

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.0 | 0.66 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.0 | 0.18 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.0 | 0.28 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.0 | 0.25 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.0 | 0.41 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.0 | 0.37 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.0 | 0.56 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.0 | 0.49 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.0 | 0.52 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.0 | 0.34 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.1 | 0.22 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.0 | 0.51 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.0 | 0.24 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.0 | 0.27 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.0 | 0.22 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.0 | 1.7  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.0 | 0.17 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.0 | 0.17 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.0 | 0.33 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.0 | 0.50 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 10  | 2.8  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.0 | 0.40 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.0 | 0.34 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.0 | 0.28 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.0 | 0.27 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.0 | 0.21 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.1 | 0.28 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.1 | 0.39 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.1 | 0.45 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.0 | 0.66 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.0 | 0.49 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.1 | 0.23 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.0 | 0.18 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.0 | 0.22 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.0 | 0.38 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 367-12-4  | 2-Fluorophenol       | 42%    |        | 14-88%  |
| 4165-62-2 | Phenol-d5            | 27%    |        | 10-110% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

Page 3 of 3

Client Sample ID: MW-14  
Lab Sample ID: JC34340-1  
Matrix: AQ - Ground Water  
Method: SW846 8270D SW846 3510C  
Project: BSMC, Building 5 Area, PR

Date Sampled: 12/20/16  
Date Received: 12/23/16  
Percent Solids: n/a

4.1  
4

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 77%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 62%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 70%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 86%    |        | 10-126% |

(a) The acid spike standard was not added to the LCS. There is no sample left to reextract.



ND = Not detected MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-14  
**Lab Sample ID:** JC34340-1  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D BY SIM SW846 3510C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67748.D | 1  | 12/30/16 | SG | 12/27/16  | OP99497A   | E3M3155          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 980 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.051 | 0.023 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.051 | 0.034 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.10  | 0.044 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.10  | 0.034 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.10  | 0.027 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.10  | 0.037 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.10  | 0.039 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.10  | 0.030 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | 2.71   | 0.10  | 0.050 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 83%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 72%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 65%    |        | 10-119% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-14  
**Lab Sample ID:** JC34340-1  
**Matrix:** AQ - Ground Water  
**Method:** SW846-8015C (DAI)  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107979.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 102%   |        | 56-145% |
| 111-27-3 | Hexanol              | 85%    |        | 56-145% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | MW-18                      | <b>Date Sampled:</b>   | 12/20/16 |
| <b>Lab Sample ID:</b>    | JC34340-2                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8260C                |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68034.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 107%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 113%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 113%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: MW-18  
 Lab Sample ID: JC34340-2  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/20/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #               | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|---------------------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 <sup>a</sup> | 2M90392.D | 1  | 01/04/17 | SB | 12/27/16  | OP99497    | E2M4011          |
| Run #2              |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 990 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                               | Result | RL  | MDL  | Units | Q |
|-----------|--|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol <sup>a</sup>            | ND     | 5.1 | 0.83 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol <sup>a</sup>  | ND     | 5.1 | 0.90 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol <sup>a</sup>        | ND     | 2.0 | 1.3  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol <sup>a</sup>        | ND     | 5.1 | 2.5  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol <sup>a</sup>         | ND     | 10  | 1.6  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol <sup>a</sup>      | ND     | 5.1 | 1.3  | ug/l  |   |
| 95-48-7   | 2-Methylphenol <sup>a</sup>            | ND     | 2.0 | 0.90 | ug/l  |   |
|           | 3&4-Methylphenol <sup>a</sup>          | ND     | 2.0 | 0.89 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol <sup>a</sup>             | ND     | 5.1 | 0.97 | ug/l  |   |
| 100-02-7  | 4-Nitrophenol <sup>a</sup>             | ND     | 10  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol <sup>a</sup>         | ND     | 4.0 | 1.4  | ug/l  |   |
| 108-95-2  | Phenol <sup>a</sup>                    | ND     | 2.0 | 0.40 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol <sup>a</sup> | ND     | 5.1 | 1.5  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol <sup>a</sup>     | ND     | 5.1 | 1.3  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol <sup>a</sup>     | ND     | 5.1 | 0.93 | ug/l  |   |
| 83-32-9   | Acenaphthene                           | ND     | 1.0 | 0.19 | ug/l  |   |
| 208-96-8  | Acenaphthylene                         | ND     | 1.0 | 0.14 | ug/l  |   |
| 98-86-2   | Acetophenone                           | ND     | 2.0 | 0.21 | ug/l  |   |
| 120-12-7  | Anthracene                             | ND     | 1.0 | 0.21 | ug/l  |   |
| 1912-24-9 | Atrazine                               | ND     | 2.0 | 0.45 | ug/l  |   |
| 100-52-7  | Benzaldehyde                           | ND     | 5.1 | 0.29 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene                     | ND     | 1.0 | 0.21 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene                         | ND     | 1.0 | 0.22 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene                   | ND     | 1.0 | 0.21 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene                   | ND     | 1.0 | 0.34 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene                   | ND     | 1.0 | 0.21 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether             | ND     | 2.0 | 0.41 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate                 | ND     | 2.0 | 0.46 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl                          | ND     | 1.0 | 0.21 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene                    | ND     | 2.0 | 0.24 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline                        | ND     | 5.1 | 0.34 | ug/l  |   |
| 86-74-8   | Carbazole                              | ND     | 1.0 | 0.23 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

**Client Sample ID:** MW-18  
**Lab Sample ID:** JC34340-2  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D SW846 3510C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL     | MDL     | Units | Q |
|-----------|-----------------------------|--------|--------|---------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.0    | 0.66    | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.0    | 0.18    | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.0    | 0.28    | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.0    | 0.25    | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.0    | 0.41    | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.0    | 0.37    | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.0    | 0.56    | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.0    | 0.48    | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.0    | 0.51    | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.0    | 0.33    | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.1    | 0.22    | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.0    | 0.50    | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.0    | 0.24    | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.0    | 0.26    | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.0    | 0.22    | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.0    | 1.7     | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.0    | 0.17    | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.0    | 0.17    | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.0    | 0.33    | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.0    | 0.50    | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 10     | 2.8     | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.0    | 0.39    | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.0    | 0.34    | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.0    | 0.28    | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.0    | 0.27    | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.0    | 0.21    | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.1    | 0.28    | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.1    | 0.39    | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.1    | 0.44    | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.0    | 0.65    | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.0    | 0.49    | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.1    | 0.22    | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.0    | 0.18    | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.0    | 0.22    | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.0    | 0.37    | ug/l  |   |
| CAS No.   | Surrogate Recoveries        | Run# 1 | Run# 2 | Limits  |       |   |
| 367-12-4  | 2-Fluorophenol              | 33%    |        | 14-88%  |       |   |
| 4165-62-2 | Phenol-d5                   | 21%    |        | 10-110% |       |   |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | MW-18                      | <b>Date Sampled:</b>   | 12/20/16 |
| <b>Lab Sample ID:</b>    | JC34340-2                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 72%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 58%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 64%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 75%    |        | 10-126% |

(a) The acid spike standard was not added to the LCS. There is no sample left to reextract.



ND = Not detected      MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-18  
**Lab Sample ID:** JC34340-2  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D BY SIM SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67749.D | 1  | 12/30/16 | SG | 12/27/16  | OP99497A   | E3M3155          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 990 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.051 | 0.023 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.051 | 0.034 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.10  | 0.044 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.10  | 0.033 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.10  | 0.026 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.10  | 0.037 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.10  | 0.038 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.10  | 0.030 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | ND     | 0.10  | 0.049 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 78%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 68%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 64%    |        | 10-119% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-18  
**Lab Sample ID:** JC34340-2  
**Matrix:** AQ - Ground Water  
**Method:** SW846-8015C (DAI)  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107980.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 97%    |        | 56-145% |
| 111-27-3 | Hexanol              | 79%    |        | 56-145% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-18  
**Lab Sample ID:** JC34340-2  
**Matrix:** AQ - Ground Water  
**Method:** RSK-175  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | AA56675.D | 1  | 12/30/16 | LM | n/a       | n/a        | GAA1104          |
| Run #2 |           |    |          |    |           |            |                  |

| CAS No. | Compound | Result | RL   | MDL   | Units | Q |
|---------|----------|--------|------|-------|-------|---|
| 74-82-8 | Methane  | 0.48   | 0.11 | 0.036 | ug/l  |   |



ND = Not detected      MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

## Report of Analysis

Page 1 of 1

|   |                                |
|---|--------------------------------|
| <b>Client Sample ID:</b> MW-18            | <b>Date Sampled:</b> 12/20/16  |
| <b>Lab Sample ID:</b> JC34340-2           | <b>Date Received:</b> 12/23/16 |
| <b>Matrix:</b> AQ - Ground Water          | <b>Percent Solids:</b> n/a     |
| <b>Project:</b> BSMC, Building 5 Area, PR |                                |

4.2  
4

## Total Metals Analysis

| Analyte   | Result | RL  | MDL  | Units | DF | Prep     | Analyzed By | Method                   | Prep Method              |
|-----------|--------|-----|------|-------|----|----------|-------------|--------------------------|--------------------------|
| Iron      | 2130   | 100 | 12   | ug/l  | 1  | 12/28/16 | 12/29/16 ND | SW846 6010C <sup>1</sup> | SW846 3010A <sup>2</sup> |
| Manganese | 74.7   | 15  | 0.39 | ug/l  | 1  | 12/28/16 | 12/29/16 ND | SW846 6010C <sup>1</sup> | SW846 3010A <sup>2</sup> |

(1) Instrument QC Batch: MA41067

(2) Prep QC Batch: MP97875



RL = Reporting Limit  
MDL = Method Detection Limit

U = Indicates a result < MDL  
B = Indicates a result > = MDL but < RL

## Report of Analysis

|   |                                |
|---|--------------------------------|
| <b>Client Sample ID:</b> MW-18            | <b>Date Sampled:</b> 12/20/16  |
| <b>Lab Sample ID:</b> JC34340-2           | <b>Date Received:</b> 12/23/16 |
| <b>Matrix:</b> AQ - Ground Water          | <b>Percent Solids:</b> n/a     |
| <b>Project:</b> BSMC, Building 5 Area, PR |                                |

## General Chemistry

| Analyte                                | Result | RL    | Units | DF | Analyzed       | By | Method              |
|--|--------|-------|-------|----|----------------|----|---------------------|
| Alkalinity, Total as CaCO <sub>3</sub> | 207    | 5.0   | mg/l  | 1  | 12/28/16 21:50 | CB | SM2320 B-11         |
| Iron, Ferric <sup>a</sup>              | 2.0    | 0.30  | mg/l  | 1  | 12/29/16 22:23 | ND | SM3500FE B-11       |
| Iron, Ferrous <sup>b</sup>             | < 0.20 | 0.20  | mg/l  | 1  | 12/24/16 12:48 | YR | SM3500FE B-11       |
| Nitrogen, Nitrate <sup>c</sup>         | 0.58   | 0.11  | mg/l  | 1  | 01/03/17 12:49 | BM | EPA353.2/SM4500NO2B |
| Nitrogen, Nitrate + Nitrite            | 0.59   | 0.10  | mg/l  | 1  | 01/03/17 12:49 | BM | EPA 353.2/LACHAT    |
| Nitrogen, Nitrite <sup>d</sup>         | 0.015  | 0.010 | mg/l  | 1  | 12/23/16 23:10 | HS | SM4500NO2 B-11      |
| Sulfate                                | < 10   | 10    | mg/l  | 1  | 01/07/17 06:13 | JN | EPA 300/SW846 9056A |
| Sulfide                                | < 2.0  | 2.0   | mg/l  | 1  | 12/27/16 10:48 | MP | SM4500S2- F-11      |

(a) Calculated as: (Iron) - (Iron, Ferrous)

(b) Field analysis required. Received out of hold time and analyzed by request.

(c) Calculated as: (Nitrogen, Nitrate + Nitrite) - (Nitrogen, Nitrite) Nitrogen, Nitrite analysis done past holding time.

(d) Received and analyzed out of holding time.



RL = Reporting Limit

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | FB122016                   | <b>Date Sampled:</b>   | 12/20/16 |
| <b>Lab Sample ID:</b>    | JC34340-3                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water     | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8260C                |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68047.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 106%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 113%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 115%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: FB122016  
 Lab Sample ID: JC34340-3  
 Matrix: AQ - Field Blank Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/20/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

|                     | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|---------------------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 <sup>a</sup> | M130548.D | 1  | 01/04/17 | KM | 12/27/16  | OP99497    | EM5577           |
| Run #2 <sup>b</sup> | P110134.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |

|        | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 910 ml         | 1.0 ml       |
| Run #2 | 925 ml         | 1.0 ml       |

## ABN TCL Special List

| CAS No.   | Compound                               | Result | RL  | MDL  | Units | Q |
|-----------|--|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol <sup>a</sup>            | ND     | 5.5 | 0.90 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol <sup>a</sup>  | ND     | 5.5 | 0.98 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol <sup>a</sup>        | ND     | 2.2 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol <sup>a</sup>        | ND     | 5.5 | 2.7  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol <sup>a</sup>         | ND     | 11  | 1.7  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol <sup>a</sup>      | ND     | 5.5 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol <sup>a</sup>            | ND     | 2.2 | 0.98 | ug/l  |   |
|           | 3&4-Methylphenol <sup>a</sup>          | ND     | 2.2 | 0.97 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol <sup>a</sup>             | ND     | 5.5 | 1.1  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol <sup>a</sup>             | ND     | 11  | 1.3  | ug/l  |   |
| 87-86-5   | Pentachlorophenol <sup>a</sup>         | ND     | 4.4 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol <sup>a</sup>                    | ND     | 2.2 | 0.43 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol <sup>a</sup> | ND     | 5.5 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol <sup>a</sup>     | ND     | 5.5 | 1.5  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol <sup>a</sup>     | ND     | 5.5 | 1.0  | ug/l  |   |
| 83-32-9   | Acenaphthene                           | ND     | 1.1 | 0.21 | ug/l  |   |
| 208-96-8  | Acenaphthylene                         | ND     | 1.1 | 0.15 | ug/l  |   |
| 98-86-2   | Acetophenone                           | ND     | 2.2 | 0.23 | ug/l  |   |
| 120-12-7  | Anthracene                             | ND     | 1.1 | 0.23 | ug/l  |   |
| 1912-24-9 | Atrazine                               | ND     | 2.2 | 0.49 | ug/l  |   |
| 100-52-7  | Benzaldehyde                           | ND     | 5.5 | 0.32 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene                     | ND     | 1.1 | 0.22 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene                         | ND     | 1.1 | 0.23 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene                   | ND     | 1.1 | 0.23 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene                   | ND     | 1.1 | 0.37 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene                   | ND     | 1.1 | 0.23 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether             | ND     | 2.2 | 0.44 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate                 | ND     | 2.2 | 0.50 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl                          | ND     | 1.1 | 0.23 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene                    | ND     | 2.2 | 0.26 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline                        | ND     | 5.5 | 0.37 | ug/l  |   |
| 86-74-8   | Carbazole                              | ND     | 1.1 | 0.25 | ug/l  |   |

ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

**Client Sample ID:** FB122016  
**Lab Sample ID:** JC34340-3  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846 8270D SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.2 | 0.71 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.2 | 0.31 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.2 | 0.27 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.2 | 0.40 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.1 | 0.61 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.1 | 0.52 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.2 | 0.56 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.1 | 0.36 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.5 | 0.24 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.2 | 0.55 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.2 | 0.26 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.2 | 0.29 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.2 | 0.24 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.2 | 1.8  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.1 | 0.36 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.1 | 0.54 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 11  | 3.1  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.2 | 0.43 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.1 | 0.36 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.2 | 0.30 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.1 | 0.29 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.1 | 0.23 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.5 | 0.30 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.5 | 0.43 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.5 | 0.48 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.2 | 0.71 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.2 | 0.53 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.5 | 0.24 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.1 | 0.24 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.2 | 0.41 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 367-12-4  | 2-Fluorophenol       | 44%    | 44%    | 14-88%  |
| 4165-62-2 | Phenol-d5            | 28%    | 29%    | 10-110% |

ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound





## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | FB122016                   | <b>Date Sampled:</b>   | 12/20/16 |
| <b>Lab Sample ID:</b>    | JC34340-3                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water     | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 93%    | 91%    | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 70%    | 66%    | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 71%    | 75%    | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 83%    | 87%    | 10-126% |

- (a) The acid spike standard was not added to the LCS. Results are confirmed by reextraction outside the holding time.
- (b) Confirmation run.



ND = Not detected MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                                |                        |          |
|--------------------------|--------------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | FB122016                       | <b>Date Sampled:</b>   | 12/20/16 |
| <b>Lab Sample ID:</b>    | JC34340-3                      | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water         | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D BY SIM SW846 3510C |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR     |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67750.D | 1  | 12/30/16 | SG | 12/27/16  | OP99497A   | E3M3155          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 910 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.055 | 0.025 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.055 | 0.037 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.048 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.036 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.029 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.040 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.042 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.11  | 0.032 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | ND     | 0.11  | 0.054 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 82%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 68%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 73%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** FB122016  
**Lab Sample ID:** JC34340-3  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846-8015C (DAI)  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/20/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107981.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 103%   |        | 56-145% |
| 111-27-3 | Hexanol              | 87%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** EB122116  
**Lab Sample ID:** JC34340-4  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846 8260C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68048.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 107%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 115%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 115%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: EB122116  
 Lab Sample ID: JC34340-4  
 Matrix: AQ - Field Blank Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 2M90361.D | 1  | 01/03/17 | AN | 12/28/16  | OP99513    | E2M4010          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 960 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.2 | 0.85 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.2 | 0.93 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.1 | 1.3  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.2 | 2.5  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 10  | 1.6  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.2 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.1 | 0.93 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.1 | 0.92 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.2 | 1.0  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 10  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.2 | 1.4  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.1 | 0.41 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.2 | 1.5  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.2 | 1.4  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.2 | 0.96 | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.0 | 0.20 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.0 | 0.14 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.1 | 0.22 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.0 | 0.22 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.1 | 0.47 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.2 | 0.30 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.0 | 0.21 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.0 | 0.22 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.0 | 0.21 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.0 | 0.36 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.0 | 0.21 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.1 | 0.42 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.1 | 0.48 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.0 | 0.22 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.1 | 0.25 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.2 | 0.35 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.0 | 0.24 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

## Report of Analysis

**Client Sample ID:** EB122116  
**Lab Sample ID:** JC34340-4  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846 8270D SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.1 | 0.68 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.0 | 0.18 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.1 | 0.29 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.1 | 0.26 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.1 | 0.42 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.1 | 0.38 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.0 | 0.58 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.0 | 0.50 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.1 | 0.53 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.0 | 0.34 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.2 | 0.23 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.1 | 0.52 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.1 | 0.24 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.1 | 0.27 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.1 | 0.23 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.1 | 1.7  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.0 | 0.18 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.0 | 0.18 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.0 | 0.34 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.0 | 0.51 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 10  | 2.9  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.1 | 0.41 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.0 | 0.35 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.1 | 0.29 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.0 | 0.27 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.0 | 0.22 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.2 | 0.29 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.2 | 0.40 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.2 | 0.46 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.1 | 0.67 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.1 | 0.50 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.2 | 0.23 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.0 | 0.18 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.0 | 0.23 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.1 | 0.39 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 367-12-4  | 2-Fluorophenol       | 41%    |        | 14-88%  |
| 4165-62-2 | Phenol-d5            | 26%    |        | 10-110% |

ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | EB122116                   | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-4                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water     | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 81%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 64%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 71%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 92%    |        | 10-126% |



ND = Not detected MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                                |                        |          |
|--------------------------|--------------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | EB122116                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-4                      | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water         | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D BY SIM SW846 3510C |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR     |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4M69349.D | 1  | 12/29/16 | SG | 12/28/16  | OP99513A   | E4M3179          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 960 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.052 | 0.024 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.052 | 0.035 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.10  | 0.045 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.10  | 0.034 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.10  | 0.027 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.10  | 0.038 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.10  | 0.040 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.10  | 0.031 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | ND     | 0.10  | 0.051 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 59%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 63%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 87%    |        | 10-119% |



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** EB122116  
**Lab Sample ID:** JC34340-4  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846-8015C (DA1)  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107982.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 100%   |        | 56-145% |
| 111-27-3 | Hexanol              | 85%    |        | 56-145% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** TB122016NRB  
**Lab Sample ID:** JC34340-5  
**Matrix:** AQ - Trip Blank Water  
**Method:** SW846 8260C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

|        | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68049.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

|        | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 107%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 115%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 116%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** TB122016RSD  
**Lab Sample ID:** JC34340-6  
**Matrix:** AQ - Trip Blank Water  
**Method:** SW846 8260C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68065.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 103%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 107%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 97%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 115%   |        | 78-117% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** BR-1  
**Lab Sample ID:** JC34340-7  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8260C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

|        | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68035.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

|        | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 113%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 110%   |        | 78-117% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-1                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-7                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 2M90299.D | 1  | 12/30/16 | CS | 12/28/16  | OP99513    | E2M4007          |
| Run #2 | M130549.D | 2  | 01/04/17 | KM | 12/28/16  | OP99513    | EM5577           |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 1000 ml        | 1.0 ml       |
| Run #2 | 1000 ml        | 1.0 ml       |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.0 | 0.82 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.0 | 0.89 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.0 | 1.3  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.0 | 2.4  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 10  | 1.6  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.0 | 1.3  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.0 | 0.89 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.0 | 0.88 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.0 | 0.96 | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 10  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.0 | 1.4  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.0 | 0.39 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.0 | 1.5  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.0 | 1.3  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.0 | 0.92 | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.0 | 0.19 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.0 | 0.14 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.0 | 0.21 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.0 | 0.21 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.0 | 0.45 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.0 | 0.29 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.0 | 0.20 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.0 | 0.21 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.0 | 0.21 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.0 | 0.34 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.0 | 0.21 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.0 | 0.40 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.0 | 0.46 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.0 | 0.21 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.0 | 0.24 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.0 | 0.34 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.0 | 0.23 | ug/l  |   |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

Client Sample ID: BR-1  
 Lab Sample ID: JC34340-7  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result           | RL  | MDL  | Units | Q |
|-----------|-----------------------------|------------------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND               | 2.0 | 0.65 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND               | 1.0 | 0.18 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND               | 2.0 | 0.28 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND               | 2.0 | 0.25 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND               | 2.0 | 0.40 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND               | 2.0 | 0.37 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND               | 1.0 | 0.55 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND               | 1.0 | 0.48 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND               | 2.0 | 0.51 | ug/l  |   |
| 123-91-1  | 1,4-Dioxane                 | 105 <sup>a</sup> | 2.0 | 1.3  | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND               | 1.0 | 0.33 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND               | 5.0 | 0.22 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND               | 2.0 | 0.50 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND               | 2.0 | 0.23 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND               | 2.0 | 0.26 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND               | 2.0 | 0.22 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND               | 2.0 | 1.7  | ug/l  |   |
| 206-44-0  | Fluoranthene                | 0.54             | 1.0 | 0.17 | ug/l  | J |
| 86-73-7   | Fluorene                    | ND               | 1.0 | 0.17 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND               | 1.0 | 0.33 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND               | 1.0 | 0.49 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND               | 10  | 2.8  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND               | 2.0 | 0.39 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND               | 1.0 | 0.33 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND               | 2.0 | 0.28 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND               | 1.0 | 0.26 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND               | 1.0 | 0.21 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND               | 5.0 | 0.28 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND               | 5.0 | 0.39 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND               | 5.0 | 0.44 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND               | 2.0 | 0.64 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND               | 2.0 | 0.48 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND               | 5.0 | 0.22 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND               | 1.0 | 0.18 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND               | 1.0 | 0.22 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND               | 2.0 | 0.37 | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits |
|----------|----------------------|--------|--------|--------|
| 367-12-4 | 2-Fluorophenol       | 42%    | 40%    | 14-88% |

ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-1                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-7                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-62-2 | Phenol-d5            | 30%    | 28%    | 10-110% |
| 118-79-6  | 2,4,6-Tribromophenol | 89%    | 104%   | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 61%    | 69%    | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 72%    | 75%    | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 71%    | 69%    | 10-126% |

(a) Result is from Run# 2



ND = Not detected MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** BR-1  
**Lab Sample ID:** JC34340-7  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D BY SIM SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

|        | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4M69350.D | 1  | 12/29/16 | SG | 12/28/16  | OP99513A   | E4M3179          |
| Run #2 |           |    |          |    |           |            |                  |

|        | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 1000 ml        | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.050 | 0.023 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.050 | 0.033 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.10  | 0.043 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.10  | 0.033 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.10  | 0.026 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.10  | 0.036 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.10  | 0.038 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.10  | 0.029 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 57%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 63%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 71%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** BR-1  
**Lab Sample ID:** JC34340-7  
**Matrix:** AQ - Ground Water  
**Method:** SW846-8015C (DAI)  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107983.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 84%    |        | 56-145% |
| 111-27-3 | Hexanol              | 79%    |        | 56-145% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-1 DUP                   | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-8                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8260C                |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68036.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 114%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 108%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: BR-1 DUP  
 Lab Sample ID: JC34340-8  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 5P34334.D | 1  | 12/30/16 | SB | 12/28/16  | OP99514    | E5P1725          |
| Run #2 | 5P34357.D | 5  | 12/30/16 | AC | 12/28/16  | OP99514    | E5P1726          |

|        | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 910 ml         | 1.0 ml       |
| Run #2 | 910 ml         | 1.0 ml       |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.5 | 0.90 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.5 | 0.98 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.2 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.5 | 2.7  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 11  | 1.7  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.5 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.2 | 0.98 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.2 | 0.97 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.5 | 1.1  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 11  | 1.3  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.4 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.2 | 0.43 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.5 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.5 | 1.5  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.5 | 1.0  | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.1 | 0.21 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.1 | 0.15 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.2 | 0.23 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.1 | 0.23 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.2 | 0.49 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.5 | 0.32 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.1 | 0.22 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.1 | 0.23 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.1 | 0.23 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.1 | 0.37 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.1 | 0.23 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.2 | 0.50 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.1 | 0.23 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.2 | 0.26 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | 1.5    | 5.5 | 0.37 | ug/l  | J |
| 86-74-8   | Carbazole                  | ND     | 1.1 | 0.25 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

## Report of Analysis

Client Sample ID: BR-1 DUP  
 Lab Sample ID: JC34340-8  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

4.8  
4

## ABN TCL Special List

| CAS No.   | Compound                    | Result           | RL  | MDL  | Units | Q |
|-----------|-----------------------------|------------------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND               | 2.2 | 0.71 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND               | 1.1 | 0.19 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND               | 2.2 | 0.31 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND               | 2.2 | 0.27 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND               | 2.2 | 0.44 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND               | 2.2 | 0.40 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND               | 1.1 | 0.61 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND               | 1.1 | 0.52 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND               | 2.2 | 0.56 | ug/l  |   |
| 123-91-1  | 1,4-Dioxane                 | 220 <sup>a</sup> | 5.5 | 3.6  | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND               | 1.1 | 0.36 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND               | 5.5 | 0.24 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND               | 2.2 | 0.55 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND               | 2.2 | 0.26 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND               | 2.2 | 0.29 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND               | 2.2 | 0.24 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | 3.8              | 2.2 | 1.8  | ug/l  |   |
| 206-44-0  | Fluoranthene                | 0.50             | 1.1 | 0.19 | ug/l  | J |
| 86-73-7   | Fluorene                    | ND               | 1.1 | 0.19 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND               | 1.1 | 0.36 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND               | 1.1 | 0.54 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND               | 1.1 | 3.1  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND               | 2.2 | 0.43 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND               | 1.1 | 0.36 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND               | 2.2 | 0.30 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND               | 1.1 | 0.29 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND               | 1.1 | 0.23 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND               | 5.5 | 0.30 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND               | 5.5 | 0.43 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND               | 5.5 | 0.48 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND               | 2.2 | 0.71 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND               | 2.2 | 0.53 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND               | 5.5 | 0.24 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND               | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND               | 1.1 | 0.24 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND               | 2.2 | 0.41 | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits |
|----------|----------------------|--------|--------|--------|
| 367-12-4 | 2-Fluorophenol       | 59%    | 59%    | 14-88% |



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-1 DUP                   | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-8                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-62-2 | Phenol-d5            | 40%    | 40%    | 10-110% |
| 118-79-6  | 2,4,6-Tribromophenol | 86%    | 89%    | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 77%    | 77%    | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 77%    | 80%    | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 77%    | 78%    | 10-126% |

(a) Result is from Run# 2



ND = Not detected MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                                |                        |          |
|--------------------------|--------------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-1 DUP                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-8                      | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water              | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D BY SIM SW846 3510C |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR     |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67737.D | 1  | 12/30/16 | SG | 12/28/16  | OP99514A   | E3M3154          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 910 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.055 | 0.025 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.055 | 0.037 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.048 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.036 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.029 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.040 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.042 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.11  | 0.032 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 80%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 73%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 70%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** BR-1 DUP  
**Lab Sample ID:** JC34340-8  
**Matrix:** AQ - Ground Water  
**Method:** SW846-8015C (DAI)  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107984.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 66%    |        | 56-145% |
| 111-27-3 | Hexanol              | 61%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-2                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-9                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8260C                |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68038.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 107%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 112%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 105%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 3

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-2                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-9                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 5P34335.D | 1  | 12/30/16 | SB | 12/28/16  | OP99514    | E5P1725          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 940 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.3 | 0.87 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.3 | 0.95 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.1 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.3 | 2.6  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 11  | 1.6  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.3 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.1 | 0.94 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.1 | 0.94 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.3 | 1.0  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 11  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.3 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.1 | 0.42 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.3 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.3 | 1.4  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.3 | 0.98 | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.1 | 0.20 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.1 | 0.14 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.1 | 0.22 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.1 | 0.22 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.1 | 0.48 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.3 | 0.31 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.1 | 0.22 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.1 | 0.23 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.1 | 0.22 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.1 | 0.36 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.1 | 0.22 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.1 | 0.43 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.1 | 0.49 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.1 | 0.23 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.1 | 0.25 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.3 | 0.36 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.1 | 0.24 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

## Report of Analysis

Client Sample ID: BR-2  
 Lab Sample ID: JC34340-9  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

4.9  
4

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.1 | 0.69 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.1 | 0.30 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.1 | 0.26 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.1 | 0.43 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.1 | 0.39 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.1 | 0.59 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.1 | 0.51 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.1 | 0.54 | ug/l  |   |
| 123-91-1  | 1,4-Dioxane                 | 19.3   | 1.1 | 0.70 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.1 | 0.35 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.3 | 0.23 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.1 | 0.53 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.1 | 0.25 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.1 | 0.28 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.1 | 0.23 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.1 | 1.8  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.1 | 0.18 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.1 | 0.18 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.1 | 0.35 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.1 | 0.52 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 11  | 3.0  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.1 | 0.41 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.1 | 0.35 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.1 | 0.29 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.1 | 0.28 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.1 | 0.22 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.3 | 0.29 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.3 | 0.41 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.3 | 0.47 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.1 | 0.68 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.1 | 0.51 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.3 | 0.24 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.1 | 0.23 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.1 | 0.39 | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits |
|----------|----------------------|--------|--------|--------|
| 367-12-4 | 2-Fluorophenol       | 43%    |        | 14-88% |

ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-2                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-9                  | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-62-2 | Phenol-d5            | 29%    |        | 10-110% |
| 118-79-6  | 2,4,6-Tribromophenol | 71%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 57%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 59%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 71%    |        | 10-126% |



ND = Not detected      MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                                |                        |          |
|--------------------------|--------------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-2                           | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-9                      | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water              | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D BY SIM SW846 3510C |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR     |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67733.D | 1  | 12/30/16 | SG | 12/28/16  | OP99514A   | E3M3154          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 940 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.053 | 0.024 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.053 | 0.035 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.046 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.035 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.028 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.039 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.040 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.11  | 0.031 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 56%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 55%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 63%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |  |  |  |  |                        |          |
|--------------------------|----------------------------|--|--|--|--|------------------------|----------|
| <b>Client Sample ID:</b> | BR-2                       |  |  |  |  |                        |          |
| <b>Lab Sample ID:</b>    | JC34340-9                  |  |  |  |  | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Matrix:</b>           | AQ - Ground Water          |  |  |  |  | <b>Date Received:</b>  | 12/23/16 |
| <b>Method:</b>           | SW846-8015C (DAI)          |  |  |  |  | <b>Percent Solids:</b> | n/a      |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |  |  |  |  |                        |          |

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107985.D | 1  | 12/29/16 | XPL | n/a       | n/a        | GGH5599          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 76%    |        | 56-145% |
| 111-27-3 | Hexanol              | 73%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                   |                            |                 |          |
|-------------------|----------------------------|-----------------|----------|
| Client Sample ID: | BR-2                       | Date Sampled:   | 12/21/16 |
| Lab Sample ID:    | JC34340-9                  | Date Received:  | 12/23/16 |
| Matrix:           | AQ - Ground Water          | Percent Solids: | n/a      |
| Method:           | RSK-175                    |                 |          |
| Project:          | BMSMC, Building 5 Area, PR |                 |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | AA56676.D | 1  | 12/30/16 | LM | n/a       | n/a        | GAA1104          |
| Run #2 |           |    |          |    |           |            |                  |

| CAS No. | Compound | Result | RL   | MDL   | Units | Q |
|---------|----------|--------|------|-------|-------|---|
| 74-82-8 | Methane  | 4.0    | 0.11 | 0.036 | ug/l  |   |



ND = Not detected      MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

## Report of Analysis

Page 1 of 1

**Client Sample ID:** BR-2  
**Lab Sample ID:** JC34340-9  
**Matrix:** AQ - Ground Water  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

4.9

4

## Total Metals Analysis

| Analyte   | Result | RL  | MDL  | Units | DF | Prep     | Analyzed By | Method                   | Prep Method              |
|-----------|--------|-----|------|-------|----|----------|-------------|--------------------------|--------------------------|
| Iron      | 3320   | 100 | 12   | ug/l  | 1  | 12/28/16 | 12/29/16 ND | SW846 6010C <sup>1</sup> | SW846 3010A <sup>2</sup> |
| Manganese | 166    | 15  | 0.39 | ug/l  | 1  | 12/28/16 | 12/29/16 ND | SW846 6010C <sup>1</sup> | SW846 3010A <sup>2</sup> |

(1) Instrument QC Batch: MA41067

(2) Prep QC Batch: MP97875



RL = Reporting Limit  
MDL = Method Detection Limit

U = Indicates a result < MDL  
B = Indicates a result > = MDL but < RL

## Report of Analysis

Client Sample ID: BR-2  
 Lab Sample ID: JC34340-9  
 Matrix: AQ - Ground Water  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

4.9  
4

## General Chemistry

| Analyte                                | Result  | RL    | Units | DF | Analyzed       | By | Method              |
|--|---------|-------|-------|----|----------------|----|---------------------|
| Alkalinity, Total as CaCO <sub>3</sub> | 289     | 5.0   | mg/l  | 1  | 12/30/16 16:59 | JA | SM2320 B-11         |
| Iron, Ferric <sup>a</sup>              | 3.3     | 0.30  | mg/l  | 1  | 12/29/16 22:26 | ND | SM3500FE B-11       |
| Iron, Ferrous <sup>b</sup>             | < 0.20  | 0.20  | mg/l  | 1  | 12/24/16 12:48 | YR | SM3500FE B-11       |
| Nitrogen, Nitrate <sup>c</sup>         | < 0.11  | 0.11  | mg/l  | 1  | 01/03/17 12:51 | BM | EPA353 2/SM4500NO2B |
| Nitrogen, Nitrate + Nitrite            | < 0.10  | 0.10  | mg/l  | 1  | 01/03/17 12:51 | BM | EPA 353 2/LACHAT    |
| Nitrogen, Nitrite <sup>d</sup>         | < 0.010 | 0.010 | mg/l  | 1  | 12/23/16 23:10 | HS | SM4500NO2 B-11      |
| Sulfate                                | 38.6    | 10    | mg/l  | 1  | 01/07/17 06:37 | JN | EPA 300/SW846 9056A |
| Sulfide                                | < 2.0   | 2.0   | mg/l  | 1  | 12/27/16 10:48 | MP | SM4500S2- F-11      |

(a) Calculated as: (Iron) - (Iron, Ferrous)

(b) Field analysis required. Received out of hold time and analyzed by request.

(c) Calculated as: (Nitrogen, Nitrate + Nitrite) - (Nitrogen, Nitrite) Nitrogen, Nitrite analysis done past holding time.

(d) Received and analyzed out of holding time.



RL = Reporting Limit



SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-3                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-10                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8260C                |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68039.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 114%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 112%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-3                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-10                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 5P34336.D | 1  | 12/30/16 | SB | 12/28/16  | OP99514    | E5P1725          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 990 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.1 | 0.83 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.1 | 0.90 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.0 | 1.3  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.1 | 2.5  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 10  | 1.6  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.1 | 1.3  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.0 | 0.90 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.0 | 0.89 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.1 | 0.97 | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 10  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.0 | 1.4  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.0 | 0.40 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.1 | 1.5  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.1 | 1.3  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.1 | 0.93 | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.0 | 0.19 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.0 | 0.14 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.0 | 0.21 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.0 | 0.21 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.0 | 0.45 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.1 | 0.29 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.0 | 0.21 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.0 | 0.22 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.0 | 0.21 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.0 | 0.34 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.0 | 0.21 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.0 | 0.41 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.0 | 0.46 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.0 | 0.21 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.0 | 0.24 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.1 | 0.34 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.0 | 0.23 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-3                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-10                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.0 | 0.66 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.0 | 0.18 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.0 | 0.28 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.0 | 0.25 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.0 | 0.41 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.0 | 0.37 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.0 | 0.56 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.0 | 0.48 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.0 | 0.51 | ug/l  |   |
| 123-91-1  | 1,4-Dioxane                 | 27.6   | 1.0 | 0.66 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.0 | 0.33 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.1 | 0.22 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.0 | 0.50 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.0 | 0.24 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.0 | 0.26 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.0 | 0.22 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.0 | 1.7  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.0 | 0.17 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.0 | 0.17 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.0 | 0.33 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.0 | 0.50 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 10  | 2.8  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.0 | 0.39 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.0 | 0.34 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.0 | 0.28 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.0 | 0.27 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.0 | 0.21 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.1 | 0.28 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.1 | 0.39 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.1 | 0.44 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.0 | 0.65 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.0 | 0.49 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.1 | 0.22 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.0 | 0.18 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.0 | 0.22 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.0 | 0.37 | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits |
|----------|----------------------|--------|--------|--------|
| 367-12-4 | 2-Fluorophenol       | 49%    |        | 14-88% |

ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound



## Report of Analysis

|   |                                |
|---|--------------------------------|
| <b>Client Sample ID:</b> BR-3             | <b>Date Sampled:</b> 12/21/16  |
| <b>Lab Sample ID:</b> JC34340-10          | <b>Date Received:</b> 12/23/16 |
| <b>Matrix:</b> AQ - Ground Water          | <b>Percent Solids:</b> n/a     |
| <b>Method:</b> SW846 8270D SW846 3510C    |                                |
| <b>Project:</b> BSMC, Building 5 Area, PR |                                |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-62-2 | Phenol-d5            | 35%    |        | 10-110% |
| 118-79-6  | 2,4,6-Tribromophenol | 70%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 74%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 75%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 83%    |        | 10-126% |



ND = Not detected      MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                                |                        |          |
|--------------------------|--------------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-3                           | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-10                     | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water              | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D BY SIM SW846 3510C |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR     |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67734.D | 1  | 12/30/16 | SG | 12/28/16  | OP99514A   | E3M3154          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 990 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.051 | 0.023 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.051 | 0.034 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.10  | 0.044 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.10  | 0.033 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.10  | 0.026 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.10  | 0.037 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.10  | 0.038 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.10  | 0.030 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 76%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 74%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 77%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                   |                            |                 |          |
|-------------------|----------------------------|-----------------|----------|
| Client Sample ID: | BR-3                       | Date Sampled:   | 12/21/16 |
| Lab Sample ID:    | JC34340-10                 | Date Received:  | 12/23/16 |
| Matrix:           | AQ - Ground Water          | Percent Solids: | n/a      |
| Method:           | SW846-8015C (DAI)          |                 |          |
| Project:          | BMSMC, Building 5 Area, PR |                 |          |

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH108000.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 85%    |        | 56-145% |
| 111-27-3 | Hexanol              | 82%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

Client Sample ID: BR-4  
 Lab Sample ID: JC34340-11  
 Matrix: AQ - Ground Water  
 Method: SW846 8260C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68037.D | 1  | 12/31/16 | HT | n/a       | n/a        | V4B2796          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 106%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 113%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 115%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-4                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-11                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 5P34345.D | 1  | 12/30/16 | SB | 12/28/16  | OP99514    | E5P1725          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 910 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.5 | 0.90 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.5 | 0.98 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.2 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.5 | 2.7  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 11  | 1.7  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.5 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.2 | 0.98 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.2 | 0.97 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.5 | 1.1  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 11  | 1.3  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.4 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.2 | 0.43 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.5 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.5 | 1.5  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.5 | 1.0  | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.1 | 0.21 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.1 | 0.15 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.2 | 0.23 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.1 | 0.23 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.2 | 0.49 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.5 | 0.32 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.1 | 0.22 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.1 | 0.23 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.1 | 0.23 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.1 | 0.37 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.1 | 0.23 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.2 | 0.50 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.1 | 0.23 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.2 | 0.26 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.5 | 0.37 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.1 | 0.25 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound



## Report of Analysis

Client Sample ID: BR-4  
 Lab Sample ID: JC34340-11  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.2 | 0.71 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.2 | 0.31 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.2 | 0.27 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.2 | 0.40 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.1 | 0.61 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.1 | 0.52 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.2 | 0.56 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.1 | 0.36 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.5 | 0.24 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.2 | 0.55 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.2 | 0.26 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.2 | 0.29 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.2 | 0.24 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.2 | 1.8  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.1 | 0.36 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.1 | 0.54 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 1.1 | 3.1  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.2 | 0.43 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.1 | 0.36 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.2 | 0.30 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.1 | 0.29 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.1 | 0.23 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.5 | 0.30 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.5 | 0.43 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.5 | 0.48 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.2 | 0.71 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.2 | 0.53 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.5 | 0.24 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.1 | 0.24 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.2 | 0.41 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 367-12-4  | 2-Fluorophenol       | 52%    |        | 14-88%  |
| 4165-62-2 | Phenol-d5            | 37%    |        | 10-110% |

ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-4                       | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-11                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 86%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 74%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 72%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 76%    |        | 10-126% |



ND = Not detected MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                                |                        |          |
|--------------------------|--------------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | BR-4                           | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-11                     | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water              | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D BY SIM SW846 3510C |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR     |                        |          |

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4M69415.D | 1  | 12/31/16 | SG | 12/28/16  | OP99514A   | E4M3182          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 910 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.055 | 0.025 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.055 | 0.037 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.048 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.036 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.029 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.040 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.042 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.11  | 0.032 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | 0.311  | 0.11  | 0.054 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 67%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 66%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 82%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** BR-4  
**Lab Sample ID:** JC34340-11  
**Matrix:** AQ - Ground Water  
**Method:** SW846-8015C (DA1)  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107999.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 82%    |        | 56-145% |
| 111-27-3 | Hexanol              | 81%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** FB122116  
**Lab Sample ID:** JC34340-12  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846 8260C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68066.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 109%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 113%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: FB122116  
 Lab Sample ID: JC34340-12  
 Matrix: AQ - Field Blank Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 5P34346.D | 1  | 12/30/16 | SB | 12/28/16  | OP99514    | E5P1725          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 920 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.4 | 0.89 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.4 | 0.97 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.2 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.4 | 2.7  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 11  | 1.7  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.4 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.2 | 0.97 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.2 | 0.96 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.4 | 1.0  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 11  | 1.3  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.3 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.2 | 0.43 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.4 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.4 | 1.4  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.4 | 1.0  | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.1 | 0.21 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.1 | 0.15 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.2 | 0.23 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.1 | 0.23 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.2 | 0.49 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.4 | 0.31 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.1 | 0.22 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.1 | 0.23 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.1 | 0.22 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.1 | 0.37 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.1 | 0.22 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.2 | 0.50 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.1 | 0.23 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.2 | 0.26 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.4 | 0.37 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.1 | 0.25 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

Client Sample ID: FB122116  
 Lab Sample ID: JC34340-12  
 Matrix: AQ - Field Blank Water  
 Method: SW846 8270D SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16

Date Received: 12/23/16

Percent Solids: n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.2 | 0.71 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.2 | 0.30 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.2 | 0.27 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.2 | 0.40 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.1 | 0.60 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.1 | 0.52 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.2 | 0.55 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.1 | 0.36 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.4 | 0.24 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.2 | 0.54 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.2 | 0.25 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.2 | 0.28 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.2 | 0.24 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | 1.9    | 2.2 | 1.8  | ug/l  | J |
| 206-44-0  | Fluoranthene                | ND     | 1.1 | 0.18 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.1 | 0.35 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.1 | 0.53 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 11  | 3.0  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.2 | 0.42 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.1 | 0.36 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.2 | 0.30 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.1 | 0.29 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.1 | 0.23 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.4 | 0.30 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.4 | 0.42 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.4 | 0.48 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.2 | 0.70 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.2 | 0.52 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.4 | 0.24 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.1 | 0.24 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.2 | 0.40 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 367-12-4  | 2-Fluorophenol       | 57%    |        | 14-88%  |
| 4165-62-2 | Phenol-d5            | 37%    |        | 10-110% |

ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound



## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | FB122116                   | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Lab Sample ID:</b>    | JC34340-12                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water     | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 84%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 74%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 75%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 92%    |        | 10-126% |



ND = Not detected      MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** FB122116  
**Lab Sample ID:** JC34340-12  
**Matrix:** AQ - Field Blank Water  
**Method:** SW846 8270D BY SIM SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/21/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67736.D | 1  | 12/30/16 | SG | 12/28/16  | OP99514A   | E3M3154          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 920 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.054 | 0.025 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.054 | 0.036 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.047 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.036 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.028 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.039 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.041 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.11  | 0.032 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | ND     | 0.11  | 0.053 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 73%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 71%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 85%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |  |  |  |  |                        |          |
|--------------------------|----------------------------|--|--|--|--|------------------------|----------|
| <b>Client Sample ID:</b> | FB122116                   |  |  |  |  |                        |          |
| <b>Lab Sample ID:</b>    | JC34340-12                 |  |  |  |  | <b>Date Sampled:</b>   | 12/21/16 |
| <b>Matrix:</b>           | AQ - Field Blank Water     |  |  |  |  | <b>Date Received:</b>  | 12/23/16 |
| <b>Method:</b>           | SW846-8015C (DAI)          |  |  |  |  | <b>Percent Solids:</b> | n/a      |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |  |  |  |  |                        |          |

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107998.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 99%    |        | 56-145% |
| 111-27-3 | Hexanol              | 81%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

Client Sample ID: TB122116NR  
 Lab Sample ID: JC34340-13  
 Matrix: AQ - Trip Blank Water  
 Method: SW846 8260C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68067.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 104%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 113%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 113%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

Client Sample ID: TB122116RS  
 Lab Sample ID: JC34340-14  
 Matrix: AQ - Trip Blank Water  
 Method: SW846 8260C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/21/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68109.D | 1  | 01/04/17 | HT | n/a       | n/a        | V4B2799          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 110%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 109%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 104%   |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 107%   |        | 78-117% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** EB122216  
**Lab Sample ID:** JC34340-15  
**Matrix:** AQ - Equipment Blank  
**Method:** SW846 8260C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68069.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 106%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 112%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 99%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 115%   |        | 78-117% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: EB122216  
 Lab Sample ID: JC34340-15  
 Matrix: AQ - Equipment Blank  
 Method: SW846 8270D SW846 3510C  
 Project: BSMC, Building 5 Area, PR

Date Sampled: 12/22/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | P110196.D | 1  | 01/03/17 | RL | 12/29/16  | OP99540    | EP4893           |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 1.0 ml       |
| Run #2 |                |              |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.6 | 0.91 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.6 | 0.99 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.2 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.6 | 2.7  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 11  | 1.7  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.6 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.2 | 0.99 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.2 | 0.98 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.6 | 1.1  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 11  | 1.3  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.4 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.2 | 0.44 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.6 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.6 | 1.5  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.6 | 1.0  | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.1 | 0.21 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.1 | 0.15 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.2 | 0.23 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.1 | 0.23 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.2 | 0.50 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.6 | 0.32 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.1 | 0.23 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.1 | 0.24 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.1 | 0.23 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.1 | 0.38 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.1 | 0.23 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.2 | 0.45 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.2 | 0.51 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.1 | 0.24 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.2 | 0.26 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.6 | 0.38 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.1 | 0.25 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

**Client Sample ID:** EB122216  
**Lab Sample ID:** JC34340-15  
**Matrix:** AQ - Equipment Blank  
**Method:** SW846 8270D SW846 3510C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

## ABN TCL Special List

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND     | 2.2 | 0.72 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND     | 1.1 | 0.20 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND     | 2.2 | 0.31 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND     | 2.2 | 0.28 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND     | 2.2 | 0.45 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND     | 2.2 | 0.41 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND     | 1.1 | 0.61 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND     | 1.1 | 0.53 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND     | 2.2 | 0.56 | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND     | 1.1 | 0.37 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND     | 5.6 | 0.24 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND     | 2.2 | 0.55 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND     | 2.2 | 0.26 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND     | 2.2 | 0.29 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND     | 2.2 | 0.24 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND     | 2.2 | 1.8  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND     | 1.1 | 0.19 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND     | 1.1 | 0.36 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND     | 1.1 | 0.55 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND     | 11  | 3.1  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND     | 2.2 | 0.43 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND     | 1.1 | 0.37 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND     | 2.2 | 0.31 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND     | 1.1 | 0.29 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND     | 1.1 | 0.23 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND     | 5.6 | 0.31 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND     | 5.6 | 0.43 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND     | 5.6 | 0.49 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND     | 2.2 | 0.71 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND     | 2.2 | 0.53 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND     | 5.6 | 0.25 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND     | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND     | 1.1 | 0.24 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND     | 2.2 | 0.41 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 367-12-4  | 2-Fluorophenol       | 37%    |        | 14-88%  |
| 4165-62-2 | Phenol-d5            | 24%    |        | 10-110% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | EB122216                   | <b>Date Sampled:</b>   | 12/22/16 |
| <b>Lab Sample ID:</b>    | JC34340-15                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Equipment Blank       | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 118-79-6  | 2,4,6-Tribromophenol | 85%    |        | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 60%    |        | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 70%    |        | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 82%    |        | 10-126% |



ND = Not detected    MDL = Method Detection Limit  
RL = Reporting Limit  
E = Indicates value exceeds calibration range

J = Indicates an estimated value  
B = Indicates analyte found in associated method blank  
N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** EB122216  
**Lab Sample ID:** JC34340-15  
**Matrix:** AQ - Equipment Blank  
**Method:** SW846 8270D BY SIM SW846 3510C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67752.D | 1  | 12/30/16 | SG | 12/29/16  | OP99540A   | E3M3155          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.056 | 0.025 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.056 | 0.037 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.048 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.037 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.029 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.040 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.042 | ug/l  |   |
| 91-20-3  | Naphthalene            | ND     | 0.11  | 0.033 | ug/l  |   |
| 123-91-1 | 1,4-Dioxane            | ND     | 0.11  | 0.054 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 80%    |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 68%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 75%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** EB122216  
**Lab Sample ID:** JC34340-15  
**Matrix:** AQ - Equipment Blank  
**Method:** SW846-8015C (DA1)  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107997.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 91%    |        | 56-145% |
| 111-27-3 | Hexanol              | 88%    |        | 56-145% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

Client Sample ID: EB122216  
 Lab Sample ID: JC34340-15  
 Matrix: AQ - Equipment Blank  
 Method: SW846 8081B SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/22/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 8G1635.D | 1  | 01/03/17 | JR | 12/29/16  | OP99539    | G8G54            |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 10.0 ml      |
| Run #2 |                |              |

## Pesticide TCL List

| CAS No.    | Compound            | Result | RL    | MDL    | Units | Q |
|------------|---------------------|--------|-------|--------|-------|---|
| 309-00-2   | Aldrin              | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-84-6   | alpha-BHC           | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-85-7   | beta-BHC            | ND     | 0.011 | 0.0063 | ug/l  |   |
| 319-86-8   | delta-BHC           | ND     | 0.011 | 0.0051 | ug/l  |   |
| 58-89-9    | gamma-BHC (Lindane) | ND     | 0.011 | 0.0031 | ug/l  |   |
| 5103-71-9  | alpha-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 5103-74-2  | gamma-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 60-57-1    | Dieldrin            | ND     | 0.011 | 0.0040 | ug/l  |   |
| 72-54-8    | 4,4'-DDD            | ND     | 0.011 | 0.0042 | ug/l  |   |
| 72-55-9    | 4,4'-DDE            | ND     | 0.011 | 0.0068 | ug/l  |   |
| 50-29-3    | 4,4'-DDT            | ND     | 0.011 | 0.0055 | ug/l  |   |
| 72-20-8    | Endrin              | ND     | 0.011 | 0.0056 | ug/l  |   |
| 1031-07-8  | Endosulfan sulfate  | ND     | 0.011 | 0.0058 | ug/l  |   |
| 7421-93-4  | Endrin aldehyde     | ND     | 0.011 | 0.0057 | ug/l  |   |
| 53494-70-5 | Endrin ketone       | ND     | 0.011 | 0.0056 | ug/l  |   |
| 959-98-8   | Endosulfan-I        | ND     | 0.011 | 0.0055 | ug/l  |   |
| 33213-65-9 | Endosulfan-II       | ND     | 0.011 | 0.0048 | ug/l  |   |
| 76-44-8    | Heptachlor          | ND     | 0.011 | 0.0042 | ug/l  |   |
| 1024-57-3  | Heptachlor epoxide  | ND     | 0.011 | 0.0073 | ug/l  |   |
| 72-43-5    | Methoxychlor        | ND     | 0.022 | 0.0063 | ug/l  |   |
| 8001-35-2  | Toxaphene           | ND     | 0.28  | 0.20   | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 96%    |        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 100%   |        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 30%    |        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 29%    |        | 10-118% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** RA-10D  
**Lab Sample ID:** JC34340-16  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8260C  
**Project:** BMSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68061.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 112%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 97%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 105%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 3

Client Sample ID: RA-10D  
 Lab Sample ID: JC34340-16  
 Matrix: AQ - Ground Water  
 Method: SW846 8270D SW846 3510C  
 Project: BSMC, Building 5 Area, PR

Date Sampled: 12/22/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | P110152.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| Run #2 | P110195.D | 50 | 01/03/17 | RL | 12/29/16  | OP99540    | EP4893           |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 925 ml         | 1.0 ml       |
| Run #2 | 925 ml         | 1.0 ml       |

## ABN TCL Special List

| CAS No.   | Compound                   | Result | RL  | MDL  | Units | Q |
|-----------|----------------------------|--------|-----|------|-------|---|
| 95-57-8   | 2-Chlorophenol             | ND     | 5.4 | 0.89 | ug/l  |   |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND     | 5.4 | 0.96 | ug/l  |   |
| 120-83-2  | 2,4-Dichlorophenol         | ND     | 2.2 | 1.4  | ug/l  |   |
| 105-67-9  | 2,4-Dimethylphenol         | ND     | 5.4 | 2.6  | ug/l  |   |
| 51-28-5   | 2,4-Dinitrophenol          | ND     | 11  | 1.7  | ug/l  |   |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND     | 5.4 | 1.4  | ug/l  |   |
| 95-48-7   | 2-Methylphenol             | ND     | 2.2 | 0.96 | ug/l  |   |
|           | 3&4-Methylphenol           | ND     | 2.2 | 0.95 | ug/l  |   |
| 88-75-5   | 2-Nitrophenol              | ND     | 5.4 | 1.0  | ug/l  |   |
| 100-02-7  | 4-Nitrophenol              | ND     | 11  | 1.2  | ug/l  |   |
| 87-86-5   | Pentachlorophenol          | ND     | 4.3 | 1.5  | ug/l  |   |
| 108-95-2  | Phenol                     | ND     | 2.2 | 0.42 | ug/l  |   |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND     | 5.4 | 1.6  | ug/l  |   |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND     | 5.4 | 1.4  | ug/l  |   |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND     | 5.4 | 1.0  | ug/l  |   |
| 83-32-9   | Acenaphthene               | ND     | 1.1 | 0.21 | ug/l  |   |
| 208-96-8  | Acenaphthylene             | ND     | 1.1 | 0.15 | ug/l  |   |
| 98-86-2   | Acetophenone               | ND     | 2.2 | 0.22 | ug/l  |   |
| 120-12-7  | Anthracene                 | ND     | 1.1 | 0.23 | ug/l  |   |
| 1912-24-9 | Atrazine                   | ND     | 2.2 | 0.48 | ug/l  |   |
| 100-52-7  | Benzaldehyde               | ND     | 5.4 | 0.31 | ug/l  |   |
| 56-55-3   | Benzo(a)anthracene         | ND     | 1.1 | 0.22 | ug/l  |   |
| 50-32-8   | Benzo(a)pyrene             | ND     | 1.1 | 0.23 | ug/l  |   |
| 205-99-2  | Benzo(b)fluoranthene       | ND     | 1.1 | 0.22 | ug/l  |   |
| 191-24-2  | Benzo(g,h,i)perylene       | ND     | 1.1 | 0.37 | ug/l  |   |
| 207-08-9  | Benzo(k)fluoranthene       | ND     | 1.1 | 0.22 | ug/l  |   |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND     | 2.2 | 0.44 | ug/l  |   |
| 85-68-7   | Butyl benzyl phthalate     | ND     | 2.2 | 0.49 | ug/l  |   |
| 92-52-4   | 1,1'-Biphenyl              | ND     | 1.1 | 0.23 | ug/l  |   |
| 91-58-7   | 2-Chloronaphthalene        | ND     | 2.2 | 0.26 | ug/l  |   |
| 106-47-8  | 4-Chloroaniline            | ND     | 5.4 | 0.37 | ug/l  |   |
| 86-74-8   | Carbazole                  | ND     | 1.1 | 0.25 | ug/l  |   |



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | RA-10D                     | <b>Date Sampled:</b>   | 12/22/16 |
| <b>Lab Sample ID:</b>    | JC34340-16                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Compound                    | Result            | RL  | MDL  | Units | Q |
|-----------|-----------------------------|-------------------|-----|------|-------|---|
| 105-60-2  | Caprolactam                 | ND                | 2.2 | 0.70 | ug/l  |   |
| 218-01-9  | Chrysene                    | ND                | 1.1 | 0.19 | ug/l  |   |
| 111-91-1  | bis(2-Chloroethoxy)methane  | ND                | 2.2 | 0.30 | ug/l  |   |
| 111-44-4  | bis(2-Chloroethyl)ether     | ND                | 2.2 | 0.27 | ug/l  |   |
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND                | 2.2 | 0.44 | ug/l  |   |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND                | 2.2 | 0.40 | ug/l  |   |
| 121-14-2  | 2,4-Dinitrotoluene          | ND                | 1.1 | 0.60 | ug/l  |   |
| 606-20-2  | 2,6-Dinitrotoluene          | ND                | 1.1 | 0.51 | ug/l  |   |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND                | 2.2 | 0.55 | ug/l  |   |
| 123-91-1  | 1,4-Dioxane                 | 1520 <sup>a</sup> | 54  | 36   | ug/l  |   |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND                | 1.1 | 0.36 | ug/l  |   |
| 132-64-9  | Dibenzofuran                | ND                | 5.4 | 0.24 | ug/l  |   |
| 84-74-2   | Di-n-butyl phthalate        | ND                | 2.2 | 0.54 | ug/l  |   |
| 117-84-0  | Di-n-octyl phthalate        | ND                | 2.2 | 0.25 | ug/l  |   |
| 84-66-2   | Diethyl phthalate           | ND                | 2.2 | 0.28 | ug/l  |   |
| 131-11-3  | Dimethyl phthalate          | ND                | 2.2 | 0.24 | ug/l  |   |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND                | 2.2 | 1.8  | ug/l  |   |
| 206-44-0  | Fluoranthene                | ND                | 1.1 | 0.18 | ug/l  |   |
| 86-73-7   | Fluorene                    | ND                | 1.1 | 0.18 | ug/l  |   |
| 118-74-1  | Hexachlorobenzene           | ND                | 1.1 | 0.35 | ug/l  |   |
| 87-68-3   | Hexachlorobutadiene         | ND                | 1.1 | 0.53 | ug/l  |   |
| 77-47-4   | Hexachlorocyclopentadiene   | ND                | 11  | 3.0  | ug/l  |   |
| 67-72-1   | Hexachloroethane            | ND                | 2.2 | 0.42 | ug/l  |   |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND                | 1.1 | 0.36 | ug/l  |   |
| 78-59-1   | Isophorone                  | ND                | 2.2 | 0.30 | ug/l  |   |
| 90-12-0   | 1-Methylnaphthalene         | ND                | 1.1 | 0.28 | ug/l  |   |
| 91-57-6   | 2-Methylnaphthalene         | ND                | 1.1 | 0.23 | ug/l  |   |
| 88-74-4   | 2-Nitroaniline              | ND                | 5.4 | 0.30 | ug/l  |   |
| 99-09-2   | 3-Nitroaniline              | ND                | 5.4 | 0.42 | ug/l  |   |
| 100-01-6  | 4-Nitroaniline              | ND                | 5.4 | 0.48 | ug/l  |   |
| 98-95-3   | Nitrobenzene                | ND                | 2.2 | 0.69 | ug/l  |   |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND                | 2.2 | 0.52 | ug/l  |   |
| 86-30-6   | N-Nitrosodiphenylamine      | ND                | 5.4 | 0.24 | ug/l  |   |
| 85-01-8   | Phenanthrene                | ND                | 1.1 | 0.19 | ug/l  |   |
| 129-00-0  | Pyrene                      | ND                | 1.1 | 0.24 | ug/l  |   |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND                | 2.2 | 0.40 | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2          | Limits |
|----------|----------------------|--------|-----------------|--------|
| 367-12-4 | 2-Fluorophenol       | 41%    | 0% <sup>b</sup> | 14-88% |

ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | RA-10D                     | <b>Date Sampled:</b>   | 12/22/16 |
| <b>Lab Sample ID:</b>    | JC34340-16                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8270D SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |                        |          |

## ABN TCL Special List

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2          | Limits  |
|-----------|----------------------|--------|-----------------|---------|
| 4165-62-2 | Phenol-d5            | 30%    | 0% <sup>b</sup> | 10-110% |
| 118-79-6  | 2,4,6-Tribromophenol | 96%    | 0% <sup>b</sup> | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 71%    | 0% <sup>b</sup> | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 79%    | 0% <sup>b</sup> | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 87%    | 0% <sup>b</sup> | 10-126% |

(a) Result is from Run# 2

(b) Outside control limits due to dilution.



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** RA-10D  
**Lab Sample ID:** JC34340-16  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8270D BY SIM SW846 3510C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 3M67751.D | 1  | 12/30/16 | SG | 12/29/16  | OP99540A   | E3M3155          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 925 ml         | 1.0 ml       |
| Run #2 |                |              |

| CAS No.  | Compound               | Result | RL    | MDL   | Units | Q |
|----------|------------------------|--------|-------|-------|-------|---|
| 56-55-3  | Benzo(a)anthracene     | ND     | 0.054 | 0.025 | ug/l  |   |
| 50-32-8  | Benzo(a)pyrene         | ND     | 0.054 | 0.036 | ug/l  |   |
| 205-99-2 | Benzo(b)fluoranthene   | ND     | 0.11  | 0.047 | ug/l  |   |
| 207-08-9 | Benzo(k)fluoranthene   | ND     | 0.11  | 0.036 | ug/l  |   |
| 218-01-9 | Chrysene               | ND     | 0.11  | 0.028 | ug/l  |   |
| 53-70-3  | Dibenzo(a,h)anthracene | ND     | 0.11  | 0.039 | ug/l  |   |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND     | 0.11  | 0.041 | ug/l  |   |
| 91-20-3  | Naphthalene            | 0.236  | 0.11  | 0.032 | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 100%   |        | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 86%    |        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 81%    |        | 10-119% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |  |  |  |  |                        |          |
|--------------------------|----------------------------|--|--|--|--|------------------------|----------|
| <b>Client Sample ID:</b> | RA-10D                     |  |  |  |  |                        |          |
| <b>Lab Sample ID:</b>    | JC34340-16                 |  |  |  |  | <b>Date Sampled:</b>   | 12/22/16 |
| <b>Matrix:</b>           | AQ - Ground Water          |  |  |  |  | <b>Date Received:</b>  | 12/23/16 |
| <b>Method:</b>           | SW846-8015C (DAI)          |  |  |  |  | <b>Percent Solids:</b> | n/a      |
| <b>Project:</b>          | BMSMC, Building 5 Area, PR |  |  |  |  |                        |          |

| Run #  | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|-----|-----------|------------|------------------|
| Run #1 | GH107994.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| Run #2 |            |    |          |     |           |            |                  |

## Low Molecular Alcohol List

| CAS No. | Compound          | Result | RL  | MDL | Units | Q |
|---------|-------------------|--------|-----|-----|-------|---|
| 64-17-5 | Ethanol           | ND     | 100 | 55  | ug/l  |   |
| 78-83-1 | Isobutyl Alcohol  | ND     | 100 | 36  | ug/l  |   |
| 67-63-0 | Isopropyl Alcohol | ND     | 100 | 68  | ug/l  |   |
| 71-23-8 | n-Propyl Alcohol  | ND     | 100 | 43  | ug/l  |   |
| 71-36-3 | n-Butyl Alcohol   | ND     | 100 | 87  | ug/l  |   |
| 78-92-2 | sec-Butyl Alcohol | ND     | 100 | 66  | ug/l  |   |
| 67-56-1 | Methanol          | ND     | 200 | 71  | ug/l  |   |

| CAS No.  | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|----------|----------------------|--------|--------|---------|
| 111-27-3 | Hexanol              | 89%    |        | 56-145% |
| 111-27-3 | Hexanol              | 85%    |        | 56-145% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** RA-10D  
**Lab Sample ID:** JC34340-16  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8081B SW846 3510C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 8G1631.D | 1  | 01/03/17 | JR | 12/29/16  | OP99539    | G8G54            |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 10.0 ml      |
| Run #2 |                |              |

## Pesticide TCL List

| CAS No.    | Compound            | Result | RL    | MDL    | Units | Q |
|------------|---------------------|--------|-------|--------|-------|---|
| 309-00-2   | Aldrin              | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-84-6   | alpha-BHC           | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-85-7   | beta-BHC            | ND     | 0.011 | 0.0063 | ug/l  |   |
| 319-86-8   | delta-BHC           | ND     | 0.011 | 0.0051 | ug/l  |   |
| 58-89-9    | gamma-BHC (Lindane) | ND     | 0.011 | 0.0031 | ug/l  |   |
| 5103-71-9  | alpha-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 5103-74-2  | gamma-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 60-57-1    | Dieldrin            | ND     | 0.011 | 0.0040 | ug/l  |   |
| 72-54-8    | 4,4'-DDD            | ND     | 0.011 | 0.0042 | ug/l  |   |
| 72-55-9    | 4,4'-DDE            | ND     | 0.011 | 0.0068 | ug/l  |   |
| 50-29-3    | 4,4'-DDT            | ND     | 0.011 | 0.0055 | ug/l  |   |
| 72-20-8    | Endrin              | ND     | 0.011 | 0.0056 | ug/l  |   |
| 1031-07-8  | Endosulfan sulfate  | ND     | 0.011 | 0.0058 | ug/l  |   |
| 7421-93-4  | Endrin aldehyde     | ND     | 0.011 | 0.0057 | ug/l  |   |
| 53494-70-5 | Endrin ketone       | ND     | 0.011 | 0.0056 | ug/l  |   |
| 959-98-8   | Endosulfan-I        | ND     | 0.011 | 0.0055 | ug/l  |   |
| 33213-65-9 | Endosulfan-II       | ND     | 0.011 | 0.0048 | ug/l  |   |
| 76-44-8    | Heptachlor          | ND     | 0.011 | 0.0042 | ug/l  |   |
| 1024-57-3  | Heptachlor epoxide  | ND     | 0.011 | 0.0073 | ug/l  |   |
| 72-43-5    | Methoxychlor        | ND     | 0.022 | 0.0063 | ug/l  |   |
| 8001-35-2  | Toxaphene           | ND     | 0.28  | 0.20   | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 91%    |        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 91%    |        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 80%    |        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 70%    |        | 10-118% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** TB122216NRA  
**Lab Sample ID:** JC34340-17  
**Matrix:** AQ - Trip Blank Water  
**Method:** SW846 8260C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|-----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 4B68070.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| Run #2 |           |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

| CAS No.  | Compound      | Result | RL  | MDL  | Units | Q |
|----------|---------------|--------|-----|------|-------|---|
| 106-99-0 | 1,3-Butadiene | ND     | 5.0 | 0.17 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 105%   |        | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 112%   |        | 73-122% |
| 2037-26-5  | Toluene-D8            | 97%    |        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 116%   |        | 78-117% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

|                          |                            |                        |          |
|--------------------------|----------------------------|------------------------|----------|
| <b>Client Sample ID:</b> | MW-20S                     | <b>Date Sampled:</b>   | 12/22/16 |
| <b>Lab Sample ID:</b>    | JC34340-18                 | <b>Date Received:</b>  | 12/23/16 |
| <b>Matrix:</b>           | AQ - Ground Water          | <b>Percent Solids:</b> | n/a      |
| <b>Method:</b>           | SW846 8081B SW846 3510C    |                        |          |
| <b>Project:</b>          | BMSMC, Building 5 Area. PR |                        |          |

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 8G1664.D | 1  | 01/04/17 | JR | 12/29/16  | OP99539    | G8G54            |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 1000 ml        | 10.0 ml      |
| Run #2 |                |              |

## Pesticide TCL List

| CAS No.    | Compound            | Result | RL    | MDL    | Units | Q |
|------------|---------------------|--------|-------|--------|-------|---|
| 309-00-2   | Aldrin              | ND     | 0.010 | 0.0060 | ug/l  |   |
| 319-84-6   | alpha-BHC           | ND     | 0.010 | 0.0060 | ug/l  |   |
| 319-85-7   | beta-BHC            | ND     | 0.010 | 0.0057 | ug/l  |   |
| 319-86-8   | delta-BHC           | ND     | 0.010 | 0.0046 | ug/l  |   |
| 58-89-9    | gamma-BHC (Lindane) | ND     | 0.010 | 0.0028 | ug/l  |   |
| 5103-71-9  | alpha-Chlordane     | ND     | 0.010 | 0.0046 | ug/l  |   |
| 5103-74-2  | gamma-Chlordane     | ND     | 0.010 | 0.0046 | ug/l  |   |
| 60-57-1    | Dieldrin            | ND     | 0.010 | 0.0036 | ug/l  |   |
| 72-54-8    | 4,4'-DDD            | ND     | 0.010 | 0.0038 | ug/l  |   |
| 72-55-9    | 4,4'-DDE            | ND     | 0.010 | 0.0062 | ug/l  |   |
| 50-29-3    | 4,4'-DDT            | ND     | 0.010 | 0.0050 | ug/l  |   |
| 72-20-8    | Endrin              | ND     | 0.010 | 0.0050 | ug/l  |   |
| 1031-07-8  | Endosulfan sulfate  | ND     | 0.010 | 0.0053 | ug/l  |   |
| 7421-93-4  | Endrin aldehyde     | ND     | 0.010 | 0.0051 | ug/l  |   |
| 53494-70-5 | Endrin ketone       | ND     | 0.010 | 0.0051 | ug/l  |   |
| 959-98-8   | Endosulfan-I        | ND     | 0.010 | 0.0050 | ug/l  |   |
| 33213-65-9 | Endosulfan-II       | ND     | 0.010 | 0.0043 | ug/l  |   |
| 76-44-8    | Heptachlor          | ND     | 0.010 | 0.0038 | ug/l  |   |
| 1024-57-3  | Heptachlor epoxide  | ND     | 0.010 | 0.0065 | ug/l  |   |
| 72-43-5    | Methoxychlor        | ND     | 0.020 | 0.0057 | ug/l  |   |
| 8001-35-2  | Toxaphene           | ND     | 0.25  | 0.18   | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 96%    |        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 102%   |        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 49%    |        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 47%    |        | 10-118% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

**Client Sample ID:** MW-20D  
**Lab Sample ID:** JC34340-19  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8081B SW846 3510C  
**Project:** BSMC, Building 5 Area, PR

**Date Sampled:** 12/22/16  
**Date Received:** 12/23/16  
**Percent Solids:** n/a

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 8G1665.D | 1  | 01/04/17 | JR | 12/29/16  | OP99539    | G8G54            |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 10.0 ml      |
| Run #2 |                |              |

## Pesticide TCL List

| CAS No.    | Compound            | Result | RL    | MDL    | Units | Q |
|------------|---------------------|--------|-------|--------|-------|---|
| 309-00-2   | Aldrin              | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-84-6   | alpha-BHC           | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-85-7   | beta-BHC            | ND     | 0.011 | 0.0063 | ug/l  |   |
| 319-86-8   | delta-BHC           | ND     | 0.011 | 0.0051 | ug/l  |   |
| 58-89-9    | gamma-BHC (Lindane) | ND     | 0.011 | 0.0031 | ug/l  |   |
| 5103-71-9  | alpha-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 5103-74-2  | gamma-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 60-57-1    | Dieldrin            | ND     | 0.011 | 0.0040 | ug/l  |   |
| 72-54-8    | 4,4'-DDD            | ND     | 0.011 | 0.0042 | ug/l  |   |
| 72-55-9    | 4,4'-DDE            | ND     | 0.011 | 0.0068 | ug/l  |   |
| 50-29-3    | 4,4'-DDT            | ND     | 0.011 | 0.0055 | ug/l  |   |
| 72-20-8    | Endrin              | ND     | 0.011 | 0.0056 | ug/l  |   |
| 1031-07-8  | Endosulfan sulfate  | ND     | 0.011 | 0.0058 | ug/l  |   |
| 7421-93-4  | Endrin aldehyde     | ND     | 0.011 | 0.0057 | ug/l  |   |
| 53494-70-5 | Endrin ketone       | ND     | 0.011 | 0.0056 | ug/l  |   |
| 959-98-8   | Endosulfan-I        | ND     | 0.011 | 0.0055 | ug/l  |   |
| 33213-65-9 | Endosulfan-II       | ND     | 0.011 | 0.0048 | ug/l  |   |
| 76-44-8    | Heptachlor          | ND     | 0.011 | 0.0042 | ug/l  |   |
| 1024-57-3  | Heptachlor epoxide  | ND     | 0.011 | 0.0073 | ug/l  |   |
| 72-43-5    | Methoxychlor        | ND     | 0.022 | 0.0063 | ug/l  |   |
| 8001-35-2  | Toxaphene           | ND     | 0.28  | 0.20   | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 81%    |        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 87%    |        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 59%    |        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 59%    |        | 10-118% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

Client Sample ID: RA-10S  
 Lab Sample ID: JC34340-20  
 Matrix: AQ - Ground Water  
 Method: SW846 8081B SW846 3510C  
 Project: BSMC, Building 5 Area, PR

Date Sampled: 12/22/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 8G1666.D | 1  | 01/04/17 | JR | 12/29/16  | OP99539    | G8G54            |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 10.0 ml      |
| Run #2 |                |              |

## Pesticide TCL List

| CAS No.    | Compound            | Result | RL    | MDL    | Units | Q |
|------------|---------------------|--------|-------|--------|-------|---|
| 309-00-2   | Aldrin              | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-84-6   | alpha-BHC           | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-85-7   | beta-BHC            | ND     | 0.011 | 0.0063 | ug/l  |   |
| 319-86-8   | delta-BHC           | ND     | 0.011 | 0.0051 | ug/l  |   |
| 58-89-9    | gamma-BHC (Lindane) | ND     | 0.011 | 0.0031 | ug/l  |   |
| 5103-71-9  | alpha-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 5103-74-2  | gamma-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 60-57-1    | Dieldrin            | ND     | 0.011 | 0.0040 | ug/l  |   |
| 72-54-8    | 4,4'-DDD            | ND     | 0.011 | 0.0042 | ug/l  |   |
| 72-55-9    | 4,4'-DDE            | ND     | 0.011 | 0.0068 | ug/l  |   |
| 50-29-3    | 4,4'-DDT            | ND     | 0.011 | 0.0055 | ug/l  |   |
| 72-20-8    | Endrin              | ND     | 0.011 | 0.0056 | ug/l  |   |
| 1031-07-8  | Endosulfan sulfate  | ND     | 0.011 | 0.0058 | ug/l  |   |
| 7421-93-4  | Endrin aldehyde     | ND     | 0.011 | 0.0057 | ug/l  |   |
| 53494-70-5 | Endrin ketone       | ND     | 0.011 | 0.0056 | ug/l  |   |
| 959-98-8   | Endosulfan-I        | ND     | 0.011 | 0.0055 | ug/l  |   |
| 33213-65-9 | Endosulfan-II       | ND     | 0.011 | 0.0048 | ug/l  |   |
| 76-44-8    | Heptachlor          | ND     | 0.011 | 0.0042 | ug/l  |   |
| 1024-57-3  | Heptachlor epoxide  | ND     | 0.011 | 0.0073 | ug/l  |   |
| 72-43-5    | Methoxychlor        | ND     | 0.022 | 0.0063 | ug/l  |   |
| 8001-35-2  | Toxaphene           | ND     | 0.28  | 0.20   | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 103%   |        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 110%   |        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 79%    |        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 73%    |        | 10-118% |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 1

Client Sample ID: FB122216  
 Lab Sample ID: JC34340-21  
 Matrix: AQ - Field Blank Water  
 Method: SW846 8081B SW846 3510C  
 Project: BMSMC, Building 5 Area, PR

Date Sampled: 12/22/16  
 Date Received: 12/23/16  
 Percent Solids: n/a

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | 8G1667.D | 1  | 01/04/17 | JR | 12/29/16  | OP99539    | G8G54            |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Volume | Final Volume |
|--------|----------------|--------------|
| Run #1 | 900 ml         | 10.0 ml      |
| Run #2 |                |              |

## Pesticide TCL List

| CAS No.    | Compound            | Result | RL    | MDL    | Units | Q |
|------------|---------------------|--------|-------|--------|-------|---|
| 309-00-2   | Aldrin              | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-84-6   | alpha-BHC           | ND     | 0.011 | 0.0067 | ug/l  |   |
| 319-85-7   | beta-BHC            | ND     | 0.011 | 0.0063 | ug/l  |   |
| 319-86-8   | delta-BHC           | ND     | 0.011 | 0.0051 | ug/l  |   |
| 58-89-9    | gamma-BHC (Lindane) | ND     | 0.011 | 0.0031 | ug/l  |   |
| 5103-71-9  | alpha-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 5103-74-2  | gamma-Chlordane     | ND     | 0.011 | 0.0051 | ug/l  |   |
| 60-57-1    | Dieldrin            | ND     | 0.011 | 0.0040 | ug/l  |   |
| 72-54-8    | 4,4'-DDD            | ND     | 0.011 | 0.0042 | ug/l  |   |
| 72-55-9    | 4,4'-DDE            | ND     | 0.011 | 0.0068 | ug/l  |   |
| 50-29-3    | 4,4'-DDT            | ND     | 0.011 | 0.0055 | ug/l  |   |
| 72-20-8    | Endrin              | ND     | 0.011 | 0.0056 | ug/l  |   |
| 1031-07-8  | Endosulfan sulfate  | ND     | 0.011 | 0.0058 | ug/l  |   |
| 7421-93-4  | Endrin aldehyde     | ND     | 0.011 | 0.0057 | ug/l  |   |
| 53494-70-5 | Endrin ketone       | ND     | 0.011 | 0.0056 | ug/l  |   |
| 959-98-8   | Endosulfan-I        | ND     | 0.011 | 0.0055 | ug/l  |   |
| 33213-65-9 | Endosulfan-II       | ND     | 0.011 | 0.0048 | ug/l  |   |
| 76-44-8    | Heptachlor          | ND     | 0.011 | 0.0042 | ug/l  |   |
| 1024-57-3  | Heptachlor epoxide  | ND     | 0.011 | 0.0073 | ug/l  |   |
| 72-43-5    | Methoxychlor        | ND     | 0.022 | 0.0063 | ug/l  |   |
| 8001-35-2  | Toxaphene           | ND     | 0.28  | 0.20   | ug/l  |   |

| CAS No.   | Surrogate Recoveries | Run# 1 | Run# 2 | Limits  |
|-----------|----------------------|--------|--------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 90%    |        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 95%    |        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 61%    |        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 57%    |        | 10-118% |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

**Matrix Spike/Matrix Spike Duplicate Summary**

Page 1 of 1

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland &amp; Associates

Project: BSMC, Building 5 Area, PR

| Sample        | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|---------------|-----------|----|----------|----|-----------|------------|------------------|
| JC34340-16MS  | 4B68062.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| JC34340-16MSD | 4B68063.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |
| JC34340-16    | 4B68061.D | 1  | 01/03/17 | HT | n/a       | n/a        | V4B2797          |

The QC reported here applies to the following samples:

Method: SW846 8260C

JC34340-6, JC34340-12, JC34340-13, JC34340-15, JC34340-16, JC34340-17

| CAS No.  | Compound      | JC34340-16<br>ug/l | Spike<br>Q | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD | Limits<br>Rec/RPD |
|----------|---------------|--------------------|------------|------------|---------|---------------|-------------|----------|-----|-------------------|
| 106-99-0 | 1,3-Butadiene | ND                 | 50         | 29.5       | 59      | 50            | 30.3        | 61       | 3   | 10-167/20         |

| CAS No.    | Surrogate Recoveries  | MS   | MSD  | JC34340-16 | Limits  |
|------------|-----------------------|------|------|------------|---------|
| 1868-53-7  | Dibromofluoromethane  | 106% | 105% | 105%       | 76-120% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 107% | 108% | 112%       | 73-122% |
| 2037-26-5  | Toluene-D8            | 100% | 99%  | 97%        | 84-119% |
| 460-00-4   | 4-Bromofluorobenzene  | 100% | 100% | 105%       | 78-117% |



\* = Outside of Control Limits.



## Matrix Spike/Matrix Spike Duplicate Summary

Page 1 of 3

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland &amp; Associates

Project: BSMC, Building 5 Area, PR

| Sample      | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|-------------|-----------|----|----------|----|-----------|------------|------------------|
| OP99540-MS  | P110153.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| OP99540-MSD | P110154.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| JC34340-16  | P110152.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| JC34340-16  | P110195.D | 50 | 01/03/17 | RL | 12/29/16  | OP99540    | EP4893           |

The QC reported here applies to the following samples:

Method: SW846 8270D

JC34340-15, JC34340-16

| CAS No.   | Compound                   | JC34340-16<br>ug/l | Spike<br>Q | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD | Limits<br>Rec/RPD |
|-----------|----------------------------|--------------------|------------|------------|---------|---------------|-------------|----------|-----|-------------------|
| 95-57-8   | 2-Chlorophenol             | ND                 | 54.1       | 31.3       | 58      | 51.3          | 30.9        | 60       | 1   | 49-110/20         |
| 59-50-7   | 4-Chloro-3-methyl phenol   | ND                 | 54.1       | 37.7       | 70      | 51.3          | 36.5        | 71       | 3   | 44-121/18         |
| 120-83-2  | 2,4-Dichlorophenol         | ND                 | 54.1       | 41.8       | 77      | 51.3          | 40.5        | 79       | 3   | 42-120/19         |
| 105-67-9  | 2,4-Dimethylphenol         | ND                 | 54.1       | 40.7       | 75      | 51.3          | 39.4        | 77       | 3   | 33-132/23         |
| 51-28-5   | 2,4-Dinitrophenol          | ND                 | 108        | 102        | 94      | 103           | 98.6        | 96       | 3   | 21-145/26         |
| 534-52-1  | 4,6-Dinitro-o-cresol       | ND                 | 54.1       | 49.0       | 91      | 51.3          | 45.7        | 89       | 7   | 25-134/27         |
| 95-48-7   | 2-Methylphenol             | ND                 | 54.1       | 30.0       | 56      | 51.3          | 30.5        | 59       | 2   | 47-112/18         |
|           | 3&4-Methylphenol           | ND                 | 54.1       | 29.0       | 54      | 51.3          | 28.3        | 55       | 2   | 44-113/19         |
| 88-75-5   | 2-Nitrophenol              | ND                 | 54.1       | 36.2       | 67      | 51.3          | 35.4        | 69       | 2   | 45-118/20         |
| 100-02-7  | 4-Nitrophenol              | ND                 | 54.1       | 34.0       | 63      | 51.3          | 33.6        | 66       | 1   | 23-144/28         |
| 87-86-5   | Pentachlorophenol          | ND                 | 54.1       | 54.7       | 101     | 51.3          | 50.7        | 99       | 8   | 25-151/25         |
| 108-95-2  | Phenol                     | ND                 | 54.1       | 18.2       | 34      | 51.3          | 17.9        | 35       | 2   | 22-100/22         |
| 58-90-2   | 2,3,4,6-Tetrachlorophenol  | ND                 | 54.1       | 47.0       | 87      | 51.3          | 45.7        | 89       | 3   | 44-122/21         |
| 95-95-4   | 2,4,5-Trichlorophenol      | ND                 | 54.1       | 44.3       | 82      | 51.3          | 43.1        | 84       | 3   | 51-124/20         |
| 88-06-2   | 2,4,6-Trichlorophenol      | ND                 | 54.1       | 45.4       | 84      | 51.3          | 43.7        | 85       | 4   | 53-120/21         |
| 83-32-9   | Acenaphthene               | ND                 | 54.1       | 40.0       | 74      | 51.3          | 37.8        | 74       | 6   | 52-120/23         |
| 208-96-8  | Acenaphthylene             | ND                 | 54.1       | 36.5       | 68      | 51.3          | 34.3        | 67       | 6   | 50-101/22         |
| 98-86-2   | Acetophenone               | ND                 | 54.1       | 37.2       | 69      | 51.3          | 35.8        | 70       | 4   | 31-141/23         |
| 120-12-7  | Anthracene                 | ND                 | 54.1       | 41.8       | 77      | 51.3          | 39.0        | 76       | 7   | 54-117/22         |
| 1912-24-9 | Atrazine                   | ND                 | 54.1       | 52.6       | 97      | 51.3          | 49.5        | 97       | 6   | 42-152/23         |
| 100-52-7  | Benzaldehyde               | ND                 | 54.1       | 30.0       | 56      | 51.3          | 29.4        | 57       | 2   | 10-164/30         |
| 56-55-3   | Benzo(a)anthracene         | ND                 | 54.1       | 42.8       | 79      | 51.3          | 40.2        | 78       | 6   | 40-123/24         |
| 50-32-8   | Benzo(a)pyrene             | ND                 | 54.1       | 41.4       | 77      | 51.3          | 39.6        | 77       | 4   | 41-127/25         |
| 205-99-2  | Benzo(b)fluoranthene       | ND                 | 54.1       | 43.5       | 80      | 51.3          | 41.7        | 81       | 4   | 39-127/27         |
| 191-24-2  | Benzo(g,h,i)perylene       | ND                 | 54.1       | 35.3       | 65      | 51.3          | 33.4        | 65       | 6   | 34-128/28         |
| 207-08-9  | Benzo(k)fluoranthene       | ND                 | 54.1       | 42.2       | 78      | 51.3          | 39.4        | 77       | 7   | 39-122/26         |
| 101-55-3  | 4-Bromophenyl phenyl ether | ND                 | 54.1       | 43.9       | 81      | 51.3          | 40.3        | 79       | 9   | 51-124/23         |
| 85-68-7   | Butyl benzyl phthalate     | ND                 | 54.1       | 35.2       | 65      | 51.3          | 33.2        | 65       | 6   | 21-146/28         |
| 92-52-4   | 1,1'-Biphenyl              | ND                 | 54.1       | 37.4       | 69      | 51.3          | 35.3        | 69       | 6   | 27-142/23         |
| 91-58-7   | 2-Chloronaphthalene        | ND                 | 54.1       | 37.9       | 70      | 51.3          | 35.7        | 70       | 6   | 51-109/23         |
| 106-47-8  | 4-Chloroaniline            | ND                 | 54.1       | 22.2       | 41      | 51.3          | 20.5        | 40       | 8   | 10-110/55         |
| 86-74-8   | Carbazole                  | ND                 | 54.1       | 39.4       | 73      | 51.3          | 37.3        | 73       | 5   | 52-116/22         |
| 105-60-2  | Caprolactam                | ND                 | 54.1       | 10.9       | 20      | 51.3          | 11.1        | 22       | 2   | 10-106/34         |
| 218-01-9  | Chrysene                   | ND                 | 54.1       | 39.8       | 74      | 51.3          | 37.7        | 74       | 5   | 41-128/24         |
| 111-91-1  | bis(2-Chloroethoxy)methane | ND                 | 54.1       | 33.1       | 61      | 51.3          | 33.1        | 61       | 7   | 46-120/24         |
| 111-44-4  | bis(2-Chloroethyl)ether    | ND                 | 54.1       | 32.6       | 60      | 51.3          | 33.7        | 60       | 3   | 42-123/28         |

\* = Outside of Control Limits.



# Matrix Spike/Matrix Spike Duplicate Summary

Page 2 of 3

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland & Associates

Project: BSMC, Building 5 Area, PR

| Sample      | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|-------------|-----------|----|----------|----|-----------|------------|------------------|
| OP99540-MS  | P110153.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| OP99540-MSD | P110154.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| JC34340-16  | P110152.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| JC34340-16  | P110195.D | 50 | 01/03/17 | RL | 12/29/16  | OP99540    | EP4893           |

The QC reported here applies to the following samples:

Method: SW846 8270D

JC34340-15, JC34340-16

| CAS No.   | Compound                    | JC34340-16<br>ug/l | Spike<br>Q | MS<br>ug/l | MS<br>%         | Spike<br>ug/l | MSD<br>ug/l | MSD<br>%        | RPD | Limits<br>Rec/RPD |
|-----------|-----------------------------|--------------------|------------|------------|-----------------|---------------|-------------|-----------------|-----|-------------------|
| 108-60-1  | bis(2-Chloroisopropyl)ether | ND                 | 54.1       | 31.4       | 58              | 51.3          | 31.2        | 61              | 1   | 41-117/25         |
| 7005-72-3 | 4-Chlorophenyl phenyl ether | ND                 | 54.1       | 45.6       | 84              | 51.3          | 43.0        | 84              | 6   | 48-121/21         |
| 121-14-2  | 2,4-Dinitrotoluene          | ND                 | 54.1       | 47.3       | 88              | 51.3          | 46.4        | 90              | 2   | 54-123/27         |
| 606-20-2  | 2,6-Dinitrotoluene          | ND                 | 54.1       | 44.9       | 83              | 51.3          | 42.7        | 83              | 5   | 55-125/26         |
| 91-94-1   | 3,3'-Dichlorobenzidine      | ND                 | 108        | 36.7       | 34              | 103           | 27.1        | 26              | 30  | 10-107/47         |
| 123-91-1  | 1,4-Dioxane                 | 1520 <sup>b</sup>  | 54.1       | 1580       | 0* <sup>a</sup> | 51.3          | 1800        | 0* <sup>a</sup> | 13  | 10-119/31         |
| 53-70-3   | Dibenzo(a,h)anthracene      | ND                 | 54.1       | 37.2       | 69              | 51.3          | 34.8        | 68              | 7   | 35-130/27         |
| 132-64-9  | Dibenzofuran                | ND                 | 54.1       | 39.7       | 73              | 51.3          | 38.5        | 75              | 3   | 53-112/22         |
| 84-74-2   | Di-n-butyl phthalate        | ND                 | 54.1       | 39.4       | 73              | 51.3          | 37.4        | 73              | 5   | 38-129/23         |
| 117-84-0  | Di-n-octyl phthalate        | ND                 | 54.1       | 36.8       | 68              | 51.3          | 34.7        | 68              | 6   | 35-145/26         |
| 84-66-2   | Diethyl phthalate           | ND                 | 54.1       | 40.9       | 76              | 51.3          | 39.5        | 77              | 3   | 16-136/30         |
| 131-11-3  | Dimethyl phthalate          | ND                 | 54.1       | 41.0       | 76              | 51.3          | 40.0        | 78              | 2   | 10-143/39         |
| 117-81-7  | bis(2-Ethylhexyl)phthalate  | ND                 | 54.1       | 34.0       | 63              | 51.3          | 32.1        | 63              | 6   | 34-141/28         |
| 206-44-0  | Fluoranthene                | ND                 | 54.1       | 45.8       | 85              | 51.3          | 42.8        | 83              | 7   | 47-123/24         |
| 86-73-7   | Fluorene                    | ND                 | 54.1       | 43.6       | 81              | 51.3          | 41.6        | 81              | 5   | 56-117/22         |
| 118-74-1  | Hexachlorobenzene           | ND                 | 54.1       | 44.1       | 82              | 51.3          | 40.6        | 79              | 8   | 46-125/24         |
| 87-68-3   | Hexachlorobutadiene         | ND                 | 54.1       | 37.5       | 69              | 51.3          | 36.9        | 72              | 2   | 26-121/24         |
| 77-47-4   | Hexachlorocyclopentadiene   | ND                 | 108        | 64.3       | 59              | 103           | 63.4        | 62              | 1   | 10-133/31         |
| 67-72-1   | Hexachloroethane            | ND                 | 54.1       | 33.8       | 63              | 51.3          | 35.0        | 68              | 3   | 35-111/26         |
| 193-39-5  | Indeno(1,2,3-cd)pyrene      | ND                 | 54.1       | 39.8       | 74              | 51.3          | 37.3        | 73              | 6   | 32-130/30         |
| 78-59-1   | Isophorone                  | ND                 | 54.1       | 34.9       | 65              | 51.3          | 33.3        | 65              | 5   | 47-126/23         |
| 90-12-0   | 1-Methylnaphthalene         | ND                 | 54.1       | 36.1       | 67              | 51.3          | 34.2        | 67              | 5   | 34-124/25         |
| 91-57-6   | 2-Methylnaphthalene         | ND                 | 54.1       | 37.4       | 69              | 51.3          | 35.1        | 68              | 6   | 34-123/24         |
| 88-74-4   | 2-Nitroaniline              | ND                 | 54.1       | 39.9       | 74              | 51.3          | 40.0        | 78              | 0   | 46-137/23         |
| 99-09-2   | 3-Nitroaniline              | ND                 | 54.1       | 24.4       | 45              | 51.3          | 26.5        | 52              | 8   | 10-110/50         |
| 100-01-6  | 4-Nitroaniline              | ND                 | 54.1       | 37.1       | 69              | 51.3          | 34.3        | 67              | 8   | 38-118/25         |
| 98-95-3   | Nitrobenzene                | ND                 | 54.1       | 34.9       | 65              | 51.3          | 33.0        | 64              | 6   | 35-130/25         |
| 621-64-7  | N-Nitroso-di-n-propylamine  | ND                 | 54.1       | 34.3       | 63              | 51.3          | 33.2        | 65              | 3   | 45-123/22         |
| 86-30-6   | N-Nitrosodiphenylamine      | ND                 | 54.1       | 39.7       | 73              | 51.3          | 36.7        | 72              | 8   | 46-123/24         |
| 85-01-8   | Phenanthrene                | ND                 | 54.1       | 41.8       | 77              | 51.3          | 39.4        | 77              | 6   | 48-121/23         |
| 129-00-0  | Pyrene                      | ND                 | 54.1       | 39.8       | 74              | 51.3          | 37.9        | 74              | 5   | 43-124/26         |
| 95-94-3   | 1,2,4,5-Tetrachlorobenzene  | ND                 | 54.1       | 48.5       | 90              | 51.3          | 45.2        | 88              | 7   | 25-142/24         |

\* = Outside of Control Limits.



## Matrix Spike/Matrix Spike Duplicate Summary

Page 3 of 3

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland & Associates

Project: BSMC, Building 5 Area, PR

| Sample      | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|-------------|-----------|----|----------|----|-----------|------------|------------------|
| OP99540-MS  | P110153.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| OP99540-MSD | P110154.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| JC34340-16  | P110152.D | 1  | 12/30/16 | JJ | 12/29/16  | OP99540    | EP4891           |
| JC34340-16  | P110195.D | 50 | 01/03/17 | RL | 12/29/16  | OP99540    | EP4893           |

The QC reported here applies to the following samples:

Method: SW846 8270D

JC34340-15, JC34340-16

| CAS No.   | Surrogate Recoveries | MS  | MSD | JC34340-16 | JC34340-16       | Limits  |
|-----------|----------------------|-----|-----|------------|------------------|---------|
| 367-12-4  | 2-Fluorophenol       | 44% | 47% | 41%        | 0%* <sup>c</sup> | 14-88%  |
| 4165-62-2 | Phenol-d5            | 34% | 34% | 30%        | 0%* <sup>c</sup> | 10-110% |
| 118-79-6  | 2,4,6-Tribromophenol | 86% | 86% | 96%        | 0%* <sup>c</sup> | 39-149% |
| 4165-60-0 | Nitrobenzene-d5      | 65% | 66% | 71%        | 0%* <sup>c</sup> | 32-128% |
| 321-60-8  | 2-Fluorobiphenyl     | 74% | 73% | 79%        | 0%* <sup>c</sup> | 35-119% |
| 1718-51-0 | Terphenyl-d14        | 67% | 63% | 87%        | 0%* <sup>c</sup> | 10-126% |

(a) Outside control limits due to high level in sample relative to spike amount.

(b) Result is from Run #2.

(c) Outside control limits due to dilution.



\* = Outside of Control Limits.

SGS

374 of 2441  
ACCUTEST  
JC34340

8.3.4  
8

## Matrix Spike/Matrix Spike Duplicate Summary

Page 1 of 1

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland &amp; Associates

Project: BSMC, Building 5 Area, PR

| Sample       | File ID   | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------------|-----------|----|----------|----|-----------|------------|------------------|
| OP99540A-MS  | 3M67757.D | 1  | 12/31/16 | SG | 12/29/16  | OP99540A   | E3M3155          |
| OP99540A-MSD | 3M67758.D | 1  | 12/31/16 | SG | 12/29/16  | OP99540A   | E3M3155          |
| JC34340-16   | 3M67751.D | 1  | 12/30/16 | SG | 12/29/16  | OP99540A   | E3M3155          |

The QC reported here applies to the following samples:

Method: SW846 8270D BY SIM

JC34340-15, JC34340-16

| CAS No.  | Compound               | JC34340-16<br>ug/l | Spike<br>Q | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD   | Limits<br>Rec/RPD |
|----------|------------------------|--------------------|------------|------------|---------|---------------|-------------|----------|-------|-------------------|
| 56-55-3  | Benzo(a)anthracene     | ND                 | 1.03       | 0.773      | 75      | 1.05          | 0.591       | 56       | 27    | 25-135/33         |
| 50-32-8  | Benzo(a)pyrene         | ND                 | 1.03       | 0.675      | 66      | 1.05          | 0.420       | 40       | 47* a | 10-116/38         |
| 205-99-2 | Benzo(b)fluoranthene   | ND                 | 1.03       | 0.756      | 74      | 1.05          | 0.549       | 52       | 32    | 10-131/40         |
| 207-08-9 | Benzo(k)fluoranthene   | ND                 | 1.03       | 0.712      | 69      | 1.05          | 0.481       | 46       | 39    | 10-120/45         |
| 218-01-9 | Chrysene               | ND                 | 1.03       | 0.740      | 72      | 1.05          | 0.576       | 55       | 25    | 31-125/33         |
| 53-70-3  | Dibenzo(a,h)anthracene | ND                 | 1.03       | 0.557      | 54      | 1.05          | 0.352       | 33       | 45    | 10-116/48         |
| 193-39-5 | Indeno(1,2,3-cd)pyrene | ND                 | 1.03       | 0.515      | 50      | 1.05          | 0.314       | 30       | 48    | 10-116/48         |
| 91-20-3  | Naphthalene            | 0.236              | 1.03       | 0.875      | 62      | 1.05          | 0.730       | 47       | 18    | 23-140/36         |
| 123-91-1 | 1,4-Dioxane            | 1670               | EB 1.03    | 1240       | 0* b    | 1.05          | 1450        | 0* b     | 16    | 20-160/30         |

| CAS No.   | Surrogate Recoveries | MS  | MSD | JC34340-16 | Limits  |
|-----------|----------------------|-----|-----|------------|---------|
| 4165-60-0 | Nitrobenzene-d5      | 79% | 66% | 100%       | 24-125% |
| 321-60-8  | 2-Fluorobiphenyl     | 68% | 59% | 86%        | 19-127% |
| 1718-51-0 | Terphenyl-d14        | 66% | 46% | 81%        | 10-119% |

(a) Analytical precision exceeds in-house control limits.

(b) Outside control limits due to high level in sample relative to spike amount.



\* = Outside of Control Limits.

**Matrix Spike/Matrix Spike Duplicate Summary**

Page 1 of 1

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland &amp; Associates

Project: BSMC, Building 5 Area, PR

| Sample        | File ID    | DF | Analyzed | By  | Prep Date | Prep Batch | Analytical Batch |
|---------------|------------|----|----------|-----|-----------|------------|------------------|
| JC34340-16MS  | GH107995.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| JC34340-16MSD | GH107996.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |
| JC34340-16    | GH107994.D | 1  | 12/30/16 | XPL | n/a       | n/a        | GGH5600          |

The QC reported here applies to the following samples:

Method: SW846-8015C (DAI)

JC34340-10, JC34340-11, JC34340-12, JC34340-15, JC34340-16

| CAS No. | Compound          | JC34340-16<br>ug/l | Spike<br>Q | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD | Limits<br>Rec/RPD |
|---------|-------------------|--------------------|------------|------------|---------|---------------|-------------|----------|-----|-------------------|
| 64-17-5 | Ethanol           | ND                 | 5000       | 4400       | 88      | 5000          | 5180        | 104      | 16  | 58-145/27         |
| 78-83-1 | Isobutyl Alcohol  | ND                 | 5000       | 4800       | 96      | 5000          | 5110        | 102      | 6   | 69-131/25         |
| 67-63-0 | Isopropyl Alcohol | ND                 | 5000       | 4430       | 89      | 5000          | 4700        | 94       | 6   | 70-133/28         |
| 71-23-8 | n-Propyl Alcohol  | ND                 | 5000       | 4690       | 94      | 5000          | 5200        | 104      | 10  | 66-137/29         |
| 71-36-3 | n-Butyl Alcohol   | ND                 | 5000       | 4230       | 85      | 5000          | 4530        | 91       | 7   | 63-131/25         |
| 78-92-2 | sec-Butyl Alcohol | ND                 | 5000       | 5370       | 107     | 5000          | 5700        | 114      | 6   | 64-136/25         |
| 67-56-1 | Methanol          | ND                 | 5000       | 4110       | 82      | 5000          | 4670        | 93       | 13  | 48-148/34         |

| CAS No.  | Surrogate Recoveries | MS  | MSD | JC34340-16 | Limits  |
|----------|----------------------|-----|-----|------------|---------|
| 111-27-3 | Hexanol              | 88% | 87% | 89%        | 56-145% |
| 111-27-3 | Hexanol              | 85% | 88% | 85%        | 56-145% |



\* = Outside of Control Limits.

## Matrix Spike/Matrix Spike Duplicate Summary

Page 1 of 1

Job Number: JC34340

Account: AMANYWP Anderson, Mulholland &amp; Associates

Project: BSMC, Building 5 Area, PR

| Sample      | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|-------------|----------|----|----------|----|-----------|------------|------------------|
| OP99539-MS  | 8G1632.D | 1  | 01/03/17 | JR | 12/29/16  | OP99539    | G8G54            |
| OP99539-MSD | 8G1633.D | 1  | 01/03/17 | JR | 12/29/16  | OP99539    | G8G54            |
| JC34340-16  | 8G1631.D | 1  | 01/03/17 | JR | 12/29/16  | OP99539    | G8G54            |

The QC reported here applies to the following samples:

Method: SW846 8081B

JC34340-15, JC34340-16, JC34340-18, JC34340-19, JC34340-20, JC34340-21

| CAS No.    | Compound            | JC34340-16<br>ug/l | Spike<br>Q | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD | Limits<br>Rec/RPD |
|------------|---------------------|--------------------|------------|------------|---------|---------------|-------------|----------|-----|-------------------|
| 309-00-2   | Aldrin              | ND                 | 0.25       | 0.26       | 104     | 0.25          | 0.26        | 104      | 0   | 37-159/40         |
| 319-84-6   | alpha-BHC           | ND                 | 0.25       | 0.28       | 112     | 0.25          | 0.28        | 112      | 0   | 37-164/37         |
| 319-85-7   | beta-BHC            | ND                 | 0.25       | 0.27       | 108     | 0.25          | 0.27        | 108      | 0   | 46-151/36         |
| 319-86-8   | delta-BHC           | ND                 | 0.25       | 0.30       | 120     | 0.25          | 0.31        | 124      | 3   | 32-168/36         |
| 58-89-9    | gamma-BHC (Lindane) | ND                 | 0.25       | 0.29       | 116     | 0.25          | 0.29        | 116      | 0   | 44-160/37         |
| 5103-71-9  | alpha-Chlordane     | ND                 | 0.25       | 0.39       | 156     | 0.25          | 0.38        | 152      | 3   | 38-160/35         |
| 5103-74-2  | gamma-Chlordane     | ND                 | 0.25       | 0.29       | 116     | 0.25          | 0.29        | 116      | 0   | 39-157/37         |
| 60-57-1    | Dieldrin            | ND                 | 0.25       | 0.30       | 120     | 0.25          | 0.30        | 120      | 0   | 42-161/36         |
| 72-54-8    | 4,4'-DDD            | ND                 | 0.25       | 0.30       | 120     | 0.25          | 0.32        | 128      | 6   | 40-161/36         |
| 72-55-9    | 4,4'-DDE            | ND                 | 0.25       | 0.25       | 100     | 0.25          | 0.26        | 104      | 4   | 34-158/36         |
| 50-29-3    | 4,4'-DDT            | ND                 | 0.25       | 0.16       | 64      | 0.25          | 0.16        | 64       | 0   | 41-173/33         |
| 72-20-8    | Endrin              | ND                 | 0.25       | 0.29       | 116     | 0.25          | 0.29        | 116      | 0   | 44-166/35         |
| 1031-07-8  | Endosulfan sulfate  | ND                 | 0.25       | 0.29       | 116     | 0.25          | 0.30        | 120      | 3   | 46-161/36         |
| 7421-93-4  | Endrin aldehyde     | ND                 | 0.25       | 0.30       | 120     | 0.25          | 0.27        | 108      | 11  | 34-149/36         |
| 53494-70-5 | Endrin ketone       | ND                 | 0.25       | 0.28       | 112     | 0.25          | 0.28        | 112      | 0   | 44-157/36         |
| 959-98-8   | Endosulfan-I        | ND                 | 0.25       | 0.29       | 116     | 0.25          | 0.30        | 120      | 3   | 43-154/35         |
| 33213-65-9 | Endosulfan-II       | ND                 | 0.25       | 0.30       | 120     | 0.25          | 0.31        | 124      | 3   | 40-162/35         |
| 76-44-8    | Heptachlor          | ND                 | 0.25       | 0.27       | 108     | 0.25          | 0.27        | 108      | 0   | 33-153/37         |
| 1024-57-3  | Heptachlor epoxide  | ND                 | 0.25       | 0.29       | 116     | 0.25          | 0.29        | 116      | 0   | 45-154/37         |
| 72-43-5    | Methoxychlor        | ND                 | 0.25       | 0.26       | 104     | 0.25          | 0.25        | 100      | 4   | 48-169/32         |
| 8001-35-2  | Toxaphene           | ND                 |            | ND         |         |               | ND          |          | nc  | 50-150/30         |

| CAS No.   | Surrogate Recoveries | MS  | MSD | JC34340-16 | Limits  |
|-----------|----------------------|-----|-----|------------|---------|
| 877-09-8  | Tetrachloro-m-xylene | 97% | 94% | 91%        | 26-132% |
| 877-09-8  | Tetrachloro-m-xylene | 96% | 94% | 91%        | 26-132% |
| 2051-24-3 | Decachlorobiphenyl   | 63% | 75% | 80%        | 10-118% |
| 2051-24-3 | Decachlorobiphenyl   | 49% | 63% | 70%        | 10-118% |



\* = Outside of Control Limits.

CW  
 FB  
 EB  
 WTB

## CHAIN OF CUSTODY

SGS Accutest • Dayton  
2235 Route 130, Dayton, NJ 08810  
TEL: 732-329-0200 FAX: 732-329-3490 3480  
[www.acctest.com](http://www.acctest.com)

7 720 2806 4240

PAGE 1 OF 2[illegible]

## 5.2

### JC34340: Chain of Custody

Page 1 of 4



## CHAIN OF CUSTODY

PAGE 2 OF 2

SGS Acculast - Dayton  
3235 Route 130, Dayton, NJ 08810  
TEL 732-324-0200 FAX 732-324-1474/3480  
www.acculast.com

|  |                                |  |  |
|--|--------------------------------|--|--|
| PED 23.1 (2-10-90)<br><b>7780 28063210</b><br>SC&S Account Quota #   |                                | Verbu Contrace #<br><b>JC34340</b><br>SC&S Account Job # |  |
| Requested Analysis (see TEST CODE sheet)   |                                | Matrix Codes   |  |
| D2015LMA<br>P8081PE8TCTCL<br>AB270SL<br>B8276NSIM+DIOX<br>BMS+MNAF, BMS+2MNAF<br>BSM+BAANTH, BSM+BAFTYN<br>BSM+BEFLJAN, BSM+BEFLJAN<br>BSM+CHRYE, BSM+DBANTH, BSM+1123PVR<br>BSM+MNAF<br>VZ26013BUTAON | WET CHEMISTRY (SEE NOTE BELOW) |  | DW: Drinking Water<br>GW: Ground Water<br>HW: Waste<br>SW: Surface Water<br>SO: Soil<br>SL: Sludge<br>SED: Sediment<br>OL: Oil<br>LIQ: Other Liquids<br>AIR: Air<br>SOL: Other Solids<br>WP: Wipe<br>FB: Food Blank<br>EB: Equipment Blank<br>RB: Rose Blank<br>TR: Trip Blank |
| LAB USE ONLY   |                                |  |  |
| Comments / Special Instructions  |                                |  |  |
| WET CHEMISTRY INCLUDES ALK, XFE3, MN, VR5K175CH4, XNO3O, S04, AND S  |                                |  |  |
| Sample Inventory is verified upon receipt in the Laboratory  |                                |  |  |
| Submitting courier delivery  |                                | Received By: <i>[Signature]</i>                          |  |
| Date Time: <i>11/13/85</i>   |                                | Received By: <i>[Signature]</i>                          |  |
| Date Time:   |                                | Received By:   |  |
| Preserved where applicable   |                                | On Ice   |  |
| Coolant Temp.  |                                | Coolant Temp.  |  |

## 5.2

**JC34340: Chain of Custody**  
**Page 2 of 4**



## EXECUTIVE NARRATIVE

SDG No: **JC34340** Laboratory: **Accutest, New Jersey**  
Analysis: **SW846-8260C** Number of Samples: **19**  
Location: **BMSMC, Building 5 Area**  
**Humacao, PR**

**SUMMARY:** Nineteen (19) samples were analyzed for selected VOAs of the TCL list (1,3-butadiene) by method SW846-8260C. Samples were validated following USEPA Hazardous Waste Support Section SOP No. HW-33A Revision 0 SOM02.2. Low/Medium Volatile Data Validation. July, 2015. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

**Critical issues:** **None**  
**Major:** **None**  
**Minor:** **None**

**Critical findings:** **None**  
**Major findings:** **None**  
**Minor findings:** **None**

**COMMENTS:** Results are valid and can be used for decision making purposes.

**Reviewers Name:** **Rafael Infante**  
**Chemist License 1888**

**Signature:**

A handwritten signature in blue ink, reading "Rafael Infante", is written over a horizontal line.

**Date:** **January 27, 2017**

## SAMPLE ORGANIC DATA SAMPLE SUMMARY

Sample ID: JC34340-1

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-2

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-3

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: AQ - Field Blank Water

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-4

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: AQ - Equipment Blank

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-5

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: AQ - Trip Blank Water

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-6

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: AQ - Trip Blank Water

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-7

Sample location: BMSMC Building 5 Area

Sampling date: 21-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-8

Sample location: BMSMC Building 5 Area

Sampling date: 21-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-9

Sample location: BMSMC Building 5 Area

Sampling date: 21-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-10  
Sample location: BMSMC Building 5 Area  
Sampling date: 21-Dec-16  
Matrix: Groundwater  
METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-11  
Sample location: BMSMC Building 5 Area  
Sampling date: 21-Dec-16  
Matrix: Groundwater  
METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-12  
Sample location: BMSMC Building 5 Area  
Sampling date: 21-Dec-16  
Matrix: AQ - Field Blank Water  
METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-13  
Sample location: BMSMC Building 5 Area  
Sampling date: 21-Dec-16  
Matrix: AQ - Trip Blank Water  
METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-14  
Sample location: BMSMC Building 5 Area  
Sampling date: 21-Dec-16  
Matrix: AQ - Trip Blank Water  
METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-15

Sample location: BMSMC Building 5 Area

Sampling date: 22-Dec-16

Matrix: AQ - Equipment Blank

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-16

Sample location: BMSMC Building 5 Area

Sampling date: 22-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-17

Sample location: BMSMC Building 5 Area

Sampling date: 22-Dec-16

Matrix: AQ - Trip Blank Water

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 5.0    | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-16MS

Sample location: BMSMC Building 5 Area

Sampling date: 22-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 29.5   | ug/l  | 1               | -        | -          | Yes        |

Sample ID: JC34340-16MSD

Sample location: BMSMC Building 5 Area

Sampling date: 22-Dec-16

Matrix: Groundwater

METHOD: 8260C

| Analyte Name  | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------|--------|-------|-----------------|----------|------------|------------|
| 1,3-butadiene | 30.3   | ug/l  | 1               | -        | -          | Yes        |

## DATA REVIEW WORKSHEETS

Project Number: JC34340  
Date: December 20-22, 2016  
Shipping date: December 16, 2016  
EPA Region: 2

### REVIEW OF VOLATILE ORGANIC PACKAGE Low/Medium Volatile Data Validation

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: USEPA Hazardous Waste Support Section SOP No. HW-33A Revision 0 SOM02.2. Low/Medium Volatile Data Validation. July, 2015. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Accutest data package received has been reviewed and the quality control and performance data summarized. The data review for VOCs included:

Lab. Project/SDG No.: JC34340 Sample matrix: Groundwater  
No. of Samples: 19  
Trip blank No.: JC34340-5; JC34340-6; JC34340-13; JC34340-14; JC34340-17  
Field blank No.: JC34340-3; JC34340-12  
Equipment blank No.: JC34340-4; JC34340-15  
Field duplicate No.: JC34340-7/JC34340-8

|   |   |
|---|---|
| <input checked="" type="checkbox"/> Data Completeness                   | <input checked="" type="checkbox"/> Laboratory Control Spikes |
| <input checked="" type="checkbox"/> Holding Times                       | <input checked="" type="checkbox"/> Field Duplicates          |
| <input checked="" type="checkbox"/> GC/MS Tuning                        | <input checked="" type="checkbox"/> Calibrations              |
| <input checked="" type="checkbox"/> Internal Standard Performance       | <input checked="" type="checkbox"/> Compound Identifications  |
| <input checked="" type="checkbox"/> Blanks                              | <input checked="" type="checkbox"/> Compound Quantitation     |
| <input checked="" type="checkbox"/> Surrogate Recoveries                | <input checked="" type="checkbox"/> Quantitation Limits       |
| <input checked="" type="checkbox"/> Matrix Spike/Matrix Spike Duplicate |   |

Overall Comments: Selected\_VOA\_(1,3-Butadiene)\_from\_the\_TCL\_list\_(SW846\_8260C)

#### Definition of Qualifiers:

J- Estimated results  
U- Compound not detected  
R- Rejected data  
UJ- Estimated nondetect

Reviewer: Rafael Infante  
Date: January 27, 2017



## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

| SAMPLE ID  | DATE SAMPLED | DATE ANALYZED | pH | ACTION |
|--|--------------|---------------|----|--------|
|  |              |               |    |        |
|  |              |               |    |        |
|  |              |               |    |        |
| All samples analyzed within method recommended holding time. Samples properly preserved. |              |               |    |        |
|  |              |               |    |        |
|  |              |               |    |        |
|  |              |               |    |        |

### Criteria

Aqueous samples – 14 days from sample collection for preserved samples ( $\text{pH} \leq 2$ ,  $4 \pm 2^\circ\text{C}$ ), no air bubbles.

Aqueous samples – 7 days from sample collection for unpreserved samples,  $4^\circ\text{C}$ , no air bubbles.

Soil samples- 14 days from sample collection.

Cooler temperature (Criteria:  $4 \pm 2^\circ\text{C}$ ):  $5.4^\circ\text{C}$  - OK

### Actions

#### Aqueous samples

- If there is no evidence that the samples were properly preserved ( $\text{pH} < 2$ ,  $T = 4^\circ\text{C} \pm 2^\circ\text{C}$ ), but the samples were analyzed within the technical holding time [7 days from sample collection], no qualification of the data is necessary.
- If there is no evidence that the samples were properly preserved, and the samples were analyzed outside of the technical holding time [7 days from sample collection], qualify detects for all volatile compounds as estimated (J) and non-detects as unusable (R).
- If the samples were properly preserved, and the samples were analyzed within the technical holding time [14 days from sample collection], no qualification of the data is necessary.
- If the samples were properly preserved, but were analyzed outside of the technical holding time [14 days from sample collection], qualify detects as estimated (J) and non-detects as unusable (R).
- If air bubbles were present in the sample vial used for analysis, qualify detected compounds as estimated (J-) and non-detected compounds as estimated (UJ).

#### Non-aqueous samples

- If there is no evidence that the samples were properly preserved ( $T < -7^\circ\text{C}$  or  $T = 4^\circ\text{C} \pm 2^\circ\text{C}$  and preserved with  $\text{NaHSO}_4$ ), but the samples were analyzed within the technical holding time [14 days



## DATA REVIEW WORKSHEETS

from sample collection], qualify detects for all volatile compounds as estimated (J) and non-detects as (UJ) or unusable (R) using professional judgment.

b. If the samples were properly preserved, and the samples were analyzed within the technical holding time [14 days from sample collection], no qualification of the data is necessary.

c. If there is no evidence that the samples were properly preserved, and the samples were analyzed outside of the technical holding time [14 days from sample collection], qualify detects for all volatile compounds as estimated (J) and non-detects as unusable (R).

d. If the samples were properly preserved, but were analyzed outside of the technical holding time [14 days from sample collection], qualify detects as estimated (J) and non-detects as unusable (R).

### **Qualify TCLP/SPLP samples**

a. If the TCLP/SPLP ZHE procedure is performed within the extraction technical holding time of 14 days, detects and non-detects should not be qualified.

b. If the TCLP/SPLP ZHE procedure is performed outside the extraction technical holding time of 14 days, qualify detects as estimated (J) and non-detects as unusable (R).

c. If TCLP/SPLP aqueous samples and TCLP/SPLP leachate samples are analyzed within the technical holding time of 7 days, detects and non-detects should not be qualified.

d. If TCLP/SPLP aqueous samples and TCLP/SPLP leachate samples are analyzed outside of the technical holding time of 7 days, qualify detects as estimated (J) and non-detects as unusable (R).

DATA REVIEW WORKSHEETS

Table 1. Holding Time Actions for Low/Medium Volatile Analyses - Summary

| Matrix  | Preserved   | Criteria  | Action                        |                                   |
|---|---|-----------|-------------------------------|-----------------------------------|
|   |   |           | Detected Associated Compounds | Non-Detected Associated Compounds |
|   |   |           |                               |                                   |
| Aqueous   | No  | ≤ 7 days  | No qualification              |                                   |
|   | No  | > 7 days  | J                             | R                                 |
|   | Yes   | ≤ 14 days | No qualification              |                                   |
|   | Yes   | > 14 days | J                             | R                                 |
| Non-Aqueous   | No  | ≤ 14 days | J                             | Professional judgment, UJ or R    |
|   | Yes   | ≤ 14 days | No qualification              |                                   |
|   | Yes/No  | > 14 days | J                             | R                                 |
| TCLP/SPLP   | Yes   | ≤ 14 days | No qualification              |                                   |
| TCLP/SPLP   | No  | > 14 days | J                             | R                                 |
| TCLP/SPLP   | ZHE performed within the 14-day technical holding time  |           | No qualification              |                                   |
| TCLP/SPLP   | ZHE performed outside the 14-day technical holding time |           | J                             | R                                 |
| TCLP/SPLP aqueous & TCLP/SPLP leachate                              | Analyzed within 7 days                                  |           | No qualification              |                                   |
| TCLP/SPLP aqueous & TCLP/SPLP leachate                              | Analyzed outside 7 days                                 |           | J                             | R                                 |
| Sample temperature outside 4°C ± 2°C upon receipt at the laboratory |   |           | Use professional judgment     |                                   |
| Holding times grossly exceeded                                      |   |           | J                             | R                                 |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met see below       

### GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

  X   The BFB performance results were reviewed and found to be within the specified criteria.

  X   BFB tuning was performed for every 12 hours of sample analysis.

**NOTES:** All mass spectrometer instrument conditions must be identical to those used during the sample analysis. Background subtraction actions resulting in spectral distortions for the sole purpose of meeting the method specifications are contrary to the Quality Assurance (QA) objectives, and are therefore unacceptable.

**NOTES:** No data should be qualified based on BFB failure. Instances of this should be noted in the narrative.

All ion abundance ratios must be normalized to m/z 95, the nominal base peak, even though the ion abundance of m/z 174 may be up to 120% that of m/z 95.

#### Actions:

If samples are analyzed without a preceding valid instrument performance check, qualify all data in those samples as unusable (R).

If ion abundance criteria are not met, professional judgment may be applied to determine to what extent the data may be utilized. When applying professional judgment to this topic, the most important factors to consider are the empirical results that are relatively insensitive to location on the chromatographic profile and the type of instrumentation. Therefore, the critical ion abundance criteria for BFB are the m/z 95/96, 174/572, 174/176, and 176/177 ratios. The relative abundances of m/z 50 and 75 are of lower importance. This issue is more critical for Tentatively Identified Compounds (TICs) than for target analytes.

**Note:** State in the Data Review Narrative, decisions to use analytical data associated with BFB instrument performance checks not meeting contract requirements.

**Note:** Verify that that instrument instrument performance check criteria were achieved using techniques described in Low/Medium Volatiles Organic Analysis, Section II.D.5 of the SOM02.2 NFG, obtain additional information on the instrument performance checks. Make sure that background subtraction was performed from the BFB peak and not from background subtracting from the solvent front or from another region of the chromatogram.

## DATA REVIEW WORKSHEETS

Use professional judgment to determine whether associated data should be qualified based on the spectrum of the mass calibration compound.

List the samples affected:

---

---

---

---

---

---

If mass calibration is in error, all associated data are rejected.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below \_\_\_\_\_

### CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 12/08/16  
 Dates of continuing (initial) calibration: 12/08/16  
 Dates of continuing calibration: 12/31/16; 01/03/17; 01/04/17  
 Dates of ending calibration: -  
 Instrument ID numbers: GCMS4B  
 Matrix/Level: Aqueous/low

| DATE | LAB ID# | FILE | CRITERIA OUT<br>RFs, %RSD, %D, r | COMPOUND | SAMPLES<br>AFFECTED |
|------|---------|------|----------------------------------|----------|---------------------|
|      |         |      |                                  |          |                     |
|      |         |      |                                  |          |                     |
|      |         |      |                                  |          |                     |
|      |         |      |                                  |          |                     |
|      |         |      |                                  |          |                     |
|      |         |      |                                  |          |                     |

**Note:** Initial calibration, initial calibration verification, and continuing calibration verification within the method and validation guidance document required performance criteria. Closing calibration check verification not included in data package. No action taken, professional judgment.

#### Criteria

The analyte calibration criteria in the following Table must be obtained. Analytes not meeting the criteria are qualified.

A separate worksheet should be filled for each initial curve

DATA REVIEW WORKSHEETS

Initial Calibration - Table 2. RRF, %RSD, and %D Acceptance Criteria for Initial Calibration and CCV for Low/Medium Volatile Analysis

| Analyte                               | Minimum RRF | Maximum %RSD | Opening Maximum %D <sup>1</sup> | Closing Maximum %D |
|---------------------------------------|-------------|--------------|---------------------------------|--------------------|
| Dichlorodifluoromethane               | 0.010       | 25.0         | ±40.0                           | ±50.0              |
| Chloromethane                         | 0.010       | 20.0         | ±30.0                           | ±50.0              |
| Vinyl chloride                        | 0.010       | 20.0         | ±25.0                           | ±50.0              |
| Bromomethane                          | 0.010       | 40.0         | ±30.0                           | ±50.0              |
| Chloroethane                          | 0.010       | 40.0         | ±25.0                           | ±50.0              |
| Trichlorofluoromethane                | 0.010       | 40.0         | ±30.0                           | ±50.0              |
| 1,1-Dichloroethene                    | 0.060       | 20.0         | ±20.0                           | ±25.0              |
| 1,1,2-Trichloro-1,2,2-trifluoroethane | 0.050       | 25.0         | ±25.0                           | ±50.0              |
| Acetone                               | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Carbon disulfide                      | 0.100       | 20.0         | ±25.0                           | ±25.0              |
| Methyl acetate                        | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Methylene chloride                    | 0.010       | 40.0         | ±30.0                           | ±50.0              |
| trans-1,2-Dichloroethene              | 0.100       | 20.0         | ±20.0                           | ±25.0              |
| Methyl tert-butyl ether               | 0.100       | 40.0         | ±25.0                           | ±50.0              |
| 1,1-Dichloroethane                    | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| cis-1,2-Dichloroethene                | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 2-Butanone                            | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Bromochloromethane                    | 0.100       | 20.0         | ±20.0                           | ±25.0              |
| Chloroform                            | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| 1,1,1-Trichloroethane                 | 0.050       | 20.0         | ±25.0                           | ±25.0              |
| Cyclohexane                           | 0.010       | 40.0         | ±25.0                           | ±50.0              |
| Carbon tetrachloride                  | 0.100       | 20.0         | ±25.0                           | ±25.0              |
| Benzene                               | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 1,2-Dichloroethane                    | 0.070       | 20.0         | ±20.0                           | ±25.0              |
| Trichloroethene                       | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Methylcyclohexane                     | 0.050       | 40.0         | ±25.0                           | ±50.0              |
| 1,2-Dichloropropane                   | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Bromodichloromethane                  | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| cis-1,3-Dichloropropene               | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| 4-Methyl-2-pentanone                  | 0.030       | 25.0         | ±30.0                           | ±50.0              |
| Toluene                               | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| trans-1,3-Dichloropropene             | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 1,1,2-Trichloroethane                 | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Tetrachloroethene                     | 0.100       | 20.0         | ±20.0                           | ±25.0              |
| 2-Hexanone                            | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Dibromochloromethane                  | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 1,2-Dibromoethane                     | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Chlorobenzene                         | 0.400       | 20.0         | ±20.0                           | ±25.0              |
| Ethylbenzene                          | 0.400       | 20.0         | ±20.0                           | ±25.0              |

## DATA REVIEW WORKSHEETS

| Analyte                                  | Minimum RRF | Maximum %RSD | Opening Maximum %D <sup>1</sup> | Closing Maximum |
|--|-------------|--------------|---------------------------------|-----------------|
| m,p-Xylene                               | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| o-Xylene                                 | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| Styrene                                  | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| Bromoform                                | 0.100       | 20.0         | ±25.0                           | ±50.0           |
| Isopropylbenzene                         | 0.400       | 20.0         | ±25.0                           | ±25.0           |
| 1,1,2,2-Tetrachloroethane                | 0.200       | 20.0         | ±25.0                           | ±25.0           |
| 1,3-Dichlorobenzene                      | 0.500       | 20.0         | ±20.0                           | ±25.0           |
| 1,4-Dichlorobenzene                      | 0.600       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dichlorobenzene                      | 0.600       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dibromo-3-chloropropane              | 0.010       | 25.0         | ±30.0                           | ±50.0           |
| 1,2,4-Trichlorobenzene                   | 0.400       | 20.0         | ±30.0                           | ±50.0           |
| 1,2,3-Trichlorobenzene                   | 0.400       | 25.0         | ±30.0                           | ±50.0           |
| <b>Deuterated Monitoring Compound</b>    |             |              |                                 |                 |
| Vinyl chloride-d <sub>3</sub>            | 0.010       | 20.0         | ±30.0                           | ±50.0           |
| Chloroethane-d <sub>3</sub>              | 0.010       | 40.0         | ±30.0                           | ±50.0           |
| 1,1-Dichloroethene-d <sub>2</sub>        | 0.050       | 20.0         | ±25.0                           | ±25.0           |
| 2-Butanone-d <sub>5</sub>                | 0.010       | 40.0         | ±40.0                           | ±50.0           |
| Chloroform-d                             | 0.300       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dichloroethane-d <sub>4</sub>        | 0.060       | 20.0         | ±25.0                           | ±25.0           |
| Benzene-d <sub>6</sub>                   | 0.300       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dichloropropane-d <sub>6</sub>       | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| Toluene-d <sub>8</sub>                   | 0.300       | 20.0         | ±20.0                           | ±25.0           |
| trans-1,3-Dichloropropene-d <sub>4</sub> | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| 2-Hexanone-d <sub>5</sub>                | 0.010       | 40.0         | ±40.0                           | ±50.0           |
| 1,1,2,2-Tetrachloroethane-d <sub>2</sub> | 0.200       | 20.0         | ±25.0                           | ±25.0           |
| 1,2-Dichlorobenzene-d <sub>4</sub>       | 0.400       | 20.0         | ±20.0                           | ±25.0           |

- <sup>1</sup> If a closing CCV is acting as an opening CCV, all target analytes and DMCs must meet the requirements for an opening CCV.

### Actions:

1. If any volatile target compound has an RRF value less than the minimum in the table, use professional judgment for detects, based on mass spectral identification, to qualify the data as estimated (J+ or R).
  - a. If any volatile target compound has an RRF value less than the minimum criterion, qualify non-detected compounds as unusable (R).
  - b. If any of the volatile target compounds listed in the Table has %RSD greater than the criteria, qualify detects as estimated (J), and non-detected compounds using professional judgment.
  - c. If the volatile target compounds meet the acceptance criteria for RRF and the %RSD, no qualification of the data is necessary.

## DATA REVIEW WORKSHEETS

- d. No qualification of the data is necessary on the DMC RRF and %RSD data alone. Use professional judgment and follow the guidelines in Action 2 to evaluate the DMC RRF and %RSD data in conjunction with the DMC recoveries to determine the need for qualification of data.
2. At the reviewer's discretion, and based on the project-specific Data Quality Objectives (DQOs), a more in-depth review may be considered using the following guidelines:
    - a. If any volatile target compound has a %RSD greater than the maximum criterion in the Table, and if eliminating either the high or the low-point of the curve does not restore the %RSD to less than or equal to the required maximum:
      - i. Qualify detects for that compound(s) as estimated (J).
      - ii. Qualify non-detected volatile target compounds using professional judgment.
    - b. If the high-point of the curve is outside of the linearity criteria (e.g., due to saturation):
      - i. Qualify detects outside of the linear portion of the curve as estimated (J).
      - ii. No qualifiers are required for detects in the linear portion of the curve.
      - iii. No qualifiers are required for volatile target compounds that were not detected.
    - c. If the low-point of the curve is outside of the linearity criteria:
      - i. Qualify low-level detects in the area of non-linearity as estimated (J).
      - ii. No qualifiers are required for detects in the linear portion of the curve.
      - iii. For non-detected volatile compounds, use the lowest point of the linear portion of the curve to determine the new quantitation limit.

**Note:** If the laboratory has failed to provide adequate calibration information, inform the Region's designated representative to contact the laboratory and request the necessary information. If the information is not available, the reviewer must use professional judgment to assess the data.

State in the Data Review Narrative, if possible, the potential effects on the data due to calibration criteria exceedance.

Note, for the Laboratory COR action, if calibration criteria are grossly exceeded.

Table. Initial Calibration Actions for Low/Medium Volatile Analysis – Summary

| Criteria  | Action                               |                                |
|---|--------------------------------------|--------------------------------|
|   | Detect                               | Non-detect                     |
| Initial Calibration not performed at specified frequency and sequence | Use professional judgment<br>R       | Use professional judgment<br>R |
| Initial Calibration not performed at the specified concentrations     | J                                    | UJ                             |
| RRF < Minimum RRF in Table for target analyte                         | Use professional judgment<br>J+ or R | R                              |
| RRF > Minimum RRF in Table for target analyte                         | No qualification                     | No qualification               |
| %RSD > Maximum %RSD in Table for target analyte                       | J                                    | Use professional judgment      |
| %RSD ≤ Maximum %RSD in Table for target analyte                       | No qualification                     | No qualification               |



All criteria were met   X    
Criteria were not met  
and/or see below           

### Continuing Calibration Verification (CCV)

**NOTE:** Verify that the CCV was run at the required frequency (an opening and closing CCV must be run within 12-hour period) and the CCV was compared to the correct initial calibration. If the mid-point standard from the initial calibration is used as an opening CCV, verify that the result (RRF) of the mid-point standard was compared to the average RRF from the correct initial calibration.

The closing CCV used to bracket the end of a 12-hour analytical sequence may be used as the opening CCV for the new 12-hour analytical sequence, provided that all the technical acceptance criteria are met for an opening CCV (see criteria show before in the Table) . If the closing CCV does not meet the technical acceptance criteria for an opening CCV, then a BFB tune followed by an opening CCV is required and the next 12-hour time period begins with the BFB tune.

All DMCs must meet RRF criteria. No qualification of the data is necessary on the DMCs RRF and %RSD/%D data alone. However, use professional judgment to evaluate the DMC and %RSD/%D data in conjunction with the DMC recoveries to determine the need of qualification the data.

#### Action:

1. If a CCV (opening and closing) was not run at the appropriate frequency, qualify data using professional judgment.
2. Qualify all volatile target compounds in Table shown before using the following criteria:
  - a. For an opening CCV, if any volatile target compound has an RRF value less than the minimum criterion, use professional judgment for detects, based on mass spectral identification, to qualify the data as estimated (J) and qualify non-detected compounds as unusable (R).
  - b. For a closing CCV, if any volatile target compound has an RRF value less than the criteria, use professional judgment for detects based on mass spectral identification to qualify the data as estimated (J), and qualify non-detected compounds as unusable (R).
  - c. For an opening CCV, if the Percent Difference value for any of the volatile target compounds is outside the limits in calibration criteria Table shown before, qualify detects as estimated (J) and non-detected compounds as estimated (UJ).
  - d. For a closing CCV, if the Percent Difference value for any volatile target compound is outside the limits in calibration criteria table, qualify detects as estimated (J) and non-detected compounds as estimated (UJ).
  - e. If the volatile target compounds meet the acceptable criteria for RRF and the Percent Difference, no qualification of the data is necessary.

## DATA REVIEW WORKSHEETS

- f. No qualification of the data is necessary on the DMC RRF and the Percent Difference data alone. Use professional judgment to evaluate the DMC RRF and Percent Difference data in conjunction with the DMC recoveries to determine the need for qualification of data.

Notes: If the laboratory has failed to provide adequate calibration information, inform the Region's designated representative to contact the laboratory and request the necessary information. If the information is not available, the reviewer must use professional judgment to assess the data.

State in the Data Review Narrative, if possible, the potential effects on the data due to calibration criteria exceedance.

Note, for Contract Laboratory COR action, if calibration criteria are grossly exceeded.

Table. Continuing Calibration Actions for Low/Medium Volatile Analysis – Summary

| Criteria for Opening CCV  | Criteria for Closing CCV  | Action                              |                                |
|---|---|-------------------------------------|--------------------------------|
|   |   | Detect                              | Non-detect                     |
| CCV not performed at required frequency   | CCV not performed at required frequency                                       | Use professional judgment<br>R      | Use professional judgment<br>R |
| CCV not performed at specified concentration                                    | CCV not performed at specified concentration                                  | Use professional judgment           | Use professional judgment      |
| RRF < Minimum RRF in Table 2 for target analyte                                 | RRF < Minimum RRF in Table for target analyte                                 | Use professional judgment<br>J or R | R                              |
| RRF ≥ Minimum RRF in Table 2 for target analyte                                 | RRF ≥ Minimum RRF in Table for target analyte                                 | No qualification                    | No qualification               |
| %D outside the Opening Maximum %D limits in Table 2 for target analyte          | %D outside the Closing Maximum %D limits in Table for target analyte          | J                                   | UJ                             |
| %D within the inclusive Opening Maximum %D limits in Table 2 for target analyte | %D within the inclusive Closing Maximum %D limits in Table for target analyte | No qualification                    | No qualification               |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

The concentration of a target analyte in any blank must not exceed its Contract Required Quantitation Limit (CRQL) (2x CRQLs for Methylene chloride, Acetone, and 2-Butanone). TIC concentration in any blanks must be  $\leq 5.0$   $\mu\text{g/L}$  for water (0.0050 mg/L for TCLP leachate) and  $\leq 5.0$   $\mu\text{g/kg}$  for soil matrices.

#### Laboratory blanks

The method blank, like any other sample in the SDG, must meet the technical acceptance criteria for sample analysis.

| DATE<br>ANALYZED                             | LAB ID | LEVEL/<br>MATRIX | COMPOUND | CONCENTRATION<br>UNITS |
|--|--------|------------------|----------|------------------------|
| No target analyte detected in method blanks. |        |                  |          |                        |
|  |        |                  |          |                        |
|  |        |                  |          |                        |
|  |        |                  |          |                        |
|  |        |                  |          |                        |

#### Field/Equipment/Trip blank

If field or trip blanks are present, the data reviewer should evaluate this data in a similar fashion as the method blanks.

| DATE<br>ANALYZED  | LAB ID | LEVEL/<br>MATRIX | COMPOUND | CONCENTRATION<br>UNITS |
|---|--------|------------------|----------|------------------------|
| No target analytes detected in the field/trip/equipment blanks associated with this data package. |        |                  |          |                        |
|   |        |                  |          |                        |
|   |        |                  |          |                        |
|   |        |                  |          |                        |
|   |        |                  |          |                        |
|   |        |                  |          |                        |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### BLANK ANALYSIS RESULTS (Section 3)

#### Blank Actions

**Note:** All fields blank results associated with a particular group of samples (may exceed one per case) must be used to qualify data. Trip blanks are used to qualify only those samples with which they were shipped. Blanks may not be qualified because of contamination in another blank. Field blanks and trip blanks must be qualified for system monitoring compounds, instrument performance criteria, and spectral or calibration QC problems.

Samples taken from a drinking water tap do not have associated field blanks.

When applied as described in the Table below, the contaminant concentration in the blank is multiplied by the sample dilution factor.

**Table. Blank and TCLP/SPLP LEB Actions for Low/Medium Volatile Analysis**

| Blank Type   | Blank Result           | Sample Result                        | Action for Samples                                      |
|--|------------------------|--------------------------------------|---|
| Method,<br>Storage, Field,<br>Trip.<br>TCLP/SPLP<br>LEB.<br>Instrument** | Detects                | Not detected                         | No qualification required                               |
|  | < CRQL *               | < CRQL*                              | Report CRQL value with a U                              |
|  |                        | ≥ CRQL*                              | No qualification required                               |
|  | > CRQL *               | < CRQL*                              | Report CRQL value with a U                              |
|  |                        | ≥ CRQL* and ≤<br>blank concentration | Report blank value for sample<br>concentration with a U |
|  |                        | ≥ CRQL* and ><br>blank concentration | No qualification required                               |
|  | = CRQL*                | ≤ CRQL*                              | Report CRQL value with a U                              |
|  |                        | > CRQL*                              | No qualification required                               |
|  | Gross<br>contamination | Detects                              | Report blank value for sample<br>concentration with a U |

\* 2x the CRQL for methylene chloride, 2-butanone and acetone.

\*\* Qualifications based on instrument blank results affect only the sample analyzed immediately after the sample that has target compounds that exceed the calibration range or non-target compounds that exceed 100 µg/L.

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

## DATA REVIEW WORKSHEETS

### Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

| CONTAMINATION<br>SOURCE/LEVEL | COMPOUND | CONC/UNITS | AL/UNITS | SQL | AFFECTED<br>SAMPLES |
|-------------------------------|----------|------------|----------|-----|---------------------|
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### DEUTERATED MONITORING COMPOUNDS (DMCs)

Laboratory performance of individual samples is established by evaluation of surrogate spike (DMCs) recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

**Table. Volatile Deuterated Monitoring Compounds (DMCs) and Recovery Limits**

| <b>DMC</b>                   | <b>%R for Water Sample</b> | <b>%R for Soil Sample</b> |
|------------------------------|----------------------------|---------------------------|
| Vinyl chloride-d3            | 60-135                     | 30-150                    |
| Chloroethane-d5              | 70-130                     | 30-150                    |
| 1,1-Dichloroethene-d2        | 60-125                     | 45-110                    |
| 2-Butanone-d5                | 40-130                     | 20-135                    |
| Chloroform-d                 | 70-125                     | 40-150                    |
| 1,2-Dichloroethane-d4        | 70-125                     | 70-130                    |
| Benzene-d6                   | 70-125                     | 20-135                    |
| 1,2-Dichloropropane-d6       | 70-120                     | 70-120                    |
| Toluene-d8                   | 80-120                     | 30-130                    |
| trans-1,3-Dichloropropene-d4 | 60-125                     | 30-135                    |
| 2-Hexanone-d5                | 45-130                     | 20-135                    |
| 1,1,2,2-Tetrachloroethane-d2 | 65-120                     | 45-120                    |
| 1,2-Dichlorobenzene-d4       | 80-120                     | 75-120                    |

**NOTE:** The recovery limits for any of the compounds listed in the above Table may be expanded at any time during the period of performance if the United States Environmental Protection Agency (EPA) determines that the limits are too restrictive.

#### Action:

Are recoveries for DMCs in volatile samples and blanks must be within the limits specified in the Table above. Yes? or No?

**NOTE:** The recovery limits for any of the compounds listed in the Table above may be expanded at any time during the period of performance if USEPA determines that the limits are too restrictive.

## DATA REVIEW WORKSHEETS

List the DMCs that may fail to meet the recovery limits

| Sample ID | Date | DMCs | % Recovery | Action |
|-----------|------|------|------------|--------|
|-----------|------|------|------------|--------|

**Note:** DMCs recoveries within the required limits and within the guidance document performance criteria (80 – 120). Other non-deuterated surrogates added to the samples, % recoveries within laboratory control limits.

**Note:** Any sample which has more than 3 DMCs outside the limits must be reanalyzed.

**Action:**

1. For any recovery greater than the upper acceptance limit:
  - a. Qualify detected associated volatile target compounds as estimated high (J+).
  - b. Do not qualify non-detected associated volatile target compounds.
2. For any recovery greater than or equal to 10%, and less than the lower acceptance limit:
  - a. Qualify detected associated volatile target compounds as estimated low (J-).
  - b. Qualify non-detected associated volatile target compounds as estimated (UJ).
3. For any recovery less than 10%:
  - a. Qualify detected associated volatile target compounds as estimated low (J-).
  - b. Qualify non-detected associated volatile target compounds as unusable (R).
4. For any recovery within acceptance limits, no qualification of the data is necessary.
5. In the special case of a blank analysis having DMCs out of specification, the reviewer must give special consideration to the validity of associated sample data. The basic concern is whether the blank problems represent an isolated problem with the blank alone, or whether there is a fundamental problem with the analytical process. For example, if one or more samples in the batch show acceptable DMC recoveries, the reviewer may choose to consider the blank problem to be an isolated occurrence. However, even if this judgment allows some use of the affected data, note analytical problems for Contract Laboratory COR action.
6. If more than three DMCs are outside of the recovery limits for Low/Medium volatiles analysis and the sample was not reanalyzed, note under Contract Problems/Non-Compliance.

**Table. Deuterated Monitoring Compound (DMC) Recovery Actions for Low/Medium Volatiles Analyses – Summary**

| Criteria   | Action                      |                                   |
|--|-----------------------------|-----------------------------------|
|  | Detect Associated Compounds | Non-detected Associated Compounds |
| %R < 10%   | J-                          | R                                 |
| 10% ≤ %R < Lower Acceptance Limit                    | J-                          | UJ                                |
| Lower Acceptance Limit ≤ %R ≤ Upper Acceptance Limit | No qualification            | No qualification                  |
| %R > Upper Acceptance Limit                          | J+                          | No qualification                  |

DATA REVIEW WORKSHEETS

TABLE. VOLATILE DEUTERATED MONITORING COMPOUNDS (DMCs) AND THE ASSOCIATED TARGET COMPOUNDS

|  |  |  |
|--|--|--|
| <b>Vinyl chloride-d<sub>3</sub> (DMC-1)</b>  | <b>Chloroethane-d<sub>5</sub> (DMC-2)</b>  | <b>1,1-Dichloroethene-d<sub>2</sub> (DMC-3)</b>  |
| Vinyl chloride   | Dichlorodifluoromethane<br>Chloromethane<br>Bromomethane<br>Chloroethane<br>Carbon disulfide | trans-1,2-Dichloroethene<br>cis-1,2-Dichloroethene<br>1,1-Dichloroethene   |
| <b>2-Butanone-d<sub>6</sub> (DMC-4)</b>  | <b>Chloroform-d (DMC-5)</b>  | <b>1,2-Dichloroethane-d<sub>4</sub> (DMC-6)</b>  |
| Acetone<br>2-Butanone  | 1,1-Dichloroethane<br>Bromochloromethane<br>Chloroform<br>Dibromochloromethane<br>Bromoform  | Trichlorofluoromethane<br>1,1,2-Trichloro-1,2,2-trifluoroethane<br>Methyl acetate<br>Methylene chloride<br>Methyl-tert-butyl ether<br>1,1,1-Trichloroethane<br>Carbon tetrachloride<br>1,2-Dibromoethane<br>1,2-Dichloroethane |
| <b>Benzene-d<sub>6</sub> (DMC-7)</b>   | <b>1,2-Dichloropropane-d<sub>4</sub> (DMC-8)</b>   | <b>Toluene-d<sub>8</sub> (DMC-9)</b>   |
| Benzene  | Cyclohexane<br>Methylcyclohexane<br>1,2-Dichloropropane<br>Bromodichloromethane              | Trichloroethene<br>Toluene<br>Tetrachloroethene<br>Ethylbenzene<br>o-Xylene<br>m,p-Xylene<br>Styrene<br>Isopropylbenzene   |
| <b>trans-1,3-Dichloropropene-d<sub>4</sub> (DMC-10)</b>  | <b>2-Hexanone-d<sub>8</sub> (DMC-11)</b>   | <b>1,1,2,2-Tetrachloroethane-d<sub>2</sub> (DMC-12)</b>  |
| cis-1,3-Dichloropropene<br>trans-1,3-Dichloropropene<br>1,1,2-Trichloroethane  | 4-Methyl-2-pentanone<br>2-Hexanone   | 1,1,2,2-Tetrachloroethane<br>1,2-Dibromo-3-chloropropane   |
| <b>1,2-Dichlorobenzene-d<sub>4</sub> (DMC-13)</b>  |  |  |
| Chlorobenzene<br>1,3-Dichlorobenzene<br>1,4-Dichlorobenzene<br>1,2-Dichlorobenzene<br>1,2,4-Trichlorobenzene<br>1,2,3-Trichlorobenzene |  |  |



## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below \_\_\_\_\_

### MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

**NOTES:** Data for MS and MSDs will not be present unless requested by the Region.  
Notify the Contract Laboratory COR if a field or trip blank was used for the MS and MSD.

For a Matrix Spike that does not meet criteria, apply the action to only the field sample used to prepare the Matrix Spike sample. If it is clearly stated in the data validation materials that the samples were taken through incremental sampling or some other method guaranteeing the homogeneity of the sample group, then the entire sample group may be qualified.

#### 1. MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

List the %Rs, RPD of the compounds which do not meet the criteria.

|                                       |                                  |
|---------------------------------------|----------------------------------|
| Sample ID: <u>JC34340-1MS/-1MSD</u>   | Matrix/Level: <u>Groundwater</u> |
| Sample ID: <u>JC34340-16MS/-16MSD</u> | Matrix/Level: <u>Groundwater</u> |
| Sample ID: <u>JC34180-5MS/-5MSD</u>   | Matrix/Level: <u>Groundwater</u> |

**Note:** MS/MSD % recoveries and RPD within laboratory control limits.

**Note:**

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

## DATA REVIEW WORKSHEETS

### Actions:

1. No qualification of the data is necessary on MS and MSD data alone. However, using professional judgment, the validator may use the MS and MSD results in conjunction with other QC criteria and determine the need for some qualification of the data.

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (UJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

A separate worksheet should be used for each MS/MSD pair.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

#### 1. LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD?  
**Yes or No.** If no make note in data review memo.

List the %R of compounds which do not meet the criteria

| LCS ID   | COMPOUND | % R | QC LIMIT |
|--|----------|-----|----------|
| Recoveries (blank spike) within laboratory control limits. _____ |          |     |          |
|  |          |     |          |
|  |          |     |          |
|  |          |     |          |
|  |          |     |          |
|  |          |     |          |

#### Note:

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

#### Actions:

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (j) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

#### 2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? Yes or No.

If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### IX. FIELD/LABORATORY DUPLICATE PRECISION

Sample IDs:   JC34340-2/-2DUP  

Matrix:   Groundwater  

Sample IDs:   JC34340-7/JC34340-8  

Matrix:   Groundwater  

Field/laboratory duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

**NOTE:** In the absence of QAPP guidance for validating data from field duplicates, the following action will be taken.

Identify which samples within the data package are field duplicates. Estimate the relative percent difference (RPD) between the values for each compound. Use professional judgment to note large RPDs (> 50%) in the narrative.

| COMPOUND   | SQL | SAMPLE CONC. | DUPLICATE CONC. | RPD | ACTION |
|--|-----|--------------|-----------------|-----|--------|
|  |     |              |                 |     |        |
|  |     |              |                 |     |        |
| Field/laboratory duplicate analyzed with this data package. PRD within required criteria, ≤ 50 % for target analytes detected at concentration > 5x the SQL. |     |              |                 |     |        |

#### Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions are suggested based on professional judgment:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

All criteria were met   X    
Criteria were not met  
and/or see below \_\_\_\_\_

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

| DATE  | SAMPLE ID | IS OUT | IS AREA | ACCEPTABLE RANGE | ACTION |
|---|-----------|--------|---------|------------------|--------|
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
| Internal standard area counts within the required criteria for all samples. |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |

1. If an internal standard area count for a sample or blank is greater than 200.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration) (see Table below):
  - a. Qualify detects for compounds quantitated using that internal standard as estimated low (J-).
  - b. Do not qualify non-detected associated compounds.
2. If an internal standard area count for a sample or blank is less than 20.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration):
  - a. Qualify detects for compounds quantitated using that internal standard as estimated high (J+).
  - b. Qualify non-detected associated compounds as unusable (R).
3. If an internal standard area count for a sample or blank is greater than or equal to 20.0%, and less than or equal to 200% of the area for the associated standard opening CCV or mid-point standard from initial calibration, no qualification of the data is necessary.
4. If an internal standard RT varies by more than 30.0 seconds: Examine the chromatographic profile for that sample to determine if any false positives or negatives exist. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for that sample fraction. Detects should not need to be qualified as unusable (R) if the mass spectral criteria are met.
5. If an internal standard RT varies by less than or equal to 30.0 seconds, no qualification of the data is necessary.

**Note:** Inform the Contract Laboratory Program Project Officer (CLP PO) if the internal standard performance criteria are grossly exceeded. Note in the Data Review Narrative potential effects on the data resulting from unacceptable internal standard performance.

## DATA REVIEW WORKSHEETS

6. If required internal standard compounds are not added to a sample or blank, qualify detects and non-detects as unusable (R).
7. If the required internal standard compound is not analyzed at the specified concentration in a sample or blank, use professional judgment to qualify detects and non-detects.

**Table. Internal Standard Actions for Low/Medium Volatiles Analyses - Summary**

| Criteria  | Action                         |                                    |
|---|--------------------------------|------------------------------------|
|   | Detected Associated Compounds* | Non-detected Associated Compounds* |
| Area counts > 200% of 12-hour standard (opening CCV or mid-point standard from initial calibration)                                 | J-                             | No qualification                   |
| Area counts < 20% of 12-hour standard (opening CCV or mid-point standard from initial calibration)                                  | J+                             | R                                  |
| Area counts $\geq$ 50% but $\leq$ 200% of 12-hour standard (opening CCV or mid-point standard from initial calibration)             | No qualification               |                                    |
| RT difference > 30.0 seconds between samples and 12-hour standard (opening CCV or mid-point standard from initial calibration)      | R **                           | R                                  |
| RT difference $\leq$ 30.0 seconds between samples and 12-hour standard (opening CCV or mid-point standard from initial calibration) | No qualification               |                                    |

\* For volatile compounds associated to each internal standard, see TABLE - VOLATILE TARGET ANALYTES, DEUTERATED MONITORING COMPOUNDS WITH ASSOCIATED INTERNAL STANDARDS FOR QUANTITATION in SOM02.2, Exhibit D, available at: <http://www.epa.gov/superfund/programs/clp/download/som/som22d.pdf>

\*\* Detects should not need to be qualified as unusable (R) if the mass spectral criteria are met.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### TARGET COMPOUND IDENTIFICATION

#### Criteria:

Is the Relative Retention Times (RRTs) of reported compounds within  $\pm 0.06$  RRT units of the standard RRT [opening Continuing Calibration Verification (CCV) or mid-point standard from the initial calibration]. Yes? or No?

List compounds not meeting the criteria described above:

| Sample ID | Compounds | Actions |
|-----------|-----------|---------|
| =====     | =====     | =====   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |

Mass spectra of the sample compound and a current laboratory-generated standard [i.e., the mass spectrum from the associated calibration standard (opening CCV or mid-point standard from initial calibration)] must match according to the following criteria:

- All ions present in the standard mass spectrum at a relative intensity greater than 10% must be present in the sample spectrum.
- The relative intensities of these ions must agree within  $\pm 20\%$  between the standard and sample spectra (e.g., for an ion with an abundance of 50% in the standard spectrum, the corresponding sample ion abundance must be between 30-70%).
- Ions present at greater than 10% in the sample mass spectrum, but not present in the standard spectrum, must be evaluated by a reviewer experienced in mass spectral interpretation.

List compounds not meeting the criteria described above:

| Sample ID | Compounds | Actions |
|-----------|-----------|---------|
| =====     | =====     | =====   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |

## DATA REVIEW WORKSHEETS

### Action:

1. The application of qualitative criteria for GC/MS analysis of target compounds requires professional judgment. It is up to the reviewer's discretion to obtain additional information from the laboratory. If it is determined that incorrect identifications were made, qualify all such data as unusable (R).
2. Use professional judgment to qualify the data if it is determined that cross-contamination has occurred.
3. Note in the Data Review Narrative any changes made to the reported compounds or concerns regarding target compound identifications. Note, for Contract Laboratory COR action, the necessity for numerous or significant changes.

### TENTATIVELY IDENTIFIED COMPOUNDS (TICS)

NOTE: Tentatively identified compounds should only be evaluated when requested by a party from outside of the Hazardous Waste Support Section (HWSS).

#### List TICs

| Sample ID | Compound | Sample ID | Compound |
|-----------|----------|-----------|----------|
| =====     |          |           |          |
|           |          |           |          |
|           |          |           |          |
|           |          |           |          |
|           |          |           |          |
|           |          |           |          |

### Action:

1. Qualify all TIC results for which there is presumptive evidence of a match (e.g. greater than or equal to 85% match) as tentatively identified (NJ), with approximated concentrations. TICs labeled "unknown" are qualified as estimated (J).
2. General actions related to the review of TIC results are as follows:
  - a. If it is determined that a tentative identification of a non-target compound is unacceptable, change the tentative identification to "unknown" or another appropriate identification, and qualify the result as estimated (J).
  - b. If all contractually-required peaks were not library searched and quantitated, the Region's designated representative may request these data from the laboratory.
3. In deciding whether a library search result for a TIC represents a reasonable identification, use professional judgment. If there is more than one possible match, report the result as "either compound X or compound Y". If there is a lack of isomer specificity, change the TIC result to a nonspecific isomer result (e.g., 1,3,5-trimethyl benzene to trimethyl benzene).



## DATA REVIEW WORKSHEETS

- isomer) or to a compound class (e.g., 2-methyl, 3-ethyl benzene to a substituted aromatic compound).
4. The reviewer may elect to report all similar compounds as a total (e.g., all alkanes may be summarized and reported as total hydrocarbons).
  5. Target compounds from other fractions and suspected laboratory contaminants should be marked as "non-reportable".
  6. Other Case factors may influence TIC judgments. If a sample TIC match is poor, but other samples have a TIC with a valid library match, similar RRT, and the same ions, infer identification information from the other sample TIC results.
  7. Note in the Data Review Narrative any changes made to the reported data or any concerns regarding TIC identifications.
  8. Note, for Contract Laboratory COR action, failure to properly evaluate and report TICs

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### SAMPLE QUANTITATION AND REPORTED CONTRACT REQUIRED QUANTITATION LIMITS (CRQLS)

#### Action:

1. If any discrepancies are found, the Region's designated representative may contact the laboratory to obtain additional information that could resolve any differences. If a discrepancy remains unresolved, the reviewer must use professional judgment to decide which value is the most accurate. Under these circumstances, the reviewer may determine that qualification of data is warranted. Note in the Data Review Narrative a description of the reasons for data qualification and the qualification that is applied to the data.
2. For non-aqueous samples, in the percent moisture is less than 70.0%, no qualification of the data is necessary. If the percent moisture is greater than or equal to 70.0% and less than 90.0%, qualify detects as estimated (J) and non-detects as approximated (UJ). If the percent moisture is greater than or equal to 90.0%, qualify detects as estimated (J) and non-detects as unusable (R) (see Table below).
3. Note, for Contract Laboratory COR action, numerous or significant failures to accurately quantify the target compounds or to properly evaluate and adjust CRQLs.
4. Results between MDL and CRQL should be qualified as estimated "J".
5. Results < MDL should be reported at the CRQL and qualified "U". MDLs themselves are not reported.

Table. Percent Moisture Actions for Low/Medium Volatiles Analysis for Non-Aqueous Samples

| Criteria                 | Action                        |                                   |
|--------------------------|-------------------------------|-----------------------------------|
|                          | Detected Associated Compounds | Non-detected Associated Compounds |
| % Moisture < 70.0        | No qualification              |                                   |
| 70.0 < % Moisture < 90.0 | J                             | UJ                                |
| % Moisture > 90.0        | J                             | R                                 |

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

Sample ID

JC34340-1 MS

1,3-butadiene

RF = 0.619

[ ] = (135288)(50)/(0.619)(225639) = 48.4 ppb    Ok

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below \_\_\_\_\_

### B. Percent Solids

List samples which have  $\geq 70\%$  solids

---

---

---

---

---

---

## QUANTITATION LIMITS

A. Dilution performed

[illegible]

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### OTHER ISSUES

#### A. System Performance

List samples qualified based on the degradation of system performance during sample analysis:

| Sample ID                                      | Comments | Actions |
|--|----------|---------|
| =====  | =====    | =====   |
| _____  | _____    | _____   |
| No degradation of system performance observed. | _____    | _____   |
| _____  | _____    | _____   |
| _____  | _____    | _____   |

Action:

Use professional judgment to qualify the data if it is determined that system performance has degraded during sample analyses. Inform the Contract Laboratory Program COR any action as a result of degradation of system performance which significantly affected the data.

#### B. Overall Assessment of Data

List samples qualified based on other issues:

| Sample ID  | Comments | Actions |
|--|----------|---------|
| =====  | =====    | =====   |
| _____  | _____    | _____   |
| No additional issues observed that require qualification of the data. Results are valid and can be used for decision purposes. | _____    | _____   |
| _____  | _____    | _____   |
| _____  | _____    | _____   |

Action:

1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
2. Write a brief narrative to give the user an indication of the analytical limitations of the data. Inform the Contract Laboratory COR the action, any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).

## EXECUTIVE NARRATIVE

SDG No: JC34340 Laboratory: Accutest, New Jersey  
Analysis: SW846-8270D Number of Samples: 14  
Location: BMSMC, Building 5 Area  
Humacao, PR

**SUMMARY:** Fourteen (14) samples were analyzed for selected SVOCs following method SW846-8270D and Selected PAHs and 1,4-Dioxane were also analyzed by SW846-8270D using the selective ion monitoring (SIM) technique. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: EPA Hazardous Waste Support Section, SOP HW-35A, July 2015 – Revision 0. Semivolatile Data Validation. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

**Critical issues:** None  
**Major:** None  
**Minor:** None

**Critical findings:** None  
**Major findings:** None  
**Minor findings:**

1. All samples extracted and analyzed within method recommended holding time except for the cases described in the Data Review Worksheet. Sample preservation was appropriate.

No action taken, professional judgment. Samples were re-extracted outside holding time for confirmation.

2. Initial and continuing calibration verifications meet the method and guidance document required performance criteria except in the cases described in the Data Review Worksheet. Results for were qualified as estimated (J or UJ) in affected samples.

No closing calibration verification included in data package. No action taken, professional judgment.

QC samples were not validated.

3. Sample JC34340-16MS/-MSD have compound(s) reported with a "B" qualifier, indicating analyte is found in the associated method blank. No action taken.

1,4-dioxane found in method blank. No action taken. 1,4-dioxane not detected in sample JC34340-15 and reported from the scan mode run in sample JC34340-16.

4. Surrogate standards recovered within laboratory control limits except for the cases described in the Data Review Worksheet. No action taken.

Surrogates not recovered in samples JC34340-16 due to dilution. No action taken.

5. MS/MSD % recovery and RPD within laboratory control limits except for the cases described in the Data Review Worksheet.

No qualification made based on RPD results, professional judgment.

No action taken for analytes not meeting the MS/MSD % recovery control limit; outside control limits due to high level in sample relative to spike amount.

MS/MSD % recovery results apply only to the unspiked sample; No qualification made on unspiked samples from another jobs.

6. Field duplicate analyzed as part of this data package. RPD within the required guidance document criteria < 50 % for detected target analytes above 5 SQL except for the cases described in the Data Review Worksheet. Results for 1,4-dioxane qualified as estimated (J) in sample and duplicate.

7. The acid surrogate standard not added to the LCS analyzed on 12/28/16. The affected samples either was not re-extracted because no sample was left or extracted outside the method recommended holding time. No action taken, professional judgment.

**COMMENTS:**

Results are valid and can be used for decision making purposes.

**Reviewers Name:**

Rafael Infante  
Chemist License 1888

**Signature:**

**Date:**

  
January 28, 2017

# **SAMPLE ORGANIC DATA SAMPLE SUMMARY**

Sample ID: JC34340-1

Sample location: BMSMC Building 5 Area

Sampling date: 12/20/2016

Matrix: Groundwater

## **METHOD: 8270D**

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 10     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 10     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.1    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.0    | ug/l  | 1               | -        | U          | Yes        |

|                             |     |      |   |   |   |     |
|-----------------------------|-----|------|---|---|---|-----|
| bis(2-Chloroethyl)ether     | 2.0 | ug/l | 1 | - | U | Yes |
| bis(2-Chloroisopropyl)ether | 2.0 | ug/l | 1 | - | U | Yes |
| 4-Chlorophenyl phenyl ether | 2.0 | ug/l | 1 | - | U | Yes |
| 2,4-Dinitrotoluene          | 1.0 | ug/l | 1 | - | U | Yes |
| 2,6-Dinitrotoluene          | 1.0 | ug/l | 1 | - | U | Yes |
| 3,3'-Dichlorobenzidine      | 2.0 | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene      | 1.0 | ug/l | 1 | - | U | Yes |
| Dibenzofuran                | 5.1 | ug/l | 1 | - | U | Yes |
| Di-n-butyl phthalate        | 2.0 | ug/l | 1 | - | U | Yes |
| Di-n-octyl phthalate        | 2.0 | ug/l | 1 | - | U | Yes |
| Diethyl phthalate           | 2.0 | ug/l | 1 | - | U | Yes |
| Dimethyl phthalate          | 2.0 | ug/l | 1 | - | U | Yes |
| bis(2-Ethylhexyl)phthalate  | 2.0 | ug/l | 1 | - | U | Yes |
| Fluoranthene                | 1.0 | ug/l | 1 | - | U | Yes |
| Fluorene                    | 1.0 | ug/l | 1 | - | U | Yes |
| Hexachlorobenzene           | 1.0 | ug/l | 1 | - | U | Yes |
| Hexachlorobutadiene         | 1.0 | ug/l | 1 | - | U | Yes |
| Hexachlorocyclopentadiene   | 10  | ug/l | 1 | - | U | Yes |
| Hexachloroethane            | 2.0 | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene      | 1.0 | ug/l | 1 | - | U | Yes |
| Isophorone                  | 2.0 | ug/l | 1 | - | U | Yes |
| 1-Methylnaphthalene         | 1.0 | ug/l | 1 | - | U | Yes |
| 2-Methylnaphthalene         | 1.0 | ug/l | 1 | - | U | Yes |
| 2-Nitroaniline              | 5.1 | ug/l | 1 | - | U | Yes |
| 3-Nitroaniline              | 5.1 | ug/l | 1 | - | U | Yes |
| 4-Nitroaniline              | 5.1 | ug/l | 1 | - | U | Yes |
| Nitrobenzene                | 2.0 | ug/l | 1 | - | U | Yes |
| N-Nitroso-di-n-propylamine  | 2.0 | ug/l | 1 | - | U | Yes |
| Nitrosodiphenylamine        | 5.1 | ug/l | 1 | - | U | Yes |
| Phenanthrene                | 1.0 | ug/l | 1 | - | U | Yes |
| Pyrene                      | 1.0 | ug/l | 1 | - | U | Yes |
| 1,2,4,5-Tetrachlorobenzene  | 2.0 | ug/l | 1 | - | U | Yes |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.051 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.051 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.10  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.10  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.10  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.10  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 2.71  | ug/l | 1 | - | - | Yes |



Sample ID: JC34340-2  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/20/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 10     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 10     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.0    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.1    | ug/l  | 1               | -        | UJ         | Yes ✓      |
| 2,4,5-Trichlorophenol      | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethyl)ether    | 2.0    | ug/l  | 1               | -        | U          | Yes        |

|                             |     |      |   |   |    |       |
|-----------------------------|-----|------|---|---|----|-------|
| bis(2-Chloroisopropyl)ether | 2.0 | ug/l | 1 | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.0 | ug/l | 1 | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.0 | ug/l | 1 | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.0 | ug/l | 1 | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.0 | ug/l | 1 | - | U  | Yes   |
| Dibenzo(a,h)anthracene      | 1.0 | ug/l | 1 | - | U  | Yes   |
| Dibenzofuran                | 5.1 | ug/l | 1 | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.0 | ug/l | 1 | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.0 | ug/l | 1 | - | U  | Yes   |
| Diethyl phthalate           | 2.0 | ug/l | 1 | - | U  | Yes   |
| Dimethyl phthalate          | 2.0 | ug/l | 1 | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.0 | ug/l | 1 | - | U  | Yes   |
| Fluoranthene                | 1.0 | ug/l | 1 | - | U  | Yes   |
| Fluorene                    | 1.0 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobenzene           | 1.0 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobutadiene         | 1.0 | ug/l | 1 | - | U  | Yes   |
| Hexachlorocyclopentadiene   | 10  | ug/l | 1 | - | UJ | Yes ✓ |
| Hexachloroethane            | 2.0 | ug/l | 1 | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.0 | ug/l | 1 | - | U  | Yes   |
| Isophorone                  | 2.0 | ug/l | 1 | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.0 | ug/l | 1 | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.0 | ug/l | 1 | - | U  | Yes   |
| 2-Nitroaniline              | 5.1 | ug/l | 1 | - | U  | Yes   |
| 3-Nitroaniline              | 5.1 | ug/l | 1 | - | U  | Yes   |
| 4-Nitroaniline              | 5.1 | ug/l | 1 | - | U  | Yes   |
| Nitrobenzene                | 2.0 | ug/l | 1 | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.0 | ug/l | 1 | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.1 | ug/l | 1 | - | U  | Yes   |
| Phenanthrene                | 1.0 | ug/l | 1 | - | U  | Yes   |
| Pyrene                      | 1.0 | ug/l | 1 | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.0 | ug/l | 1 | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.051 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.051 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.10  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.10  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.10  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.10  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 0.10  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-3  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/20/2016  
Matrix: AQ - Field Blank Water

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.4    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.5    | ug/l  | 1               | -        | UJ         | Yes ✓      |
| 2,4,5-Trichlorophenol      | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethyl)ether    | 2.2    | ug/l  | 1               | -        | UJ         | Yes ✓      |

|                             |     |      |   |   |    |     |
|-----------------------------|-----|------|---|---|----|-----|
| bis(2-Chloroisopropyl)ether | 2.2 | ug/l | 1 | - | U  | Yes |
| 4-Chlorophenyl phenyl ether | 2.2 | ug/l | 1 | - | U  | Yes |
| 2,4-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes |
| 2,6-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes |
| 3,3'-Dichlorobenzidine      | 2.2 | ug/l | 1 | - | U  | Yes |
| Dibenzo(a,h)anthracene      | 1.1 | ug/l | 1 | - | U  | Yes |
| Dibenzofuran                | 5.5 | ug/l | 1 | - | U  | Yes |
| Di-n-butyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes |
| Di-n-octyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes |
| Diethyl phthalate           | 2.2 | ug/l | 1 | - | U  | Yes |
| Dimethyl phthalate          | 2.2 | ug/l | 1 | - | U  | Yes |
| bis(2-Ethylhexyl)phthalate  | 2.2 | ug/l | 1 | - | U  | Yes |
| Fluoranthene                | 1.1 | ug/l | 1 | - | U  | Yes |
| Fluorene                    | 1.1 | ug/l | 1 | - | U  | Yes |
| Hexachlorobenzene           | 1.1 | ug/l | 1 | - | U  | Yes |
| Hexachlorobutadiene         | 1.1 | ug/l | 1 | - | UJ | Yes |
| Hexachlorocyclopentadiene   | 11  | ug/l | 1 | - | U  | Yes |
| Hexachloroethane            | 2.2 | ug/l | 1 | - | U  | Yes |
| Indeno(1,2,3-cd)pyrene      | 1.1 | ug/l | 1 | - | U  | Yes |
| Isophorone                  | 2.2 | ug/l | 1 | - | U  | Yes |
| 1-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes |
| 2-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes |
| 2-Nitroaniline              | 5.5 | ug/l | 1 | - | U  | Yes |
| 3-Nitroaniline              | 5.5 | ug/l | 1 | - | U  | Yes |
| 4-Nitroaniline              | 5.5 | ug/l | 1 | - | U  | Yes |
| Nitrobenzene                | 2.2 | ug/l | 1 | - | U  | Yes |
| N-Nitroso-di-n-propylamine  | 2.2 | ug/l | 1 | - | U  | Yes |
| Nitrosodiphenylamine        | 5.5 | ug/l | 1 | - | U  | Yes |
| Phenanthrene                | 1.1 | ug/l | 1 | - | U  | Yes |
| Pyrene                      | 1.1 | ug/l | 1 | - | U  | Yes |
| 1,2,4,5-Tetrachlorobenzene  | 2.2 | ug/l | 1 | - | U  | Yes |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.055 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.055 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.11  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 0.11  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-4  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: AQ - Equipment Blank

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 10     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 10     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.2    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.2    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.1    | ug/l  | 1               | -        | U          | Yes        |

|                             |     |      |   |   |   |     |
|-----------------------------|-----|------|---|---|---|-----|
| bis(2-Chloroethyl)ether     | 2.1 | ug/l | 1 | - | U | Yes |
| bis(2-Chloroisopropyl)ether | 2.1 | ug/l | 1 | - | U | Yes |
| 4-Chlorophenyl phenyl ether | 2.1 | ug/l | 1 | - | U | Yes |
| 2,4-Dinitrotoluene          | 1.0 | ug/l | 1 | - | U | Yes |
| 2,6-Dinitrotoluene          | 1.0 | ug/l | 1 | - | U | Yes |
| 3,3'-Dichlorobenzidine      | 2.1 | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene      | 1.0 | ug/l | 1 | - | U | Yes |
| Dibenzofuran                | 5.2 | ug/l | 1 | - | U | Yes |
| Di-n-butyl phthalate        | 2.1 | ug/l | 1 | - | U | Yes |
| Di-n-octyl phthalate        | 2.1 | ug/l | 1 | - | U | Yes |
| Diethyl phthalate           | 2.1 | ug/l | 1 | - | U | Yes |
| Dimethyl phthalate          | 2.1 | ug/l | 1 | - | U | Yes |
| bis(2-Ethylhexyl)phthalate  | 2.1 | ug/l | 1 | - | U | Yes |
| Fluoranthene                | 1.0 | ug/l | 1 | - | U | Yes |
| Fluorene                    | 1.0 | ug/l | 1 | - | U | Yes |
| Hexachlorobenzene           | 1.0 | ug/l | 1 | - | U | Yes |
| Hexachlorobutadiene         | 1.0 | ug/l | 1 | - | U | Yes |
| Hexachlorocyclopentadiene   | 10  | ug/l | 1 | - | U | Yes |
| Hexachloroethane            | 2.1 | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene      | 1.0 | ug/l | 1 | - | U | Yes |
| Isophorone                  | 2.1 | ug/l | 1 | - | U | Yes |
| 1-Methylnaphthalene         | 1.0 | ug/l | 1 | - | U | Yes |
| 2-Methylnaphthalene         | 1.0 | ug/l | 1 | - | U | Yes |
| 2-Nitroaniline              | 5.2 | ug/l | 1 | - | U | Yes |
| 3-Nitroaniline              | 5.2 | ug/l | 1 | - | U | Yes |
| 4-Nitroaniline              | 5.2 | ug/l | 1 | - | U | Yes |
| Nitrobenzene                | 2.1 | ug/l | 1 | - | U | Yes |
| N-Nitroso-di-n-propylamine  | 2.1 | ug/l | 1 | - | U | Yes |
| Nitrosodiphenylamine        | 5.2 | ug/l | 1 | - | U | Yes |
| Phenanthrene                | 1.0 | ug/l | 1 | - | U | Yes |
| Pyrene                      | 1.0 | ug/l | 1 | - | U | Yes |
| 1,2,4,5-Tetrachlorobenzene  | 2.1 | ug/l | 1 | - | U | Yes |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.052 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.052 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.10  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.10  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.10  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.10  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 0.10  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-7  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 10     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 10     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.0    | ug/l  | 1               | -        | UJ         | Yes ✓      |
| Phenol                     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.0    | ug/l  | 1               | -        | UJ         | Yes ✓      |
| 1,1'-Biphenyl              | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.0    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethyl)ether    | 2.0    | ug/l  | 1               | -        | U          | Yes        |

|                             |      |      |   |   |   |       |
|-----------------------------|------|------|---|---|---|-------|
| bis(2-Chloroisopropyl)ether | 2.0  | ug/l | 1 | - | U | Yes   |
| 4-Chlorophenyl phenyl ether | 2.0  | ug/l | 1 | - | U | Yes   |
| 2,4-Dinitrotoluene          | 1.0  | ug/l | 1 | - | U | Yes   |
| 2,6-Dinitrotoluene          | 1.0  | ug/l | 1 | - | U | Yes   |
| 3,3'-Dichlorobenzidine      | 2.0  | ug/l | 1 | - | U | Yes   |
| 1,4-Dioxane                 | 105  | ug/l | 2 | - | J | Yes ✓ |
| Dibenzo(a,h)anthracene      | 1.0  | ug/l | 1 | - | U | Yes   |
| Dibenzofuran                | 5.0  | ug/l | 1 | - | U | Yes   |
| Di-n-butyl phthalate        | 2.0  | ug/l | 1 | - | U | Yes   |
| Di-n-octyl phthalate        | 2.0  | ug/l | 1 | - | U | Yes   |
| Diethyl phthalate           | 2.0  | ug/l | 1 | - | U | Yes   |
| Dimethyl phthalate          | 2.0  | ug/l | 1 | - | U | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.0  | ug/l | 1 | - | U | Yes   |
| Fluoranthene                | 0.54 | ug/l | 1 | J | J | Yes   |
| Fluorene                    | 1.0  | ug/l | 1 | - | U | Yes   |
| Hexachlorobenzene           | 1.0  | ug/l | 1 | - | U | Yes   |
| Hexachlorobutadiene         | 1.0  | ug/l | 1 | - | U | Yes   |
| Hexachlorocyclopentadiene   | 11   | ug/l | 1 | - | U | Yes   |
| Hexachloroethane            | 2.0  | ug/l | 1 | - | U | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.0  | ug/l | 1 | - | U | Yes   |
| Isophorone                  | 2.0  | ug/l | 1 | - | U | Yes   |
| 1-Methylnaphthalene         | 1.0  | ug/l | 1 | - | U | Yes   |
| 2-Methylnaphthalene         | 1.0  | ug/l | 1 | - | U | Yes   |
| 2-Nitroaniline              | 5.0  | ug/l | 1 | - | U | Yes   |
| 3-Nitroaniline              | 5.0  | ug/l | 1 | - | U | Yes   |
| 4-Nitroaniline              | 5.0  | ug/l | 1 | - | U | Yes   |
| Nitrobenzene                | 2.0  | ug/l | 1 | - | U | Yes   |
| N-Nitroso-di-n-propylamine  | 2.0  | ug/l | 1 | - | U | Yes   |
| Nitrosodiphenylamine        | 5.0  | ug/l | 1 | - | U | Yes   |
| Phenanthrene                | 1.0  | ug/l | 1 | - | U | Yes   |
| Pyrene                      | 1.0  | ug/l | 1 | - | U | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.0  | ug/l | 1 | - | U | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.050 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.050 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.10  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.10  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.10  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.10  | ug/l | 1 | - | U | Yes |



Sample ID: JC34340-8  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.4    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 1.5    | ug/l  | 1               | J        | J          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethyl)ether    | 2.2    | ug/l  | 1               | -        | U          | Yes        |

|                             |      |      |   |   |    |      |
|-----------------------------|------|------|---|---|----|------|
| bis(2-Chloroisopropyl)ether | 2.2  | ug/l | 1 | - | U  | Yes  |
| 4-Chlorophenyl phenyl ether | 2.2  | ug/l | 1 | - | U  | Yes  |
| 2,4-Dinitrotoluene          | 1.1  | ug/l | 1 | - | U  | Yes  |
| 2,6-Dinitrotoluene          | 1.1  | ug/l | 1 | - | U  | Yes  |
| 3,3'-Dichlorobenzidine      | 2.2  | ug/l | 1 | - | U  | Yes  |
| 1,4-Dioxane                 | 220  | ug/l | 5 | - | J  | Yes✓ |
| Dibenzo(a,h)anthracene      | 1.1  | ug/l | 1 | - | U  | Yes  |
| Dibenzofuran                | 5.5  | ug/l | 1 | - | U  | Yes  |
| Di-n-butyl phthalate        | 2.2  | ug/l | 1 | - | U  | Yes  |
| Di-n-octyl phthalate        | 2.2  | ug/l | 1 | - | U  | Yes  |
| Diethyl phthalate           | 2.2  | ug/l | 1 | - | U  | Yes  |
| Dimethyl phthalate          | 2.2  | ug/l | 1 | - | U  | Yes  |
| bis(2-Ethylhexyl)phthalate  | 3.8  | ug/l | 1 | - | -  | Yes  |
| Fluoranthene                | 0.50 | ug/l | 1 | J | J  | Yes  |
| Fluorene                    | 1.1  | ug/l | 1 | - | U  | Yes  |
| Hexachlorobenzene           | 1.1  | ug/l | 1 | - | U  | Yes  |
| Hexachlorobutadiene         | 1.1  | ug/l | 1 | - | UJ | Yes✓ |
| Hexachlorocyclopentadiene   | 11   | ug/l | 1 | - | U  | Yes  |
| Hexachloroethane            | 2.2  | ug/l | 1 | - | U  | Yes  |
| Indeno(1,2,3-cd)pyrene      | 1.0  | ug/l | 1 | - | U  | Yes  |
| Isophorone                  | 2.2  | ug/l | 1 | - | U  | Yes  |
| 1-Methylnaphthalene         | 1.1  | ug/l | 1 | - | U  | Yes  |
| 2-Methylnaphthalene         | 1.1  | ug/l | 1 | - | U  | Yes  |
| 2-Nitroaniline              | 5.5  | ug/l | 1 | - | U  | Yes  |
| 3-Nitroaniline              | 5.5  | ug/l | 1 | - | U  | Yes  |
| 4-Nitroaniline              | 5.5  | ug/l | 1 | - | U  | Yes  |
| Nitrobenzene                | 2.2  | ug/l | 1 | - | U  | Yes  |
| N-Nitroso-di-n-propylamine  | 2.2  | ug/l | 1 | - | U  | Yes  |
| Nitrosodiphenylamine        | 5.5  | ug/l | 1 | - | U  | Yes  |
| Phenanthrene                | 1.1  | ug/l | 1 | - | U  | Yes  |
| Pyrene                      | 1.1  | ug/l | 1 | - | U  | Yes  |
| 1,2,4,5-Tetrachlorobenzene  | 2.2  | ug/l | 1 | - | U  | Yes  |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.055 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.055 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.11  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-9  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.3    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.3    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.1    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.1    | ug/l  | 1               | -        | U          | Yes        |

|                             |      |      |   |   |    |       |
|-----------------------------|------|------|---|---|----|-------|
| bis(2-Chloroethyl)ether     | 2.1  | ug/l | 1 | - | U  | Yes   |
| bis(2-Chloroisopropyl)ether | 2.1  | ug/l | 1 | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.1  | ug/l | 1 | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.1  | ug/l | 1 | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.1  | ug/l | 1 | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.1  | ug/l | 1 | - | U  | Yes   |
| 1,4-Dioxane                 | 19.3 | ug/l | 1 | - | -  | Yes   |
| Dibenzo(a,h)anthracene      | 1.1  | ug/l | 1 | - | U  | Yes   |
| Dibenzofuran                | 5.3  | ug/l | 1 | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.1  | ug/l | 1 | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.1  | ug/l | 1 | - | U  | Yes   |
| Diethyl phthalate           | 2.1  | ug/l | 1 | - | U  | Yes   |
| Dimethyl phthalate          | 2.1  | ug/l | 1 | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.1  | ug/l | 1 | - | U  | Yes   |
| Fluoranthene                | 1.1  | ug/l | 1 | - | U  | Yes   |
| Fluorene                    | 1.1  | ug/l | 1 | - | U  | Yes   |
| Hexachlorobenzene           | 1.1  | ug/l | 1 | - | U  | Yes   |
| Hexachlorobutadiene         | 1.1  | ug/l | 1 | - | UJ | Yes ✓ |
| Hexachlorocyclopentadiene   | 11   | ug/l | 1 | - | U  | Yes   |
| Hexachloroethane            | 2.1  | ug/l | 1 | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.1  | ug/l | 1 | - | U  | Yes   |
| Isophorone                  | 2.1  | ug/l | 1 | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.1  | ug/l | 1 | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.1  | ug/l | 1 | - | U  | Yes   |
| 2-Nitroaniline              | 5.3  | ug/l | 1 | - | U  | Yes   |
| 3-Nitroaniline              | 5.3  | ug/l | 1 | - | U  | Yes   |
| 4-Nitroaniline              | 5.3  | ug/l | 1 | - | U  | Yes   |
| Nitrobenzene                | 2.1  | ug/l | 1 | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.1  | ug/l | 1 | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.3  | ug/l | 1 | - | U  | Yes   |
| Phenanthrene                | 1.1  | ug/l | 1 | - | U  | Yes   |
| Pyrene                      | 1.1  | ug/l | 1 | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.1  | ug/l | 1 | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.053 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.053 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.11  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-10  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 10     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 10     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.0    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.1    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.0    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.0    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.0    | ug/l  | 1               | -        | U          | Yes        |

|                             |      |      |   |   |    |       |
|-----------------------------|------|------|---|---|----|-------|
| bis(2-Chloroethyl)ether     | 2.0  | ug/l | 1 | - | U  | Yes   |
| bis(2-Chloroisopropyl)ether | 2.0  | ug/l | 1 | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.0  | ug/l | 1 | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.0  | ug/l | 1 | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.0  | ug/l | 1 | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.0  | ug/l | 1 | - | U  | Yes   |
| 1,4-Dioxane                 | 27.6 | ug/l | 1 | - | -  | Yes   |
| Dibenzo(a,h)anthracene      | 1.0  | ug/l | 1 | - | U  | Yes   |
| Dibenzofuran                | 5.1  | ug/l | 1 | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.0  | ug/l | 1 | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.0  | ug/l | 1 | - | U  | Yes   |
| Diethyl phthalate           | 2.0  | ug/l | 1 | - | U  | Yes   |
| Dimethyl phthalate          | 2.0  | ug/l | 1 | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.0  | ug/l | 1 | - | U  | Yes   |
| Fluoranthene                | 1.0  | ug/l | 1 | - | U  | Yes   |
| Fluorene                    | 1.0  | ug/l | 1 | - | U  | Yes   |
| Hexachlorobenzene           | 1.0  | ug/l | 1 | - | U  | Yes   |
| Hexachlorobutadiene         | 1.0  | ug/l | 1 | - | UJ | Yes ✓ |
| Hexachlorocyclopentadiene   | 10   | ug/l | 1 | - | U  | Yes   |
| Hexachloroethane            | 2.0  | ug/l | 1 | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.0  | ug/l | 1 | - | U  | Yes   |
| Isophorone                  | 2.0  | ug/l | 1 | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.0  | ug/l | 1 | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.0  | ug/l | 1 | - | U  | Yes   |
| 2-Nitroaniline              | 5.1  | ug/l | 1 | - | U  | Yes   |
| 3-Nitroaniline              | 5.1  | ug/l | 1 | - | U  | Yes   |
| 4-Nitroaniline              | 5.1  | ug/l | 1 | - | U  | Yes   |
| Nitrobenzene                | 2.0  | ug/l | 1 | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.0  | ug/l | 1 | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.1  | ug/l | 1 | - | U  | Yes   |
| Phenanthrene                | 1.0  | ug/l | 1 | - | U  | Yes   |
| Pyrene                      | 1.0  | ug/l | 1 | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.0  | ug/l | 1 | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.051 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.051 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.10  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.10  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.10  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.10  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.10  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-11  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.4    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.5    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |

|                             |     |      |   |   |    |       |
|-----------------------------|-----|------|---|---|----|-------|
| bis(2-Chloroethoxy)methane  | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Chloroethyl)ether     | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Chloroisopropyl)ether | 2.2 | ug/l | 1 | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.2 | ug/l | 1 | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.2 | ug/l | 1 | - | U  | Yes   |
| Dibenzo(a,h)anthracene      | 1.1 | ug/l | 1 | - | U  | Yes   |
| Dibenzofuran                | 5.5 | ug/l | 1 | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes   |
| Diethyl phthalate           | 2.2 | ug/l | 1 | - | U  | Yes   |
| Dimethyl phthalate          | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.2 | ug/l | 1 | - | U  | Yes   |
| Fluoranthene                | 1.1 | ug/l | 1 | - | U  | Yes   |
| Fluorene                    | 1.1 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobenzene           | 1.1 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobutadiene         | 1.1 | ug/l | 1 | - | UJ | Yes ✓ |
| Hexachlorocyclopentadiene   | 11  | ug/l | 1 | - | U  | Yes   |
| Hexachloroethane            | 2.2 | ug/l | 1 | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.1 | ug/l | 1 | - | U  | Yes   |
| Isophorone                  | 2.2 | ug/l | 1 | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2-Nitroaniline              | 5.5 | ug/l | 1 | - | U  | Yes   |
| 3-Nitroaniline              | 5.5 | ug/l | 1 | - | U  | Yes   |
| 4-Nitroaniline              | 5.5 | ug/l | 1 | - | U  | Yes   |
| Nitrobenzene                | 2.2 | ug/l | 1 | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.2 | ug/l | 1 | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.5 | ug/l | 1 | - | U  | Yes   |
| Phenanthrene                | 1.1 | ug/l | 1 | - | U  | Yes   |
| Pyrene                      | 1.1 | ug/l | 1 | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.2 | ug/l | 1 | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.055 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.055 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.11  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 0.311 | ug/l | 1 | - | - | Yes |



Sample ID: JC34340-12  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: AQ - Field Blank Water

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.3    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,5-Trichlorophenol      | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethyl)ether    | 2.2    | ug/l  | 1               | -        | U          | Yes        |

|                             |     |      |   |   |    |       |
|-----------------------------|-----|------|---|---|----|-------|
| bis(2-Chloroisopropyl)ether | 2.2 | ug/l | 1 | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.2 | ug/l | 1 | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.2 | ug/l | 1 | - | U  | Yes   |
| Dibenzo(a,h)anthracene      | 1.1 | ug/l | 1 | - | U  | Yes   |
| Dibenzofuran                | 5.4 | ug/l | 1 | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes   |
| Diethyl phthalate           | 2.2 | ug/l | 1 | - | U  | Yes   |
| Dimethyl phthalate          | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 1.9 | ug/l | 1 | J | J  | Yes   |
| Fluoranthene                | 1.1 | ug/l | 1 | - | U  | Yes   |
| Fluorene                    | 1.1 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobenzene           | 1.1 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobutadiene         | 1.1 | ug/l | 1 | - | UJ | Yes ✓ |
| Hexachlorocyclopentadiene   | 11  | ug/l | 1 | - | U  | Yes   |
| Hexachloroethane            | 2.2 | ug/l | 1 | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.1 | ug/l | 1 | - | U  | Yes   |
| Isophorone                  | 2.2 | ug/l | 1 | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2-Nitroaniline              | 5.4 | ug/l | 1 | - | U  | Yes   |
| 3-Nitroaniline              | 5.4 | ug/l | 1 | - | U  | Yes   |
| 4-Nitroaniline              | 5.4 | ug/l | 1 | - | U  | Yes   |
| Nitrobenzene                | 2.2 | ug/l | 1 | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.2 | ug/l | 1 | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.4 | ug/l | 1 | - | U  | Yes   |
| Phenanthrene                | 1.1 | ug/l | 1 | - | U  | Yes   |
| Pyrene                      | 1.1 | ug/l | 1 | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.2 | ug/l | 1 | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.054 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.054 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.11  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 0.11  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-15

Sample location: BMSMC Building 5 Area

Sampling date: 12/22/2016

Matrix: AQ- Equipment Blank

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.4    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.6    | ug/l  | 1               | -        | UJ         | Yes ✓      |
| 2,4,5-Trichlorophenol      | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.6    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |

|                             |     |      |   |   |    |       |
|-----------------------------|-----|------|---|---|----|-------|
| bis(2-Chloroethoxy)methane  | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Chloroethyl)ether     | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Chloroisopropyl)ether | 2.2 | ug/l | 1 | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.2 | ug/l | 1 | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.1 | ug/l | 1 | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.2 | ug/l | 1 | - | U  | Yes   |
| Dibenzo(a,h)anthracene      | 1.1 | ug/l | 1 | - | U  | Yes   |
| Dibenzofuran                | 5.6 | ug/l | 1 | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.2 | ug/l | 1 | - | U  | Yes   |
| Diethyl phthalate           | 2.2 | ug/l | 1 | - | U  | Yes   |
| Dimethyl phthalate          | 2.2 | ug/l | 1 | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.2 | ug/l | 1 | - | U  | Yes   |
| Fluoranthene                | 1.1 | ug/l | 1 | - | U  | Yes   |
| Fluorene                    | 1.1 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobenzene           | 1.1 | ug/l | 1 | - | U  | Yes   |
| Hexachlorobutadiene         | 1.1 | ug/l | 1 | - | UJ | Yes ✓ |
| Hexachlorocyclopentadiene   | 11  | ug/l | 1 | - | U  | Yes   |
| Hexachloroethane            | 2.2 | ug/l | 1 | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.1 | ug/l | 1 | - | U  | Yes   |
| Isophorone                  | 2.2 | ug/l | 1 | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.1 | ug/l | 1 | - | U  | Yes   |
| 2-Nitroaniline              | 5.6 | ug/l | 1 | - | U  | Yes   |
| 3-Nitroaniline              | 5.6 | ug/l | 1 | - | U  | Yes   |
| 4-Nitroaniline              | 5.6 | ug/l | 1 | - | U  | Yes   |
| Nitrobenzene                | 2.2 | ug/l | 1 | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.2 | ug/l | 1 | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.6 | ug/l | 1 | - | U  | Yes   |
| Phenanthrene                | 1.1 | ug/l | 1 | - | U  | Yes   |
| Pyrene                      | 1.1 | ug/l | 1 | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.2 | ug/l | 1 | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.056 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.056 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.11  | ug/l | 1 | - | U | Yes |
| 1,4-Dioxane            | 0.11  | ug/l | 1 | - | U | Yes |

Sample ID: JC34340-16  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol             | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloro-3-methyl phenol   | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dichlorophenol         | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dimethylphenol         | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4-Dinitrophenol          | 11     | ug/l  | 1               | -        | U          | Yes        |
| 4,6-Dinitro-o-cresol       | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2-Methylphenol             | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 3&4-Methylphenol           | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2-Nitrophenol              | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 4-Nitrophenol              | 11     | ug/l  | 1               | -        | U          | Yes        |
| Pentachlorophenol          | 4.3    | ug/l  | 1               | -        | U          | Yes        |
| Phenol                     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 2,3,4,6-Tetrachlorophenol  | 5.4    | ug/l  | 1               | -        | UJ         | Yes ✓      |
| 2,4,5,4-Trichlorophenol    | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| 2,4,6-Trichlorophenol      | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthene               | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acenaphthylene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Acetophenone               | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Anthracene                 | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Atrazine                   | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Benzaldehyde               | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)anthracene         | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(a)pyrene             | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(b)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(g,h,i)perylene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Benzo(k)fluoranthene       | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 4-Bromophenyl phenyl ether | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Butyl benzyl phthalate     | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 1,1'-Biphenyl              | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| 2-Chloronaphthalene        | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| 4-Chloroaniline            | 5.4    | ug/l  | 1               | -        | U          | Yes        |
| Carbazole                  | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| Caprolactam                | 2.2    | ug/l  | 1               | -        | U          | Yes        |
| Chrysene                   | 1.1    | ug/l  | 1               | -        | U          | Yes        |
| bis(2-Chloroethoxy)methane | 2.2    | ug/l  | 1               | -        | U          | Yes        |

|                             |      |      |    |   |    |       |
|-----------------------------|------|------|----|---|----|-------|
| bis(2-Chloroethyl)ether     | 2.2  | ug/l | 1  | - | UJ | Yes ✓ |
| bis(2-Chloroisopropyl)ether | 2.2  | ug/l | 1  | - | U  | Yes   |
| 4-Chlorophenyl phenyl ether | 2.2  | ug/l | 1  | - | U  | Yes   |
| 2,4-Dinitrotoluene          | 1.1  | ug/l | 1  | - | U  | Yes   |
| 2,6-Dinitrotoluene          | 1.1  | ug/l | 1  | - | U  | Yes   |
| 3,3'-Dichlorobenzidine      | 2.2  | ug/l | 1  | - | U  | Yes   |
| 1,4-Dioxane                 | 1520 | ug/l | 50 | - | -  | Yes   |
| Dibenzo(a,h)anthracene      | 1.1  | ug/l | 1  | - | U  | Yes   |
| Dibenzofuran                | 5.4  | ug/l | 1  | - | U  | Yes   |
| Di-n-butyl phthalate        | 2.2  | ug/l | 1  | - | U  | Yes   |
| Di-n-octyl phthalate        | 2.2  | ug/l | 1  | - | U  | Yes   |
| Diethyl phthalate           | 2.2  | ug/l | 1  | - | U  | Yes   |
| Dimethyl phthalate          | 2.2  | ug/l | 1  | - | U  | Yes   |
| bis(2-Ethylhexyl)phthalate  | 2.2  | ug/l | 1  | - | U  | Yes   |
| Fluoranthene                | 1.1  | ug/l | 1  | - | U  | Yes   |
| Fluorene                    | 1.1  | ug/l | 1  | - | U  | Yes   |
| Hexachlorobenzene           | 1.1  | ug/l | 1  | - | U  | Yes   |
| Hexachlorobutadiene         | 1.1  | ug/l | 1  | - | UJ | Yes ✓ |
| Hexachlorocyclopentadiene   | 11   | ug/l | 1  | - | U  | Yes   |
| Hexachloroethane            | 2.2  | ug/l | 1  | - | U  | Yes   |
| Indeno(1,2,3-cd)pyrene      | 1.1  | ug/l | 1  | - | U  | Yes   |
| Isophorone                  | 2.2  | ug/l | 1  | - | U  | Yes   |
| 1-Methylnaphthalene         | 1.1  | ug/l | 1  | - | U  | Yes   |
| 2-Methylnaphthalene         | 1.1  | ug/l | 1  | - | U  | Yes   |
| 2-Nitroaniline              | 5.4  | ug/l | 1  | - | U  | Yes   |
| 3-Nitroaniline              | 5.4  | ug/l | 1  | - | U  | Yes   |
| 4-Nitroaniline              | 5.4  | ug/l | 1  | - | U  | Yes   |
| Nitrobenzene                | 2.2  | ug/l | 1  | - | U  | Yes   |
| N-Nitroso-di-n-propylamine  | 2.2  | ug/l | 1  | - | U  | Yes   |
| Nitrosodiphenylamine        | 5.4  | ug/l | 1  | - | U  | Yes   |
| Phenanthrene                | 1.1  | ug/l | 1  | - | U  | Yes   |
| Pyrene                      | 1.1  | ug/l | 1  | - | U  | Yes   |
| 1,2,4,5-Tetrachlorobenzene  | 2.2  | ug/l | 1  | - | U  | Yes   |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.054 | ug/l | 1 | - | U | Yes |
| Benzo(a)pyrene         | 0.054 | ug/l | 1 | - | U | Yes |
| Benzo(b)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Benzo(k)fluoranthene   | 0.11  | ug/l | 1 | - | U | Yes |
| Chrysene               | 0.11  | ug/l | 1 | - | U | Yes |
| Dibenzo(a,h)anthracene | 0.11  | ug/l | 1 | - | U | Yes |
| Indeno(1,2,3-cd)pyrene | 0.11  | ug/l | 1 | - | U | Yes |
| Naphthalene            | 0.236 | ug/l | 1 | - | - | Yes |

Sample ID: JC34340-16MS  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name                | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol              | 31.3   | ug/l  | 1               | -        | -          | Yes        |
| 4-Chloro-3-methyl phenol    | 37.7   | ug/l  | 1               | -        | -          | Yes        |
| 2,4-Dichlorophenol          | 41.8   | ug/l  | 1               | -        | -          | Yes        |
| 2,4-Dimethylphenol          | 40.7   | ug/l  | 1               | -        | -          | Yes        |
| 2,4-Dinitrophenol           | 102    | ug/l  | 1               | -        | -          | Yes        |
| 4,6-Dinitro-o-cresol        | 49.0   | ug/l  | 1               | -        | -          | Yes        |
| 2-Methylphenol              | 30.0   | ug/l  | 1               | -        | -          | Yes        |
| 3&4-Methylphenol            | 29.0   | ug/l  | 1               | -        | -          | Yes        |
| 2-Nitrophenol               | 36.2   | ug/l  | 1               | -        | -          | Yes        |
| 4-Nitrophenol               | 34.0   | ug/l  | 1               | -        | -          | Yes        |
| Pentachlorophenol           | 54.7   | ug/l  | 1               | -        | -          | Yes        |
| Phenol                      | 18.2   | ug/l  | 1               | -        | -          | Yes        |
| 2,3,4,6-Tetrachlorophenol   | 47.0   | ug/l  | 1               | -        | -          | Yes        |
| 2,4,5-Trichlorophenol       | 44.3   | ug/l  | 1               | -        | -          | Yes        |
| 2,4,6-Trichlorophenol       | 45.4   | ug/l  | 1               | -        | -          | Yes        |
| Acenaphthene                | 40.0   | ug/l  | 1               | -        | -          | Yes        |
| Acenaphthylene              | 36.5   | ug/l  | 1               | -        | -          | Yes        |
| Acetophenone                | 37.2   | ug/l  | 1               | -        | -          | Yes        |
| Anthracene                  | 41.8   | ug/l  | 1               | -        | -          | Yes        |
| Atrazine                    | 52.6   | ug/l  | 1               | -        | -          | Yes        |
| Benzaldehyde                | 30.0   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(a)anthracene          | 42.8   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(a)pyrene              | 41.4   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(b)fluoranthene        | 43.5   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(g,h,i)perylene        | 35.3   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(k)fluoranthene        | 42.2   | ug/l  | 1               | -        | -          | Yes        |
| 4-Bromophenyl phenyl ether  | 43.9   | ug/l  | 1               | -        | -          | Yes        |
| Butyl benzyl phthalate      | 35.2   | ug/l  | 1               | -        | -          | Yes        |
| 1,1'-Biphenyl               | 37.4   | ug/l  | 1               | -        | -          | Yes        |
| 2-Chloronaphthalene         | 37.9   | ug/l  | 1               | -        | -          | Yes        |
| 4-Chloroaniline             | 22.2   | ug/l  | 1               | -        | -          | Yes        |
| Carbazole                   | 39.4   | ug/l  | 1               | -        | -          | Yes        |
| Caprolactam                 | 10.9   | ug/l  | 1               | -        | -          | Yes        |
| Chrysene                    | 39.8   | ug/l  | 1               | -        | -          | Yes        |
| bis(2-Chloroethoxy)methane  | 33.1   | ug/l  | 1               | -        | -          | Yes        |
| bis(2-Chloroethyl)ether     | 32.6   | ug/l  | 1               | -        | -          | Yes        |
| bis(2-Chloroisopropyl)ether | 31.4   | ug/l  | 1               | -        | -          | Yes        |

|                             |      |      |   |   |   |     |
|-----------------------------|------|------|---|---|---|-----|
| 4-Chlorophenyl phenyl ether | 45.6 | ug/l | 1 | - | - | Yes |
| 2,4-Dinitrotoluene          | 47.3 | ug/l | 1 | - | - | Yes |
| 2,6-Dinitrotoluene          | 44.9 | ug/l | 1 | - | - | Yes |
| 3,3'-Dichlorobenzidine      | 36.7 | ug/l | 1 | - | - | Yes |
| 1,4-Dioxane                 | 1580 | ug/l | 1 | - | - | Yes |
| Dibenzo(a,h)anthracene      | 37.2 | ug/l | 1 | - | - | Yes |
| Dibenzofuran                | 39.7 | ug/l | 1 | - | - | Yes |
| Di-n-butyl phthalate        | 39.4 | ug/l | 1 | - | - | Yes |
| Di-n-octyl phthalate        | 36.8 | ug/l | 1 | - | - | Yes |
| Diethyl phthalate           | 40.9 | ug/l | 1 | - | - | Yes |
| Dimethyl phthalate          | 41.0 | ug/l | 1 | - | - | Yes |
| bis(2-Ethylhexyl)phthalate  | 34.0 | ug/l | 1 | - | - | Yes |
| Fluoranthene                | 45.8 | ug/l | 1 | - | - | Yes |
| Fluorene                    | 43.6 | ug/l | 1 | - | - | Yes |
| Hexachlorobenzene           | 44.1 | ug/l | 1 | - | - | Yes |
| Hexachlorobutadiene         | 37.5 | ug/l | 1 | - | - | Yes |
| Hexachlorocyclopentadiene   | 64.3 | ug/l | 1 | - | - | Yes |
| Hexachloroethane            | 33.8 | ug/l | 1 | - | - | Yes |
| Indeno(1,2,3-cd)pyrene      | 39.8 | ug/l | 1 | - | - | Yes |
| Isophorone                  | 34.9 | ug/l | 1 | - | - | Yes |
| 1-Methylnaphthalene         | 36.1 | ug/l | 1 | - | - | Yes |
| 2-Methylnaphthalene         | 37.4 | ug/l | 1 | - | - | Yes |
| 2-Nitroaniline              | 39.9 | ug/l | 1 | - | - | Yes |
| 3-Nitroaniline              | 24.4 | ug/l | 1 | - | - | Yes |
| 4-Nitroaniline              | 37.1 | ug/l | 1 | - | - | Yes |
| Nitrobenzene                | 34.9 | ug/l | 1 | - | - | Yes |
| N-Nitroso-di-n-propylamine  | 34.3 | ug/l | 1 | - | - | Yes |
| Nitrosodiphenylamine        | 39.7 | ug/l | 1 | - | - | Yes |
| Phenanthrene                | 41.8 | ug/l | 1 | - | - | Yes |
| Pyrene                      | 39.8 | ug/l | 1 | - | - | Yes |
| 1,2,4,5-Tetrachlorobenzene  | 48.5 | ug/l | 1 | - | - | Yes |

METHOD: 8270D (SIM)

|                        |       |      |   |    |    |     |
|------------------------|-------|------|---|----|----|-----|
| Benzo(a)anthracene     | 0.773 | ug/l | 1 | -  | -  | Yes |
| Benzo(a)pyrene         | 0.675 | ug/l | 1 | -  | -  | Yes |
| Benzo(b)fluoranthene   | 0.756 | ug/l | 1 | -  | -  | Yes |
| Benzo(k)fluoranthene   | 0.712 | ug/l | 1 | -  | -  | Yes |
| Chrysene               | 0.740 | ug/l | 1 | -  | -  | Yes |
| Dibenzo(a,h)anthracene | 0.557 | ug/l | 1 | -  | -  | Yes |
| Indeno(1,2,3-cd)pyrene | 0.515 | ug/l | 1 | -  | -  | Yes |
| Naphthalene            | 0.875 | ug/l | 1 | -  | -  | Yes |
| 1,4-Dioxane            | 1240  | ug/l | 1 | EB | EB | Yes |



Sample ID: JC34340-16MSD  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: Groundwater

METHOD: 8270D

| Analyte Name                | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|-----------------|----------|------------|------------|
| 2-Chlorophenol              | 30.9   | ug/l  | 1               | -        | -          | Yes        |
| 4-Chloro-3-methyl phenol    | 36.5   | ug/l  | 1               | -        | -          | Yes        |
| 2,4-Dichlorophenol          | 40.5   | ug/l  | 1               | -        | -          | Yes        |
| 2,4-Dimethylphenol          | 39.4   | ug/l  | 1               | -        | -          | Yes        |
| 2,4-Dinitrophenol           | 98.6   | ug/l  | 1               | -        | -          | Yes        |
| 4,6-Dinitro-o-cresol        | 45.7   | ug/l  | 1               | -        | -          | Yes        |
| 2-Methylphenol              | 30.5   | ug/l  | 1               | -        | -          | Yes        |
| 3&4-Methylphenol            | 28.3   | ug/l  | 1               | -        | -          | Yes        |
| 2-Nitrophenol               | 35.4   | ug/l  | 1               | -        | -          | Yes        |
| 4-Nitrophenol               | 33.6   | ug/l  | 1               | -        | -          | Yes        |
| Pentachlorophenol           | 50.7   | ug/l  | 1               | -        | -          | Yes        |
| Phenol                      | 17.9   | ug/l  | 1               | -        | -          | Yes        |
| 2,3,4,6-Tetrachlorophenol   | 45.7   | ug/l  | 1               | -        | -          | Yes        |
| 2,4,5-Trichlorophenol       | 43.1   | ug/l  | 1               | -        | -          | Yes        |
| 2,4,6-Trichlorophenol       | 43.7   | ug/l  | 1               | -        | -          | Yes        |
| Acenaphthene                | 37.8   | ug/l  | 1               | -        | -          | Yes        |
| Acenaphthylene              | 34.3   | ug/l  | 1               | -        | -          | Yes        |
| Acetophenone                | 35.8   | ug/l  | 1               | -        | -          | Yes        |
| Anthracene                  | 39.0   | ug/l  | 1               | -        | -          | Yes        |
| Atrazine                    | 49.5   | ug/l  | 1               | -        | -          | Yes        |
| Benzaldehyde                | 29.4   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(a)anthracene          | 40.2   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(a)pyrene              | 39.6   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(b)fluoranthene        | 41.7   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(g,h,i)perylene        | 33.4   | ug/l  | 1               | -        | -          | Yes        |
| Benzo(k)fluoranthene        | 39.4   | ug/l  | 1               | -        | -          | Yes        |
| 4-Bromophenyl phenyl ether  | 40.3   | ug/l  | 1               | -        | -          | Yes        |
| Butyl benzyl phthalate      | 33.2   | ug/l  | 1               | -        | -          | Yes        |
| 1,1'-Biphenyl               | 35.3   | ug/l  | 1               | -        | -          | Yes        |
| 2-Chloronaphthalene         | 35.7   | ug/l  | 1               | -        | -          | Yes        |
| 4-Chloroaniline             | 20.5   | ug/l  | 1               | -        | -          | Yes        |
| Carbazole                   | 37.3   | ug/l  | 1               | -        | -          | Yes        |
| Caprolactam                 | 11.1   | ug/l  | 1               | -        | -          | Yes        |
| Chrysene                    | 37.7   | ug/l  | 1               | -        | -          | Yes        |
| bis(2-Chloroethoxy)methane  | 31.0   | ug/l  | 1               | -        | -          | Yes        |
| bis(2-Chloroethyl)ether     | 33.7   | ug/l  | 1               | -        | -          | Yes        |
| bis(2-Chloroisopropyl)ether | 31.2   | ug/l  | 1               | -        | -          | Yes        |

|                             |      |      |   |   |   |     |
|-----------------------------|------|------|---|---|---|-----|
| 4-Chlorophenyl phenyl ether | 43.0 | ug/l | 1 | - | - | Yes |
| 2,4-Dinitrotoluene          | 46.4 | ug/l | 1 | - | - | Yes |
| 2,6-Dinitrotoluene          | 42.7 | ug/l | 1 | - | - | Yes |
| 3,3'-Dichlorobenzidine      | 27.1 | ug/l | 1 | - | - | Yes |
| 1,4-Dioxane                 | 1800 | ug/l | 1 | - | - | Yes |
| Dibenzo(a,h)anthracene      | 34.8 | ug/l | 1 | - | - | Yes |
| Dibenzofuran                | 38.5 | ug/l | 1 | - | - | Yes |
| Di-n-butyl phthalate        | 37.4 | ug/l | 1 | - | - | Yes |
| Di-n-octyl phthalate        | 34.7 | ug/l | 1 | - | - | Yes |
| Diethyl phthalate           | 39.5 | ug/l | 1 | - | - | Yes |
| Dimethyl phthalate          | 40.0 | ug/l | 1 | - | - | Yes |
| bis(2-Ethylhexyl)phthalate  | 32.1 | ug/l | 1 | - | - | Yes |
| Fluoranthene                | 42.8 | ug/l | 1 | - | - | Yes |
| Fluorene                    | 41.6 | ug/l | 1 | - | - | Yes |
| Hexachlorobenzene           | 40.6 | ug/l | 1 | - | - | Yes |
| Hexachlorobutadiene         | 36.9 | ug/l | 1 | - | - | Yes |
| Hexachlorocyclopentadiene   | 63.4 | ug/l | 1 | - | - | Yes |
| Hexachloroethane            | 35.0 | ug/l | 1 | - | - | Yes |
| Indeno(1,2,3-cd)pyrene      | 37.3 | ug/l | 1 | - | - | Yes |
| Isophorone                  | 33.3 | ug/l | 1 | - | - | Yes |
| 1-Methylnaphthalene         | 34.2 | ug/l | 1 | - | - | Yes |
| 2-Methylnaphthalene         | 35.1 | ug/l | 1 | - | - | Yes |
| 2-Nitroaniline              | 40.0 | ug/l | 1 | - | - | Yes |
| 3-Nitroaniline              | 26.5 | ug/l | 1 | - | - | Yes |
| 4-Nitroaniline              | 34.3 | ug/l | 1 | - | - | Yes |
| Nitrobenzene                | 33.0 | ug/l | 1 | - | - | Yes |
| N-Nitroso-di-n-propylamine  | 33.2 | ug/l | 1 | - | - | Yes |
| Nitrosodiphenylamine        | 36.7 | ug/l | 1 | - | - | Yes |
| Phenanthrene                | 39.4 | ug/l | 1 | - | - | Yes |
| Pyrene                      | 37.9 | ug/l | 1 | - | - | Yes |
| 1,2,4,5-Tetrachlorobenzene  | 45.2 | ug/l | 1 | - | - | Yes |

METHOD: 8270D (SIM)

|                        |       |      |   |   |   |     |
|------------------------|-------|------|---|---|---|-----|
| Benzo(a)anthracene     | 0.591 | ug/l | 1 | - | - | Yes |
| Benzo(a)pyrene         | 0.420 | ug/l | 1 | - | - | Yes |
| Benzo(b)fluoranthene   | 0.549 | ug/l | 1 | - | - | Yes |
| Benzo(k)fluoranthene   | 0.481 | ug/l | 1 | - | - | Yes |
| Chrysene               | 0.576 | ug/l | 1 | - | - | Yes |
| Dibenzo(a,h)anthracene | 0.352 | ug/l | 1 | - | - | Yes |
| Indeno(1,2,3-cd)pyrene | 0.314 | ug/l | 1 | - | - | Yes |
| Naphthalene            | 0.730 | ug/l | 1 | - | - | Yes |
| 1,4-Dioxane            | 1450  | ug/l | 1 | - | - | Yes |

# DATA REVIEW WORKSHEETS

Project Number: JC34340  
 Date: December 20-22, 2016  
 Shipping Date: December 22, 2016  
 EPA Region: 2

## REVIEW OF SEMIVOLATILE ORGANIC PACKAGE

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: EPA Hazardous Waste Support Section, SOP HW-35A, July 2015 –Revision 0. *Semivolatile Data Validation*. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Accutest data package received has been reviewed and the quality control and performance data summarized. The data review for SVOCs included:

Lab. Project/SDG No.: JC34340 Sample matrix: Groundwater  
 No. of Samples: 14 SIM/14 SCAN  
 Trip blank No.: -  
 Field blank No.: JC34340-3; JC34340-12  
 Equipment blank No.: JC34340-4; JC34340-15  
 Field duplicate No.: JC34340-7/JC34340-8

|   |   |
|---|---|
| <input checked="" type="checkbox"/> Data Completeness                   | <input checked="" type="checkbox"/> Laboratory Control Spikes |
| <input checked="" type="checkbox"/> Holding Times                       | <input checked="" type="checkbox"/> Field Duplicates          |
| <input checked="" type="checkbox"/> GC/MS Tuning                        | <input checked="" type="checkbox"/> Calibrations              |
| <input checked="" type="checkbox"/> Internal Standard Performance       | <input checked="" type="checkbox"/> Compound Identifications  |
| <input checked="" type="checkbox"/> Blanks                              | <input checked="" type="checkbox"/> Compound Quantitation     |
| <input checked="" type="checkbox"/> Surrogate Recoveries                | <input checked="" type="checkbox"/> Quantitation Limits       |
| <input checked="" type="checkbox"/> Matrix Spike/Matrix Spike Duplicate |   |

Overall Comments: SVOCs TCL special list analyzed by method SW846-8270D; Selected PAHs and 1,4-Dioxane analyzed by method SW846-8270D (SIM)

### Definition of Qualifiers:

J- Estimated results  
 U- Compound not detected  
 R- Rejected data  
 UJ- Estimated nondetect

Reviewer: \_\_\_\_\_  
 Date: January 27, 2017

## DATA COMPLETENESS

DATE RECEIVED

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. A dashed diagonal line runs across the page from the upper-left corner towards the lower-right corner. The paper appears to be a template for a document or a notebook page.

# DATA REVIEW WORKSHEETS

All criteria were met X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

## HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

| SAMPLE ID   | DATE SAMPLED | DATE EXTRACTED/ANALYZED | pH | ACTION   |
|---|--------------|-------------------------|----|--|
| JC34340-3   | 12/20/16     | 12/29/16                | -  | Confirmation run; the acid spike standard was not added to the LCS. No action. |
|   |              |                         |    |  |
| All samples extracted and analyzed within method recommended holding time except for the cases described in this document. Sample preservation appropriate. |              |                         |    |  |
|   |              |                         |    |  |

Cooler temperature (Criteria:  $4 \pm 2$  °C): 5.4°C

## Actions

Results will be qualified based on the criteria of the following Table:

**Table 1. Holding Time Actions for Semivolatile Analyses**

| Matrix      | Preserved | Criteria   | Action                        |                                   |
|-------------|-----------|--|-------------------------------|-----------------------------------|
|             |           |  | Detected Associated Compounds | Non-Detected Associated Compounds |
| Aqueous     | No        | $\leq 7$ days (for extraction)<br>$\leq 40$ days (for analysis)  | Use professional judgment     |                                   |
|             | No        | $> 7$ days (for extraction)<br>$> 40$ days (for analysis)        | J                             | Use professional judgment         |
|             | Yes       | $\leq 7$ days (for extraction)<br>$\leq 40$ days (for analysis)  | No qualification              |                                   |
|             | Yes       | $> 7$ days (for extraction)<br>$> 40$ days (for analysis)        | J                             | UJ                                |
|             | Yes/No    | Grossly Exceeded   | J                             | UJ or R                           |
| Non-Aqueous | No        | $\leq 14$ days (for extraction)<br>$\leq 40$ days (for analysis) | Use professional judgment     |                                   |
|             | No        | $> 14$ days (for extraction)<br>$> 40$ days (for analysis)       | J                             | Use professional judgment         |
|             | Yes       | $\leq 14$ days (for extraction)<br>$\leq 40$ days (for analysis) | No qualification              |                                   |
|             | Yes       | $> 14$ days (for extraction)<br>$> 40$ days (for analysis)       | J                             | UJ                                |
|             | Yes/No    | Grossly Exceeded   | J                             | UJ or R                           |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met see below       

### GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

  X   The DFTPP performance results were reviewed and found to be within the specified criteria.

  X   DFTPP tuning was performed for every 12 hours of sample analysis.

If no, use professional judgment to determine whether the associated data should be accepted, qualified or rejected.

Notes: These requirements do not apply when samples are analyzed by the Selected Ion Monitoring (SIM) technique.

All mass spectrometer conditions must be identical to those used during the sample analysis. Background subtraction actions resulting in spectral distortion are unacceptable

Notes: No data should be qualified based of DFTPP failure.

The requirement to analyze the instrument performance check solution is optional when analysis of PAHs/pentachlorophenol is to be performed by the SIM technique.

List the samples affected:

---

---

---

---

#### Actions:

1. If sample are analyzed without a preceding valid instrument performance check or are analyzed 12 hours after the Instrument Performance Check, qualify all data in those samples as unusable (R).
2. If ion abundance criteria are not met, use professional judgment to determine to what extent the data may be utilized.
3. State in the Data Review Narrative, decisions to use analytical data associated with DFTPP instrument performance checks not meeting the contract requirements.
4. Use professional judgment to determine if associated data should be qualified based on the spectrum of the mass calibration compounds.

## DATA REVIEW WORKSHEETS

All criteria were met X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### INITIAL CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 12/21/16 (SIM) 12/15/16 (SIM)  
 Instrument ID numbers: GCMS3M GCMS4M  
 Matrix/Level: Aqueous/low Aqueous/low

Date of initial calibration: 11/16/16; 12/01/16 (SCAN)  
 Instrument ID numbers: GCMS2M  
 Matrix/Level: Aqueous/low

Date of initial calibration: 12/23/16 (SCAN) 12/27-28/16 (SCAN)  
 Instrument ID numbers: GCMS5P GCMSM  
 Matrix/Level: Aqueous/low Aqueous/low

Date of initial calibration: 12/28-29/16 (SCAN)  
 Instrument ID numbers: GCMSP  
 Matrix/Level: Aqueous/low

| DATE   | LAB<br>ID# | FILE | CRITERIA OUT<br>RFs, %RSD, %D, r | COMPOUND | SAMPLES<br>AFFECTED |
|--|------------|------|----------------------------------|----------|---------------------|
|  |            |      |                                  |          |                     |
| Initial and initial calibration verification meets the method and guidance validation document performance criteria. |            |      |                                  |          |                     |
|  |            |      |                                  |          |                     |

**Note:** Instruments GCMS3M; GCMS4P; and GCMS3P were also employed for running QC samples for this data packages. QC samples not validated.

Actions:

Qualify the initial calibration analytes listed in Table 2 using the following criteria:

**Table 3. Initial Calibration Actions for Semivolatile Analysis**

| Criteria  | Action                               |                                |
|---|--------------------------------------|--------------------------------|
|   | Detect                               | Non-detect                     |
| Initial Calibration not performed at specified frequency and sequence | Use professional judgment<br>R       | Use professional judgment<br>R |
| Initial Calibration not performed at the specified concentrations     | J                                    | UJ                             |
| RRF < Minimum RRF in Table 2 for target analyte                       | Use professional judgment<br>J+ or R | R                              |
| RRF ≥ Minimum RRF in Table 2 for target analyte                       | No qualification                     | No qualification               |
| %RSD > Maximum %RSD in Table 2 for target analyte                     | J                                    | Use professional judgment      |
| %RSD ≤ Maximum %RSD in Table 2 for target analyte                     | No qualification                     | No qualification               |

# DATA REVIEW WORKSHEETS

## Initial Calibration

**Table 2. RRF, %RSD, and %D Acceptance Criteria in Initial Calibration and CCV for Semivolatil Analysis**

| Analyte                       | Minimum RRF | Maximum %RSD | Opening Maximum %D <sup>1</sup> | Opening Maximum %D <sup>1</sup> |
|-------------------------------|-------------|--------------|---------------------------------|---------------------------------|
| 1,4-Dioxane                   | 0.010       | 40.0         | ± 40.0                          | ± 50.0                          |
| Benzaldehyde                  | 0.100       | 40.0         | ± 40.0                          | ± 50.0                          |
| Phenol                        | 0.080       | 20.0         | ± 20.0                          | ± 25.0                          |
| Bis(2-chloroethyl)ether       | 0.100       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2-Chlorophenol                | 0.200       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2-Methylphenol                | 0.010       | 20.0         | ± 20.0                          | ± 25.0                          |
| 3-Methylphenol                | 0.010       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2,2'-Oxybis-(1-chloropropane) | 0.010       | 20.0         | ± 25.0                          | ± 50.0                          |
| Acetophenone                  | 0.060       | 20.0         | ± 20.0                          | ± 25.0                          |
| 4-Methylphenol                | 0.010       | 20.0         | ± 20.0                          | ± 25.0                          |
| N-Nitroso-di-n-propylamine    | 0.080       | 20.0         | ± 25.0                          | ± 25.0                          |
| Hexachloroethane              | 0.100       | 20.0         | ± 20.0                          | ± 25.0                          |
| Nitrobenzene                  | 0.090       | 20.0         | ± 20.0                          | ± 25.0                          |
| Isophorone                    | 0.100       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2-Nitrophenol                 | 0.060       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2,4-Dimethylphenol            | 0.050       | 20.0         | ± 25.0                          | ± 50.0                          |
| Bis(2-chloroethoxy)methane    | 0.080       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2,4-Dichlorophenol            | 0.060       | 20.0         | ± 20.0                          | ± 25.0                          |
| Naphthalene                   | 0.200       | 20.0         | ± 20.0                          | ± 25.0                          |
| 4-Chloroaniline               | 0.010       | 40.0         | ± 40.0                          | ± 50.0                          |
| Hexachlorobutadiene           | 0.040       | 20.0         | ± 20.0                          | ± 25.0                          |
| Caprolactam                   | 0.010       | 40.0         | ± 30.0                          | ± 50.0                          |
| 4-Chloro-3-methylphenol       | 0.040       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2-Methylnaphthalene           | 0.100       | 20.0         | ± 20.0                          | ± 25.0                          |
| Hexachlorocyclopentadiene     | 0.010       | 40.0         | ± 40.0                          | ± 50.0                          |
| 2,4,6-Trichlorophenol         | 0.090       | 20.0         | ± 20.0                          | ± 25.0                          |
| 2,4,5-Trichlorophenol         | 0.100       | 20.0         | ± 20.0                          | ± 25.0                          |
| 1,1'-Biphenyl                 | 0.200       | 20.0         | ± 20.0                          | ± 25.0                          |



DATA REVIEW WORKSHEETS

| Analyte                    | Minimum<br>RRF | Maximum<br>%RSD | Opening<br>Maximum<br>%D <sup>1</sup> | Opening<br>Maximum<br>%D <sup>1</sup> |
|----------------------------|----------------|-----------------|---------------------------------------|---------------------------------------|
| 2-Chloronaphthalene        | 0.300          | 20.0            | ± 20.0                                | ± 25.0                                |
| 2-Nitroaniline             | 0.060          | 20.0            | ± 25.0                                | ± 25.0                                |
| Dimethylphthalate          | 0.300          | 20.0            | ± 25.0                                | ± 25.0                                |
| 2,6-Dinitrotoluene         | 0.080          | 20.0            | ± 20.0                                | ± 25.0                                |
| Acenaphthylene             | 0.400          | 20.0            | ± 20.0                                | ± 25.0                                |
| 3-Nitroaniline             | 0.010          | 20.0            | ± 25.0                                | ± 50.0                                |
| Acenaphthene               | 0.200          | 20.0            | ± 20.0                                | ± 25.0                                |
| 2,4-Dinitrophenol          | 0.010          | 40.0            | ± 50.0                                | ± 50.0                                |
| 4-Nitrophenol              | 0.010          | 40.0            | ± 40.0                                | ± 50.0                                |
| Dibenzofuran               | 0.300          | 20.0            | ± 20.0                                | ± 25.0                                |
| 2,4-Dinitrotoluene         | 0.070          | 20.0            | ± 20.0                                | ± 25.0                                |
| Diethylphthalate           | 0.300          | 20.0            | ± 20.0                                | ± 25.0                                |
| 1,2,4,5-Tetrachlorobenzene | 0.100          | 20.0            | ± 20.0                                | ± 25.0                                |
| 4-Chlorophenyl-phenylether | 0.100          | 20.0            | ± 20.0                                | ± 25.0                                |
| Fluorene                   | 0.200          | 20.0            | ± 20.0                                | ± 25.0                                |
| 4-Nitroaniline             | 0.010          | 40.0            | ± 40.0                                | ± 50.0                                |
| 4,6-Dinitro-2-methylphenol | 0.010          | 40.0            | ± 30.0                                | ± 50.0                                |
| 4-Bromophenyl-phenyl ether | 0.070          | 20.0            | ± 20.0                                | ± 25.0                                |
| N-Nitrosodiphenylamine     | 0.100          | 20.0            | ± 20.0                                | ± 25.0                                |
| Hexachlorobenzene          | 0.050          | 20.0            | ± 20.0                                | ± 25.0                                |
| Atrazine                   | 0.010          | 40.0            | ± 25.0                                | ± 50.0                                |
| Pentachlorophenol          | 0.010          | 40.0            | ± 40.0                                | ± 50.0                                |
| Phenanthrene               | 0.200          | 20.0            | ± 20.0                                | ± 25.0                                |
| Anthracene                 | 0.200          | 20.0            | ± 20.0                                | ± 25.0                                |
| Carbazole                  | 0.050          | 20.0            | ± 20.0                                | ± 25.0                                |
| Di-n-butylphthalate        | 0.500          | 20.0            | ± 20.0                                | ± 25.0                                |
| Fluoranthene               | 0.100          | 20.0            | ± 20.0                                | ± 25.0                                |
| Pyrene                     | 0.400          | 20.0            | ± 25.0                                | ± 50.0                                |
| Butylbenzylphthalate       | 0.100          | 20.0            | ± 25.0                                | ± 50.0                                |

DATA REVIEW WORKSHEETS

| Analyte                     | Minimum<br>RRF | Maximum<br>%RSD | Opening<br>Maximum<br>%D <sup>1</sup> | Opening<br>Maximum<br>%D <sup>1</sup> |
|-----------------------------|----------------|-----------------|---------------------------------------|---------------------------------------|
| 3,3'-Dichlorobenzidine      | 0.010          | 40.0            | ± 40.0                                | ± 50.0                                |
| Benzo(a)anthracene          | 0.300          | 20.0            | ± 20.0                                | ± 25.0                                |
| Chrysene                    | 0.200          | 20.0            | ± 20.0                                | ± 50.0                                |
| Bis(2-ethylhexyl) phthalate | 0.200          | 20.0            | ± 25.0                                | ± 50.0                                |
| Di-n-octylphthalate         | 0.010          | 40.0            | ± 40.0                                | ± 50.0                                |
| Benzo(b)fluoranthene        | 0.010          | 20.0            | ± 25.0                                | ± 50.0                                |
| Benzo(k)fluoranthene        | 0.010          | 20.0            | ± 25.0                                | ± 50.0                                |
| Benzo(a)pyrene              | 0.010          | 20.0            | ± 20.0                                | ± 50.0                                |
| Indeno(1,2,3-cd)pyrene      | 0.010          | 20.0            | ± 25.0                                | ± 50.0                                |
| Dibenzo(a,h)anthracene      | 0.010          | 20.0            | ± 25.0                                | ± 50.0                                |
| Benzo(g,h,i)perylene        | 0.010          | 20.0            | ± 30.0                                | ± 50.0                                |
| 2,3,4,6-Tetrachlorophenol   | 0.040          | 20.0            | ± 20.0                                | ± 50.0                                |
| Naphthalene                 | 0.600          | 20.0            | ± 25.0                                | ± 25.0                                |
| 2-Methylnaphthalene         | 0.300          | 20.0            | ± 20.0                                | ± 25.0                                |
| Acenaphthylene              | 0.900          | 20.0            | ± 20.0                                | ± 25.0                                |
| Acenaphthene                | 0.500          | 20.0            | ± 20.0                                | ± 25.0                                |
| Fluorene                    | 0.700          | 20.0            | ± 25.0                                | ± 50.0                                |
| Phenanthrene                | 0.300          | 20.0            | ± 25.0                                | ± 50.0                                |
| Anthracene                  | 0.400          | 20.0            | ± 25.0                                | ± 50.0                                |
| Fluoranthene                | 0.400          | 20.0            | ± 25.0                                | ± 50.0                                |
| Pyrene                      | 0.500          | 20.0            | ± 30.0                                | ± 50.0                                |
| Benzo(a)anthracene          | 0.400          | 20.0            | ± 25.0                                | ± 50.0                                |
| Chrysene                    | 0.400          | 20.0            | ± 25.0                                | ± 50.0                                |
| Benzo(b)fluoranthene        | 0.100          | 20.0            | ± 30.0                                | ± 50.0                                |
| Benzo(k)fluoranthene        | 0.100          | 20.0            | ± 30.0                                | ± 50.0                                |
| Benzo(a)pyrene              | 0.100          | 20.0            | ± 25.0                                | ± 50.0                                |
| Indeno(1,2,3-cd)pyrene      | 0.100          | 20.0            | ± 40.0                                | ± 50.0                                |
| Dibenzo(a,h)anthracene      | 0.010          | 25.0            | ± 40.0                                | ± 50.0                                |
| Benzo(g,h,i)perylene        | 0.020          | 25.0            | ± 40.0                                | ± 50.0                                |

# DATA REVIEW WORKSHEETS

| Pentachlorophenol                         | 0.010       | 40.0         | ± 50.0                          | ± 50.0             |
|---|-------------|--------------|---------------------------------|--------------------|
| <b>Deuterated Monitoring Compounds</b>    |             |              |                                 |                    |
| Analyte                                   | Minimum RRF | Maximum %RSD | Opening Maximum %D <sup>1</sup> | Closing Maximum %D |
| 1,4-Dioxane-d <sub>8</sub>                | 0.010       | 20.0         | ± 25.0                          | ± 50.0             |
| Phenol-d <sub>5</sub>                     | 0.010       | 20.0         | ± 25.0                          | ± 25.0             |
| Bis-(2-chloroethyl)ether-d <sub>8</sub>   | 0.100       | 20.0         | ± 20.0                          | ± 25.0             |
| 2-Chlorophenol-d <sub>4</sub>             | 0.200       | 20.0         | ± 20.0                          | ± 25.0             |
| 4-Methylphenol-d <sub>8</sub>             | 0.010       | 20.0         | ± 20.0                          | ± 25.0             |
| 4-Chloroaniline-d <sub>4</sub>            | 0.010       | 40.0         | ± 40.0                          | ± 50.0             |
| Nitrobenzene-d <sub>5</sub>               | 0.050       | 20.0         | ± 20.0                          | ± 25.0             |
| 2-Nitrophenol-d <sub>4</sub>              | 0.050       | 20.0         | ± 20.0                          | ± 25.0             |
| 2,4-Dichlorophenol-d <sub>3</sub>         | 0.060       | 20.0         | ± 20.0                          | ± 25.0             |
| Dimethylphthalate-d <sub>6</sub>          | 0.300       | 20.0         | ± 20.0                          | ± 25.0             |
| Acenaphthylene-d <sub>8</sub>             | 0.400       | 20.0         | ± 20.0                          | ± 25.0             |
| 4-Nitrophenol-d <sub>4</sub>              | 0.010       | 40.0         | ± 40.0                          | ± 50.0             |
| Fluorene-d <sub>10</sub>                  | 0.100       | 20.0         | ± 20.0                          | ± 25.0             |
| 4,6-Dinitro-2-methylphenol-d <sub>2</sub> | 0.010       | 40.0         | ± 30.0                          | ± 50.0             |
| Anthracene-d <sub>10</sub>                | 0.300       | 20.0         | ± 20.0                          | ± 25.0             |
| Pyrene-d <sub>10</sub>                    | 0.300       | 20.0         | ± 25.0                          | ± 50.0             |
| Benzo(a)pyrene-d <sub>12</sub>            | 0.010       | 20.0         | ± 20.0                          | ± 50.0             |
| Fluoranthene-d <sub>10</sub> (SIM)        | 0.400       | 20.0         | ± 25.0                          | ± 50.0             |
| 2-Methylnaphthalene-d <sub>10</sub> (SIM) | 0.300       | 20.0         | ± 20.0                          | ± 25.0             |

<sup>1</sup> If a closing CCV is acting as an opening CCV, all target analytes must meet the requirements for an opening CCV.

Note: If analysis by SIM technique is requested for PAH/pentachlorophenols, calibration standards analyzed at 0.10, 0.20, 0.40, 0.80, and 1.0 ng/uL for each target compound of interest and the associated DMCs. Pentachlorophenol will require only a four point initial calibration at 0.20, 0.40, 0.80, and 1.0 ng/uL.

# DATA REVIEW WORKSHEETS

All criteria were met \_\_\_\_\_  
 Criteria were not met \_\_\_\_\_  
 and/or see below \_\_\_\_\_X\_\_\_\_\_

## CONTINUING CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

|   |                    |
|---|--------------------|
| Date of initial calibration: 11/16/16; 12/01/16 (SCAN)                | 12/21/16 (SIM)     |
| Date of initial calibration verification (ICV): 11/16-17/16; 12/01/16 | 12/21-22/16        |
| Date of continuing calibration verification (CCV): 12/27/16; 12/29/16 | 12/29/16; 12/30/16 |
| 01/03/17  | 12/30/16           |
| Date of closing CCV: -  | -                  |
| Instrument ID numbers: GCMS2M   | GCMS3M             |
| Matrix/Level: Aqueous/low   | Aqueous/low        |
| Date of initial calibration: 12/15/16 (SIM)                           | 12/23/16 (Scan)    |
| Date of initial calibration verification (ICV): 12/15/16; 12/19/16    | 12/24/16; 12/27/16 |
| Date of continuing calibration verification (CCV): 12/29-31/16        | 12/29/16; 12/30/16 |
| Date of closing CCV: -  | -                  |
| Instrument ID numbers: GCMS4M   | GCM5P              |
| Matrix/Level: Aqueous/low   | Aqueous/low        |
| Date of initial calibration: 11/28-29/16 (Scan)                       | 12/27-28/16 (Scan) |
| Date of initial calibration verification (ICV): 11/29-03/16           | 12/27/28/16        |
| Date of continuing calibration verification (CCV): 12/30/16; 01/03/17 | 01/03-04/17        |
| Date of closing CCV: -  | -                  |
| Instrument ID numbers: GCMSP  | GCM5M              |
| Matrix/Level: Aqueous/low   | Aqueous/low        |

| DATE     | LAB FILE ID# | CRITERIA OUT RFs, %RSD, %D, r | COMPOUND                   | SAMPLES AFFECTED |
|----------|--------------|-------------------------------|----------------------------|------------------|
| GCMS2M   |              |                               |                            |                  |
| 12/27/16 | cc3953-50    | 27.6                          | 1,4-dioxane*^              | JC34340-1        |
|          |              | 35.1                          | Hexachlorocyclopentadiene* |                  |
|          |              | 34.7                          | Pentachlorophenol*         |                  |
|          |              | -27.8                         | di-n-octylphthalate*       |                  |
|          |              | -35.4                         | Indeno(1,2,3-cd)pyrene*    |                  |
| 12/29/16 | cc3953-25    | 29.6                          | 1,4-dioxane*^^             | JC34340-7        |
|          |              | 37.5                          | Hexachlorocyclopentadiene* |                  |
|          |              | 40.8 ✓                        | Pentachlorophenol          |                  |
|          |              | -25.3 ✓                       | Butylbenzylphthalate       |                  |
|          |              | -27.6                         | di-n-octylphthalate*       |                  |
|          |              | -33.4                         | Indeno(1,2,3-cd)pyrene*    |                  |
| 01/03/17 | cc3953-50    | 27.8                          | 1,4-dioxane^^              | JC34340-4        |
|          |              | 27.9                          | Hexachlorocyclopentadiene* |                  |
|          |              | 27.2                          | Pentachlorophenol*         |                  |

DATA REVIEW WORKSHEETS

| DATE     | LAB FILE ID# | CRITERIA OUT RFs, %RSD, %D, r | COMPOUND                     | SAMPLES AFFECTED             |
|----------|--------------|-------------------------------|------------------------------|------------------------------|
| GCMS2M   |              |                               |                              |                              |
| 01/03/17 | cc3953-50    | -34.6                         | di-n-octylphthalate*         | JC34340-4                    |
|          |              | -28.1                         | Indeno(1,2,3-cd)pyrene*      |                              |
| 01/03/17 | cc3953-25    | 23.8                          | 1,4-dioxane*                 | JC34340-2                    |
|          |              | 40.2 ✓                        | Hexachlorocyclopentadiene    |                              |
|          |              | 20.2 ✓                        | 2,3,4,6-tetrachlorophenol    |                              |
|          |              | 30.6                          | Pentachlorophenol*           |                              |
|          |              | -26.0                         | di-n-octylphthalate*         |                              |
|          |              | -30.3                         | Indeno(1,2,3-cd)pyrene*      |                              |
|          |              | GCMS3M                        |                              |                              |
| 12/30/16 | cc3145-0.5   | -24.6                         | 1,4-dioxane*                 | JC34340-9; -10; -12; -8      |
| GCMS5P   |              |                               |                              |                              |
| 12/29/16 | cc1717-50    | 21.4 ✓                        | Hexachlorobutadiene          | JC34340-8; -9; -10; -11; -12 |
|          |              | 26.0                          | Hexachlorocyclopentadiene*   |                              |
|          |              | 26.9                          | 4-nitrophenol*               |                              |
| GCMS5P   |              |                               |                              |                              |
| 12/30/16 | cc4851-50    | -45.1 ✓                       | bis(2-chloroethyl)ether      | JC34340-3; -16               |
|          |              | 24.8                          | 4-chloroaniline*             |                              |
|          |              | -23.1 ✓                       | Hexachlorobutadiene          |                              |
|          |              | -30.8                         | 2,4-dinitropheno*I           |                              |
|          |              | -29.1 ✓                       | 2,3,4,6-tetrachlorophenol    |                              |
|          |              | -23.4                         | 4,6-dinitro-2-methyl phenol* |                              |
| 01/03/17 | CC4851-50    | -29.7 ✓                       | Hexachlorobutadiene          | JC34340-16; -15              |
|          |              | -24.3 ✓                       | 2,3,4,6-tetrachlorophenol    |                              |
|          |              | -21.3                         | 4,6-dinitro-2-methyl phenol* |                              |
|          |              | -24.8                         | Pentachlorophenol*           |                              |
| 01/03/17 | CC4852-50    | 26.3                          | Benzaldehyde*                | JC34340-16; -15              |

**Note:** Initial and continuing calibration verifications meet the method and guidance document required performance criteria except for the cases described in this document. Results qualified as estimated (J or UJ) in affected samples.

\* % difference outside was method performance criteria but within the guidance document performance criteria. No action taken.

No action taken for QC samples.

^ Quantitated in the SIM mode.

^^ Reported from run on 01/04/17 (2x dilution)

No closing calibration verification included in data package. No action taken, professional judgment.

## DATA REVIEW WORKSHEETS

### Actions:

Notes: Verify that the CCV is run at the required frequency (an opening and closing CCV must be run within 12-hour period).

All DMCs must meet the RRF values given in Table 2. No qualification of the data is necessary on DMCs RRF and %RSD/%D alone. Use professional judgment to evaluate DMCs and %RSD/%D data in conjunction with DMCs recoveries to determine the need for qualification of the data.

Qualify the initial calibration analytes listed in Table 2 using the following criteria in the CCVs:

**Table 4. CCV Actions for Semivolatile Analysis**

| Criteria for Opening CCV  | Criteria for Closing CCV  | Action                              |                                |
|---|---|-------------------------------------|--------------------------------|
|   |   | Detect                              | Non-detect                     |
| CCV not performed at required frequency and sequence                            | CCV not performed at required frequency   | Use professional judgment<br>R      | Use professional judgment<br>R |
| CCV not performed at specified concentration                                    | CCV not performed at specified concentration                                    | Use professional judgment           | Use professional judgment      |
| RRF < Minimum RRF in Table 2 for target analyte                                 | RRF < Minimum RRF in Table 2 for target analyte                                 | Use professional judgment<br>J or R | R                              |
| RRF ≥ Minimum RRF in Table 2 for target analyte                                 | RRF ≥ Minimum RRF in Table 2 for target analyte                                 | No qualification                    | No qualification               |
| %D outside the Opening Maximum %D limits in Table 2 for target analyte          | %D outside the Closing Maximum %D limits in Table 2 for target analyte          | J                                   | UJ                             |
| %D within the inclusive Opening Maximum %D limits in Table 2 for target analyte | %D within the inclusive Closing Maximum %D limits in Table 2 for target analyte | No qualification                    | No qualification               |

## DATA REVIEW WORKSHEETS

All criteria were met \_\_\_\_\_  
 Criteria were not met \_\_\_\_\_  
 and/or see below   X  

### BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

Notes: The concentration of non-target compounds in all blanks must be less than or equal to 10 ug/L.

The concentration of target compounds in all blanks must be less than its CRQL listed in the method.

Samples taken from a drinking water tap do not have an associated field blank.

#### Laboratory blanks

| DATE ANALYZED  | LAB ID       | LEVEL/MATRIX | COMPOUND    | CONCENTRATION UNITS |
|--|--------------|--------------|-------------|---------------------|
| No target analytes detected in method blanks except for the cases described in this document |              |              |             |                     |
| 12/30/16   | OP99540A-MB1 | Aq./low      | 1,4-Dioxane | 0.390 ug/l          |
|  |              |              |             |                     |
|  |              |              |             |                     |

Note: No action taken. 1,4-dioxane not detected in sample JC34340-15 and reported from the scan mode run in sample JC34340-16.

#### Field/Equipment/Trip blank

| DATE ANALYZED  | LAB ID     | LEVEL/MATRIX | COMPOUND                   | CONCENTRATION UNITS |
|--|------------|--------------|----------------------------|---------------------|
| No target analytes detected in the field/equipment blanks analyzed with this data package except for the cases described in this document. |            |              |                            |                     |
| 12/30/16   | JC34340-12 | Aq./low      | bis(2-Ethylhexyl)phthalate | 1.9 ug/l            |
|  |            |              |                            |                     |
|  |            |              |                            |                     |

Note: No action taken, concentration below the reporting limit.

# DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## BLANK ANALYSIS RESULTS (Section 3)

### Blank Actions

Qualify samples based on the criteria summarized in Table 5:

**Table 5. Blank and TCLP/SPLP LEB Actions for Semivolatile Analysis**

| Blank Type                         | Blank Result  | Sample Result             | Action  |
|------------------------------------|---|---------------------------|---|
| Method,<br>TCLP/SPLP<br>LEB, Field | Detect  | Non-detect                | No qualification  |
|                                    | < CRQL  | < CRQL                    | Report at CRQL and qualify as non-detect (U)                              |
|                                    |   | ≥ CRQL                    | Use professional judgment   |
|                                    | ≥ CRQL  | < CRQL                    | Report at CRQL and qualify as non-detect (U)                              |
|                                    |   | ≥ CRQL but < Blank Result | Report at sample results and qualify as non-detect (U) or as unusable (R) |
|                                    |   | ≥ CRQL and ≥ Blank Result | Use professional judgment   |
|                                    | Grossly high  | Detect                    | Report at sample results and qualify as unusable (R)                      |
|                                    | TIC > 5.0 ug/L (water) or 0.0050 mg/L (TCLP leachate)<br>or<br>TIC > 170 ug/Kg (soil) | Detect                    | Use professional judgment   |

List samples qualified

| CONTAMINATION SOURCE/LEVEL | COMPOUND | CONC/UNITS | AL/UNITS | SQL | AFFECTED SAMPLES |
|----------------------------|----------|------------|----------|-----|------------------|
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |
|                            |          |            |          |     |                  |



## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### SURROGATE SPIKE RECOVERIES – DEUTERATED MONITORING COMPOUNDS (DMCs)

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries – deuterated monitoring compounds. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

Notes: Recoveries for DMCs in samples and blanks must be within the limits specified in Table 6.

The recovery limits for any of the compounds listed in Table 6 may be expanded at any time during the period of performance if USEPA determines that the limits are too restrictive.

If a DMC is not added in the samples and blanks or the concentrations of DMCs in the samples and blank not the specified, use professional judgment in qualifying the data.

**Table 7. DMC Actions for Semivolatile Analysis**

| Criteria  | Action           |                  |
|---|------------------|------------------|
|   | Detect           | Non-detect       |
| %R < 10% (excluding DMCs with 10% as a lower acceptance limit)                          | J-               | R                |
| 10% ≤ %R (excluding DMCs with 10% as a lower acceptance limit) < Lower Acceptance Limit | J-               | UJ               |
| Lower Acceptance limit ≤ %R ≤ Upper Acceptance Limit                                    | No qualification | No qualification |
| %R > Upper Acceptance Limit   | J+               | No qualification |

List the percent recoveries (%Rs) which do not meet the criteria for DMCs (surrogate) recovery.

Matrix: Groundwater

| SAMPLE ID | SURROGATE COMPOUND | ACTION |
|-----------|--------------------|--------|
|-----------|--------------------|--------|

DMCs meet the required criteria in all samples analyzed except for the cases described in this document. Non- deuterated surrogates added to the samples and were within laboratory recovery limits except for the cases described in this document.

**Note:** Surrogate standards not recovered in sample JC34340-16 due to dilution. Surrogate standards recovered within the laboratory control limits in the original run.

# DATA REVIEW WORKSHEETS

**Table 8. Semivolatile DMCs and the Associated Target Analytes**

| <b>1,4-Dioxane-d<sub>8</sub> (DMC-1)</b>   | <b>Phenol-d<sub>5</sub> (DMC-2)</b>   | <b>Bis(2-Chloroethyl) ether-d<sub>8</sub> (DMC-3)</b>  |
|--|---|--|
| 1,4-Dioxane  | Benzaldehyde<br>Phenol  | Bis(2-chloroethyl) ether<br>2,2'-Oxybis(1-chloropropane)<br>Bis(2-chloroethoxy)methane   |
| <b>2-Chlorophenol-d<sub>4</sub> (DMC-4)</b>  | <b>4-Methylphenol-d<sub>8</sub> (DMC-5)</b>   | <b>4-Chloroaniline-d<sub>4</sub> (DMC-6)</b>   |
| 2-Chlorophenol   | 2-Methylphenol<br>3-Methylphenol<br>4-Methylphenol<br>2,4-Dimethylphenol                        | 4-Chloroaniline<br>Hexachlorocyclopentadiene<br>Dichlorobenzidine  |
| <b>Nitrobenzene-d<sub>5</sub> (DMC-7)</b>  | <b>2-Nitrophenol-d<sub>4</sub> (DMC-8)</b>  | <b>2,4-Dichlorophenol-d<sub>3</sub> (DMC-9)</b>  |
| Acetophenone<br>N-Nitroso-di-n-propylamine<br>Hexachloroethane<br>Nitrobenzene<br>2,6-Dinitrotoluene<br>2,4-Dinitrotoluene<br>N-Nitrosodiphenylamine                       | Isophorone<br>2-Nitrophenol   | 2,4-Dichlorophenol<br>Hexachlorobutadiene<br>Hexachlorocyclopentadiene<br>4-Chloro-3-methylphenol<br>2,4,6-Trichlorophenol<br>2,4,5-Trichlorophenol<br>1,2,4,5-Tetrachlorobenzene<br>*Pentachlorophenol<br>2,3,4,6-Tetrachlorophenol |
| <b>Dimethylphthalate-d<sub>6</sub> (DMC-10)</b>  | <b>Acenaphthylene-d<sub>8</sub> (DMC-11)</b>  | <b>4-Nitrophenol-d<sub>4</sub> (DMC-12)</b>  |
| Caprolactam<br>1,1'-Biphenyl<br>Dimethylphthalate<br>Diethylphthalate<br>Di-n-butylphthalate<br>Butylbenzylphthalate<br>Bis(2-ethylhexyl) phthalate<br>Di-n-octylphthalate | *Naphthalene<br>*2-Methylnaphthalene<br>2-Chloronaphthalene<br>*Acenaphthylene<br>*Acenaphthene | 2-Nitroaniline<br>3-Nitroaniline<br>2,4-Dinitrophenol<br>4-Nitrophenol<br>4-Nitroaniline   |

# DATA REVIEW WORKSHEETS

| <b>Fluorene-d<sub>10</sub> (DMC-13)</b>   | <b>4,6-Dinitro-2-methylphenol-d<sub>2</sub> (DMC-14)</b>   | <b>Anthracene-d<sub>10</sub> (DMC-15)</b>                     |
|---|--|---|
| Dibenzofuran<br>*Fluorene<br>4-Chlorophenyl-phenylether<br>4-Bromophenyl-phenylether<br>Carbazole | 4,6-Dinitro-2-methylphenol   | Hexachlorobenzene<br>Atrazine<br>*Phenanthrene<br>*Anthracene |
| <b>Pyrene-d<sub>10</sub> (DMC-16)</b>   | <b>Benzo(a)pyrene-d<sub>12</sub> (DMC-17)</b>  |   |
| *Fluoranthene<br>*Pyrene<br>*Benzo(a)anthracene<br>*Chrysene                                      | 3,3'-Dichlorobenzidine<br>*Benzo(b)fluoranthene<br>*Benzo(k)fluoranthene<br>*Benzo(a)pyrene<br>*Indeno(1,2,3-cd)pyrene<br>*Dibenzo(a,h)anthracene<br>*Benzo(g,h,i)perylene |   |

\*Included in optional Target Analyte List (TAL) of PAHs and PCP only.

**Table 9. Semivolatile SIM DMCs and the Associated Target Analytes**

| <b>Fluoranthene-d<sub>10</sub> (DMC-1)</b> | <b>2-Methylnaphthalene-d<sub>10</sub> (DMC-2)</b> |
|--|---|
| Fluoranthene                               | Naphthalene                                       |
| Pyrene                                     | 2-Methylnaphthalene                               |
| Benzo(a)anthracene                         | Acenaphthylene                                    |
| Chrysene                                   | Acenaphthene                                      |
| Benzo(b)fluoranthene                       | Fluorene  |
| Benzo(k)fluoranthene                       | Pentachlorophenol                                 |
| Benzo(a)pyrene                             | Phenanthrene                                      |
| Indeno(1,2,3-cd)pyrene                     | Anthracene  |
| Dibenzo(a,h)anthracene                     |   |
| Benzo(g,h,i)perylene                       |   |

# DATA REVIEW WORKSHEETS

All criteria were met \_\_\_\_\_  
 Criteria were not met \_\_\_\_\_  
 and/or see below \_\_\_\_\_X\_\_\_\_\_

## VII. A MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

### 1. MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

**NOTES:** Data for MS and MSDs will not be present unless requested by the Region.  
 Notify the Contract Laboratory COR if a field or trip blank was used for the MS and MSD.

For a Matrix Spike that does not meet criteria, apply the action to only the field sample used to prepare the Matrix Spike sample. If it is clearly stated in the data validation materials that the samples were taken through incremental sampling or some other method guaranteeing the homogeneity of the sample group, then the entire sample group may be qualified.

List the %Rs, RPD of the compounds which do not meet the criteria.

|                                       |                                     |
|---------------------------------------|-------------------------------------|
| Sample ID: _____JC34340-1_____        | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34340-2_(SIM)_____  | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34340-8_____        | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34280-5_(SIM)_____  | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34064-7_____        | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34340-16_____       | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34340-16_(SIM)_____ | Matrix/Level: _____Groundwater_____ |
| Sample ID: _____JC34180-1_(SIM)_____  | Matrix/Level: _____Groundwater_____ |

The QC reported here applies to the following samples:  
 JC34340-4, JC34340-7

Method: SW846 8270D

| Compound                | JC34064-7<br>ug/l | Q | Spike<br>ug/l | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD   | Limits<br>Rec/RPD |
|-------------------------|-------------------|---|---------------|------------|---------|---------------|-------------|----------|-------|-------------------|
| 2,4-Dimethyl-phenol     | ND                |   | 109           | 23.6       | 22* a   | 109           | 17.9        | 16* a    | 27* b | 33-132/23         |
| 4-Chloroaniline         | ND                |   | 109           | ND         | 0* a    | 109           | ND          | 0* a     | nc    | 10-110/55         |
| 3,3'-Dichloro-benzidine | ND                |   | 217           | ND         | 0* a    | 217           | ND          | 0* a     | nc    | 10-107/47         |
| 3-Nitroaniline          | ND                |   | 109           | 11.8       | 11      | 109           | 8.6         | 8* a     | 31    | 10-110/50         |
| 4-Nitroaniline          | ND                |   | 109           | 31.3       | 29* a   | 109           | 22.1        | 20* a    | 34* b | 38-118/25         |

(a) Outside control limits due to matrix interference.

(b) Outside in-house control limits.

\* - outside control limits

# DATA REVIEW WORKSHEETS

**Note:** No action taken. MS/MSD results apply to unspiked sample. Unspiked sample was from another job.

The QC reported here applies to the following samples:  
JC34340-15, JC34340-16

Method: SW846 8270D

| Compound    | JC34340-16<br>ug/l | Q | Spike<br>ug/l | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD | Limits<br>Rec/RPD |
|-------------|--------------------|---|---------------|------------|---------|---------------|-------------|----------|-----|-------------------|
| 1,4-Dioxane | 1520               | b | 54.1          | 1580       | 0* a    | 51.3          | 1800        | 0* a     | 13  | 10-119/31         |

(a) Outside control limits due to high level in sample relative to spike amount.

(b) Result is from Run #2.

\* - outside control limits

**Note:** No action taken, outside control limits due to high level in sample relative to spike amount.

The QC reported here applies to the following samples:  
JC34340-4, JC34340-7

Method: SW846 8270D BY SIM

| Compound             | JC34180-1<br>ug/l | Q | Spike<br>ug/l | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD   | Limits<br>Rec/RPD |
|----------------------|-------------------|---|---------------|------------|---------|---------------|-------------|----------|-------|-------------------|
| Benzo(a)anthracene   | ND                |   | 2.04          | 4.74       | 232* b  | 2.04          | 5.20        | 255* b   | 9     | 25-135/33         |
| Benzo(a)pyrene       | ND                |   | 2.04          | 2.18       | 107     | 2.04          | 2.46        | 121* b   | 12    | 10-116/38         |
| Benzo(b)fluoranthene | ND                |   | 2.04          | 2.23       | 109     | 2.04          | 3.39        | 166* b   | 41* c | 10-131/40         |
| Chrysene             | ND                |   | 2.04          | 5.06       | 248* b  | 2.04          | 6.36        | 312* b   | 23    | 31-125/33         |
| Naphthalene          | ND                |   | 2.04          | 72.8       | 3567* b | 2.04          | 100         | 4900* b  | 31    | 23-140/36         |

(b) Outside control limits due to matrix interference.

(c) Analytical precision exceeds in-house control limits.

\* - outside control limits

**Note:** No action taken. MS/MSD results apply to unspiked sample. Unspiked sample was from another job.

The QC reported here applies to the following samples:  
JC34340-15, JC34340-16

Method: SW846 8270D BY SIM

| Compound       | JC34340-16<br>ug/l | Q  | Spike<br>ug/l | MS<br>ug/l | MS<br>% | Spike<br>ug/l | MSD<br>ug/l | MSD<br>% | RPD   | Limits<br>Rec/RPD |
|----------------|--------------------|----|---------------|------------|---------|---------------|-------------|----------|-------|-------------------|
| Benzo(a)pyrene | ND                 |    | 1.03          | 0.675      | 66      | 1.05          | 0.420       | 40       | 47* a | 10-116/38         |
| 1,4-Dioxane    | 1670               | EB | 1.03          | 1240       | 0* b    | 1.05          | 1450        | 0* b     | 16    | 20-160/36         |

(a) Analytical precision exceeds in-house control limits.

(b) Outside control limits due to high level in sample relative to spike amount.

\* = Outside of Control Limits.

**Note:** No qualification made base on RPD results, professional judgment. No action taken 1,4-dioxane MS/MSD % recoveries outside control limit due to high level in sample relative to spike amount.

**Note:** The acid standard was not added to sample JC34340-1MS/-1MSD. No action taken.

## DATA REVIEW WORKSHEETS

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

Actions:

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (JJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

A separate worksheet should be used for each MS/MSD pair.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

List the internal standard area of samples which do not meet the criteria.

| DATE  | SAMPLE ID | IS OUT | IS AREA | ACCEPTABLE RANGE | ACTION |
|---|-----------|--------|---------|------------------|--------|
| Internal area meets the required criteria for batch samples corresponding to this data package. |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |
|   |           |        |         |                  |        |

#### Action:

1. If an internal standard area count for a sample or blank is greater than 213.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration) (see Table 10 below):
  - a. Qualify detects for compounds quantitated using that internal standard as estimated low (J-).
  - b. Do not qualify non-detected associated compounds.
2. If an internal standard area count for a sample or blank is less than 20.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration):
  - a. Qualify detects for compounds quantitated using that internal standard as estimated high (J+).
  - b. Qualify non-detected associated compounds as unusable (R).
3. If an internal standard area count for a sample or blank is greater than or equal to 50.0%, and less than or equal to 213% of the area for the associated standard opening CCV or mid-point standard from initial calibration, no qualification of the data is necessary.
4. If an internal standard RT varies by more than 10.0 seconds: Examine the chromatographic profile for that sample to determine if any false positives or negatives exist. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for that sample fraction. Detects should not need to be qualified as unusable (R) if the mass spectral criteria are met.
5. If an internal standard RT varies by less than or equal to 10.0 seconds, no qualification of the data is necessary.

## DATA REVIEW WORKSHEETS

**Note:** Inform the Contract Laboratory Program Project Officer (CLP PO) if the internal standard performance criteria are grossly exceeded. Note in the Data Review Narrative potential effects on the data resulting from unacceptable internal standard performance.

State in the Data Review Narrative if the required internal standard compounds are not added to a sample or blank or if the required internal standard compound is not analyzed at the specified concentration.

Actions:

**Table 10. Internal Standard Actions for Semivolatile Analysis**

| Criteria   | Action           |                  |
|--|------------------|------------------|
|  | Detect           | Non-detect       |
| Area response < 20% of the opening CCV or mid-point standard CS3 from ICAL                       | J+               | R                |
| 20% ≤ Area response < 50% of the opening CCV or mid-point standard CS3 from ICAL                 | J+               | UJ               |
| 50% ≤ Area response ≤ 200% of the opening CCV or mid-point standard CS3 from ICAL                | No qualification | No qualification |
| Area response > 200% of the opening CCV or mid-point standard CS3 from ICAL                      | J-               | No qualification |
| RT shift between sample/blank and opening CCV or mid-point standard CS3 from ICAL > 10.0 seconds | R                | R                |
| RT shift between sample/blank and opening CCV or mid-point standard CS3 from ICAL < 10.0 seconds | No qualification | No qualification |



## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below \_\_\_\_\_

### TARGET COMPOUND IDENTIFICATION

#### Criteria:

Is the Relative Retention Times (RRTs) of reported compounds within  $\pm 0.06$  RRT units of the standard RRT [opening Continuing Calibration Verification (CCV) or mid-point standard from the initial calibration].  
**Yes? or No?**

List compounds not meeting the criteria described above:

| Sample ID | Compounds | Actions |
|-----------|-----------|---------|
| =====     | =====     | =====   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |

Mass spectra of the sample compound and a current laboratory-generated standard [i.e., the mass spectrum from the associated calibration standard (opening CCV or mid-point standard from initial calibration)] must match according to the following criteria:

- All ions present in the standard mass spectrum at a relative intensity greater than 10% must be present in the sample spectrum.
- The relative intensities of these ions must agree within  $\pm 20\%$  between the standard and sample spectra (e.g., for an ion with an abundance of 50% in the standard spectrum, the corresponding sample ion abundance must be between 30-70%).
- Ions present at greater than 10% in the sample mass spectrum, but not present in the standard spectrum, must be evaluated by a reviewer experienced in mass spectral interpretation.

List compounds not meeting the criteria described above:

| Sample ID                                       | Compounds | Actions |
|---|-----------|---------|
| =====   | =====     | =====   |
| _____   | _____     | _____   |
| Identified compounds meet the required criteria | _____     | _____   |
| _____   | _____     | _____   |

## DATA REVIEW WORKSHEETS

### Action:

1. The application of qualitative criteria for GC/MS analysis of target compounds requires professional judgment. It is up to the reviewer's discretion to obtain additional information from the laboratory. If it is determined that incorrect identifications were made, qualify all such data as unusable (R).
2. Use professional judgment to qualify the data if it is determined that cross-contamination has occurred.
3. Note in the Data Review Narrative any changes made to the reported compounds or concerns regarding target compound identifications. Note, for Contract Laboratory COR action, the necessity for numerous or significant changes.

### TENTATIVELY IDENTIFIED COMPOUNDS (TICS)

NOTE: Tentatively identified compounds should only be evaluated when requested by a party from outside of the Hazardous Waste Support Section (HWSS).

#### List TICs

| Sample ID | Compound | Sample ID | Compound |
|-----------|----------|-----------|----------|
| =====     |          |           |          |
|           |          |           |          |
|           |          |           |          |
|           |          |           |          |
|           |          |           |          |

### Action:

1. Qualify all TIC results for which there is presumptive evidence of a match (e.g. greater than or equal to 85% match) as tentatively identified (NJ), with approximated concentrations. TICs labeled "unknown" are qualified as estimated (J).
2. General actions related to the review of TIC results are as follows:
  - a. If it is determined that a tentative identification of a non-target compound is unacceptable, change the tentative identification to "unknown" or another appropriate identification, and qualify the result as estimated (J).
  - b. If all contractually-required peaks were not library searched and quantitated, the Region's designated representative may request these data from the laboratory.
3. In deciding whether a library search result for a TIC represents a reasonable identification, use professional judgment. If there is more than one possible match, report the result as "either compound X or compound Y". If there is a lack of isomer specificity, change the TIC result to a nonspecific isomer result (e.g., 1,3,5-trimethyl benzene to trimethyl benzene isomer) or to a compound class (e.g., 2-methyl, 3-ethyl benzene to a substituted aromatic compound).
4. The reviewer may elect to report all similar compounds as a total (e.g., all alkanes may be summarized and reported as total hydrocarbons).

## DATA REVIEW WORKSHEETS

5. Target compounds from other fractions and suspected laboratory contaminants should be marked as "non-reportable".
6. Other Case factors may influence TIC judgments. If a sample TIC match is poor, but other samples have a TIC with a valid library match, similar RRT, and the same ions, infer identification information from the other sample TIC results.
7. Note in the Data Review Narrative any changes made to the reported data or any concerns regarding TIC identifications.
8. Note, for Contract Laboratory COR action, failure to properly evaluate and report TICs

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below \_\_\_\_\_

### SAMPLE QUANTITATION AND REPORTED CONTRACT REQUIRED QUANTITATION LIMITS (CRQLS)

#### Action:

1. When a sample is analyzed at more than one dilution, the lower CRQL are used unless a QC exceedance dictates the use of higher CRQLs from the diluted sample. Samples reported with an "E" qualifier should be reported from the diluted sample.
2. If any discrepancies are found, the Region's designated representative may contact the laboratory to obtain additional information that could resolve any differences. If a discrepancy remains unresolved, the reviewer must use professional judgment to decide which value is the most accurate. Under these circumstances, the reviewer may determine that qualification of data is warranted. Note in the Data Review Narrative a description of the reasons for data qualification and the qualification that is applied to the data.
3. For non-aqueous samples, if the solids is less than 10.0%, use professional judgment for both detects and non-detects. If the percent solid for a soil sample is greater than or equal to 10.0% and less than 30.0%, use professional judgment to qualify detects and non-detects. If the percent solid for a soil sample is greater than or equal to 30.0%, detects and non-detects should not be qualified (see Table 11).
4. Note, for Contract Laboratory COR action, numerous or significant failures to accurately quantify the target compounds or to properly evaluate and adjust CRQLs.
5. Results between MDL and CRQL should be qualified as estimated "J".
6. Results < MDL should be reported at the CRQL and qualified "U". MDLs themselves should not be reported.

**Table 11. Percent Solids Actions for Semivolatile Analysis for Non-Aqueous Samples**

| Criteria                | Action                    |                           |
|-------------------------|---------------------------|---------------------------|
|                         | Detects                   | Non-detects               |
| %Solids < 10.0%         | Use professional judgment | Use professional judgment |
| 10.0% ≤ %Solids ≤ 30.0% | Use professional judgment | Use professional judgment |
| %Solids > 30.0%         | No qualification          | No qualification          |

### SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

Sample ID:   JC34340-1  (SIM)      Analyte:   1,4-dioxane        RF:   0.175  

$$\begin{aligned}
 [ ] &= (23472)(4.0)/(202526)(0.175) \\
 &= 2.65 \text{ ppm} \quad \text{Ok}
 \end{aligned}$$

## DATA REVIEW WORKSHEETS

### QUANTITATION LIMITS

A. Dilution performed

| SAMPLE ID  | DILUTION FACTOR | REASON FOR DILUTION                   |
|------------|-----------------|---------------------------------------|
| JC34340-7  | 2 x             | 1,4-dioxane outside calibration range |
| JC34340-8  | 5 x             | 1,4-dioxane outside calibration range |
| JC34340-16 | 50 x            | 1,4-dioxane outside calibration range |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |
|            |                 |                                       |

## DATA REVIEW WORKSHEETS

All criteria were met \_\_\_\_\_  
 Criteria were not met \_\_\_\_\_  
 and/or see below   X  

### FIELD DUPLICATE PRECISION

Sample IDs:   JC34340-7/-8  

Matrix:   Groundwater  

Field duplicate samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

Suggested criteria: if large RPD (> 50 %) is observed, confirm identification of the samples and note differences. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

| COMPOUND   | SQL<br>ug/L | SAMPLE<br>CONC. (ug/l) | DUPLICATE<br>CONC. (ug/l) | RPD  | ACTION   |
|--|-------------|------------------------|---------------------------|------|--|
| 1,4-dioxane  | 3.6         | 105                    | 220                       | 71 % | Results qualified<br>as estimated (J) in<br>affected samples |
|  |             |                        |                           |      |  |
| Field duplicate analyzed as part of this data package. RPD within the required guidance document criteria < 50 % for detected target analytes above 5 SQL except for the cases described in this document. |             |                        |                           |      |  |
|  |             |                        |                           |      |  |
|  |             |                        |                           |      |  |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### OTHER ISSUES

#### A. System Performance

List samples qualified based on the degradation of system performance during sample analysis:

| Sample ID | Comments | Actions |
|-----------|----------|---------|
| =====     | =====    | =====   |
| _____     | _____    | _____   |
| _____     | _____    | _____   |
| _____     | _____    | _____   |
| _____     | _____    | _____   |

Action:

Use professional judgment to qualify the data if it is determined that system performance has degraded during sample analyses. Inform the Contract Laboratory Program COR any action as a result of degradation of system performance which significantly affected the data.

#### B. Overall Assessment of Data

List samples qualified based on other issues:

| Sample ID   | Comments | Actions |
|---|----------|---------|
| =====   | =====    | =====   |
| _____   | _____    | _____   |
| No other issues that required the need to qualify the data. Results are valid and can be used for decision purposes. Other discrepancies are shown below. |          |         |
| _____   | _____    | _____   |
| _____   | _____    | _____   |

**Note:** The acid surrogate standard not added to the LCS analyzed on 12/28/16. The affected samples either was not re-extracted because no sample was left or extracted outside the method recommended holding time. No action taken, professional judgment.

Action:

1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
2. Write a brief narrative to give the user an indication of the analytical limitations of the data. Inform the Contract Laboratory COR the action, any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of

## DATA REVIEW WORKSHEETS

the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).

3. Sometimes, due to dilutions, re-analysis or SIM/Scan runs are being performed, there will be multiple results for a single analyte from a single sample. The following criteria and professional judgment are used to determine which result should be reported:

- The analysis with the lower CRQL
- The analysis with the better QC results
- The analysis with the higher results



## EXECUTIVE NARRATIVE

SDG No: **JC34340** Laboratory: **Accutest, New Jersey**  
Analysis: **SW846-8015C** Number of Samples: **14**  
Location: **BMSMC, Building 5 Area**  
**Humacao, PR**

**SUMMARY:** Fourteen (14) samples were analyzed for the low molecular weight alcohols (LMWAs) list following method SW846-8015C. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: "Test Methods for Evaluating Solid Waste, Physical/Chemical Methods SW-846 (Final Update III, December 1996)," specifically for Methods 8000/8015C are utilized. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

**Critical issues:** **None**  
**Major:** **None**  
**Minor:** **None**

**Critical findings:** **None**  
**Major findings:** **None**  
**Minor findings:** **None**

**COMMENTS:** Results are valid and can be used for decision making purposes.

**Reviewers Name:** **Rafael Infante**  
**Chemist License 1888**



**Signature:**

**Date:** **January 28, 2017**

**SAMPLE ORGANIC DATA SAMPLE SUMMARY****Sample ID: JC34340-1****Sample location: BMSMC Building 5 Area****Sampling date: 12/20/2016****Matrix: Groundwater****METHOD: 8015C**

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

**Sample ID: JC34340-2****Sample location: BMSMC Building 5 Area****Sampling date: 12/20/2016****Matrix: Groundwater****METHOD: 8015C**

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

**Sample ID: JC34340-3****Sample location: BMSMC Building 5 Area****Sampling date: 12/20/2016****Matrix: AQ - Field Blank Water****METHOD: 8015C**

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-4  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: AQ - Equipment Blank

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-7  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-8  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-9  
Sample location: BSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-10  
Sample location: BSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-11  
Sample location: BSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-12  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/21/2016  
Matrix: AQ - Field Blank Water

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-15  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: AQ - Equipment Blank

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-16  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isobutyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Isopropyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Propyl Alcohol  | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| n-Butyl Alcohol   | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| sec-Butyl Alcohol | 100    | ug/l  | 1.0             | -        | U          | Yes        |
| Methanol          | 200    | ug/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-16MS  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 4400   | ug/l  | 1.0             | -        | -          | Yes        |
| Isobutyl Alcohol  | 4800   | ug/l  | 1.0             | -        | -          | Yes        |
| Isopropyl Alcohol | 4430   | ug/l  | 1.0             | -        | -          | Yes        |
| n-Propyl Alcohol  | 4690   | ug/l  | 1.0             | -        | -          | Yes        |
| n-Butyl Alcohol   | 4230   | ug/l  | 1.0             | -        | -          | Yes        |
| sec-Butyl Alcohol | 5370   | ug/l  | 1.0             | -        | -          | Yes        |
| Methanol          | 4110   | ug/l  | 1.0             | -        | -          | Yes        |

Sample ID: JC34340-16MSD  
Sample location: BMSMC Building 5 Area  
Sampling date: 12/22/2016  
Matrix: Groundwater

METHOD: 8015C

| Analyte Name      | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-------------------|--------|-------|-----------------|----------|------------|------------|
| Ethanol           | 5180   | ug/l  | 1.0             | -        | -          | Yes        |
| Isobutyl Alcohol  | 5110   | ug/l  | 1.0             | -        | -          | Yes        |
| Isopropyl Alcohol | 4700   | ug/l  | 1.0             | -        | -          | Yes        |
| n-Propyl Alcohol  | 5200   | ug/l  | 1.0             | -        | -          | Yes        |
| n-Butyl Alcohol   | 4530   | ug/l  | 1.0             | -        | -          | Yes        |
| sec-Butyl Alcohol | 5700   | ug/l  | 1.0             | -        | -          | Yes        |
| Methanol          | 4670   | ug/l  | 1.0             | -        | -          | Yes        |

# DATA REVIEW WORKSHEETS

Project Number: JC34340  
 Date: 12/20-22/2016  
 Shipping Date: 12/22/2016  
 EPA Region: 2

## REVIEW OF VOLATILE ORGANIC PACKAGE

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: "Test Methods for Evaluating Solid Waste, Physical/Chemical Methods SW-846 (Final Update III, December 1996)," specifically for Methods 8000/8015C are utilized. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Accutest data package received has been reviewed and the quality control and performance data summarized. The modified data review for VOCs included:

Lab. Project/SDG No.: JC34340 Sample matrix: Groundwater  
 No. of Samples: 14

Trip blank No.: -  
 Field blank No.: JC34340-3; JC34340-12  
 Equipment blank No.: JC34340-4; JC34340-15  
 Field duplicate No.: JC34340-7/JC34340-8

|   |   |
|---|---|
| <input checked="" type="checkbox"/> Data Completeness                   | <input checked="" type="checkbox"/> Laboratory Control Spikes |
| <input checked="" type="checkbox"/> Holding Times                       | <input checked="" type="checkbox"/> Field Duplicates          |
| <input type="checkbox"/> N/A GC/MS Tuning                               | <input checked="" type="checkbox"/> Calibrations              |
| <input type="checkbox"/> N/A Internal Standard Performance              | <input checked="" type="checkbox"/> Compound Identifications  |
| <input checked="" type="checkbox"/> Blanks                              | <input checked="" type="checkbox"/> Compound Quantitation     |
| <input checked="" type="checkbox"/> Surrogate Recoveries                | <input checked="" type="checkbox"/> Quantitation Limits       |
| <input checked="" type="checkbox"/> Matrix Spike/Matrix Spike Duplicate |   |

Overall Comments: Low molecular weight alcohols by SW-846\_8015C.

### Definition of Qualifiers:

J- Estimated results  
 U- Compound not detected  
 R- Rejected data  
 UJ- Estimated nondetect

Reviewer:   
 Date: January 28, 2017

## DATA REVIEW WORKSHEETS

## DATA COMPLETENESS

### MISSING INFORMATION

DATE LAB. CONTACTED

DATE RECEIVED

This image shows a blank sheet of white paper with horizontal blue or grey ruling lines. A single dashed diagonal line runs from the upper-left corner towards the lower-right corner, likely serving as a guide for writing or drawing. The paper appears to be a standard notebook page.



## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below \_\_\_\_\_

### HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

| SAMPLE ID   | DATE SAMPLED | DATE ANALYZED | pH | ACTION |
|---|--------------|---------------|----|--------|
|   |              |               |    |        |
| All samples analyzed within the recommended method holding. All samples properly preserved. |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |

### Criteria

Aqueous samples – 14 days from sample collection for preserved samples ( $\text{pH} \leq 2$ ,  $4^{\circ}\text{C}$ ), no air bubbles.

Aqueous samples – 7 days from sample collection for unpreserved samples,  $4^{\circ}\text{C}$ , no air bubbles.

Soil samples- 7 days from sample collection.

Cooler temperature (Criteria:  $4 \pm 2^{\circ}\text{C}$ ):  $5.4^{\circ}\text{C}$

### Actions

If the VOCs vial(s) have air bubbles, estimate positive results (J) and reject nondetects (R).

If the % solids of soil samples is 10-50%, estimates positive results (J) and nondetects (UJ)

If the % solid of soil samples is  $< 10\%$ , estimate positive results (J) and reject nondetects (R).

If holding times are exceeded but  $< 14$  days beyond criteria, estimate positive results (J) and nondetects (UJ).

If holding times are exceeded but  $< 28$  days beyond criteria, estimate positive results (J) and reject nondetects (R).

If holding times are grossly exceeded ( $> 28$  days beyond criteria), reject all results (R).

If samples were not iced or if the ice were melted ( $> 10^{\circ}\text{C}$ ), estimate positive results (J) and nondetects (UJ).

## DATA REVIEW WORKSHEETS

All criteria were met N/A  
Criteria were not met see below \_\_\_\_\_

### GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

N/A The BFB performance results were reviewed and found to be within the specified criteria.

N/A BFB tuning was performed for every 12 hours of sample analysis.

If no, use professional judgment to determine whether the associated data should be accepted, qualified or rejected.

List the samples affected: \_\_\_\_\_

If mass calibration is in error, all associated data are rejected.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 10/10/16  
 Dates of continuing calibration: 12/29/16; 12/30/16  
 Dates of final calibration verification: 10/10/10; 12/29/16; 12/30/16  
 Instrument ID number: GCGH  
 Matrix/Level: Aqueous/low

| DATE | LAB FILE ID# | CRITERIA OUT<br>RFs, %RSD, %D, r | COMPOUND | SAMPLES<br>AFFECTED |
|------|--------------|----------------------------------|----------|---------------------|
|      |              |                                  |          |                     |
|      |              |                                  |          |                     |
|      |              |                                  |          |                     |
|      |              |                                  |          |                     |
|      |              |                                  |          |                     |
|      |              |                                  |          |                     |

**Note:** Initial, continuing, and final calibration verifications meets method specific criteria in at least one of the two columns. Final calibration verification included in data packages.

#### Criteria

All RFs must be  $> 0.05$  regardless of method requirements for SPCC.

All %RSD must be  $\leq 15\%$  regardless of method requirements for CCC.

All %Ds must be  $\leq 20\%$  regardless of method requirements for CCC.

It should be noted that Region 2 SOP HW-24 does not specify criterion for the curve correlation coefficient (r). A limit for r of  $\geq 0.995$  has therefore been utilized as professional judgment.

#### Actions

If any compound has an initial RF or a continuing RF of  $< 0.05$ , estimate positive results (J) and reject nondetects (R), regardless of method requirements.

If any compound has a %RSD  $> 15\%$ , estimate positive results (J) and use professional judgment to qualify nondetects.

If any compound has a %RSD  $> 90\%$ , estimate positive results (J) and reject nondetects (R).

If any compound has a %D  $> 20\%$ , estimate positive results (J) and reject nondetects (R).

If any compound has a %D  $> 20\%$ , estimate positive results (J) and nondetects (UJ).

If any compound has a %D  $> 90\%$ , estimate positive results (J) and reject nondetects (R).

If any compound has  $r < 0.995$ , estimate positive results and nondetects.

A separate worksheet should be filled for each initial curve

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below \_\_\_\_\_

#### V A. BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

### Laboratory blanks

| DATE ANALYZED                                   | LAB ID | LEVEL/MATRIX | COMPOUND | CONCENTRATION UNITS |
|---|--------|--------------|----------|---------------------|
|   |        |              |          |                     |
|   |        |              |          |                     |
| All method blank meeth method specific criteria |        |              |          |                     |
|   |        |              |          |                     |
|   |        |              |          |                     |
|   |        |              |          |                     |

## Field/Equipment/Trip blank

[illegible]

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### V B. BLANK ANALYSIS RESULTS (Section 3)

#### Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

ALs = 10x the amount of common contaminants (methylene chloride, acetone, 2-butanone, and toluene)  
 ALs = 5x for any other compounds

Specific actions are as follows:

If the concentration is < sample quantitation limit (SQL) and  $\leq$  AL, report the compound as not detected (U) at the SQL.

If the concentration is  $\geq$  SQL but  $\leq$  AL, report the compound as not detected (U) at the reported concentration.

If the concentration is  $\geq$  SQL and > AL, report the concentration unqualified.

Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

| CONTAMINATION<br>SOURCE/LEVEL | COMPOUND | CONC/UNITS | AL/UNITS | SQL | AFFECTED<br>SAMPLES |
|-------------------------------|----------|------------|----------|-----|---------------------|
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |

# DATA REVIEW WORKSHEETS

All criteria were met ☒   
 Criteria were not met   
 and/or see below \_\_\_\_\_

## SURROGATE SPIKE RECOVERIES

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

List the percent recoveries (%Rs) which do not meet the criteria for surrogate recovery.

Matrix: solid/aqueous

| SAMPLE ID     | SURROGATE COMPOUND |      |        |     | ACTION |
|---------------|--------------------|------|--------|-----|--------|
|               | Hexanol            | DBFM | TOL-d8 | BFB |        |
|               | S1 a               | S1 b |        |     |        |
| JC34340-1     | 102                | 85   |        |     |        |
| JC34340-2     | 97                 | 79   |        |     |        |
| JC34340-3     | 103                | 87   |        |     |        |
| JC34340-4     | 100                | 85   |        |     |        |
| JC34340-7     | 84                 | 79   |        |     |        |
| JC34340-8     | 66                 | 61   |        |     |        |
| JC34340-9     | 76                 | 73   |        |     |        |
| JC34340-10    | 85                 | 82   |        |     |        |
| JC34340-11    | 82                 | 81   |        |     |        |
| JC34340-12    | 99                 | 81   |        |     |        |
| JC34340-15    | 91                 | 88   |        |     |        |
| JC34340-16    | 89                 | 85   |        |     |        |
| GGH5599-BS    | 98                 | 98   |        |     |        |
| GGH5599-MB2   | 87                 | 90   |        |     |        |
| GGH5600-BS    | 94                 | 97   |        |     |        |
| GGH5600-MB2   | 78                 | 84   |        |     |        |
| JC34212-5MS   | 86                 | 68   |        |     |        |
| JC34212-5MSD  | 82                 | 85   |        |     |        |
| JC34340-16MS  | 88                 | 85   |        |     |        |
| JC34340-16MSD | 87                 | 88   |        |     |        |
| GGH5599-MB1   | 86                 | 87   |        |     |        |

(a) Recovery from GC signal #2

(b) Recovery from GC signal #1

**Note:** All surrogate recoveries within laboratory control limits.

QC Limits\* (Aqueous)

\_\_\_\_ LL to UL \_\_\_\_ 56 to 145 \_\_\_\_ to \_\_\_\_ to \_\_\_\_ to \_\_\_\_

QC Limits\* (Solid-Low)

\_\_\_\_ LL to UL \_\_\_\_ to \_\_\_\_ to \_\_\_\_ to \_\_\_\_ to \_\_\_\_

QC Limits\* (Solid-Med)

\_\_\_\_ LL to UL \_\_\_\_ to \_\_\_\_ to \_\_\_\_ to \_\_\_\_ to \_\_\_\_

## DATA REVIEW WORKSHEETS

1,2-DCA = 1,2-Dichloromethane-d4  
DBFM = Dibromofluoromethane

TOL-d8 = Toluene-d8  
BFB = Bromofluorobenzene

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 80 – 120 % for aqueous and 70 – 130 % for solid samples.

Actions:

| QUALITY            | %R < 10% | %R = 10% - LL | %R > UL |
|--------------------|----------|---------------|---------|
| Positive results   | J        | J             | J       |
| Nondetects results | R        | UJ            | Accept  |

Surrogate action should be applied:

If one or more surrogate in the VOC fraction is out of specification, but has a recovery of > 10%.  
If any one surrogate in a fraction shows < 10 % recovery.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### VII. A MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

#### 1. MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID: JC34212-5MS/-5MSD Matrix/Level: Groundwater/low  
 Sample ID: JC34340-16MS/-16MSD Matrix/Level: Groundwater/low

| MS OR MSD | COMPOUND | % R | RPD | QC LIMITS | ACTION |
|-----------|----------|-----|-----|-----------|--------|
|-----------|----------|-----|-----|-----------|--------|

MS/MSD % recoveries and RPD within laboratory control limits.

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

#### Note:

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

Actions:

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |



## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (UJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

### VII. B MATRIX SPIKE/MATRIX SPIKE DUPLICATE

#### MS/MSD – Unspiked Compounds

It should be noted that Region 2 SOP HW-24 does not specify a MS/MSD criteria for the unspiked compounds in the sample. A %RSD of < 50% has therefore been utilized as professional judgment.

If all target analytes were spiked in the MS/MSD, this review element is not applicable.

List the %RSD of the compounds which do not meet the criteria.

Sample ID: \_\_\_\_\_ - \_\_\_\_\_ Matrix/Level/Unit: \_\_\_\_\_ - \_\_\_\_\_

| COMPOUND | SAMPLE<br>CONC. | MS CONC. | MSD CONC. | % RSD | ACTION |
|----------|-----------------|----------|-----------|-------|--------|
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |
|          |                 |          |           |       |        |

Actions:

\* If the % RSD > 50, qualify the positive result in the unspiked samples as estimated (J).

\* If the % RSD is not calculated (NC) due to nondetected value, use professional judgment to qualify the data.

A separate worksheet should be used for each MS/MSD pair.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### VIII. LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

#### 1. LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD? **Yes**  
 or No. If no make note in data review memo.

List the %R of compounds which do not meet the criteria

| LCS ID   | COMPOUND | % R | QC LIMIT |
|--|----------|-----|----------|
| Recoveries within laboratory control limits. _____ |          |     |          |
| _____  |          |     |          |
| _____  |          |     |          |
| _____  |          |     |          |

#### Note:

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

#### Actions:

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (j) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

#### 2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? Yes or No.

If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

## DATA REVIEW WORKSHEETS

All criteria were met ☒ X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### IX. FIELD/LABORATORY DUPLICATE PRECISION

Sample IDs: JC34340-7/JC34340-8

Matrix: Groundwater

Field/laboratory duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

Suggested criteria: RPD  $\pm$  30% for aqueous samples, RPD  $\pm$  50 % for solid samples. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

| COMPOUND   | SQL | SAMPLE CONC. | DUPLICATE CONC. | RPD | ACTION |
|--|-----|--------------|-----------------|-----|--------|
|  |     |              |                 |     |        |
| Field duplicates analyzed with this data package. RPD within laboratory, generally acceptable and guidance document performance criteria control limits. |     |              |                 |     |        |
|  |     |              |                 |     |        |
|  |     |              |                 |     |        |

#### Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

## DATA REVIEW WORKSHEETS

All criteria were met N/A  
Criteria were not met  
and/or see below \_\_\_\_\_

## X. INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

List the internal standard area of samples which do not meet the criteria.

- \* Area of +100% or -50% of the IS area in the associated calibration standard.
- \* Retention time (RT) within 30 seconds of the IS area in the associated calibration standard.

| DATE | SAMPLE ID | IS OUT | IS AREA | ACCEPTABLE RANGE | ACTION |
|------|-----------|--------|---------|------------------|--------|
|------|-----------|--------|---------|------------------|--------|

| Age Group | Percentage |
|-----------|------------|
| 18-24     | 10%        |
| 25-34     | 15%        |
| 35-44     | 20%        |
| 45-54     | 25%        |
| 55-64     | 30%        |
| 65+       | 95%        |

**Actions:**

1. IS actions should be applied to the compound quantitated with the out-of-control ISs

| QUALITY             | IS AREA < -25% | IS AREA = -25 %<br>TO – 50% | IS AREA > + 100% |
|---------------------|----------------|-----------------------------|------------------|
| Positive results    | J              | J                           | J                |
| Nondetected results | R              | UJ                          | ACCEPT           |

2. If a IS retention time varies more than 30 seconds, the chromatographic profile for that sample must be examined to determine if any false positive or negative exists. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for the sample fraction.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### XII. SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

JC34340-16MS

n-propyl alcohol

RF = 25.71

$$[ ] = (143046)/(25.71)$$

$$= 5,564 \text{ ppm OK}$$

| Age Group | Percentage of Respondents |
|-----------|---------------------------|
| 18-29     | 65%                       |
| 30-49     | 75%                       |
| 50-69     | 80%                       |
| 70+       | 85%                       |

All criteria were met X  
Criteria were not met  
and/or see below \_\_\_\_\_

## XII. QUANTITATION LIMITS

**A. Dilution performed**

[illegible]

### B. Percent Solids

List samples which have  $\leq 50\%$  solids

**Actions:**

If the % solids of a soil sample is 10-50%, estimate positive results (J) and nondetects (UJ)

If the % solids of a soil sample is  $< 10\%$ , estimate positive results (J) and reject nondetects (R)

## MEMORANDUM

**TO:** Mr. Haley Royer  
Anderson, Mulholland and Associates

**DATE:** January 26, 2017

**FROM:** R. Infante

**FILE:** JC34340

**RE:** Data Validation  
**SDG:** JC34340

### SUMMARY

Full validation was performed on the data for two groundwater samples analyzed for dissolved methane by method RSK-175. The samples were collected at the Bristol Myer Squib-Building 5 Area, Humacao, PR site on December 20-21, 2016 and submitted to Accutest Laboratories of Dayton, New Jersey that analyzed and reported the results under delivery groups (SDG) JC34340. The sample results were assessed according to USEPA general data validation guidance documents.

In general the data is valid as reported and may be used for decision making purposes. The data results are acceptable for use.

### SAMPLES

The samples included in the review are listed below

| Client<br>Sample ID | Lab. Sample ID | Collected<br>Date | Matrix      | Analysis |
|---------------------|----------------|-------------------|-------------|----------|
| MW-18               | JC34340-2      | 12/20/16          | Groundwater | Methane  |
| BR-2                | JC34340-9      | 12/21/16          | Groundwater | Methane  |

### REVIEW ELEMENTS

Sample data were reviewed for the following parameters, where applicable to the method

- o Agreement of analysis conducted with chain of custody (COC) form
- o Holding time and sample preservation
- o Gas chromatography/mass spectrometry (GC/MS) tunes
- o Initial and continuing calibrations
- o Method blanks/trip blanks/field blank
- o Canister cleaning certification criteria
- o Surrogate spike recovery
- o Internal standard performance and retention times
- o Field duplicate results
- o Laboratory control sample/laboratory control sample duplicate (LCS/LCSD) results
- o Quantitation limits and sample results

## **DISCUSSION**

### **Agreement of Analysis Conducted with COC Request**

Sample reports corresponded to the analytical request designated on the chain-of-custody.

### **Holding Times and Sample Preservation**

Sample preservation was acceptable.

Samples analyzed within method recommended holding time.

### **Initial and Continuing Calibrations**

Initial and continuing calibrations meet method specific requirements. Initial calibration retention times meet method specific requirements.

### **Method Blank/Trip Blank/Field Blank**

Target analytes were not detected in laboratory method blanks.

No trip/field/equipment blank analyzed with this data package.

### **Laboratory/Field Duplicate Results**

Field duplicates were analyzed as part of this data set. Target analytes meet the RPD performance criteria of  $\pm 25\%$  for analytes  $5 \times \text{SQL}$ .

- JC34212-13/-13DUP - 21 % RPD outside the in house control limits ( $\pm 14\%$ ). No action taken, duplicate RPD apply to the sample and its duplicate. Sample and its duplicate from another job. RPD within generally acceptable control limits.

### **LCS/LCSD Results**

LCS (blank spike) was analyzed by the laboratory associated with this data package. Recoveries and RPD within laboratory control limits.


### **Quantitation Limits and Sample Results**

Dilutions were not performed.

Calculations were spot checked.

### **Summary**

Samples JC34340-2 and JC34340-9 were analyzed following standard procedures accepted by regulatory agencies. The quality control requirements met the methods criteria except in the occasions described in this document.



Rafael Infante  
Chemist License 1888



## SAMPLE METHANE DATA SAMPLE SUMMARY

Sample ID: JC34340-2

Sample location: BMSMC Building 5 Area

Sampling date: 20-Dec-16

Matrix: Groundwater

METHOD: RSK -175

| Analyte Name | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|--------------|--------|-------|-----------------|----------|------------|------------|
| Methane      | 0.48   | ug/l  | 100             | -        | -          | Yes        |

Sample ID: JC34340-9

Sample location: BMSMC Building 5 Area

Sampling date: 21-Dec-16

Matrix: Groundwater

METHOD: RSK-175

| Analyte Name | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|--------------|--------|-------|-----------------|----------|------------|------------|
| Methane      | 4.0    | ug/l  | 20              | -        | -          | Yes        |

## MEMORANDUM

TO: Mr. Haley Royer  
Anderson, Mulholland and Associates

DATE: January 28, 2017

FROM: R. Infante *RMI*

FILE: JC34340

RE: Data Validation  
BMSMC, Building 5 Area  
SM04.00.06/  
Accutest Job Numbers: JC34340

### SUMMARY

Full validation was performed on the data for two (2) groundwater samples analyzed selected inorganics (iron - ferric and ferrous; nitrate-nitrogen; nitrite-nitrogen; nitrate + nitrite - nitrogen; sulfate and sulfide). The methods employed are listed in Table 1. The samples were collected at the BMSMC, Building 5 Area, Humaco, PR site on December 20-21, 2016 and submitted to Accutest Laboratories of Dayton, New Jersey that analyzed and reported the results under delivery groups (SDG) JC34340.

Table 1.

| ANALYTE                        | METHOD              | ANALYTE                     | METHOD              |
|--------------------------------|---------------------|-----------------------------|---------------------|
| Iron, ferric <sup>a</sup>      | SM3500FE B-11       | Iron, ferrous <sup>b</sup>  | SM3500FE B-11       |
| Nitrogen, nitrate <sup>c</sup> | EPA353.2/SM4500NO2B | Nitrogen, nitrate + nitrite | EPA352.2/LACHAT     |
| Nitrogen, nitrite              | SM4500NO2 B-11      | Sulfate                     | EPA 300/SW846-9056A |
| Sulfide                        | SM4500S2-F-11       |                             |                     |

(a) Calculated as: (Iron) - (Iron, Ferrous)

(b) Field analysis required. Received out of hold time and analyzed by request.

(c) Calculated as: (Nitrogen, Nitrate + Nitrite) - (Nitrogen, Nitrite)

The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: *USEPA Contract Laboratory program National Functional Guidelines for Inorganic data Review (OSWER 9240.1-45, EPA 540-R-04-004, October 2004- Final)*, (noted herein as the "primary guidance document"). Also, QC criteria from *"Test Methods for Evaluating Solid Waste, Physical/Chemical Methods SW-846 (Final Update IV, December 1998)"*, and the QC requirements for the methods performed following the Standard Method guidelines are utilized. The guidelines were modified to accommodate the non-CLP methodology. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

In general the data are valid as reported and may be used for decision making purposes. The data results are acceptable for use; some of the results were qualified. Results for ferrous and ferric iron were qualified as estimated (J) in samples: JC34340-2; and -9. Results for Nitrate + Nitrite Nitrogen qualified as estimated (J) in samples: JC34340-1. Results for Nitrite qualified as estimated (J or UJ) in samples JC34340-2 and -9. Results for Nitrate are qualified as estimated (J or UJ) in samples JC34340-2 and -9.

## SAMPLES

The samples included in the review are listed below

| FIELD SAMPLE ID | LABORATORY ID | ANALYSIS    |
|-----------------|---------------|-------------|
| MW-18           | JC34340-2     | See Table 1 |
| BR-2            | JC34340-9     | See Table 1 |

## REVIEW ELEMENTS

Sample data were reviewed for the following parameters, where applicable to the method

- Agreement of analysis conducted with chain of custody (COC) form
- Holding time and sample preservation
- Initial and continuing calibrations
- Method blanks/trip blanks/field blank
- Surrogate spike recovery
- Matrix spike/matrix spike duplicate (MS/MSD) results
- Internal standard performance
- Field duplicate results
- Laboratory control sample/laboratory control sample duplicate (LCS/LCSD) results
- Quantitation limits and sample results

## DISCUSSION

### Agreement of Analysis Conducted with COC Request

Sample reports corresponded to the analytical request designated on the chain-of-custody form.

### Holding Times and Sample Preservation

The cooler temperatures were within the QC acceptance criteria of  $4^{\circ}\text{C} \pm 2^{\circ}\text{C}$ .

Sample preservation was acceptable.

Samples analyzed within method recommended holding time except for the following:

- JC34340-2 for Iron, Ferrous: Field analysis required. Received out of hold time and analyzed by request.
- JC34340-9 for Iron, Ferrous: Field analysis required. Received out of hold time and analyzed by request.
- Nitrite analysis done past holding time. The samples were received and analyzed out of holding time.

**Note:** Results for ferrous and ferric iron qualified as estimated (J). Results for Nitrite qualified as estimated (J). Results for Nitrate are qualified as estimated (J or U) in samples JC34340-2 and -9.

### **Initial and Continuing Calibrations**

Initial and continuing calibration meets method performance criteria.

### **Method Blank/Equipment Blank/Field Blank**

Target analytes were not detected in laboratory method blanks above the reporting limit.

No field/equipment blanks analyzed as part of this data package.

### **MS/MSD**

Matrix spike was performed. Recoveries for MS/MSD were within laboratory control limits; RPD for MS/MSD were within control limits.

### **Field/Laboratory Duplicate Results**

Field/laboratory duplicate were analyzed as part of this data set. When no field/laboratory duplicates were analyzed, MS/MSD RPD was used to assess precision. RPD results were within laboratory/recommended control limits except for the following:

- Iron, Ferrous JC34340-2 - 23.3 % RPD; control limit  $\pm 20\%$ . No action taken, low sample and duplicate concentration;  $< 5 \times \text{IDL}$ .
- Nitrogen, Nitrate + Nitrite JC34362-1 - 72.7 % RPD; control limit  $\pm 22\%$ . No action taken, low sample and duplicate concentration;  $< 5 \times \text{IDL}$ . QC sample from another job.

### **LCS/LCSD Results**

The laboratory analyzed one LCS (blank spike) associated with each matrix from this data set. The % recoveries of all spiked analytes were within the laboratory QC acceptance limits.

### **Quantitation Limits and Sample Results**

Dilutions were not required with this data set.

Calculations were spot checked.

### **Summary**

The following samples JC34340-2 and JC34340-9 were analyzed following standard procedures accepted by regulatory agencies. The quality control requirements met the methods criteria except in the occasions described in this document. Some of the results were qualified, the results are valid.



Rafael Infante  
Chemist License 1888

# SAMPLE INORGANIC DATA SAMPLE SUMMARY

Sample ID: JC34340-2

Sample location: BMSMC Building 5 Area

Sampling date: 12/20/2016

Matrix: Groundwater

| Analyte Name                | Method               | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-----------------------------|----------------------|--------|-------|-----------------|----------|------------|------------|
| Fe                          | SW846-6010C          | 2130   | ug/l  | 1.0             | -        | -          | Yes        |
| Mn                          | SW846-6010C          | 75     | ug/l  | 1.0             | -        | -          | Yes        |
| Alkalinity, Total as CaCO3  | SM2320 B-11          | 207    | mg/l  | 1.0             | -        | -          | Yes        |
| Iron, ferric                | SM3500FE B-11        | 2.0    | mg/l  | 1.0             | -        | J          | Yes        |
| Iron, ferrous               | SM3500FE B-11        | < 0.20 | mg/l  | 1.0             | -        | J          | Yes        |
| Nitrogen, nitrate           | EPA 353.2/SM4500NO2B | 0.58   | mg/l  | 1.0             | -        | J          | Yes        |
| Nitrogen, nitrate + nitrite | EPA 353.2/LACHAT     | 0.59   | mg/l  | 1.0             | -        | -          | Yes        |
| Nitrogen, nitrite           | SM4500NO2 B-11       | 0.015  | mg/l  | 1.0             | -        | J          | Yes        |
| Sulfate                     | EPA 300/SW846 9056A  | < 10   | mg/l  | 1.0             | -        | U          | Yes        |
| Sulfide                     | SM4500S2- F-11       | < 2.0  | mg/l  | 1.0             | -        | U          | Yes        |

Sample ID: JC34340-9

Sample location: BMSMC Building 5 Area

Sampling date: 12/21/2016

Matrix: Groundwater

| Analyte Name                | Method               | Result  | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-----------------------------|----------------------|---------|-------|-----------------|----------|------------|------------|
| Fe                          | SW846-6010C          | 3320    | ug/l  | 1.0             | -        | -          | Yes        |
| Mn                          | SW846-6010C          | 166     | ug/l  | 1.0             | -        | -          | Yes        |
| Alkalinity, Total as CaCO3  | SM2320 B-11          | 289     | mg/l  | 1.0             | -        | -          | Yes        |
| Iron, ferric                | SM3500FE B-11        | 3.3     | mg/l  | 1.0             | -        | J          | Yes        |
| Iron, ferrous               | SM3500FE B-11        | <0.20   | mg/l  | 1.0             | -        | J          | Yes        |
| Nitrogen, nitrate           | EPA 353.2/SM4500NO2B | <0.11   | mg/l  | 1.0             | -        | J          | Yes        |
| Nitrogen, nitrate + nitrite | EPA 353.2/LACHAT     | <0.10   | mg/l  | 1.0             | -        | -          | Yes        |
| Nitrogen, nitrite           | SM4500NO2 B-11       | < 0.010 | mg/l  | 1.0             | -        | UJ         | Yes        |
| Sulfate                     | EPA 300/SW846 9056A  | 38.6    | mg/l  | 1.0             | -        | -          | Yes        |
| Sulfide                     | SM4500S2- F-11       | < 2.0   | mg/l  | 1.0             | -        | U          | Yes        |

# DATA REVIEW WORKSHEETS

Type of validation Full: X Project Number: JC34340  
 Limited: \_\_\_\_\_ Date: 12/20-21/2016  
 EPA Region: 2 Date shipped: 12/22/16

## REVIEW OF INORGANIC ANALYSIS DATA PACKAGE

The following guidelines for evaluating metals analyses (6010C/6020/7000A series method) sulfide, and/or cyanide were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: *Hazardous Waste Support Section SOP N0. HW-3b Revision 0 (July 2015) ISM02 ICP-MS Data Validation; USEPA Contract Laboratory program National Functional Guidelines for Inorganic data Review (OSWER 9240.1-45, EPA 540-R-04-004, October 2004- Final). Validation of Metal for the Contract Laboratory Program (CLP) (SOP HW-2, Revision 13. Based on ILM05.3 (August 2009).* Quality control validation criteria were derived from "Test Methods for Evaluating Solid Waste, Physical/Chemical Methods SW-846 (Final Update IV, 1998)". The project QAPP is reviewed for project specific information (if available). The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Accutest data package received has been reviewed and the quality control and performance data summarized. The data review for inorganic included:

Lab. Project/SDG No.: JC34340 Sample matrix: Groundwater  
 No. of Samples: 2  
 Field blank No.: -  
 Equipment blank No.: -  
 Field duplicate No.: -

|  |                                      |
|--|--------------------------------------|
| <u>X</u> Data deliverables                   | <u>X</u> Laboratory Duplicates       |
| <u>X</u> Holding Times                       | <u>X</u> Field Duplicates            |
| <u>X</u> Calibrations                        | <u>X</u> Laboratory Control Samples  |
| <u>X</u> Blanks                              | <u>X</u> ICP Serial Dilution Results |
| <u>X</u> ICP Interference Check Results      | <u>X</u> Detection Limits Results    |
| <u>X</u> Matrix Spike/Matrix Spike Duplicate | <u>X</u> Sample Quantitation         |

Overall Comments: Fe\_and\_Mn\_(SW846-6010C)  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

### Definition of Qualifiers:

J- Estimated results  
 U- Compound not detected  
 R- Rejected data  
 UJ- Estimated non-detect  
 E- Laboratory qualifier

Reviewer: Rafael Difant Date: 01/28/2017

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below \_\_\_\_\_

## I. DATA DELIVERABLES

**A. Data Package:**

### MISSING INFORMATION

DATE LAB. CONTACTED

DATE RECEIVED

[illegible]

**B. Other Discrepancies:**

[illegible]

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of preparation, and subsequently from the time of preparation to the time of analysis.

Complete table for all samples and circle the analysis date for samples not within criteria

| SAMPLE ID   | DATE SAMPLED | CYANIDE DATE ANALYSIS | Hg DATE ANALYSIS | OTHERS DATE ANALYSIS | pH | SULFIDE | ACTION |
|---|--------------|-----------------------|------------------|----------------------|----|---------|--------|
|   |              |                       |                  |                      |    |         |        |
|   |              |                       |                  |                      |    |         |        |
| SAMPLES DIGESTED AND ANALYZED WITHIN THE METHOD RECOMMENDED HOLDING |              |                       |                  |                      |    |         |        |
|   |              |                       |                  |                      |    |         |        |
|   |              |                       |                  |                      |    |         |        |
|   |              |                       |                  |                      |    |         |        |
|   |              |                       |                  |                      |    |         |        |
|   |              |                       |                  |                      |    |         |        |

### Criteria

Metals – 180 days from time of collection.

Mercury – 28 days from time of collection.

Hexavalent Chromium (solids)- 30/7 from day of collection; 48 hrs aqueous samples

Cyanide – 14 days from time of collection

Sulfide - 14 days from time of collection

pH measurements of aqueous samples upon receipt at the laboratory (criteria  $\text{pH} \leq 2$  for metals;

$\text{pH} \geq 12$  for cyanide)

Actions: Qualify positive results/nondetects as follows:

If holding times are exceeded, estimate positive results (J) and rejects nondetects (R).

If  $\text{pH} > 2$  for metals or  $\text{pH} < 12$  for cyanide, positive results (J) and nondetects (UJ).

Cooler Temperature (Criteria:  $4^{\circ}\text{C} + 2^{\circ}\text{C}$ ):   5.4°C  

If cooler temperature is  $> 10^{\circ}\text{C}$ , flag non-detects as (UJ) and detects as (J).



## DATA REVIEW WORKSHEETS

All criteria were met \_\_\_N/A\_\_\_  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### ICP-MS TUNE ANALYSIS

Is the ICP-MS tuned prior to calibration? Yes or No?

Does the % RSD exceeds 5% for any isotope in the tuning solution? Yes or No?

#### Action:

**NOTES:** For ICP-MS tunes that do not meet the technical criteria, apply the action to all samples reported from the analytical run.

1. If the ICP-MS instrument was not tuned prior to calibration, the sample data should be qualified as unusable (R).

2. If the tuning solution was not analyzed or scanned at least 5x consecutively or the tuning solution does not contain the required analytes spanning the analytical range, the reviewer should use professional judgment to determine if the associated sample data should be qualified. The reviewer may need to obtain additional information from the laboratory. The situation should be recorded in the Data Review Narrative and noted for Contract Laboratory Program Project Officer (CLP PO) action.

3. If the resolution of the mass calibration is not within 0.1 u for any isotope in the tuning solution, qualify all analyte results that are  $\geq$  Method Detection Limit (MDL) associated with that isotope as estimated (J), and all non-detects associated with that isotope as estimated (UJ). The situation should be recorded in the Data Review Narrative and noted for CLP PO action.

4. If the %RSD exceeds 5% for any isotope in the tuning solution, qualify all sample results that are  $\geq$  MDL associated with that tune as estimated (J), and all non-detects associated with that tune as estimated (UJ). The situation should be recorded in the Data Review Narrative and noted for CLP PO action.

**Table 2. ICP-MS Tune Actions for ICP-MS Analysis**

| ICP-MS Tune Results                            | Action for Samples  |
|--|---|
| Tune not performed                             | Qualify all results as unusable (R)   |
| Tune not performed properly                    | Use professional judgment   |
| Resolution of mass calibration not within 0.1u | Qualify results that are $\geq$ MDL as estimated (J)<br>Qualify non-detects as estimated (UJ) |
| % RSD > 5%                                     | Qualify results that are $\geq$ MDL as estimated (J)<br>Qualify non-detects as estimated (UJ) |

**Note:** Analytes (As) analyzed by SW846-6010 – no tuning necessary.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### INSTRUMENT CALIBRATION (SECTION 1)

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data. Minimum of 2 calibration points for ICP-AES and ICP-MS; 5 points for Hg; and 4 points for cyanide. One initial calibration standard at the CRQL level for cyanide and Hg. If no, write in the non-compliance section of the data review narrative.

List the analytes which did not meet the percent recovery (%R) criteria for Initial or Continuing Calibration Verification standards (ICV or CCV).

| <u>Acceptance Criteria</u> | <u>ICV %R</u> | <u>CCV %R</u> |
|----------------------------|---------------|---------------|
| Metals by 6010C/6020       | 100 + 10%     | 100 + 10%     |
| Mercury/Metals by 7000s    | 100 + 10%     | 100 + 20%     |
| Cyanide                    | 100 + 15%     | 100 + 15%     |
| Sulfide                    | 100 + 15%     | 100 + 15%     |

| DATE   | ICV/CCV# | ANALYTE | %R | ACTION | SAMPLES AFFECTED |
|--|----------|---------|----|--------|------------------|
|  |          |         |    |        |                  |
| INITIAL AND CONTINUING CALIBRATION MEET METHOD SPECIFIC CRITERIA |          |         |    |        |                  |
|  |          |         |    |        |                  |
|  |          |         |    |        |                  |
|  |          |         |    |        |                  |

**ACTIONS:** If any analyte does not meet the %R criteria, follow the actions stated below. Qualify five samples on either side of the ICV/CCV out of control limit.

| Estimate positive results (J) if: | ICV        | CCV        |
|-----------------------------------|------------|------------|
| Metals by 6010C/6020              | 111 – 125% | 111 – 125% |
| Mercury/Metals by 7000s           | 111 – 125% | 111 – 135% |
| Cyanide                           | 116 – 130% | 116 – 130% |
| Sulfide                           | 116 – 130% | 116 – 130% |

| Estimate positive results and nondetects (U/UJ) if: |          |          |
|---|----------|----------|
| Metals by 6010C/6020                                | 75 – 89% | 75 – 89% |
| Mercury/Metals by 7000s                             | 75 – 89% | 65 – 79% |
| Cyanide   | 70 – 84% | 70 – 84% |
| Sulfide   | 70 – 84% | 70 – 84% |

| Reject positive results and nondetects (R) if: |             |             |
|--|-------------|-------------|
| Metals by 6010C/6020                           | <75%, >125% | <75%, >125% |
| Mercury/Metals by 7000s                        | <75%, >125% | <65%, >135% |
| Cyanide  | <70%, >130% | <70%, >130% |
| Sulfide  | <70%, >130% | <70%, >130% |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### III. INSTRUMENT CALIBRATIONS (SECTIONS 2 & 3)

#### 2. Analytical Sequence

Did the laboratory use the proper number of standards for calibration as described in the method? **Yes or No**

B. Were calibrations performed at the beginning of each analysis? **Yes or No**

Were calibration verification standards analyzed at the beginning of sample analysis and the proper frequency according to the method? **Yes or No**

D. Where the AA correlation coefficients (r) for the calibration curves  $\geq 0.995$ ? If  $r < 0.995$ , estimate positive results and nondetects (J/UJ). It is not necessary to qualify results if the laboratory used order regression. **Yes or No**

Data quality may be affected if any of the above answer are "no". Use professional judgment to determine the severity of the effect and qualify the data accordingly. Discuss any actions below and list the sample affected.

#### 3. Other Check Standards

Laboratories may analyze an additional check standard after establishing the calibration curve. This standard may contain low level concentrations of target analytes and be analyzed and evaluated by the laboratory similar to a CLP "CRLD" standard (CRI for ICP, CRA for AA, and/or mid-range standard for CN and Sulfide). A  $100 \pm 20\%$  recovery acceptance limit should be used by the validator to evaluate the standard.

**ACTIONS:** If any analyte does not meet the %R criteria, follow the action needed below. Qualify 50% of either side of the CRI/CRA out of control limits.

| % R  | %R < 50% | %R = 50-79% | %R = 121-150% | %R > 150% | Affected Range       |
|--|----------|-------------|---------------|-----------|----------------------|
| <b>Qualify Positive/Nondetects Results</b> |          |             |               |           |                      |
| Metals by 6010C/6020                       | R/R      | J/UJ        | J/A           | R/A       | <2x CRI conc.        |
| Hg/metals by 7000s                         | R/R      | J/UJ        | J/A           | R/A       | <1.5x CRI conc.      |
| Cyanide                                    | R/R      | J/UJ        | J/A           | R/A       | <1.5x mid std. conc. |
| Sulfide                                    | R/R      | J/UJ        | J/A           | R/A       | <1.5x mid std. conc. |

CRI is not required for Al, Ba, Ca, Fe, Mg, Na, and K.

**NOTE:** CRLD standard within laboratory and method specific criteria.

## DATA REVIEW WORKSHEETS

All criteria were met N/A  
 Criteria were not met  
 and/or see below \_\_\_\_\_

**Table 4. Calibration Actions for ICP-MS Analysis**

| <b>Calibration Result</b>   | <b>Action for Samples</b>  |
|---|--|
| Calibration not performed   | Qualify all results as unusable (R)  |
| Calibration incomplete  | Use professional judgment<br>Qualify results that are $\geq$ MDL as estimated (J)<br>Qualify non-detects as estimated (UJ) |
| Not at least one calibration standard at or below the CRQL for each analyte         | Qualify results that are $\geq$ MDL but $< 2x$ the CRQL as estimated (J)<br>Qualify non-detects as estimated (UJ)          |
| Correlation coefficient $< 0.995$ ; %D outside $\pm 30\%$ ; y-intercept $\geq$ CRQL | Qualify results that are $\geq$ MDL as estimated (J)<br>Qualify non-detects as estimated (UJ)                              |
| Correlation coefficient $< 0.990$   | Qualify results that are $\geq$ MDL as estimated (J)<br>Qualify non-detects as unusable (R)                                |
| ICV/CCV %R $< 75\%$   | Qualify results that are $\geq$ MDL as unusable (R)<br>Qualify all non-detects as unusable (R)                             |
| ICV/CCV %R 75-89%   | Qualify results that are $\geq$ MDL as estimated low (J-)<br>Qualify non-detects as estimated (UJ)                         |
| ICV/CCV %R 111-125%   | Qualify results that are $\geq$ MDL as estimated high (J+)   |
| ICV/CCV %R $> 125\%$  | Qualify results that are $\geq$ MDL as estimated high (J+)   |
| ICV/CCV %R $> 160\%$  | Qualify results that are $\geq$ MDL as unusable (R)  |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below \_\_\_\_\_

### IV. BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including equipment, field, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in Sections 1 & 2 below. A separate worksheet page should be used for soil and water blanks.

Laboratory blanks

Matrix:   Aqueous  

| DATE ANALYZED | ICB/CCB# | PREP BLK | ANALYTE | CONCENTRATION UNITS |
|---------------|----------|----------|---------|---------------------|
|---------------|----------|----------|---------|---------------------|

  No analyte detected in method blanks above reporting limits.  

Field/Equipment

Matrix:   Aqueous  

| DATE ANALYZED | EQUIPMENT/FIELD BLANK | ANALYTE | CONCENTRATION UNITS |
|---------------|-----------------------|---------|---------------------|
|---------------|-----------------------|---------|---------------------|

  No field/equipment blank analyzed as part of this data package.  

**Table. Field/Rinsate/Trip Blank Actions for ICP-MS Analysis**

| Blank Result | Sample Result                             | Action for Samples  |
|--------------|---|---|
| > CRQL       | ≥ MDL but ≤ CRQL                          | Report CRQL value with a "U"                                  |
|              | > CRQL but < Blank Result                 | Report at level of Blank Result with a "U"                    |
|              | > Blank Result but < 10x the Blank Result | Use professional judgment to qualify results as estimated (J) |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### IV. BLANK ANALYSIS RESULTS (Section 3)

#### Frequency requirements

Was the preparation blank analyzed for each matrix,  
at the frequency of the method?

Yes or No

If no, estimate positive results < 10x IDL for which preparation blank was not analyzed.

If more than 20 samples/batch, qualification begins at the 21<sup>st</sup> sample.

B. Was an ICB analyzed?

Yes or No

C. Was a CCB analyzed at the frequency stated in the method?

Yes or No

Data quality may be affected if any of the above answer is "no". Use professional judgment to determine the severity of the effect and qualify the data accordingly. Discuss any actions below, and list the samples affected.

---

---

---

---

---

#### NOTE FOR SOIL SAMPLES

Compare raw sample value with blank results in ug/L unit, or

Convert blanks analyzed during a soil case to mg/Kg in order to compare them with the sample results.

Conc. In ug/L x [Volume diluted to (mL)]/[Weight digested] x 1L/1000mL x 1000g/1Kg x  
1mg/1000ug = concentration in wet weight (mg/Kg)

Concentration, dry weight (mg/Kg) = (Wet weight concentration)/(% Solids) x 100

### BLANK ANALYSIS RESULTS (Sections 4,5)

Laboratory blanks (PB, ICB/CCB) must first be used to qualify field and/or equipment blanks and samples.

Any contamination remaining in the field or equipment blank will be used to qualify the associated samples.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### 4. Initial/Continuing Calibration Blanks (ICB/CCB) Actions

Are all ICB/CCBs less than the SQL?

Yes or No

If no, qualify five samples on either side of the ICB/CCB out of control limits.  
 Estimate positive results (J)  $\leq$  the ICB/CCB value.

| ICB/CCB# | ANALYTE | CONC/UNITS | SAMPLES AFFECTED |
|----------|---------|------------|------------------|
| _____    | _____   | _____      | _____            |
| _____    | _____   | _____      | _____            |
| _____    | _____   | _____      | _____            |
| _____    | _____   | _____      | _____            |
| _____    | _____   | _____      | _____            |

Are the PB less than the SQL?

Yes or No

If yes, reject all results (R)  $< 10x$  the PB value.

| PB    | ANALYTE | CONC/UNITS | SAMPLES AFFECTED |
|-------|---------|------------|------------------|
| _____ | _____   | _____      | _____            |
| _____ | _____   | _____      | _____            |
| _____ | _____   | _____      | _____            |
| _____ | _____   | _____      | _____            |

### BLANK ANALYSIS RESULTS (Section 6)

### 6. Field/Equipment Blank (FB/EB) Actions

Are the FB/EB less than the SQL?

Yes or No

N/A

If no, was the FB/EB value already rejected due to other QC criteria? Yes or No

If no, reject (R) positive results  $\leq 5x$  the FB/EB value. Reject soil data with raw digest results  $< 5x$  the FB/EB value

| PB    | ANALYTE | CONC/UNITS | SAMPLES AFFECTED |
|-------|---------|------------|------------------|
| _____ | _____   | _____      | _____            |
| _____ | _____   | _____      | _____            |
| _____ | _____   | _____      | _____            |
| _____ | _____   | _____      | _____            |

DATA REVIEW WORKSHEETS

All criteria were met \_\_N/A\_\_  
 Criteria were not met  
 and/or see below \_\_\_\_\_

**Table 5. Calibration/Preparation Blank Actions for ICP-MS Analysis - Summary**

| Blank Type                        | Blank Result                     | Sample Result                              | Action for Samples  |
|-----------------------------------|----------------------------------|--|---|
| ICB/CCB                           | $\geq$ MDL but $\leq$ CRQL       | Non-detect                                 | No action   |
| $\geq$ MDL but $\leq$ CRQL        |                                  | Report CRQL value with a "U"               |   |
| > CRQL                            |                                  | Use professional judgment                  |   |
| ICB/CCB                           | > CRQL                           | $\geq$ MDL but $\leq$ CRQL                 | Report CRQL value with a "U"  |
| > CRQL but < Blank Result         |                                  | Report at level of Blank Result with a "U" |   |
| > Blank Result                    |                                  | Use professional judgment                  |   |
| ICB/CCB                           | $\leq$ (-MDL) but $\geq$ (-CRQL) | $\geq$ MDL, or non-detect                  | Use professional judgment   |
| ICB/CCB                           | < (-CRQL)                        | < 10x the CRQL                             | Qualify results that are $\geq$ CRQL as estimated low (J-)<br>Qualify non-detects as estimated (UJ) |
| Preparation Blank                 | > CRQL                           | $\geq$ MDL but $\leq$ CRQL                 | Report CRQL value with a "U"  |
| > CRQL but < 10x the Blank Result |                                  | Qualify results as estimated high (J+)     |   |
| $\geq$ 10x the Blank Result       |                                  | No action                                  |   |
| Preparation Blank                 | $\geq$ MDL but $\leq$ CRQL       | Non-detect                                 | No action   |
| $\geq$ MDL but $\leq$ CRQL        |                                  | Report CRQL value with a "U"               |   |
| > CRQL                            |                                  | Use professional judgment                  |   |
| Preparation Blank                 | < (-CRQL)                        | < 10x the CRQL                             | Qualify results that are $\geq$ CRQL as estimated low (J-)<br>Qualify non-detects as estimated (UJ) |



## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### INDUCTIVELY COUPLED PLASMA (ICP) INTERFERENCE CHECK SAMPLE

The assessment of the ICP interference check sample (ICS) is to verify the laboratory's interelement and background correction factors.

#### 1. Recovery Criteria

List any elements in the ICS AB and ICS A solutions which did not meet the %R criteria (80 – 120 %).

| DATE  | ELEMENT | %R    | ACTION | SAMPLES AFFECTED |
|---|---------|-------|--------|------------------|
| <u>Interference check sample within method performance criteria</u> |         |       |        |                  |
| _____   | _____   | _____ | _____  | _____            |
| _____   | _____   | _____ | _____  | _____            |
| _____   | _____   | _____ | _____  | _____            |
| _____   | _____   | _____ | _____  | _____            |

#### ACTIONS:

If an element does not meet the %R criteria, follow the actions stated below

| % R                                 | %R < 50% | %R = 50-79% | %R = 121-150% | %R > 150% |
|-------------------------------------|----------|-------------|---------------|-----------|
| Qualify Positive/Nondetects Results |          |             |               |           |
| Metals by 6010C/6020                | R/R      | J/UJ        | J/A           | R/A       |

#### 2. Frequency requirements

Were interference QC samples run at the frequency stated in the method (beginning of the analytical run)?

Yes or No

If no,

ACTIONS: Estimate positive results (J) all samples for which Al, Ca, Fe, Mg > ICS value.

The data may be affected. Use professional judgment to determine the severity of the effect and qualify the data accordingly. Discuss any actions below and list the samples affected.

---

---

---

---

---

---

---

---

---

---

## DATA REVIEW WORKSHEETS

All criteria were met \_\_\_N/A\_\_\_  
 Criteria were not met  
 and/or see below \_\_\_\_\_

**Table 6. Interference Check Actions for ICP-MS Analysis - Summary**

| <b>Interference Check Sample Results</b>                     | <b>Action for Samples</b>   |
|--|---|
| ICS not analyzed   | Qualify detects and non-detects as unusable (R)   |
| ICS not analyzed in proper sequence                          | Use professional judgment.  |
| ICS %R>150%  | Use professional judgment   |
| ICS %R > 120% (or greater than true value + 2x the CRQL)     | Qualify results that are $\geq$ MDL as estimated high (J+)  |
| ICS %R 80-12-%   | No qualification  |
| ICS %R 50-79% (or less than true value – 2x the CRQL)        | Qualify results that are $\geq$ MDL as estimated low (J-)<br>Qualify non-detects as estimated (UJ)                                |
| ICSAB %R < 50%   | Qualify detects as estimated low (J-) and non-detects as unusable (R)   |
| Potential false positives in field samples with interferents | Qualify results that are $\geq$ MDL as estimated high (J+)  |
| Potential false negatives in field samples with interferents | Qualify results that are $\geq$ MDL but < 10x the (negative value) as estimated low (J-)<br>Qualify non-detects as estimated (UJ) |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### VI. MATRIX SPIKE (MS)

Sample #   JC34250-2MS/-2MSD   Matrix:   Groundwater   Units:   ug/L  

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. Note that for Region 2, MS not required for: Ca, Mg, K, and Na for aqueous matrix.

Al, Ca, Fe, Mg, K, Na, for soil matrix

MS Recovery Criteria. List the percent recoveries for analytes which did not meet the %R criteria (75 – 125%); (85 – 115 % FOR Cr (VI)).

| ANALYTE   | SPIKE SAMPLE<br>RESULT (SSR) | SAMPLE<br>RESULT (SR) | SPIKE<br>ADDED | % R | ACTION |
|---|------------------------------|-----------------------|----------------|-----|--------|
| MS/MSD recoveries and RPD within laboratory control limits. |                              |                       |                |     |        |
|   |                              |                       |                |     |        |
|   |                              |                       |                |     |        |
|   |                              |                       |                |     |        |
|   |                              |                       |                |     |        |
|   |                              |                       |                |     |        |
|   |                              |                       |                |     |        |
|   |                              |                       |                |     |        |

ACTIONS: Matrix spike actions apply to all samples of the same matrix. The qualification will also be applied to the results of all samples within a given area of the site, if deemed appropriate.

If the sample results  $\geq 4x$  the spike concentration, no action is taken.

If any analyte does not meet the %R criteria, follow the actions stated below.

**Table 9. Spike Sample Actions for ICP-MS Analysis**

| Spike Sample Results  | Action for Samples  |
|---|---|
| Matrix Spike %R < 30%<br>Post-digestion spike %R < 75%        | Qualify affected results that are $\geq$ MDL as estimated low (J-) and affected non-detects as unusable (R)   |
| Matrix Spike %R < 30%<br>Post-digestion spike %R $\geq$ 75%   | Qualify affected results that are $\geq$ MDL as estimated (J) and affected non-detects as estimated (UJ)      |
| Matrix Spike %R 30-74%<br>Post-digestion Spike %R < 75%       | Qualify affected results that are $\geq$ MDL as estimated low (J-) and affected non-detects as estimated (UJ) |
| Matrix Spike %R 30-74%<br>Post-digestion spike %R $\geq$ 75%  | Qualify affected results that are $\geq$ MDL as estimated (J) and affected non-detects as estimated (UJ)      |
| Matrix Spike %R > 125%<br>Post-digestion spike %R > 125%      | Qualify affected results that are $\geq$ MDL as estimated high (J+)   |
| Matrix Spike %R > 125%<br>Post-digestion spike %R $\leq$ 125% | Qualify affected results that are $\geq$ MDL as estimated (J)   |

## DATA REVIEW WORKSHEETS

| Spike Sample Results  | Action for Samples  |
|---|---|
| Matrix Spike %R < 30%<br>No post-digestion spike performed  | Qualify affected results that are $\geq$ MDL as estimated low (J-) and affected non-detects as unusable (R) |
| Matrix Spike %R 30-74%<br>No post-digestion spike performed | Qualify affected results that are $\geq$ MDL as estimated low (J-) and non-detects as estimated (UJ)        |
| Matrix Spike %R > 125%<br>No post-digestion spike performed | Qualify affected results that are $\geq$ MDL as estimated high (J+)<br>Non-detects are not qualified        |

### 2. Frequency Criteria

A. Was a matrix spike prepared at the frequency stated in the method (1/20)? Yes  
or No

If no, estimate positive results (J) for which analyte was not spiked.

If more than 20 samples/batch, qualification begins at the 21<sup>st</sup> sample.

B. Was a field blank used as spiked sample? Yes or No

If yes, estimate positive results (J) < 4x spike level added for the analyte.

A separate worksheet page should be used for each matrix spike

# DATA REVIEW WORKSHEETS

All criteria were met   N/A    
 Criteria were not met  
 and/or see below       

## VII. FIELD DUPLICATES

Sample #:            -            Matrix:            -            Units: ug/L       

Field duplicate samples may be taken and analyzed as an indication of overall precision. Field duplicate analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which measure only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

List the concentrations and RPDs in the field duplicate pair. RPD criteria:  $\pm 20\%$  for aqueous;  $\pm 35\%$  for soil. For soil duplicates, if the % solids for the sample and its duplicate differ by more than 1%, report concentrations in ug/L and calculate RPD or difference for each analyte.

| ANALYTE | SQL<br>ug/L  | SQL<br>ug/Kg | SAMPLE<br>RESULTS | DUPLICATE<br>RESULTS | RPD | ACTION |
|---------|--|--------------|-------------------|----------------------|-----|--------|
| Al      |  |              |                   |                      |     |        |
| Sb      |  |              |                   |                      |     |        |
| As      | No field/laboratory duplicates analyzed with data set. MS/MSD % recoveries RPD used to assess precision. RPD within laboratory and generally acceptable control limits |              |                   |                      |     |        |
| Ba      |  |              |                   |                      |     |        |
| Be      |  |              |                   |                      |     |        |
| Cd      |  |              |                   |                      |     |        |
| Ca      |  |              |                   |                      |     |        |
| Cr      |  |              |                   |                      |     |        |
| Co      |  |              |                   |                      |     |        |
| Cu      |  |              |                   |                      |     |        |
| Fe      |  |              |                   |                      |     |        |
| Pb      |  |              |                   |                      |     |        |
| Mg      |  |              |                   |                      |     |        |
| Mn      |  |              |                   |                      |     |        |
| Hg      |  |              |                   |                      |     |        |
| Ni      |  |              |                   |                      |     |        |
| K       |  |              |                   |                      |     |        |
| Se      |  |              |                   |                      |     |        |
| Ag      |  |              |                   |                      |     |        |
| Na      |  |              |                   |                      |     |        |
| Tl      |  |              |                   |                      |     |        |
| V       |  |              |                   |                      |     |        |
| Zn      |  |              |                   |                      |     |        |
| Cyanide |  |              |                   |                      |     |        |
| Cr(VI)  |  |              |                   |                      |     |        |
|         |  |              |                   |                      |     |        |

Field duplicate actions should be applied to only the sample and its duplicate.

## DATA REVIEW WORKSHEETS

All criteria were met   N/A    
 Criteria were not met  
 and/or see below       

**Actions:** Indicates which criterion was used to evaluate precision by circling either the RPD or SQL for each element. If both sample and duplicate are nondetects, the RPD is not calculated (NC), no action is needed.

**Table 8. Duplicate Sample Actions for ICP-MS Analysis**

| <b>Duplicate Sample Results</b>   | <b>Action for Samples</b>   |
|---|---|
| <i>Aqueous:</i><br>Both original sample and duplicate sample > 5x the CRQL and 20% < RPD < 100%                                       | Qualify those results that are ≥ CRQL as estimated (J)                                  |
| <i>Aqueous:</i><br>Both original sample and duplicate sample > 5x the CRQL and RPD ≥ 100%   | Qualify those results that are ≥ CRQL as unusable (R)                                   |
| <i>Soil/Sediment:</i><br>Both original sample and duplicate sample > 5x the CRQL and 35% < RPD < 120%                                 | Qualify those results that are ≥ CRQL as estimated (J)                                  |
| <i>Soil/Sediment:</i><br>Both original sample and duplicate sample > 5x the CRQL and RPD ≥ 120%                                       | Qualify those results that are ≥ CRQL as unusable (R)                                   |
| Original sample or duplicate sample ≤ 5x the CRQL (including non-detects) and absolute difference between sample and duplicate > CRQL | Qualify those results that are ≥ MDL as estimated (J) and non-detects as estimated (UJ) |

A separate worksheet page should be used for each laboratory duplicate analysis

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### VIII. LABORATORY DUPLICATES (Section 1)

Laboratory run duplicates samples to verify laboratory consistency and precision. They are a measure of laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

#### 1. Difference Criteria

List the concentrations of any analyte not meeting the RPD criteria ( $\pm 20\%$  for aqueous;  $\pm 35\%$  for soil). For soil duplicates, if the % solids for the sample and its duplicate differ by more than 1%, report concentrations in  $\mu\text{g/L}$  and calculate RPD or difference for each analyte.

Sample #                     

Matrix:        -           

Units:        -       

| ANALYTE | SQL<br>ug/L | SQL<br>mg/Kg | SAMPLE<br>RESULTS | DUPLICATE<br>RESULTS | RPD | ACTION |
|---------|-------------|--------------|-------------------|----------------------|-----|--------|
| Al      |             |              |                   |                      |     |        |
| Sb      |             |              |                   |                      |     |        |
| As      |             |              |                   |                      |     |        |
| Ba      |             |              |                   |                      |     |        |
| Be      |             |              |                   |                      |     |        |
| Cd      |             |              |                   |                      |     |        |
| Ca      |             |              |                   |                      |     |        |
| Cr      |             |              |                   |                      |     |        |
| Co      |             |              |                   |                      |     |        |
| Cu      |             |              |                   |                      |     |        |
| Fe      |             |              |                   |                      |     |        |
| Pb      |             |              |                   |                      |     |        |
| Mg      |             |              |                   |                      |     |        |
| Mn      |             |              |                   |                      |     |        |
| Hg      |             |              |                   |                      |     |        |
| Ni      |             |              |                   |                      |     |        |
| K       |             |              |                   |                      |     |        |
| Se      |             |              |                   |                      |     |        |
| Ag      |             |              |                   |                      |     |        |
| Na      |             |              |                   |                      |     |        |
| Tl      |             |              |                   |                      |     |        |
| V       |             |              |                   |                      |     |        |
| Zn      |             |              |                   |                      |     |        |
| Cr(VI)  |             |              |                   |                      |     |        |
| Sulfide |             |              |                   |                      |     |        |
| Cyanide |             |              |                   |                      |     |        |

#### Note:

Laboratory duplicates actions should be applied to all other samples of the same matrix type. This qualification will also be applied to the results of all samples within a given area of the site, if deemed appropriate.

## DATA REVIEW WORKSHEETS

All criteria were met \_\_N/A\_\_  
 Criteria were not met  
 and/or see below \_\_\_\_\_

**Actions:** Indicates which criterion was used to evaluate precision by circling either the RPD or SQL for each element. If both sample and duplicate are non-detects, the RPD is not calculated (NC), no action is needed.

**Table 8. Field Duplicate Sample Actions for ICP-MS Analysis**

| Sample Type   | Field Duplicate Result  | Action for Samples  |
|---------------|---|---|
| Aqueous       | Sample and its field duplicate $\geq 5x$ the CRQL and RPD $> 20\%$                        | Qualify sample and its duplicate as estimated (J)                                     |
|               | Sample and/or its field duplicate $< 5x$ the CRQL and absolute difference $>$ the CRQL    | Qualify results $>$ the MDL as estimated (J)<br>Qualify non-detects as estimated (UJ) |
| Soil/Sediment | Sample and its field duplicate $\geq 5x$ the CRQL and RPD $> 50\%$                        | Qualify sample and its duplicate as estimated (J)                                     |
|               | Sample and/or its field duplicate $< 5x$ the CRQL and absolute difference $> 2x$ the CRQL | Qualify results $>$ the MDL as estimated (J)  |
|               |   | Qualify non-detects as estimated (UJ)   |

### 2. Frequency Criteria

A. Was a laboratory duplicate prepared at the frequency stated in the method (1/20)? **Yes or No**

If no, estimate positive results (J) for the analyte which duplicate was not performed. If more than 20 samples/batch, qualification begins at the 21<sup>st</sup> sample.

B. Was a field blank used for laboratory duplicate analysis? **Yes or No**

If yes, estimate positive results (J) for the analyte if field blank was used for duplicate analysis.



## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### IX. LABORATORY CONTROL SAMPLE (LCS/LCSD)

The assessment of the LCSs is to determine both intralaboratory contamination and matrix specific precision and accuracy. Note that for Region 2, LCS is not required for aqueous Hg and Cyanide.

#### LCS Recoveries Criteria

##### A. Aqueous LCS/Solid LCS

List any LCS recoveries not within %R criteria (80 – 120%) and the samples affected.

| DATE   | ELEMENT | % R | ACTION | SAMPLES AFFECTED |
|--|---------|-----|--------|------------------|
| <u>Recoveries_within_laboratory_control_limits</u> |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |
|  |         |     |        |                  |

**ACTIONS:** If analyte does not meet the %R criteria, follow the actions stated below:

**Table 7. LCS Actions for ICP-MS Analysis**

| LCS Result | Action for Samples   |
|------------|--|
| %R 40-69%  | Qualify results that are $\geq$ MDL as estimated low (J-)<br>Qualify non-detects as estimated (UJ) |
| %R > 130%  | Qualify results that are $\geq$ MDL as estimated high (J+)   |
| %R 70-130% | No qualification   |
| %R < 40%   | Qualify results that are $\geq$ MDL as estimated low (J-)<br>Qualify non-detects as unusable (R)   |
| %R > 150%  | Qualify detects as unusable (R) ; non-detects no qualification                                     |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### 2. Frequency Criteria

A. Was a laboratory control sample prepared at the frequency stated in the method (1/20)?  
Yes or No

If no, estimate positive results (J) for the analyte if LCS was not performed.

If more than 20 samples/batch, qualification begins at the 21<sup>st</sup> sample.

# DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## X. ICP SERIAL DILUTION ANALYSIS (Section 1)

The assessment of the ICP serial dilution analysis is to determine the precision of the laboratory through a 5x dilution.

### 1. Percent Difference (%D) Criteria:

  X   Serial dilutions were performed for each matrix and results for the diluted samples analysis agreed within 10% of the undiluted analysis for the analyte concentrations  $\leq$  50x MDL.

       Serial dilutions were not performed for the following target analytes:

       Serial dilutions were performed, but analytical results did not agree within 10% difference for analyte concentrations  $>$  50x IDL before dilution.

List the %Ds for analytes which did not meet the %D criteria (10%/100%)

Sample #   JC34250-2   Matrix:   Groundwater   Units:   ug/L  

| ANALYTE | IDL | 50x IDL | SAMPLE RESULTS | SERIAL DILUTION | %D | ACTION |
|---------|-----|---------|----------------|-----------------|----|--------|
| Al      |     |         |                |                 |    |        |
| Sb      |     |         |                |                 |    |        |
| As      |     |         |                |                 |    |        |
| Ba      |     |         |                |                 |    |        |
| Be      |     |         |                |                 |    |        |
| Cd      |     |         |                |                 |    |        |
| Ca      |     |         |                |                 |    |        |
| Cr      |     |         |                |                 |    |        |
| Co      |     |         |                |                 |    |        |
| Cu      |     |         |                |                 |    |        |
| Fe      |     |         |                |                 |    |        |
| Pb      |     |         |                |                 |    |        |
| Mg      |     |         |                |                 |    |        |
| Mn      |     |         |                |                 |    |        |
| Hg      |     |         |                |                 |    |        |
| Ni      |     |         |                |                 |    |        |
| K       |     |         |                |                 |    |        |
| Se      |     |         |                |                 |    |        |
| Ag      |     |         |                |                 |    |        |
| Na      |     |         |                |                 |    |        |
| Tl      |     |         |                |                 |    |        |
| V       |     |         |                |                 |    |        |
| Zn      |     |         |                |                 |    |        |

**Note:** Serial dilution within method performance criteria.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

**ACTIONS:** Actions apply to all samples of the same matrix. The qualification will also be applied to the results of all samples within a given area of the site, if deemed appropriate. Qualify only samples with raw results > 50x MDL.

Flag results with an (E) for elements exhibiting %D > 10%.

Estimate (J) positive results > 50x MDL for elements that exhibited %D > 10 but < 100.

Reject (R) positive results > 50x MDL for elements which exhibited %D ≥ 100%.

### SERIAL DILUTION ANALYSIS (Section 2)

#### 2. Frequency Criteria

A. Was a serial dilution analysis prepared as required by the method? **Yes or No**

If no, estimate positive results ≥ 50x MDL (J) for the analyte which serial dilution analysis was not performed.

B. Was a field blank used for serial dilution analysis? **Yes or No**

If yes, estimate positive results ≥ 50x MDL (J) for the analyte if field blank was used for serial dilution analysis.

**Table 10. Serial Dilution Actions for ICP-MS Analysis**

| Serial Dilution Result  | Action for Samples   |
|---|--|
| <i>Aqueous:</i><br>Sample concentration > 50x MDL and 10% < %D < 100%       | Qualify affected results whose raw data are > MDL as estimated (J) |
| <i>Aqueous:</i><br>Sample concentration > 50x MDL and %D ≥ 100%             | Qualify affected results whose raw data are > MDL as unusable (R)  |
| <i>Soil/Sediment:</i><br>Sample concentration > 50x MDL and 15% < %D < 120% | Qualify affected results whose raw data are > MDL as estimated (J) |
| <i>Soil/Sediment:</i><br>Sample concentration > 50x MDL and %D ≥ 120%       | Qualify affected results whose raw data are > MDL as unusable (R)  |
| Interferences present   | Use professional judgment  |

A separate worksheet page should be used for each serial dilution analysis.

## DATA REVIEW WORKSHEETS

All criteria were met \_\_N/A\_\_  
Criteria were not met  
and/or see below \_\_\_\_\_

### XI. ICP-MS INTERNAL STANDARDS

Are internal standard added to the sample? Yes\_or No?

Are the proper number of internal standard added to the sample? Yes or No?

Is the % Relative Intensities for all internal standards in a sample is within 60-125% of the response in the calibration blank? Yes or No?

Note: ICP-OES internal standards used; relative intensities within the guidance document performance criteria. \_\_\_\_\_

#### Action:

NOTE: Apply the action to the affected analytes for each sample that does not meet the internal standard criteria.

1. If no internal standards were analyzed with the run, the sample data should be qualified as unusable (R). Record this in the Data Review Narrative and note for CLP Project Officer (CLP PO) action.

2. If less than five of the required internal standards were analyzed with the run, or a target analyte(s) is (are) not associated to an internal standard, the sample data, or analyte data not associated to an internal standard should be qualified as unusable (R). Record this in the Data Review Narrative and note for CLP PO action.

3. If the % Relative Intensities for all internal standards in a sample is within 60-125% of the response in the calibration blank, the sample data should not be qualified.

4. If the %RI for an internal standard in a sample is not within the 60-125% limit, qualify the data for those analytes associated with the internal standard(s) outside the limit as follows:

a. If the sample was reanalyzed at a two-fold dilution with internal standard %RI within the limits, report the result of the diluted analysis without qualification. If the %RI of the diluted analysis was not within the 60-125% limit, report the results of the original undiluted analyses and qualify the data for all analytes that are  $\geq$  Method Detection Limit (MDL) in the sample associated with the internal standard as estimated (UJ).

b. If the sample was not reanalyzed at a two-fold dilution, the reviewer should use professional judgment to determine the reliability of the data. The reviewer may determine that the results are estimated (J) or unusable (R).

## DATA REVIEW WORKSHEETS

**Table 11. Internal Standard Actions for ICP-MS Analysis**

| <b>Internal Standard Results</b>  | <b>Action for Samples</b>   |
|---|---|
| No internal standards   | Qualify all results as unusable (R)   |
| < 5 of the required internal standards  | Qualify all results as unusable (R)   |
| Target analyte not associated with internal standard  | Qualify all analyte results not associated with an internal standard as unusable (R)  |
| % RI < 60% or > 125%, original sample reanalyzed at 2-fold dilution, and % RI of diluted sample analysis is between 60% and 125%          | Do not qualify the data   |
| % RI < 60% or > 125%, original sample reanalyzed at 2-fold dilution, and % RI of diluted sample analysis is outside the 60% to 125% limit | Qualify analytes associated with the failed internal standard that are $\geq$ MDL as estimated (J) and qualify associated non-detects as estimated (UJ) |
| Original sample not reanalyzed at 2-fold dilution   | Use professional judgment<br>Qualify sample results as estimated (J) or unusable ®  |

## DATA REVIEW WORKSHEETS

### XII. DETECTION LIMITS RESULTS

The detection limit assessment is to verify that samples results are within instrument calibration range or linear range (ICP).

Instrument Detection Limits (IDL). Note IDL is not required for Cyanide.

A. IDL/MDL (or lowest quantitation limit used) results were present and found to be at levels that meet the project objectives? Yes or No

B. IDL/MDL (or lowest quantitation limit used) were not met for the following elements: \_\_\_\_\_

#### 2. Reporting Requirements

A. Were sample results on Form I (or equivalent) reported down to the IDL/MDL or lowest quantitation limit used for all analytes? Yes or No

B. Were sample weights, volumes, and dilutions taken into account when reporting results (positive and nondetects)? Yes or No

If no, the reported results may be inaccurate. Request the laboratory resubmit the corrected data.

#### 3. Sediment Sample Percent Solids (% solids):

A. Were the % solids for any sediment samples  $< 50\%$  but  $\geq 10\%$ ? Yes or No  
If yes, estimate positive results and nondetects (J/UJ) if the % solids is 10-50%. List the affected samples: \_\_\_\_\_

B. Were the % solids for any sediment samples  $< 10\%$ ? Yes or No  
If yes, reject all results (R) if the % solid is  $< 10\%$ . List the affected samples: N/A

### XI. TOTAL/DISSOLVED OR INORGANIC/TOTAL ANALYTES

A. Were any analyses performed for dissolved as well as total analytes on the same sample(s)? Yes or No

B. Were any analyses performed for inorganic as well as total analytes on the same sample(s)? Yes or No

If yes, compare the differences between dissolved (or inorganic) and total analyte concentrations. Compute each difference as a percent of the total analyte only when both of the following conditions are fulfilled:

- (1) The dissolved (or inorganic) concentration is greater than total concentration, and
- (2) greater than or equal to 5xMDL.

## DATA REVIEW WORKSHEETS

All criteria were met N/A  
Criteria were not met  
and/or see below \_\_\_\_\_

C. Is any dissolved (or inorganic) concentration greater than its total concentration by more than 20%? Yes or No

D. Is any dissolved (or inorganic) concentration greater than its total concentration by more than 50%? Yes or No

### ACTION:

If the percent difference is greater than 20%, flag (J) both dissolved/inorganic and total concentrations as estimated. If the difference is more than 50%, reject (R) both the values.

## XII. SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results.

X Sample results fall within the linear range for ICP and within the calibration range for all other parameters.

\_\_\_\_\_ If samples results were beyond the linear range/calibration range of the instrument, were dilution performed?

List the affected samples/elements/dilution:

In the space below, please show a minimum of one sample calculation per method:

ICP/ICP-MS

Computer printout

Hg/Metals by AA

Hexavalent Chromium

Cyanide

Others

For soil samples, the following equation may be necessary to convert raw data values reported in ug/L to actual sample concentrations (mg/Kg):

$$\text{Conc. in ug/L} \times \frac{\text{Volume diluted to, mL}}{\text{Weight digested, g}} \times \frac{1\text{L}}{1000\text{ mL}} \times \frac{1000\text{ g}}{1\text{ Kg}} \times \frac{1\text{ mg}}{1000\text{ mg}} = \text{concentration in wet weight mg/Kg}$$

In addition the sample results are converted to dry weight by using the percent solid calculations:

Wet weight concentration x 100 = final concentration, dry weight (mg/Kg) % solids



## DATA REVIEW WORKSHEETS

### OVERALL ASSESSMENT

#### Action:

1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the QC criteria previously discussed.
2. Write a brief Data Review Narrative to give the user an indication of the analytical limitations of the data. Note any discrepancies between the data and the Sample Delivery Group (SDG) Narrative for Contract Laboratory Program Project Officer (CLP PO) action. If sufficient information on the intended use and required quality of the data is available, the reviewer should include an assessment of the data usability within the given context.
3. If any discrepancies are found, the laboratory may be contacted by the Region's designated representative to obtain additional information for resolution. If a discrepancy remains unresolved, the reviewer may determine that qualification of the data is warranted.

Note: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

## EXECUTIVE NARRATIVE

SDG No: JC34340 Laboratory: Accutest, New Jersey  
Analysis: SW846-8081B Number of Samples: 8

Location: BSMC, Building 5 Area  
Humacao, PR

**SUMMARY:** Eight (8) samples were analyzed for the TCL pesticides list following method SW846-8081B. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence *Hazardous Waste Support Section SOP No. HW-36A, Revision 0, June, 2015. SOM02.2. Pesticide Data Validation*. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

**Critical issues:** None  
**Major:** None  
**Minor:** None

**Critical findings:** None  
**Major findings:** None  
**Minor findings:** 1. Initial and initial calibration verification within the guidance document performance criteria. Continuing calibration % differences meet the performance criteria in at least one of the two columns. Final calibration verification not included in data package. No action taken, professional judgment.

**COMMENTS:** Results are valid and can be used for decision making purposes.

**Reviewers Name:** Rafael Infante  
Chemist License 1888

**Signature:**

A handwritten signature in blue ink, appearing to read 'Rafael Infante', is written over a horizontal line.

**Date:** January 28, 2017

# **SAMPLE ORGANIC DATA SAMPLE SUMMARY**

Sample ID: JC34340-1

Sample location: BMSMC Building 5 Area

Sampling date: 15-Dec-16

Matrix: AQ - Equipment Blank

## **METHOD: 8081B**

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| beta-BHC            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| delta-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-BHC (Lindane) | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Dieldrin            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDD            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDE            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDT            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan sulfate  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin aldehyde     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin ketone       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-I        | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-II       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor          | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor epoxide  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Methoxychlor        | 0.022  | ug/l  | 1               | -        | U          | Yes        |
| Toxaphene           | 0.28   | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-16  
Sample location: BMSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: Groundwater

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| beta-BHC            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| delta-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-BHC (Lindane) | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Dieldrin            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDD            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDE            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDT            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan sulfate  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin aldehyde     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin ketone       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-I        | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-II       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor          | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor epoxide  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Methoxychlor        | 0.022  | ug/l  | 1               | -        | U          | Yes        |
| Toxaphene           | 0.28   | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-18  
Sample location: BSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: Groundwater

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| alpha-BHC           | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| beta-BHC            | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| delta-BHC           | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| gamma-BHC (Lindane) | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| alpha-Chlordane     | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| gamma-Chlordane     | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Dieldrin            | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDD            | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDE            | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDT            | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Endrin              | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan sulfate  | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Endrin aldehyde     | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Endrin ketone       | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-I        | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-II       | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor          | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor epoxide  | 0.010  | ug/l  | 1               | -        | U          | Yes        |
| Methoxychlor        | 0.020  | ug/l  | 1               | -        | U          | Yes        |
| Toxaphene           | 0.25   | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-19  
Sample location: BMSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: Groundwater

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| beta-BHC            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| delta-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-BHC (Lindane) | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Dieldrin            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDD            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDE            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDT            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan sulfate  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin aldehyde     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin ketone       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-I        | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-II       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor          | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor epoxide  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Methoxychlor        | 0.022  | ug/l  | 1               | -        | U          | Yes        |
| Toxaphene           | 0.28   | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-20  
Sample location: BMSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: Groundwater

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| beta-BHC            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| delta-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-BHC (Lindane) | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Dieldrin            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDD            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDE            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDT            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan sulfate  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin aldehyde     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin ketone       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-I        | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-II       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor          | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor epoxide  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Methoxychlor        | 0.022  | ug/l  | 1               | -        | U          | Yes        |
| Toxaphene           | 0.28   | ug/l  | 1               | -        | U          | Yes        |

Sample ID: JC34340-21  
Sample location: BMSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: AQ - Field Blank Water

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| beta-BHC            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| delta-BHC           | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-BHC (Lindane) | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| alpha-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| gamma-Chlordane     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Dieldrin            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDD            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDE            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| 4,4'-DDT            | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin              | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan sulfate  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin aldehyde     | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endrin ketone       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-I        | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Endosulfan-II       | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor          | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Heptachlor epoxide  | 0.011  | ug/l  | 1               | -        | U          | Yes        |
| Methoxychlor        | 0.022  | ug/l  | 1               | -        | U          | Yes        |
| Toxaphene           | 0.28   | ug/l  | 1               | -        | U          | Yes        |



Sample ID: JC34340-16MS  
Sample location: BSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: Groundwater

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.26   | ug/l  | 1               | -        | -          | Yes        |
| alpha-BHC           | 0.28   | ug/l  | 1               | -        | -          | Yes        |
| beta-BHC            | 0.27   | ug/l  | 1               | -        | -          | Yes        |
| delta-BHC           | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| gamma-BHC (Lindane) | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| alpha-Chlordane     | 0.39   | ug/l  | 1               | -        | -          | Yes        |
| gamma-Chlordane     | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Dieldrin            | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| 4,4'-DDD            | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| 4,4'-DDE            | 0.25   | ug/l  | 1               | -        | -          | Yes        |
| 4,4'-DDT            | 0.16   | ug/l  | 1               | -        | -          | Yes        |
| Endrin              | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Endosulfan sulfate  | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Endrin aldehyde     | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| Endrin ketone       | 0.28   | ug/l  | 1               | -        | -          | Yes        |
| Endosulfan-I        | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Endosulfan-II       | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| Heptachlor          | 0.27   | ug/l  | 1               | -        | -          | Yes        |
| Heptachlor epoxide  | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Methoxychlor        | 0.26   | ug/l  | 1               | -        | -          | Yes        |
| Toxaphene           | ND     | ug/l  | 1               | -        | -          | Yes        |

Sample ID: JC34340-16MSD  
Sample location: BSMC Building 5 Area  
Sampling date: 22-Dec-16  
Matrix: Groundwater

METHOD: 8081B

| Analyte Name        | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|---------------------|--------|-------|-----------------|----------|------------|------------|
| Aldrin              | 0.26   | ug/l  | 1               | -        | -          | Yes        |
| alpha-BHC           | 0.28   | ug/l  | 1               | -        | -          | Yes        |
| beta-BHC            | 0.27   | ug/l  | 1               | -        | -          | Yes        |
| delta-BHC           | 0.31   | ug/l  | 1               | -        | -          | Yes        |
| gamma-BHC (Lindane) | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| alpha-Chlordane     | 0.38   | ug/l  | 1               | -        | -          | Yes        |
| gamma-Chlordane     | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Dieldrin            | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| 4,4'-DDD            | 0.32   | ug/l  | 1               | -        | -          | Yes        |
| 4,4'-DDE            | 0.26   | ug/l  | 1               | -        | -          | Yes        |
| 4,4'-DDT            | 0.160  | ug/l  | 1               | -        | -          | Yes        |
| Endrin              | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Endosulfan sulfate  | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| Endrin aldehyde     | 0.27   | ug/l  | 1               | -        | -          | Yes        |
| Endrin ketone       | 0.28   | ug/l  | 1               | -        | -          | Yes        |
| Endosulfan-I        | 0.30   | ug/l  | 1               | -        | -          | Yes        |
| Endosulfan-II       | 0.31   | ug/l  | 1               | -        | -          | Yes        |
| Heptachlor          | 0.27   | ug/l  | 1               | -        | -          | Yes        |
| Heptachlor epoxide  | 0.29   | ug/l  | 1               | -        | -          | Yes        |
| Methoxychlor        | 0.25   | ug/l  | 1               | -        | -          | Yes        |
| Toxaphene           | ND     | ug/l  | 1               | -        | -          | Yes        |

# DATA REVIEW WORKSHEETS

Project/Case Number: JC34340  
 Sampling Date: 12/21-22/2016  
 Shipping Date: 12/22/2016  
 EPA Region No.: 2

## REVIEW OF PESTICIDE ORGANIC PACKAGE

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence *Hazardous Waste Support Section SOP No. HW-36A, Revision 0, June, 2015. SOM02.2. Pesticide Data Validation*. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Accutest data package received has been reviewed and the quality control and performance data summarized. The data review for VOCs included:

Lab. Project/SDG No.: JC34340 Sample matrix: Groundwater  
 No. of Samples: 8  
 Trip blank No.: -  
 Field blank No.: JC34340-21  
 Equipment blank No.: JC34340-15  
 Field duplicate No.:   
 Field spikes No.: JC34340-16MS/-16MSD  
 QC audit samples: -

|   |   |
|---|---|
| <input checked="" type="checkbox"/> Data Completeness                   | <input checked="" type="checkbox"/> Laboratory Control Spikes |
| <input checked="" type="checkbox"/> Holding Times                       | <input checked="" type="checkbox"/> Field Duplicates          |
| <input type="checkbox"/> N/A GC/MS Tuning                               | <input checked="" type="checkbox"/> Calibrations              |
| <input checked="" type="checkbox"/> Internal Standard Performance       | <input checked="" type="checkbox"/> Compound Identifications  |
| <input checked="" type="checkbox"/> Blanks                              | <input checked="" type="checkbox"/> Compound Quantitation     |
| <input checked="" type="checkbox"/> Surrogate Recoveries                | <input checked="" type="checkbox"/> Quantitation Limits       |
| <input checked="" type="checkbox"/> Matrix Spike/Matrix Spike Duplicate |   |

Overall Comments: TCL\_pesticides\_list\_by\_SW846-8081B

### Definition of Qualifiers:

|                      |                          |
|----------------------|--------------------------|
| J- Estimated results | U- Compound not detected |
| R- Rejected data     | UJ- Estimated nondetect  |

Reviewer: Rafael Defaut  
 Date: January 28, 2017



## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

| SAMPLE ID  | DATE SAMPLED | DATE EXTRACTED/ANALYZED | ACTION |
|--|--------------|-------------------------|--------|
| Samples properly preserved. All samples extracted and analyzed within the required criteria. |              |                         |        |
|  |              |                         |        |
|  |              |                         |        |
|  |              |                         |        |
|  |              |                         |        |
|  |              |                         |        |

### Note:

#### Criteria

Aqueous samples - seven (7) days from sample collection for extraction; 40 days from sample collection for analysis.

Non-aqueous samples – fourteen (14) days from sample collection for extraction; 40 days from sample collection for analysis.

Cooler temperature (Criteria:  $4 \pm 2$  °C): 5.4°C - OK

#### Actions

**Qualify aqueous sample results using preservation and technical holding time information as follows:**

- If there is no evidence that the samples were properly preserved ( $T = 4^{\circ}\text{C} \pm 2^{\circ}\text{C}$ ), and the samples were extracted or analyzed within the technical holding times, qualify detects as estimated (J) and non-detects as estimated (UJ).
- If there is no evidence that the samples were properly preserved ( $T = 4^{\circ}\text{C} \pm 2^{\circ}\text{C}$ ), and the samples were extracted or analyzed outside the technical holding times, qualify detects as estimated (J) and non-detects as estimated (UJ).
- If the samples were properly preserved, and were extracted and analyzed within the technical holding times, no qualification of the data is necessary.
- If the samples were properly preserved, and were extracted or analyzed outside the technical holding times, qualify detects as estimated (J) and non-detects as estimated (UJ). Note in the Data

## DATA REVIEW WORKSHEETS

Review Narrative that holding times were exceeded and the effect of exceeding the holding time on the resulting data.

- e. Use professional judgment to qualify samples whose temperature upon receipt at the laboratory is either below 2 degrees centigrade or above 6 degrees centigrade.
- f. If technical holding times are grossly exceeded, use professional judgment to qualify the data.

### **Qualify non-aqueous sample results using preservation and technical holding time information as follows:**

- a. If there is no evidence that the samples were properly preserved ( $T = 4^{\circ}\text{C} \pm 2^{\circ}\text{C}$ ), and the samples were extracted or analyzed within the technical holding time, qualify detects as estimated (J) and non-detects as estimated (UJ).
- b. If there is no evidence that the samples were properly preserved ( $T = 4^{\circ}\text{C} \pm 2^{\circ}\text{C}$ ), and the samples were extracted or analyzed outside the technical holding time, qualify detects as estimated (J) and non-detects as estimated (UJ).
- c. If the samples were properly preserved, and were extracted and analyzed within the technical holding time, no qualification of the data is necessary.
- d. If the samples were properly preserved, and were extracted or analyzed outside the technical holding time, qualify detects as estimated (J) and non-detects as estimated (UJ). Note in the Data Review Narrative that holding times were exceeded and the effect of exceeding the holding time on the resulting data.
- e. Use professional judgment to qualify samples whose temperature upon receipt at the laboratory is either below 2 degrees centigrade or above 6 degrees centigrade.
- f. If technical holding times are grossly exceeded, use professional judgment to qualify the data.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met see below       

### GAS CHROMATOGRAPH WITH ELECTRON CAPTURE DETECTOR (GC/ECD) INSTRUMENT PERFORMANCE CHECK (SECTIONS 1 TO 5)

#### 1. Resolution Check Mixture

##### Criteria

Is the resolution between two adjacent peaks in the Resolution Check Mixture C greater than or equal to 80.0% for all analytes for the primary column and greater than or equal to 50.0% for the confirmation column? Yes? or No?

Is the resolution between two adjacent peaks in the Resolution Check Mixture (A and B) greater than or equal to 60.0%? Yes? or No?

Note: If resolution criteria are not met, the quantitative results may not be accurate due to inadequate resolution. Qualitative identifications may also be questionable if coelution exists.

##### Action

- a. Qualify detects for target compounds that were not adequately resolved as tentatively identified (NJ).
- b. Qualify non-detected compounds as unusable (R).

#### 2. Performance Evaluation Mixture (PEM) Resolution Criteria

##### Criteria

Is PEM analysis performed at the required frequency (at the end of each pesticide initial calibration sequence and every 12 hours)? Yes? or No?

##### Action

- a. If PEM is not performed at the required frequency, qualify all associated sample and blank results as unusable (R).

##### Criteria

Is PEM % Resolution < 90%? Yes? or **No?**

##### Action

- a. a. Qualify detects for target compounds that were not adequately resolved as tentatively identified (NJ).
- b. Qualify non-detected compounds as unusable (R).

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met see below       

### 3. PEM 4,4'-DDT Breakdown

#### Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is detected? Yes? or No?

#### Action

a. Qualify detects for 4,4'-DDT; detects for 4,4'-DDD; and detects for 4,4'-DDE as estimated (J)

#### Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is not detected Yes? or No?

#### Action

- a. Qualify non-detects for 4,4'- DDT as unusable (R )
- b. Qualify detects for 4,4'-DDD as tentatively identified (NJ)
- c. Qualify detects for 4,4'-DDE as tentatively identified (NJ)

### 4. PEM Endrin Breakdown

#### Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is detected? Yes? or No?

#### Action

a. Qualify detects for Endrin; detects for Endrin aldehyde; and detects for Endrin ketone as estimated (J)

#### Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is not detected Yes? or No?

#### Action

- a. Qualify non-detects for Endrin as unusable (R )
- b. Qualify detects for Endrin aldehyde as tentatively identified (NJ)
- c. Qualify detects for Endrin ketone as tentatively identified (NJ)



## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met see below       

### 5. Mid-point Individual Standard Mixture Resolution -

#### Criteria

Is the resolution between two adjacent peaks in the Resolution Check Mixture C greater than or equal to 80.0% for all analytes for the primary column and greater than or equal to 50.0% for the confirmation column? Yes? or No?

Is the resolution between two adjacent peaks in the Resolution Check Mixture (A and B) greater than or equal to 90.0%? Yes? or No?

Note: If resolution criteria are not met, the quantitative results may not be accurate due to inadequate resolution. Qualitative identifications may also be questionable if coelution exists.

#### Action

- a. Qualify detects for target compounds that were not adequately resolved as tentatively identified (NJ).
- b. Qualify non-detected compounds as unusable (R).

#### Criteria

Is mid-point individual standard mixture analysis performed at the required frequency (every 12 hours)? Yes? or No?

#### Action

- a. If the mid-point individual standard mixture analysis is not performed at the required frequency, qualify all associated sample and blank results as unusable (R).

## DATA REVIEW WORKSHEETS

All criteria were met X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 11/15/16  
 Dates of initial calibration verification: 12/15/16  
 Dates of continuing calibration: 01/03/17; 01/04/17  
 Dates of final calibration: -  
 Instrument ID numbers: GCG8  
 Matrix/Level: Aqueous/low

| DATE  | LAB ID# | FILE | CRITERIA OUT<br>RFs, %RSD, %D, r | COMPOUND | SAMPLES AFFECTED |
|---|---------|------|----------------------------------|----------|------------------|
|   |         |      |                                  |          |                  |
| Initial and initial calibration verification within the guidance document performance criteria. Continuing calibration % differences meet the performance criteria in the two columns. Final calibration verification included in data package. |         |      |                                  |          |                  |
|   |         |      |                                  |          |                  |
|   |         |      |                                  |          |                  |

#### Criteria

Are a five point calibration curve delivered with concentration levels as shown in Table 3 of SOP HW-36A, Revision 0, June, 2015? Yes? or No?

#### Actions

If the standard concentrations listed in Table 3 are not used, use professional judgment to evaluate the effect on the data

#### Criteria

Are RT Windows calculated correctly? Yes? or No?

#### Action

Recalculate the windows and use the corrected values for all evaluations.

#### Criteria

Are the Percent Relative Standard Deviation (%RSD) of the CFs for each of the single component target compounds less than or equal to 20.0%, except for alpha-BHC and delta-BHC?

Yes? or No?

## DATA REVIEW WORKSHEETS

All criteria were met X  
Criteria were not met  
and/or see below \_\_\_\_\_

Are the %RSD of the CFs for alpha-BHC and delta-BHC less than or equal to 25.0%. Yes? or No?

Is the %RSD of the CFs for each of the Toxaphene peaks must be < 30% when 5-point ICAL is performed? Yes? or No?

Is the %RSD of the CFs for the two surrogates (tetrachloro-m-xylene and decachlorobiphenyl) less than or equal to 30.0%. Yes? or No?

### Action

- a. If the %RSD criteria are not met, qualify detects as estimated (J) and use professional judgment to qualify non-detected target compounds.
- b. If the %RSD criteria are within allowable limits, no qualification of the data is necessary

### Continuing Calibration Checks

#### Criteria

Is the continuing calibration standard analyzed at the acceptable time intervals? Yes? or No?

#### Action

- a. If more than 14 hours has elapsed from the injection of the instrument blank that begins an analytical sequence (opening CCV) and the injection of either a PEM or mid-point concentration of the Individual Standard Mixtures (A and B) or (C), qualify all data as unusable (R).
- b. If more than 12 hours has elapsed from the injection of the instrument blank that begins an analytical sequence (opening CCV) and the injection of the last sample or blank that is part of the same analytical sequence, qualify all data as unusable (R).
- c. If more than 72 hours has elapsed from the injection of the sample with a Toxaphene detection and the Toxaphene Calibration Verification Standard (CS3), qualify all data as unusable (R).

#### Criteria

Is the Percent Difference (%D) within  $\pm 25.0\%$  for the PEM sample? Yes? or No?

#### Action

- a. Qualify associated detects as estimated (J) and non-detects as estimated (UJ).

#### Criteria

For the Calibration Verification Standard (CS3); is the Percent Difference (%D) within  $\pm 25.0\%$ ? Yes? or No?

#### Action

Qualify associated detects as estimated (J) and non-detects as estimated (UJ).

## DATA REVIEW WORKSHEETS

### Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is detected? Yes? or No?

### Action

- a. Qualify detects for 4,4'-DDT; detects for 4,4'-DDD; and detects for 4,4'-DDE as estimated (J)
- b. Non-detected associated compounds are not qualified

### Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is not detected? Yes? or No?

### Action

- a. Qualify non-detects for 4,4'- DDT as unusable (R )
- b. Qualify detects for 4,4'-DDD as tentatively identified (NJ)
- c. Qualify detects for 4,4'-DDE as tentatively identified (NJ)

### Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is detected? Yes? or No?

### Action

- a. Qualify detects for Endrin; detects for Endrin aldehyde; and detects for Endrin ketone as estimated (J)
- b. Non-detected associated compounds are not qualified

### Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is not detected? Yes? or No?

### Action

- a. Qualify non-detects for Endrin as unusable (R )
- b. Qualify detects for Endrin aldehyde as tentatively identified (NJ)
- c. Qualify detects for Endrin ketone as tentatively identified (NJ)

A separate worksheet should be filled for each initial curve

## DATA REVIEW WORKSHEETS

All criteria were met X  
Criteria were not met  
and/or see below

### BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

CRQL concentration N/A

### Laboratory blanks

| DATE ANALYZED | LAB ID | LEVEL/<br>MATRIX | COMPOUND | CONCENTRATION<br>UNITS |
|---------------|--------|------------------|----------|------------------------|
|---------------|--------|------------------|----------|------------------------|

No target analytes detected in method blanks at a reporting limit of 0.01, 0.02, and 0.25 ug/L

**Field/Equipment/Trip blank**

| DATE ANALYZED | LAB ID | LEVEL/ MATRIX | COMPOUND | CONCENTRATION UNITS |
|---------------|--------|---------------|----------|---------------------|
|---------------|--------|---------------|----------|---------------------|

No target anayte detected in the field/equipment blanks analyzed with this data\_package.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### BLANK ANALYSIS RESULTS (Section 3)

#### Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

The concentration of non-target compounds in all blanks must be less than or equal to 10 µg/L. The concentration of each target compound found in the method or field blanks must be less than its CRQL listed in the method.

Data concerning the field blanks are not evaluated as part of the CCS process. If field blanks are present, the data reviewer should evaluate this data in a similar fashion as the method blanks.

Specific actions are as follows:

#### Blank Actions for Pesticide Analyses

| Blank Type   | Blank Result        | Sample Result                    | Action for Samples                                   |
|--|---------------------|----------------------------------|--|
| Method, Sulfur Cleanup, Instrument, Field, TCLP/SPLP | Detects             | Not detected                     | No qualification required                            |
|  | < CRQL              | < CRQL                           | Report CRQL value with a U                           |
|  |                     | ≥ CRQL                           | No qualification required                            |
|  | > CRQL              | < CRQL                           | Report CRQL value with a U                           |
|  |                     | ≥ CRQL and ≤ blank concentration | Report blank value for sample concentration with a U |
|  |                     | ≥ CRQL and > blank concentration | No qualification required                            |
|  | = CRQL              | ≤ CRQL                           | Report CRQL value with a U                           |
|  |                     | > CRQL                           | No qualification required                            |
|  | Gross contamination | Detects                          | Report blank value for sample concentration with a U |

DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

| CONTAMINATION<br>SOURCE/LEVEL | COMPOUND | CONC/UNITS | AL/UNITS | SQL | AFFECTED SAMPLES |
|-------------------------------|----------|------------|----------|-----|------------------|
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |
|                               |          |            |          |     |                  |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met \_\_\_\_\_  
 and/or see below \_\_\_\_\_

### SURROGATE SPIKE RECOVERIES

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

List the percent recoveries (%Rs) which do not meet the criteria for surrogate recovery.

Matrix: Aqueous

| Lab<br>Sample ID | Lab<br>File ID | S1 a | S1 b | S2 a | S2 b |
|------------------|----------------|------|------|------|------|
| JC34340-15       | 8G1635.D       | 96   | 100  | 30   | 29   |
| JC34340-16       | 8G1631.D       | 91   | 91   | 80   | 70   |
| JC34340-18       | 8G1664.D       | 96   | 102  | 49   | 47   |
| JC34340-19       | 8G1665.D       | 81   | 87   | 59   | 59   |
| JC34340-20       | 8G1666.D       | 103  | 110  | 79   | 73   |
| JC34340-21       | 8G1667.D       | 90   | 95   | 61   | 57   |
| OP99539-BS1      | 8G1630.D       | 97   | 100  | 58   | 50   |
| OP99539-MB1      | 8G1629.D       | 90   | 91   | 45   | 41   |
| OP99539-MS       | 8G1632.D       | 97   | 96   | 63   | 49   |
| OP99539-MSD      | 8G1633.D       | 94   | 94   | 75   | 63   |

#### Surrogate Compounds

#### Recovery Limits

S1 = Tetrachloro-m-xylene

26-132%

S2 = Decachlorobiphenyl

10-118%

(a) Recovery from GC signal #1

(b) Recovery from GC signal #2

**Note:** Surrogate recoveries within laboratory control limits.

#### Actions:

- For any surrogate recovery greater than 150%, qualify detected target compounds as biased high (J+).
- Do not qualify non-detected target compounds for surrogate recovery > 150 %.
- If both surrogate recoveries are greater than or equal to 30% and less than or equal to 150%, no qualification of the data is necessary.
- For any surrogate recovery greater than or equal to 10% and less than 30%, qualify detected target compounds as biased low (J-).
- For any surrogate recovery greater than or equal to 10% and less than 30%, qualify non-detected target compounds as approximated (UJ).



## DATA REVIEW WORKSHEETS

f. If low surrogate recoveries are from sample dilution, professional judgment should be used to determine if the resulting data should be qualified. If sample dilution is not a factor:

- i. Qualify detected target compounds as biased low (J-).
- ii. Qualify non-detected target compounds as unusable (R).

g. If surrogate RTs in PEMs, Individual Standard Mixtures, samples, and blanks are outside of the RT Windows, the reviewer must use professional judgment to qualify data.

h. If surrogate RTs are within RT windows, no qualification of the data is necessary.

i. If the two surrogates were not added to all samples, MS/MSDs, standards, LCSs, and blanks, use professional judgment in qualifying data as missing surrogate analyte may not directly apply to target analytes.

### Summary Surrogate Actions for Pesticide Analyses

| Criteria                                | Action*                   |                               |
|---|---------------------------|-------------------------------|
|   | Detected Target Compounds | Non-detected Target Compounds |
| %R > 150%                               | J+                        | No qualification              |
| 30% < %R < 150%                         | No qualification          |                               |
| 10% < %R < 30%                          | J-                        | UJ                            |
| %R < 10% (sample dilution not a factor) | J-                        | R                             |
| %R < 10% (sample dilution is a factor)  | Use professional judgment |                               |
| RT out of RT window                     | Use professional judgment |                               |
| RT within RT window                     | No qualification          |                               |

\* Use professional judgment in qualifying data, as surrogate recovery problems may not directly apply to target analytes.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below           

### MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

#### 1. MS/MSD Recoveries and Precision Criteria

Data for MS and MSDs will not be present unless requested by the Region.

Notify the Contract Laboratory Program Project Officer (CLP PO) if a field blank was used for the MS and MSD, unless designated as such by the Region.

**NOTE:** For a Matrix Spike that does not meet criteria, apply the action to only the field sample used to prepare the Matrix Spike sample. If it is clearly stated in the data validation materials that the samples were taken through incremental sampling or some other method guaranteeing the homogeneity of the sample group, then the entire sample group may be qualified.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID:   JC34340-16MS/MSD  

Matrix/Level:   Groundwater  

**Note:** MS/MSD % recoveries and RPD within laboratory control limits.

#### Action

No qualification of the data is necessary on MS and MSD data alone. However, using professional judgment, the validator may use the MS and MSD results in conjunction with other QC criteria and determine the need for some qualification of the data.

A separate worksheet should be used for each MS/MSD pair.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below

### LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

## 1. LCS Recoveries Criteria

| LCS Spike Compound               | Recovery Limits (%) |
|----------------------------------|---------------------|
| gamma-BHC                        | 50 – 120            |
| Heptachlor epoxide               | 50 – 150            |
| Dieldrin                         | 30 – 130            |
| 4,4'-DDE                         | 50 – 150            |
| Endrin                           | 50 – 120            |
| Endosulfan sulfate               | 50 – 120            |
| trans-Chlordane                  | 30 – 130            |
| Tetrachloro-m-xylene (surrogate) | 30 – 150            |
| Decachlorobiphenyl (surrogate)   | 30 – 150            |

LCS concentrations: 0.25 ug/l;

List the %R of compounds which do not meet the criteria

| LCS ID   | COMPOUND | % R | QC LIMIT |
|--|----------|-----|----------|
| %_recovery_and_RPD_within_laboratory_control_limits. |          |     |          |
|  |          |     |          |
|  |          |     |          |

**Note:**

### Action

The following guidance is suggested for qualifying sample data for which the associated LCS does not meet the required criteria.

- a. If the LCS recovery exceeds the upper acceptance limit, qualify detected target compounds as estimated (J). Do not qualify non-detected target compounds.
- b. If the LCS recovery is less than the lower acceptance limit, qualify detected target compounds as estimated (J) and non-detects as unusable (R).
- c. Use professional judgment to qualify data for compounds other than those compounds that are included in the LCS.
- d. Use professional judgment to qualify non-LCS compounds. Take into account the compound class, compound recovery efficiency, analytical problems associated with each compound, and comparability in the performance of the LCS compound to the non-LCS compound.

## DATA REVIEW WORKSHEETS

e. If the LCS recovery is within allowable limits, no qualification of the data is necessary.

### 2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? Yes or No.

If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

## DATA REVIEW WORKSHEETS

All criteria were met \_\_\_\_\_  
Criteria were not met \_\_\_\_\_  
and/or see below N/A

### FLORISIL CARTRIDGE PERFORMANCE CHECK

NOTE: Florisil cartridge cleanup is mandatory for all extracts.

#### Criteria

Is the Florisil cartridge performance check conducted at least once on each lot of cartridges used for sample cleanup or every 6 months, whichever is most frequent? Yes? or No? N/A

#### Criteria

Are the results for the Florisil Cartridge Performance Check solution included with the data package? Yes? or No? N/A

Note: If % criteria are not met, examine the raw data for the presence of polar interferences and use professional judgment in qualifying the data as follows:

#### Action:

- a. If the Percent Recovery is greater than 120% for any of the pesticide target compounds in the Florisil Cartridge Performance Check, qualify detected compounds as estimated (J). Do not qualify non-detected target compounds.
- b. If the Percent Recovery is greater than or equal to 80% and less than or equal to 120% for all the pesticide target compounds, no qualification of the data is necessary.
- c. If the Percent Recovery is greater than or equal to 10% and less than 80% for any of the pesticide target compounds in the Florisil Cartridge Performance Check, qualify detected target compounds as estimated (J) and non-detected target compounds as approximated (UJ).
- d. If the Percent Recovery is less than 10% for any of the pesticide target compounds in the Florisil Cartridge Performance Check, qualify detected compounds as estimated (J) and qualify non-detected target compounds as unusable (R).
- e. If the Percent Recovery of 2,4,5-trichlorophenol in the Florisil Cartridge Performance Check is greater than or equal to 5%, use professional judgment to qualify detected and non-detected target compounds, considering interference on the sample chromatogram.

Note: State in the Data Review Narrative potential effects on the sample data resulting from the Florisil Cartridge Performance Check analysis not yielding acceptable results.

Note: No information for florisil cartridge performance check included in data package. There is evidence tahtFlorisil cartridge was used for sample extraction/clean-up. No qualification of the data performed, professional judgment.

## DATA REVIEW WORKSHEETS

All criteria were met N/A  
Criteria were not met  
and/or see below \_\_\_\_\_

### GEL PERMEATION CHROMATOGRAPHY (GPC) PERFORMANCE CHECK

NOTE: GPC cleanup is mandatory for all soil samples.

If GPC criteria are not met, examine the raw data for the presence of high molecular weight contaminants; examine subsequent sample data for unusual peaks; and use professional judgment in qualifying the data. Notify the Contract Laboratory Program Project Officer (CLP PO) if the laboratory chooses to analyze samples under unacceptable GPC criteria.

#### Action:

- a. If the Percent Recovery is less than 10% for the pesticide compounds and surrogates during the GPC calibration check, the non-detected target compounds may be suspect, qualify detected compounds as estimated (J).
- b. If the Percent Recovery is less than 10% for the pesticide compounds and surrogates during the GPC calibration check, qualify all non-detected target compounds as unusable (R).
- c. If the Percent Recovery is greater than or equal to 10% and is less than 80% for any of the pesticide target compounds in the GPC calibration, qualify detected target compounds as estimated (J) and non-detected target compounds as approximated (UJ).
- d. If the Percent Recovery is greater than or equal to 80% and less than or equal to 120% for all the pesticide target compounds, no qualification of the data is necessary.
- e. If high recoveries (i.e., greater than 120%) were obtained for the pesticides and surrogates during the GPC calibration check, qualify detected compounds as estimated (J). Do not qualify non-detected target compounds.

Note: State in the Data Review Narrative potential effects on the sample data resulting from the GPC cleanup analyses not yielding acceptable results.

**Note:** No information for performance of GPC cleanup included in data package. No qualification of the data performed, professional judgment.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met \_\_\_\_\_  
and/or see below \_\_\_\_\_

### TARGET COMPOUND IDENTIFICATION

#### Criteria:

1. Is Retention Times (RTs) of both of the surrogates and reported target compounds in each sample within the calculated RT Windows on both columns? Yes? or No?
2. Is the Tetrachloro-m-xylene (TCX) RT  $\pm 0.05$  minutes of the Mean RT (RT) determined from the initial calibration and Decachlorobiphenyl (DCB) within  $\pm 0.10$  minutes of the RT determined from the initial calibration? Yes? or No?
3. Is the Percent Difference (%D) for the detected mean concentrations of a pesticide target compound between the two Gas Chromatograph (GC) columns within the inclusive range of  $\pm 25.0$  %? Yes? or No?
4. When no analytes are identified in a sample; are the chromatograms from the analyses of the sample extract and the low-point standard of the initial calibration associated with those analyses on the same scaling factor? Yes? or No?
5. Does the chromatograms display the Single Component Pesticides (SCPs) detected in the sample and the largest peak of any multi-component analyte detected in the sample at less than full scale. Yes? or No?
6. If an extract is diluted; does the chromatogram display SCPs peaks between 10-100% of full scale, and multi-component analytes between 25-100% of full scale? Yes? or No? N/A
7. For any sample; does the baseline of the chromatogram return to below 50% of full scale before the elution time of alpha-BHC, and also return to below 25% of full scale after the elution time of alpha-BHC and before the elution time of DCB? Yes? or No?
8. If a chromatogram is replotted electronically to meet these requirements; is the scaling factor used displayed on the chromatogram, and both the initial chromatogram and the replotted chromatogram submitted in the data package. Yes? or No?

#### Action:

- a. If the qualitative criteria for both columns were not met, all target compounds that are reported as detected should be considered non-detected.
- b. Use professional judgment to assign an appropriate quantitation limit using the following guidance:
  - i. If the detected target compound peak was sufficiently outside the pesticide RT Window, the reported values may be a false positive and should be replaced with the sample Contract Required Quantitation Limits (CRQL) value.

## DATA REVIEW WORKSHEETS

- ii. If the detected target compound peak poses an interference with potential detection of another target peak, the reported value should be considered and qualified as unusable (R).

c. If the data reviewer identifies a peak in both GC column analyses that falls within the appropriate RT Windows, but was reported as a non-detect, the compound may be a false negative. Use professional judgment to decide if the compound should be included.

Note: State in the Data Review Narrative all conclusions made regarding target compound identification.

d. If the Toxaphene peak RT windows determined from the calibration overlap with SCPs or chromatographic interferences, use professional judgment to qualify the data.

e. If target compounds were detected on both GC columns, and the Percent Difference between the two results is greater than 25.0%, consider the potential for coelution and use professional judgment to decide whether a much larger concentration obtained on one column versus the other indicates the presence of an interfering compound. If an interfering compound is indicated, use professional judgment to determine how best to report, and if necessary, qualify the data according to these guidelines.

f. If Toxaphene exhibits a marginal pattern-matching quality, use professional judgment to establish whether the differences are due to environmental "weathering" (i.e., degradation of the earlier eluting peaks relative to the later eluting peaks). If the presence of Toxaphene is strongly suggested, report results as presumptively present (N).

## GAS CHROMATOGRAPH/MASS SPECTROMETER (GC/MS) CONFIRMATION

NOTE: This confirmation is not usually provided by the laboratory. In cases where it is provided, use professional judgment to determine if data qualified with "C" can be salvaged if it was previously qualified as unusable (R).

### Action:

a. If the quantitative criteria for both columns were met ( $\geq 5.0$  ng/ $\mu$ L for SCPs and  $\geq 125$  ng/ $\mu$ L for Toxaphene), determine whether GC/MS confirmation was performed. If it was performed, qualify the data using the following guidance:

- i. If GC/MS confirmation was not required because the quantitative criteria for both columns was not met, but it was still performed, use professional judgment when evaluating the data to decide whether the detect should be qualified with "C".
- ii. If GC/MS confirmation was performed, but unsuccessful for a target compound detected by GC/ECD analysis, qualify those detects as "X".



## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

### COMPOUND QUANTITATION AND REPORTED CONTRACT REQUIRED QUANTITATION LIMITS (CRQLS)

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

JC34340-1

tetrachloro-m-xylene

RF = 0.982

$$[ ] = \frac{(87236052)(50)}{(115.7 \times 10^6)(0.982)}$$

$$= 38.4 \text{ ppb} \quad \text{Ok}$$

#### Action:

- If sample quantitation is different from the reported value, qualify result as unusable (R).
- When a sample is analyzed at more than one dilution, the lowest CRQLs are used unless a QC exceedance dictates the use of the higher CRQLs from the diluted sample.
- Replace concentrations that exceed the calibration range in the original analysis by crossing out the "E" and its corresponding value on the original reporting form and substituting the data from the diluted sample.
- Results between the MDL and CRQL should be qualified as estimated (J).
- Results less than the MDL should be reported at the CRQL and qualified (U). MDLs themselves are not reported.
- For non-aqueous samples, if the percent moisture is less than 70.0%, no qualification of the data is necessary. If the percent moisture is greater than or equal to 70.0% and less than 90.0%, qualify detects as estimated (J) and non-detects as approximated (UJ). If the percent moisture is greater than or equal to 90.0%, qualify detects as estimated (J) and non-detects as unusable (R) (see Table).

#### Percent Moisture Actions for Pesticide Analysis for Non-Aqueous Samples

| Criteria                 | Action                        |                                   |
|--------------------------|-------------------------------|-----------------------------------|
|                          | Detected Associated Compounds | Non-detected Associated Compounds |
| % Moisture < 70.0        | No qualification              |                                   |
| 70.0 < % Moisture < 90.0 | J                             | UJ                                |
| % Moisture > 90.0        | J                             | R                                 |

DATA REVIEW WORKSHEETS

List samples which have  $\leq 50$  % solids

|  |
|--|
|  |
|  |
|  |
|  |
|  |
|  |

Note: If any discrepancies are found, the Region's designated representative may contact the laboratory to obtain additional information that could resolve any differences. If a discrepancy remains unresolved, the reviewer must use professional judgment to decide which value is the most accurate. Under these circumstances, the reviewer may determine that qualification of data is warranted. Note in the Data Review Narrative a description of the reasons for data qualification and the qualification that is applied to the data.

Dilution performed

| SAMPLE ID | DILUTION FACTOR | REASON FOR DILUTION |
|-----------|-----------------|---------------------|
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |
|           |                 |                     |

## DATA REVIEW WORKSHEETS

All criteria were met \_\_N/A\_\_  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### FIELD DUPLICATE PRECISION

**NOTE:** In the absence of QAPP guidance for validating data from field duplicates, the following action will be taken.

Field duplicate samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples. Identify which samples within the data package are field duplicates. Estimate the relative percent difference (RPD) between the values for each compound. If large RPDs (> 50%) is observed, confirm identification of samples and note difference in the executive summary.

Sample IDs: \_\_\_\_\_

Matrix: \_\_\_\_\_ - \_\_\_\_\_

| COMPOUND   | SQL<br>ug/L | SAMPLE<br>CONC. | DUPLICATE<br>CONC. | RPD | ACTION |
|--|-------------|-----------------|--------------------|-----|--------|
|  |             |                 |                    |     |        |
|  |             |                 |                    |     |        |
| No field/laboratory duplicate analyzed with this data package. MS/MSD % recovery RPD used to assess precision. RPD within the required criteria of < 50 %. |             |                 |                    |     |        |
|  |             |                 |                    |     |        |
|  |             |                 |                    |     |        |

#### Actions:

a. Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

b. If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:

- i. If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).
- ii. If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.
- iii. If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.
- iv. If both sample and duplicate results are not detected, no action is needed.

## DATA REVIEW WORKSHEETS

### OVERALL ASSESSMENT OF DATA

#### Action:

1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
2. Write a brief narrative to give the user an indication of the analytical limitations of the data.

**Note:** The Contract Laboratory Program Project Officer (CLP PO) must be informed if any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).

**Overall assessment of the data:** Results are valid; the data can be used for decision making purposes.